LG X Charge (M322) Cleaning after Water Exposure Kailey Cozart

Required photos noted in green.

<u>Step 0</u>: Here is the phone at the beginning of the exercise. It had been submerged in salt water for five days.



Step 1: Rinse phone with water to remove some of the residue and identify the device.



Step 2: Pry the back cover off. This was pretty difficult to do with the salt.



<u>Step 3</u>: Pry the plastic covering off of the main part of the phone. Once again, this part is difficult to do with how sticky and nasty everything is.



<u>Step 4</u>: Remove the screws from the body of the board and lift the board out. The front and back of the board look like this: *(Before Cleaning)*



<u>Step 5</u>: Put scrubbing bubbles on the board and wash the device in an ultrasonic cleaner @35 watts for 2 minutes.



<u>Step 6</u>: Remove the board and scrub all of the board's parts with a brush. Then place back into the ultrasonic cleaner @55 watts for 3 minutes.

Step 7: Dry the device by giving it time to dry and with a soldering gun / rework station.

Step 8: The board is now cleaned. (After Cleaning)

