

1. Overview & specifications

The Vortex Dishwasher DW-14 (Vortex, dishwasher) is covered by this service manual for authorised technicians holding the 'kitchen-appliance' skill. It documents diagnosis, fault codes, and board/mechanical-level repair.

Specifications — type: free-standing dishwasher, placeSettings: 14, powerW: 1900.

Warranty: 24 months. Parts and labour 24 months. Spray arms and seals are consumables.

Reference: <https://support.example-fieldflow.test/dw-14/manual>

Vortex Dishwasher DW-14 — Service Manual — page 1

2. Installation & commissioning

Connect the inlet and drain within the rated height, prime the softener with salt, and run a hot rinse before first use.

Record the serial number and commissioning date against the work order. A failed self-test must be cleared before the visit is closed.

3. Fault codes

D1 — Dishes cold; flow heater open. Replace HEAT-14. Skill: kitchen-appliance.

D3 — Poor wash; circulation pump weak. Replace PUMP-14. Skill: kitchen-appliance.

D5 — Not filling; inlet valve stuck. Replace VALV-14. Skill: kitchen-appliance.

D8 — Standing water; drain pump blocked. Replace DRN-14. Skill: kitchen-appliance.

Vortex Dishwasher DW-14 — Service Manual — page 3

4. Part replacement — PUMP-14 / PCB-14

PUMP-14 — Wash circulation pump (pump). Isolate mains and follow the safety SOP. Remove the faulty unit, fit PUMP-14, and run the self-test. Requires 'kitchen-appliance'. This part is covered under active warranty (free). List price ■2,300.

PCB-14 — Dishwasher control board (board). Isolate mains and follow the safety SOP. Remove the faulty unit, fit PCB-14, and run the self-test. Requires 'kitchen-appliance'. This part is covered under active warranty (free). List price ■1,700.

5. Part replacement — HEAT-14 / VALV-14

HEAT-14 — Flow-through heater (heating-element). Isolate mains and follow the safety SOP. Remove the faulty unit, fit HEAT-14, and run the self-test. Requires 'kitchen-appliance'. This part is covered under active warranty (free). List price ■1,400.

VALV-14 — Water inlet valve (valve). Isolate mains and follow the safety SOP. Remove the faulty unit, fit VALV-14, and run the self-test. Requires 'kitchen-appliance'. This part is chargeable (out of warranty scope). List price ■600.

6. Part replacement — DRN-14 / SEAL-14

DRN-14 — Drain pump (pump). Isolate mains and follow the safety SOP. Remove the faulty unit, fit DRN-14, and run the self-test. Requires 'kitchen-appliance'. This part is chargeable (out of warranty scope). List price ■850.

SEAL-14 — Door seal (consumable). Isolate mains and follow the safety SOP. Remove the faulty unit, fit SEAL-14, and run the self-test. Requires 'kitchen-appliance'. This part is chargeable (out of warranty scope). List price ■380.

7. Maintenance, safety & warranty

Maintenance: inspect at each visit; clean or replace consumables on the service interval; log any recurring fault code.

Isolate mains and shut the inlet tap before removing the pump or heater.

Warranty annex: under an active warranty, PUMP-14, PCB-14, HEAT-14 are replaced free with labour. Consumables and cosmetic parts are never covered. If warranty is expired or the fault is outside the original scope, the part is chargeable: a quote is raised and payment is collected before the visit is confirmed.

Policy reference: <https://support.example-fieldflow.test/warranty/v5>

Vortex Dishwasher DW-14 — Service Manual — page 7