

1. Overview & specifications

The Vortex Front-Load Washer FL-70 (Vortex, washing-machine) is covered by this service manual for authorised technicians holding the 'laundry' skill. It documents diagnosis, fault codes, and board/mechanical-level repair.

Specifications — type: front-load washer, capacityKg: 7.0, maxRpm: 1200, powerW: 2000.

Warranty: 24 months. Motor covered 10 years; parts and labour 24 months. Hoses and detergent trays excluded.

Reference: <https://support.example-fieldflow.test/fl-70/manual>

Vortex Front-Load Washer FL-70 — Service Manual — page 1

2. Installation & commissioning

Remove the transit bolts, level the chassis against vibration, connect the inlet and standpipe drain, and run an empty calibration cycle.

Record the serial number and commissioning date against the work order. A failed self-test must be cleared before the visit is closed.

3. Fault codes

L1 — Drum not spinning; drive motor fault. Replace MOT-70. Skill: laundry.

L2 — Will not drain; drain pump blocked or failed. Replace PUMP-70. Skill: laundry.

L4 — Door lock error; cycle won't start. Replace DOOR-70. Skill: laundry.

L7 — No hot wash; heater element open. Replace HEAT-70. Skill: laundry. SAFETY: high-risk, follow discharge/isolation SOP.

L9 — Control board unresponsive. Replace PCB-70. Skill: laundry.

Vortex Front-Load Washer FL-70 — Service Manual — page 3

4. Part replacement — MOT-70 / PCB-70

MOT-70 — BLDC drive motor (motor). Isolate mains and follow the safety SOP. Remove the faulty unit, fit MOT-70, and run the self-test. Requires 'laundry'. This part is covered under active warranty (free). List price ■5,400.

PCB-70 — Washer main control board (board). Isolate mains and follow the safety SOP. Remove the faulty unit, fit PCB-70, and run the self-test. Requires 'laundry'. This part is covered under active warranty (free). List price ■2,850.

5. Part replacement — PUMP-70 / DOOR-70

PUMP-70 — Drain pump assembly (pump). Isolate mains and follow the safety SOP. Remove the faulty unit, fit PUMP-70, and run the self-test. Requires 'laundry'. This part is chargeable (out of warranty scope). List price ■1,200.

DOOR-70 — Door lock interlock (mechanical). Isolate mains and follow the safety SOP. Remove the faulty unit, fit DOOR-70, and run the self-test. Requires 'laundry'. This part is chargeable (out of warranty scope). List price ■780.

6. Part replacement — BELT-70 / HEAT-70

BELT-70 — Drive belt (consumable). Isolate mains and follow the safety SOP. Remove the faulty unit, fit BELT-70, and run the self-test. Requires 'laundry'. This part is chargeable (out of warranty scope). List price ■360.

HEAT-70 — Wash heater element (heating-element). Isolate mains and follow the safety SOP. Remove the faulty unit, fit HEAT-70, and run the self-test. Requires 'laundry'. This part is covered under active warranty (free). List price ■1,100.

7. Maintenance, safety & warranty

Maintenance: inspect at each visit; clean or replace consumables on the service interval; log any recurring fault code.

Isolate mains and discharge; the heater circuit can hold a lethal charge. Never bypass the door interlock.

Warranty annex: under an active warranty, MOT-70, PCB-70, HEAT-70 are replaced free with labour. Consumables and cosmetic parts are never covered. If warranty is expired or the fault is outside the original scope, the part is chargeable: a quote is raised and payment is collected before the visit is confirmed.

Policy reference: <https://support.example-fieldflow.test/warranty/v5>

Vortex Front-Load Washer FL-70 — Service Manual — page 7