## FH-OÖ Hagenberg/ESD Advanced Methods of Verification, SS 2015


Rainer Findenig © 2008

1. Übung: Bus Functional Models




#### 1 Bus Functional Models

Die Testbench eines Design under Verification (DUV) modelliert das das DUV umgebende Universum: ein Stimulus-Generator stellt alle in diesen Universum generierten und für das DUV relevanten Signale zur Verfügung, und ein Response Checker prüft die vom DUV generierten Signale:



Da das DUV speziell bei SoC-Entwürfen meistens Busprotokolle wie Wishbone oder AMBA (AHB oder APB) verwendet, ist die Generierung eines korrekten Stimulus meist aufwändig. Daher wird zur Verifikation die Busschnittstelle oft ausgeklammert und nur das DUV selbst verifiziert – dies birgt allerdings natürlich die Gefahr, dass dabei Fehler in der Busschnittstelle und ihrer Anbindung an das DUV unentdeckt bleiben.

Idealerweise wird das DUV also gemeinsam mit seinen Schnittstellen verifiziert; dazu muss jedoch die Testbench auch das Busprotokoll unterstützen. Eine einfache, aber effektive Methode, die nicht nur den Abstraktionsgrad der Testbench stark erhöht, sondern auch eine hohe Wiederverwertbarkeit bietet, sind *Bus Functional Models* (BFM):



Ein BFM besteht aus einer Sammlung (sprich: *Package*!) von Datentypen, Konstanten und (*behavioral*!) Funktionen, die die verschiedenen möglichen Buszugriffe (zum Beispiel: *Idle, Write, Read, Burst Write* und *Burst Read*) kapseln:

```
busIdle(..)
busRead(..) ← BFM
busWrite(..) busout
```

In einer Testbench könnte der Test eines RAMs daher zum Beispiel so aussehen:

Die Manipulationen der einzelnen Signals wird dabei in Funktionen gekapselt:

```
type aBusIn is record
1
       dat_i : std_ulogic_vector(cWidth-1 downto 0);
2
       -- ...
3
   end record;
4
   type aBusOut is record
6
7
       we_o : std_ulogic;
       adr_o : std_ulogic_vector(cWidth-1 downto 0);
8
       dat_o : std_ulogic_vector(cWidth-1 downto 0);
10
       -- ...
  end record;
11
12
   procedure busWrite (
13
       constant addr : in std_ulogic_vector(cWidth-1 downto 0);
14
       constant data : in std_ulogic_vector(cWidth-1 downto 0);
15
       signal busin : in aBusIn;
16
       signal
               busout : out aBusOut) is
17
  begin
18
19
        -- clock edge 0
20
       wait on busin.clk_i until busin.clk_i = '1';
21
22
       busout.adr_o <= addr;</pre>
23
       busout.dat_o <= data;</pre>
       busout.we_o <= '1';
24
25
26
  end busWrite;
27
```

#### 1.1 Signal-Parameter

Die Prozeduren busWrite und busRead haben jeweils die beiden Signal -Parameter busin und busout. Signal -Parameter erlauben einer Prozedur, Werte von Signals zu lesen und

auch auf diese zu schreiben [Ash02]. Dabei gelten jedoch die gleichen Einschränkungen wie bei der Verwendung von *Signals* in einer *Entity*, insbesondere muss also die Richtung der Signals definiert werden. Daher ist es notwendig, wie im voranstehenden Listing die *Signals* entsprechend ihrer Richtung auf zwei *Records* aufzuteilen<sup>1</sup>.

#### 2 Wishbone

Wishbone [Ope02] (genauer: WISHBONE System-on-Chip (SoC) Interconnect Architecture for Portable IP Cores) ist ein offenes (public domain) Bussystem für SoC-Entwürfe, so verwenden beispielsweise die meisten Cores von OpenCores (www.opencores.org) und auch Lattices Mico32 [Lat07] diesen Bus.

Implementieren Sie ein BFM für den Wishbone-Bus:

- Die Breite des Daten- bzw. Adressbusses wird auf 32 bzw. 8 Bit festgelegt. Beachten Sie dabei jedoch, dass natürlich keine *Magic Numbers* verwendet werden dürfen!
- Die wichtigsten Transferarten des Wishbone-Busses sind *Single Read* ([Ope02], S. 48), *Single Write* (S. 50), *Block Read* (S. 54) und *Block Write* (S. 57). Diese, und natürlich der *Idle -*Zyklus, müssen unterstützt werden.
- Der RMW-Zyklus sowie Registered Feedback Bus Cycles werden für diese Übung vernachlässigt.
- Ein byteweiser Zugriff ist nicht notwendig, das Signal sel\_o kann also während eines Zugriffs immer an allen Stellen 'l' sein.

Erstellen Sie aufbauend auf Ihr BFM eine Testbench, die das zur Verfügung gestellte Wishbone-RAM-Modell verifiziert<sup>2</sup>. Dabei können Sie, genau wie in den obigen Abbildungen, von einem Single-Master-System ausgehen, das Sie direkt mit dem DUV verbinden: der Stimulus-Generator ist also Teil einer Testbench, die die Buszugriffe mit Hilfe des BFMs durchführt.

#### Hinweise dazu:

• Muss die maximale Anzahl der Waitstates, die der Slave erzeugen darf, begrenzt werden?

Dies wäre als Fehlerbehandlung interessant, falls der Slave überhaupt nicht antwortet. Es kann also zB über einen Parameter oder eine Konstante geprüft werden, ob eine maximale Anzahl von Waitstates vergangen ist und dann ein Fehler ausgegeben werden. Dies ist für die Übung aber nicht notwendig.

• Müssen vom Master eingefügte Waitstates simuliert werden?

Auch dies ist für eine umfangreichere Verifikation natürlich sinnvoll, jedoch im Sinne

<sup>&</sup>lt;sup>1</sup>Alternativ könnte ein einem *Package* deklariertes *Signal* verwendet werden.

<sup>&</sup>lt;sup>2</sup>Beachten Sie, dass eine Testbench selbstüberprüfend sein muss! Wie können Sie das bei einem RAM einfach erreichen?

der Aufwandsbegrenzung der Übung auch nicht notwendig.

Beantworten Sie die folgenden, für die Funktionen des BFMs durchaus interessanten,  $\Box$  Fragen:

- Welchen Effekt hat die VHDL-Anweisung wait until clk\_i = '1';? Was passiert, wenn clk\_i zum Zeitpunkt des Aufrufs bereits '1' ist?
- Welchen Effekt hat die VHDL-Anweisung wait on clk\_i until ack\_i = '1';?
- Warum müssen für die Funktionen des BFM Signal-Parameter verwendet werden (im Gegensatz zu *Constants* oder *Variables* )?

### Weitere Informationen

• Für die weiteren Übungen werden Sie zum Teil Ihren im fünften Semester entwickelten PROL16 benötigen. Bitte stellen Sie sicher, dass Sie den Quellcode zur Verfügung haben!

#### Literatur

- [Ash02] Peter J. Ashenden. *The Designer's Guide To VHDL*. Morgen Kaufmann, second edition, 2002.
- [Lat07] Lattice Semiconductor Corporation. *LatticeMico32 Processor Reference Manual*, August 2007.
- [Ope02] OpenCores Organization. WISHBONE System-on-Chip (SoC) Interconnect Architecture for Portable IP Cores, Rev B.3, September 2002. http://www.opencores.org/projects.cgi/web/wishbone/wbspec\_b3.pdf.

"Debugging is twice as hard as writing the code in the first place. Therefore, if you write the code as cleverly as possible, you are, by definition, not smart enough to debug it."

Brian W. Kernighan

# 1 Beantwortung der Fragen

- Die VHDL-Anweisung wait until pausiert einen Prozess so lange bis sich eines der Signale im Statement ändert die gegebene Bedingung erfüllt ist. Das heißt bei wait until clk\_i = '1' wird auf die steigende Flanke von clk\_i gewartet. Wenn clk\_i bereits '1' ist wird so lange gewartet bis wieder eine steigende Flanke kommt.
- Bei dieser VHDL-Anweisung wird so lange gewartet bis ack\_i während einer Änderung von clk\_i '1' ist.
- Das RAM könnte sonst nicht verbunden werden. In VHDL werden Signals verwendet um Parallelität zu modellieren.

Quelle: http://www.ics.uci.edu/~jmoorkan/vhdlref

### 2 Testfälle

Es wurden die unten aufgelisteten Funktionen der BFM getestet. Dazu wurde der gesamte Speicherbereich des RAM zweimal geschrieben und gelesen. Beim ersten Mal waren auf der Datenleitung alle geraden Bit 1 und ungeraden Bit 0. Beim zweiten Mal wurde der Wert invertiert.

Zusätzlich gibt es noch einen Idle Test der überprüft ob alle Signale auf 'Z' gesetzt sind und einen Test der zur Kontrolle fehlschlagen soll.

Getestet wurde lokal am Rechner mit Questasim, da der Applicationserver bei beiden Gruppenmitgliedern nicht funktionierte.

- SingleRead
- SingleWrite
- BlockRead
- BlockWrite
- Idle

## 3 Source Code

```
.././src/WishboneBFM-p.vhd

1 --

2 -- Title : Wishbone BFM
3 -- Project : AMV2
4 -- Author : Bernhard Selymes
5 --

6 -- Description:
7 --
8 --
```

```
9
10 library ieee;
11 use ieee.std_logic_1164.all;
12
13 package WishboneBFM is
14
15
     constant cDataWidth : natural := 32;
     constant cAddrWidth : natural := 8;
16
17
     constant cByte
                         : natural := 8;
18
19
     type aBusIn is record
20
       clk_i : std_ulogic;
21
      rst_i : std_ulogic;
22
      dat_i : std_ulogic_vector(cDataWidth-1 downto 0);
23
       ack_i : std_ulogic;
24
     end record;
25
26
     type aBusOut is record
27
       we_o : std_ulogic;
28
       adr_o : std_ulogic_vector(cAddrWidth-1 downto 0);
29
       dat_o : std_ulogic_vector(cDataWidth-1 downto 0);
30
       sel_o : std_ulogic_vector((cDataWidth/cByte)-1 downto 0);
31
      stb_o : std_ulogic;
32
      cyc_o : std_ulogic;
33
     end record;
34
35
     type aAddrBlock is array (natural range <>) of std_ulogic_vector(
         cAddrWidth-1 downto 0);
36
     type aDataBlock is array (natural range <>) of std_ulogic_vector(
         cDataWidth-1 downto 0);
37
38
     constant busInInit : aBusIn := (clk_i => '0',
                                   rst_i => '0',
39
40
                                   dat_i => (others => '0'),
41
                                   ack_i => '0');
42
43
     constant busOutInit : aBusOut := (we_o
                                                   => 'O',
44
                                  adr_o => (others => '0'),
45
                                  dat_o => (others => '0'),
                                  sel_o => (others => '0'),
46
47
                                  stb_o => '0',
48
                                  cyc_o => '0');
49
50
     procedure SingleRead (
51
       constant addr : in std_ulogic_vector(cAddrWidth-1 downto 0);
52
       variable data : out std_ulogic_vector(cDataWidth-1 downto 0); --
          variable ?
53
       signal busin : in aBusIn;
54
       signal busout : out aBusOut);
55
56
     procedure SingleWrite (
57
       constant addr : in std_ulogic_vector(cAddrWidth-1 downto 0);
58
       constant data : in std_ulogic_vector(cDataWidth-1 downto 0);
59
       signal busin : in aBusIn;
60
       signal busout : out aBusOut);
61
62
     procedure BlockRead (
63
       constant addr : in aAddrBlock;
64
       variable data : out aDataBlock;
65
      constant len : in natural;
```

```
signal busin : in aBusIn;
66
67
        signal busout : out aBusOut);
68
69
      procedure BlockWrite (
70
        constant addr : in aAddrBlock;
71
        constant data : in aDataBlock;
72
       constant len : in natural;
73
        signal busin : in aBusIn;
74
        signal busout : out aBusOut);
75
76
      procedure Idle (
77
        signal busout : out aBusOut);
78
79
    end WishboneBFM;
80
81 package body WishboneBFM is
82
83
      -- Single Read
84
      procedure SingleRead (
85
        constant addr : in std_ulogic_vector(cAddrWidth-1 downto 0);
86
        variable data : out std_ulogic_vector(cDataWidth-1 downto 0);
87
        signal busin : in aBusIn;
88
        signal busout : out aBusOut) is
89
      begin
90
        -- clock edge 0
91
        wait on busin.clk_i until busin.clk_i = '1';
92
       busout.adr_o <= addr;</pre>
93
       busout.we_o <= '0';
94
       busout.sel_o <= (others => '1');
95
       busout.cyc o <= '1';</pre>
96
       busout.stb o <= '1';
97
98
       -- setup, edge 1
99
       wait on busin.clk_i until busin.ack_i = '1';
100
101
       -- clock edge 1
102
       data := busin.dat_i;
103
       busout.stb_o <= '0';</pre>
104
       busout.cyc_o <= '0';</pre>
105
      end SingleRead;
106
107
      -- Single Write
108
      procedure SingleWrite (
109
        constant addr : in std_ulogic_vector(cAddrWidth-1 downto 0);
110
        constant data : in std_ulogic_vector(cDataWidth-1 downto 0);
111
        signal busin : in aBusIn;
112
        signal busout : out aBusOut) is
113
      begin
114
        -- clock edge 0
        wait on busin.clk_i until busin.clk_i = '1';
115
116
       busout.adr_o <= addr;</pre>
       busout.dat_o <= data;</pre>
117
118
       busout.we o <= '1';
119
       busout.sel o <= (others => '1');
       busout.cyc_o <= '1';</pre>
120
121
       busout.stb_o <= '1';</pre>
122
123
       -- setup, edge 1
124
       wait on busin.clk_i until busin.ack_i = '1';
125
```

```
126
       -- clock edge 1
127
       busout.stb_o <= '0';</pre>
128
       busout.cyc_o <= '0';
129
      end SingleWrite;
130
131
      -- Block Read
132
      procedure BlockRead (
133
        constant addr : in aAddrBlock;
134
        variable data : out aDataBlock;
135
       constant len : in natural;
136
         signal busin : in aBusIn;
137
         signal busout : out aBusOut) is
138
      begin
139
140
       Reading: for i in 0 to len-1 loop
141
          -- clock edge 0
142
          wait on busin.clk_i until busin.clk_i = '1';
143
         busout.adr_o <= addr(i);</pre>
144
         busout.we_o <= '0';
145
         busout.sel_o <= (others => '1');
146
         busout.cyc_o <= '1';</pre>
147
         busout.stb_o <= '1';</pre>
148
149
          -- setup, edge 1
150
         wait on busin.clk_i until busin.ack_i = '1';
151
152
          -- clock edge 1
153
          data(i) := busin.dat_i;
154
       end loop;
155
       busout.stb o <= '0';
156
157
       busout.cyc_o <= '0';</pre>
158
159
      end BlockRead;
160
161
      -- Block Write
162
      procedure BlockWrite (
163
        constant addr : in aAddrBlock;
164
        constant data : in aDataBlock;
       constant len : in natural;
165
         signal busin : in aBusIn;
166
167
         signal busout : out aBusOut) is
168
      begin
169
170
       Writing: for i in 0 to len-1 loop
171
          -- clock edge 0
172
          wait on busin.clk_i until busin.clk_i = '1';
         busout.adr_o <= addr(i);</pre>
173
174
         busout.dat_o <= data(i);</pre>
         busout.we_o <= '1';
175
176
         busout.sel_o <= (others => '1');
177
         busout.cyc_o <= '1';</pre>
178
         busout.stb o <= '1';
179
180
          -- setup, edge 1
181
          wait on busin.clk_i until busin.ack_i = '1';
182
       end loop;
183
184
       busout.stb_o <= '0';</pre>
185
       busout.cyc_o <= '0';</pre>
```

```
187
     end BlockWrite;
188
189
     -- Idle
190
     procedure Idle (
191
       signal busout : out aBusOut) is
192
     begin
193
     busout.adr o <= (others => 'Z');
194
     busout.dat_o <= (others => 'Z');
195
     busout.we_o <= 'Z';
196
      busout.sel_o <= (others => 'Z');
197
     busout.cyc_o <= 'Z';
198
     busout.stb_o <= 'Z';
199
   end Idle;
200
201 end WishboneBFM;
                             ../../src/WishboneBFM-tb.vhd
       ______
 2 -- Title : Wishbone BFM tb
3 -- Project : AMV2
4 -- Author : Reinhard Penn
 5 --
 6 -- Description:
 7 --
 8 --
 9
10 library ieee;
11 use ieee.std_logic_1164.all;
12 use ieee.numeric_std.all;
13 use work.WishboneBFM.all;
14
15 entity tbWishboneBFM is
16 end entity;
17
18
19 architecture bhv of tbWishboneBFM is
20
21 COMPONENT RAM PORT (
22 clk_i : in STD_ULOGIC;
23 rst_i : in STD_ULOGIC;
24 adr_i : in STD_ULOGIC_VECTOR(cAddrWidth-1 downto 0);
25 dat_i : in STD_ULOGIC_VECTOR(cDataWidth-1 downto 0);
26 sel_i : in STD_ULOGIC_VECTOR((cDataWidth/8)-1 downto 0);
27 cyc_i : in STD_ULOGIC;
28 stb_i : in STD_ULOGIC;
29 we_i : in
                STD ULOGIC;
30 dat_o : out STD_ULOGIC_VECTOR(cDataWidth-1 downto 0);
31 ack_o : out STD_ULOGIC
32 );
33 END COMPONENT;
34
35 signal busIn : aBusIn := busInInit;
36 signal busOut : aBusOut := busOutInit;
```

186

```
37
38 constant cEndAddress : natural := (2**cAddrWidth)-1;
39 constant testInput1 : std_ulogic_vector(cDataWidth-1 downto 0) := x"
      AAAAAAA";
40 constant testInput2 : std_ulogic_vector(cDataWidth-1 downto 0) := x"
      55555555";
41
42 begin
43
44 DUV : RAM PORT MAP (
45 clk i => busIn.clk i,
46 rst_i => busIn.rst_i,
47 adr_i => busOut.adr_o,
48 dat_i => busOut.dat_o,
49 sel_i => busOut.sel_o,
50 cyc_i => busOut.cyc_o,
51 stb_i => busOut.stb_o,
52 we_i => busOut.we_o,
53 dat_o => busIn.dat_i,
54 ack_o => busIn.ack_i
55 );
56
57 CLOCK:
58 busIn.clk_i <= '1' after 5 ns when busIn.clk_i = '0' else
           '0' after 5 ns when busIn.clk_i = '1';
59
60
61 Stimuli : process is
62 variable rd : std_ulogic_vector(cDataWidth-1 downto 0) := (others => '0');
63 variable addressBlock : aAddrBlock(0 to cEndAddress) := (others => (
      others => '0'));
64 variable dataBlock
                           : aDataBlock(0 to cEndAddress) := (others => (
      others => '0'));
65 variable readDataBlock : aDataBlock(0 to cEndAddress) := (others => (
      others => '0'));
66 begin
67
68
     --test Single Read Write with data 10101...
69
      for i in 0 to cEndAddress loop
70
         SingleWrite(std_ulogic_vector(to_unsigned(i, cAddrWidth)), -- address
71
         testInput1, -- data
72
            busIn, busOut);
73
         SingleRead(std_ulogic_vector(to_unsigned(i, cAddrWidth)), -- address
74
            rd, busIn, busOut);
75
76
         assert rd = testInput1
77
            report "SingleTest: TestInput1 is wrong"
78
            severity error;
79
      end loop;
80
      --test Single Read Write with data 010101...
81
82
      for i in 0 to cEndAddress loop
83
         SingleWrite(std_ulogic_vector(to_unsigned(i, cAddrWidth)), -- address
84
         testInput2, -- data
            busIn, busOut);
85
86
         SingleRead(std_ulogic_vector(to_unsigned(i, cAddrWidth)), -- address
87
            rd, busIn, busOut);
88
89
         assert rd = testInput2
90
            report "SingleTest: TestInput2 is wrong"
91
            severity error;
```

```
92
       end loop;
93
94
       --test Block Read Write with data 1010101...
95
       for i in 0 to cEndAddress loop
96
          addressBlock(i) := std_ulogic_vector(to_unsigned(i, cAddrWidth));
97
          dataBlock(i) := testInput1;
98
       end loop;
99
       BlockWrite(addressBlock, -- address
100
101
          dataBlock, -- data
102
          cEndAddress+1, busIn, busOut);
103
104
       BlockRead(addressBlock, -- address
105
          readDataBlock, -- data
106
          cEndAddress+1, busIn, busOut);
107
108
       for i in 0 to cEndAddress loop
109
          assert readDataBlock(i) = testInput1
110
             report "BlockTest: TestInput1 is wrong"
111
             severity error;
112
       end loop;
113
114
       --test Block Read Write with data 01010101...
115
       for i in 0 to cEndAddress loop
116
          addressBlock(i) := std_ulogic_vector(to_unsigned(i, cAddrWidth));
117
118
          dataBlock(i) := testInput2;
119
       end loop;
120
121
       BlockWrite(addressBlock, -- address
122
          dataBlock, -- data
123
          cEndAddress+1, busIn, busOut);
124
125
       BlockRead(addressBlock, -- address
126
          readDataBlock, -- data
          cEndAddress+1, busIn, busOut);
127
128
129
       for i in 0 to cEndAddress loop
130
          assert readDataBlock(i) = testInput2
131
             report "BlockTest: TestInput2 is wrong"
132
             severity error;
133
       end loop;
134
135
       --control test
136
       assert readDataBlock(0) = testInput1
137
          report "ControlTest: This test is supposed to be wrong"
138
          severity note;
139
140
       --idle test
141
       Idle(busOut);
142
       wait on busin.clk_i until busin.clk_i = '1';
143
144
       for i in 0 to cAddrWidth-1 loop
          assert busout.adr_o(i) = 'Z'
145
146
             report "IdleTest: busout.adr_o should be Z"
147
             severity error;
148
       end loop;
149
150
       for i in 0 to cDataWidth-1 loop
151
          assert busout.dat_o(i) = 'Z'
```

```
152
              report "IdleTest: busout.dat_o should be Z"
153
              severity error;
154
       end loop;
155
156
       for i in 0 to (cDataWidth/cByte)-1 loop
157
           assert busout.sel_o(i) = 'Z'
158
              report "IdleTest: busout.sel_o should be Z"
159
              severity error;
160
       end loop;
161
       assert busout.we o = 'Z'
162
163
           report "IdleTest: busout.we_o should be Z"
164
           severity error;
165
166
       assert busout.cyc_o = 'Z'
167
           report "IdleTest: busout.cyc_o should be Z"
168
           severity error;
169
       assert busout.stb o = 'Z'
170
171
           report "IdleTest: busout.stb_o should be Z"
172
           severity error;
173
174
175 assert false
        report "This is not a failure: Simulation finished !!!"
176
177
        severity failure;
178
179
        wait;
180 end process;
181
182 end architecture;
                                     ../../sim/Compile.do
 1 vlog ../src/ram.sv
 2 vcom ../src/WishboneBFM-p.vhd
 3 vcom ../src/WishboneBFM-tb.vhd
                                       ../../sim/Sim.do
 1 vsim -novopt tbWishboneBFM
 2 add wave -position end sim:/tbwishbonebfm/busIn
 3 add wave -position end sim:/tbwishbonebfm/busOut 4 add wave -position end sim:/tbwishbonebfm/testInput1
 5 add wave -position end sim:/tbwishbonebfm/testInput2
 6 log -r *
 7 run -all
```