How to Install:

Extract Zip file to: %installationpath%\SimHub\NextionTemplate\

Uploading to your Device

For FT232RL TTL USB Adapter:

- Open the HMI file of your preference in the SimHub Nextion Editor
- Click on Upload
- Select right COM port + Baudrate
- Wait a few minutes
- Continue guide at "Set Mapping"

For Adruino Pro-Micro:

- Open the Nextion Uploader located at: SimHub_Addons\NextionUploader
- In the uploader click on "Choose File" and Open the folder of the prefered dashboard and open the folder Adruino Files
- Important! Select the right file for your device. Uploading will fail if you don't select the right one.
- Select right COM port + Baudrate
- Click upload & wait a few minutes
- Continue guide at "Set Mapping"

Set Mapping:

- Open SimHub
- From the left choose Nextion Display

- Under Connection pick the right Template corresponding to your uploaded dash
- Make sure the display is enabled on the far right

If you have problems recieving data on the screen, sometimes it helps to restart your diplay.

