

Document Number V4\_20140805

# Product specification


LSUC 002R8L 0350F EA LSUC 002R8L 0400F EA



# **Product specification**

#### Physical properties

Dimension in mm (not to scale)



#### **■** Specification

Rated Voltage	2.8 V				
Surge Voltage	3.0 V				
Capacitance Tolerance	0% / 20%				
Resistance Tolerance	< Spec. Value				
Operating temperature range	-40 ~ 65 °C				
Storage temperature range	-40 ~ 70 °C				
Life Time (25°C)	After 10 years at rated voltage and +25 °C				
	Capacitance change	Within 30% of initially specified value			
	Internal resistance change	Within 100% of initially specified value			
Cycle Life (25°C)	After 500,000 cycles between rated voltage to half rated voltage at +25 °C				
	Capacitance change	Within 30% of initially specified value			
	Internal resistance change	Within 100% of initially specified value			

#### **■ Standard Ratings**

Dark averahas	Capacitance	Resistance (m <b>Ω</b> )		Max.	Continuous	Leakage	Max. Stored
Part number	(F)	(1KHz)	DC	Current (A)		Current (mA)	Energy (Wh)
LSUC 002R8L 0400F EA	400	2.8	3	255	25	< 1	0.44
LSUC 002R8L 0350F EA	350	3.0	3.2	231	25	< 1	0.38

Dark sounds as	Dimensi	Weight	
Part number	D1 (+ 1.0)	L (±2.0)	(g)
LSUC 002R8L 0400F EA	35.0	66.0	80
LSUC 002R8L 0350F EA	35.0	61.0	72



## **Technical Information (1)**

#### ■ How to calculate specification value

#### 1. The Measurement Methods

#### 1-1 Capacitance


Apply rated voltage and charge for 5min after the constant current / constant voltage power supply has achieved the rated voltage. After a charge for 5min has finished, discharge with 10mA/F to 0.1V.

Measure the time t1 to t2 where the voltage between capacitor terminals at the time of discharge reduces from V1 to V2 as shown figure and calculate the capacitance value by the following formula:



- 2) Constant voltage charge at V<sub>R</sub> for 5min
- 3) Constant current discharge with 10mA/F to 0.1V

$$C = \frac{I \times (t_2 - t_1)}{V_2 - V_1} \quad (V_2 = 2.24V, V_1 = 1.12V)$$



#### 1-2 Resistance

The AC and DC resistance of a capacitor shall be calculated by the following formula;

$$R_{AC} = \frac{V}{I_{AC}}$$
 (The frequency of the measuring voltage shall be 1 kHz)

$$R_{DC} = \frac{\Delta V}{I_{DC}}$$

Where  $R_{AC}$  is the AC internal resistance ( $\Omega$ );


 $R_{DC}$  is the DC internal resistance ( $\Omega$ );

V is the effective value of AC voltage (V);

**△V** is the drop voltage for 10ms (V);

I<sub>AC</sub> is the effective value of AC current (A);

I<sub>DC</sub> is the discharge current (A); 5A



#### LS ULTRACAPACITOR

### **Technical Information (2)**

#### 1-3 Leakage current & Self discharge

The leakage current shall be measured using the direct voltage appropriate to the test temperature ( $25^{\circ}$ C) for 72hrs. Self discharge voltage shall be measured after charging up for 12hrs, disconnect the capacitor terminals from the voltage source. The capacitor shall be kept under standard condition for 100hrs.

#### 1-4 Maximum current

Current for 1sec discharge from the rated voltage to the half of it in constant current discharge,

$$I_{Max} = \frac{V_R - 0.5 * V_R}{\Delta t / C + R_{DC}}$$

Where  $I_{Max}$  is the Maximum current (A);

*∆t* is the discharge time (sec), 1 sec in this case ;

c is the capacitance (F);

 $R_{DC}$  is the DC resistance ( $\Omega$ );

 $V_R$  is the rated voltage (V).

1-5 Maximum stored energy ( $E_{MAX}$ )

$$E_{MAX}(Wh) = \frac{\frac{1}{2} CV_R^2}{3600}$$

#### 2. The Standard Atmospheric Condition for Measurement

All test and measurements shall be made under standard atmospheric conditions for testing. Before the measurements are made, the capacitor shall be stored at the measuring temperature for a time sufficient to allow the entire capacitor to reach this temperature. The period as prescribed for recovery at the end of a test is a normally sufficient for this purpose.

Temperature :  $15\sim35$  °C Relative humidity :  $25\sim75\%$  Air Pressure :  $86\sim106$  kPa

