

UTAustinX: UT.6.01x Embedded Systems - Shape the World

KarenWest (/dashboard)

Courseware (/courses/UTAustinX/UT.6.01x/1T2014/courseware)

Course Info (/courses/UTAustinX/UT.6.01x/1T2014/info)

Discussion (/courses/UTAustinX/UT.6.01x/1T2014/discussion/forum)

Progress (/courses/UTAustinX/UT.6.01x/1T2014/progress)

Questions (/courses/UTAustinX/UT.6.01x/1T2014/a3da417940af4ec49a9c02b3eae3460b/)

Syllabus (/courses/UTAustinX/UT.6.01x/1T2014/a827a8b3cc204927b6efaa49580170d1/)

Next we will overview the specific UART functions on the TM4C microcontroller. This section is intended to supplement rather than replace the Texas Instruments manuals. When designing systems with any I/O module, you must also refer to the reference manual of your specific microcontroller. It is also good design practice to review the errata for your microcontroller to see if any quirks (mistakes) exist in your microcontroller that might apply to the system you are designing.

Tiva TM4C microcontrollers have eight UARTs. The specific port pins used to implement the UARTs vary from one chip to the next. To find which pins your microcontroller uses, you will need to consult its datasheet. Table 11.2 shows some of the registers for the UART0 and UART1. For the other UARTs, the register names will replace the 0 with a 1 – 7. For the exact register addresses, you should include the appropriate header file (e.g., **tm4c123gh6pm.h**). To activate a UART you will need to turn on the UART clock in the **RCGC1** register. You should also turn on the clock for the digital port in the **RCGC2** register. You need to enable the transmit and receive pins as digital signals. The alternative function for these pins must also be selected. In particular we set bits in both the AFSEL and PCTL registers.

The OE, BE, PE, and FE are error flags associated with the receiver. You can see these flags in two places: associated with each data byte in <code>UARTO_DR_R</code> or as a separate error register in <code>UARTO_RSR_R</code>. The overrun error (<code>OE</code>) is set if data has been lost because the input driver latency is too long. <code>BE</code> is a break error, meaning the other device has sent a break. <code>PE</code> is a parity error (however, we will not be using parity). The framing error (<code>FE</code>) will get set if the baud rates do not match. The software can clear these four error flags by writing any value to <code>UARTO_RSR_R</code>.

The status of the two FIFOs can be seen in the **UARTO_FR_R** register. The **BUSY** flag is set while the transmitter still has unsent bits, even if the transmitter is disabled. It will become zero when the transmit FIFO is empty and the last stop bit has been sent. If you implement busy-wait output by first outputting then waiting for **BUSY** to become 0 (right flowchart of Figure 11.10), then the routine will write new data and return after that particular data has been completely transmitted.

The **UARTO_CTL_R** control register contains the bits that turn on the UART. **TXE** is the Transmitter Enable bit, and **RXE** is the Receiver Enable bit. We set **TXE**, **RXE**, and **UARTEN** equal to 1 in order to activate the UART device. However, we should clear **UARTEN** during the initialization sequence.

		31–12	11	10	9	8	7–0	Name
	\$4000.C000		OE	BE	PE	FE	DATA	UART0_DR_R
1	of 4							

Help

2 of 4

\$4000.D024		DIVINT									
		3	31–6								
\$4000.D028						UART1_FBRD_R					
	31–8	7	6-5	4	3	2	1	0			
\$4000.D02C		SPS	WPEN	FEN	STP2	EPS	PEN	BRK	UART1_LCRH_R		
	31–10	9	8	7	6–3	2	1	0			
\$4000.D030		RXE	TXE	LBE		SIRLP	SIREN	UARTEN	UART1_CTL_R		

15-0

Table 11.2. Some UART registers. Each register is 32 bits wide. Shaded bits are zero.

The **IBRD** and **FBRD** registers specify the baud rate. The baud rate **divider** is a 22-bit binary fixed-point value with a resolution of 2⁻⁶. The **Baud16** clock is created from the system bus clock, with a frequency of (Bus clock frequency)/**divider**. The baud rate is 16 times slower than **Baud16**

Baud rate = Baud16/16 = (Bus clock frequency)/(16*divider)

TM4C123 UART | 11.2 Universal Asynchrono...

31 - 16

For example, if the bus clock is 80 MHz and the desired baud rate is 19200 bits/sec, then the **divider** should be 80,000,000/16/19200 or 260.4167. Let m be the integer part, without rounding. We store the integer part (m=260) in **IBRD**. For the fraction, we find an integer n, such that n/64 is about 0.4167. More simply, we multiply 0.4167*64 = 26.6688 and round to the closest integer, 27. We store this fraction part (n=27) in **FBRD**. We did approximate the divider, so it is interesting to determine the actual baud rate. Assume the bus clock is 80 MHz.

Baud rate = (80 MHz)/(16* (m+n/64)) = (80 MHz)/(16* (260+27/64)) = 19199.616 bits/sec

The baud rates in the transmitter and receiver must match within 5% for the channel to operate properly. The error for this example is 0.002%.

The three registers **LCRH**, **IBRD**, and **FBRD** form an internal 30-bit register. This internal register is only updated when a write operation to **LCRH** is performed, so any changes to the baud-rate divisor must be followed by a write to the **LCRH** register for the changes to take effect. Out of reset, both FIFOs are disabled and act as 1-byte-deep holding registers. The FIFOs are enabled by setting the **FEN** bit in **LCRH**.

TM4C123 UART | 11.2 Universal Asynchrono... CHECKPOINT 11.2

https://courses.edx.org/courses/UTAustinX/UT...

Assume the bus clock is 10 MHz. What is the baud rate if UARTO IBRD R equals 2 and UARTO FBRD R equals 32?

Hide Answer

divider = 0010.1000002. or 2 plus 32/64 = 2.5. The baud rate is 10MHz/2.5/16 which is 250 kHz.

CHECKPOINT 11.3

Assume the bus clock is 50 MHz. What values should you put in UARTO_IBRD_R and UARTO_FBRD_R to make a baud rate of 38400 bits/sec?

Hide Answer

50,000,000/38400/16 is 81.3802, which is similar to 81 and 24/64. UARTO_IBRD_R is 81 UARTO_FBRD_R is 24. The baud rate is 50MHz/(81+24/64)/16 which is 38402 bits/sec.



About (https://www.edx.org/about-us) Jobs (https://www.edx.org/jobs)

Press (https://www.edx.org/press) FAQ (https://www.edx.org/student-faq)
Contact (https://www.edx.org/contact)



EdX is a non-profit created by founding partners Harvard and MIT whose mission is to bring the best of higher education to students of all ages anywhere in the world, wherever there is Internet access. EdX's free online MOOCs are interactive and subjects include computer science, public health, and artificial intelligence.



(http://www.meetup.com/edX-Global-Community/)



(http://www.facebook.com/EdxOnline)



(https://twitter.com/edXOnline)



(https://plus.google.com /108235383044095082735/posts)



(http://youtube.com/user/edxonline) © 2014 edX, some rights reserved.

Terms of Service and Honor Code - Privacy Policy (https://www.edx.org/edx-privacy-policy)