



4串电池接线图示 >>>



8串电池接线图示 >>>




保护板配件接线图 >>>



保护板配件接线图 >>>



并联模块接线图 >>>



保护板接口定义图 >>>

① 温度接口 (HY2.0-4P)




② 蜂鸣器/报警接口 (A1254WF-2A)



③ GPS接口 (1.25T-4PWT)




④ 显示屏接口 (A1254WF-6A)




保护板接口定义图 >>>

① 并联接口 (A1254WF-3A)



② CAN/485接口 (A1254WF-4A)



③ ACC检测接口 (A1254WF-5A)

