31390 Unmanned Autonomous Systems - Trajectory Generation

David Wuthier

June 17, 2020

GOALS

To understand:

- How to translate a path into a trajectory
- What are the constraints behind trajectory generation
- How to generate trajectories from scratch

The path planning problem (definitions)

 \mathcal{C} : robot configuration space, e.g.,

 $\mathbb{R}^2 \times \mathbb{R} \times \mathbb{S}$

 $q \in \mathcal{C}$: robot configuration

 $\mathcal{W} \subset \mathbb{R}^{\textit{N}}: \ \ \text{robot workspace with } \textit{N} = 2$

(planar) or N = 3 (volume)

 $\mathcal{O}\subset\mathcal{C}$: obstacle region

 $\mathit{A}(\mathit{q}) \subset \mathcal{W}$: robot geometry

 $\mathcal{C}_{\mathsf{obs}} = \{q \in \mathcal{C} \mid A(q) \cap \mathcal{O} \neq \emptyset\}$: C-space obstacle region

 $\mathcal{C}_{\mathsf{free}} = \mathcal{C} \setminus \mathcal{C}_{\mathsf{obs}}$: free space

The path planning problem (formulation)

Given an initial configuration q_I and a goal configuration q_G , find

$$c:[0,1] o \mathcal{C}_{\mathsf{free}}$$
 such that $c(0)=q_{\mathit{I}}$ and $c(1)=q_{\mathit{G}}.$

For example (linear path): $c(\lambda) = (1 - \lambda)q_I + \lambda q_G$.




Figure 1: a) A planar robot and an obstacle. b) the corresponding obstacle region

Paths and trajectories

- A path is geometric object; it does not entail any temporal information
- How to follow a path then? With a trajectory
- Let's say you want to follow a path c from time t_I to time t_G.
 Then, you will follow the desired trajectory

$$q_d(t)=c(s(t))$$

with a scaling function $s:[t_I,t_G]\to [0,1]$ that allows to respect kinematic and dynamic constraints.

Robot dynamics

In general, the dynamical model of a robot can be expressed as

$$\underbrace{H(q)}_{\text{inertia}} \ddot{q} + \underbrace{C(q, \dot{q})}_{\substack{\text{Coriolis}+\\ \text{centrifugal}}} \dot{q} + \underbrace{\tau_g(q)}_{\text{gravity}} = \underbrace{\tau}_{\text{input torque}}$$

This dynamics, together with the actuators' performances, structural aspects, safety, etc., can imply constraints like

$$|\tau| \le \tau_{\mathsf{max}}, \quad |\dot{q}| \le \dot{q}_{\mathsf{max}}, \quad |\ddot{q}| \le \ddot{q}_{\mathsf{max}},$$

And the smoother the trajectory, the better for the robot.

Robot control

One way to follow trajectories is *inverse dynamics control*: set the input torque to

$$au = H(q)v + C(q,\dot{q})\dot{q} + au_g(q)$$

with an auxiliary variable v that can be set to

$$v = \ddot{q}_d + K_V(\dot{q}_d - \dot{q}) + K_P(q_d - q)$$
 (PD controller)

Generating trajectories

If no path is available, a simple way to generate trajectories is to use **splines**. A spline is a piecewise polynomial function:

$$p(t) = egin{cases}
ho_0(t) ext{ if } t_0 \leq t < t_1 \
ho_1(t) ext{ if } t_1 \leq t < t_2 \
ho_m(t) ext{ if } t_m \leq t < t_{m+1} \end{cases} ext{ with } p_j(t) = \sum_{i=0}^n a_{ij} t^i$$

Trapezoidal velocity profile (n = 2)

When specifying, e.g., waypoints, peak velocity and acceleration




Figure 2: Trapezoidal velocity profiles.

Cubic splines (n = 3)

When specifying, e.g., waypoints and velocities at these waypoints.




Figure 3: Trajectory constituted by cubic splines.

Quintic splines (n = 5)

When specifying, e.g., waypoints, velocities at these waypoints and acceleration at these waypoints.




Figure 4: Trajectory constituted by quintic splines.

B-splines (n = 1, 2, 3, ...)

When specifying control points instead of waypoints.




Figure 5: Trajectory constituted by a b-spline. The crosses represent control points, and the trajectory remain in the control polygon (in blue).

B-splines

A B-spline is obtained by linearly combining a set of basis functions $N_{i,p}$ using control points P_i , i = 1, 2, ..., n:

$$p(t) = \sum_{i=1}^{n} P_i N_{i,p}(t).$$

These basis can be computed with the Cox-de Boor recursion formula for $t_0 \le t_1 \le \ldots \le t_m$:

$$N_{i,0}(t) = egin{cases} 1 & ext{if } t_i \leq t < t_{i+1} \ 0 & ext{otherwise} \end{cases}$$
 $N_{i,p}(t) = rac{t-t_i}{t_{i+p}-t_i} N_{i,p-1}(t) + rac{t_{i+p+1}-t}{t_{i+p+1}-t_{i+1}} N_{i+1,p-1}(t).$

B-splines

The computation of the basis functions follows a pyramid scheme:




Figure 6: The de Boor algorithm.




Figure 7: A set of basis functions.

Higher order?

Let's see in Mellinger and Kumar (2011)

REFERENCES



B. Siciliano and O. Khatib, Springer handbook of robotics. Springer, 2016.



https://se.mathworks.com/help/robotics/index.html?s_tid=CRUX_lftnav



B-spline curve. [Online]. Available: https://web.mit.edu/hyperbook/Patrikalakis-Maekawa-Cho/node17.html




B-spline (wolfram). [Online]. Available: https://mathworld.wolfram.com/B-Spline.html



B-spline basis functions. [Online]. Available:

The robotics systems toolbox. [Online]. Available:





D. Mellinger and V. Kumar, "Minimum snap trajectory generation and control for quadrotors," in 2011 IEEE International Conference on Robotics and Automation. IEEE, 2011, pp. 2520–2525.



T. Lee, M. Leok, and N. H. McClamroch, "Control of complex maneuvers for a quadrotor uav using geometric methods on se (3)," arXiv preprint arXiv:1003.2005, 2010.