## 13. List of Mechanical Parts

Item:	Ordering Number:		Description:
1 2 3 4 5	4008 108 56010 2408 135 00032 2408 135 00036 4008 108 55690 4008 107 58590	5. A. 1. A.	FRONT PLATE ASSY KNOB FOR BUTTON (GREY) KNOB FOR BUTTON W/LED HANDLE ASSY TOP COVER
6 7 8 9 10 11 12 13	4008 127 03930 4008 118 86280 4008 104 60130 4008 105 91260 4008 105 91270 2422 025 09571 4008 103 66750 4008 103 56030 4008 108 04650 4008 127 03910		BOTTOM/REAR PLATE GND CONNECTOR ASSY MAINS SWITCH MAINS INLET CONNECTOR FUSE HOLDER CONNECTOR "REMOTE" CONNECTOR "PT 5210 1/2" BNC CONNECTOR COVER FOR BNC CONNECTOR OPTION PLATE
	4008 105 25000 4008 105 91300		FUSE 1.6A POWER SUPPLY
15 16	4008 103 66580 2422 025 10013		XLR CONNECTOR CONN. "IN 1/2"

Warning: For reasons of safety, please use only original parts for the power supply and all parts connected to or adjacent to primary circuits.




Fig. 13-1 Front of the Instrument




Fig. 13-2 Rear of the Instrument




Fig. 13-3 PT 8618 Option