

<Note>

 $\pm 1:$ The tolerance of the tip's position is $\pm 0.5 \, \text{mm}$ from the standard position.



Unit:mm

								MI 621 / F9D
<u>ө</u>		C *		0 0	k e d	Approved	Name	MEOZI /IJD
Sca		- 0		0 0	Chec		No.	PS-ML06528