

DK - Technologies

Worldwide Offices

DENMARK (HEAD OFFICE)

DK-Technologies A/S, Marielundvej 37D, DK-2730 Herlev.

Tel: +45 44 85 02 55 Fax: +45 44 85 02 50 Email: info@dk-technologies.com

UK

DK-Technologies (UK) Ltd, Coles Yard Barn, North Lane, Clanfield, Hampshire PO8 ORN, England.

Tel: +44 (0) 23 92 59 61 00 Te Fax: +44 (0) 23 92 59 61 20 Fa Email: info.uk@dk-technologies.com Ei

GERMANY

DK-Technologies Germany GmbH,

Tibarg 32c,

D-22459 Hamburg.

Tel: +49 (0) 40 70 10 37 07 Fax: +49 (0) 40 70 10 37 05 Email: cr@dk-technologies.com

USA

DK-Technologies America, 2100 B2 Walsh Ave,

Santa Clara, CA 95050-2590, USA.

Tel: 0800 421 0888 Fax: +45 44 85 02 50

Email: info@dk-technologies.com

www.dk-technologies.com







DK - Technologies

DK METER

COMPACT AUDIO LOUDNESS METER

Quick Start Guide



In the box...

- 1 x DK Meter
- 1 x Interface Cable including USB Power
- 1 x Universal USB Power Supply including US, Euro & UK compatibility
- 1 x Meter Mount
- 1 x Panel Mount Template
- 1 x Quick Start Guide







DK METER

Quick Start Guide

BNC USB Connector Connector

Multi-Pin Connector



Desktop Mount Meter Assembly

Quick Start Guide...

When the contents have been checked please proceed as set out below:

- Connect the interface cable to the multi-pin connector at the back of the meter.
- Fit the mounting system if required. See the picture "Desktop Mount Meter Assembly" on page 2.
- 3. Connect the AES BNC connector to the audio source.
- Fit the correct power adaptor to the USB power supply.
- Connect the USB connector the the USB power supply.
- Connect the USB power supply into a mains outlet and turn on. The meter will illuminate shortly.
- Update the software with "dkMeterOnline.exe" which can be downloaded at:
 http://download.dk-technologies.com/dkMeterOnline.exe

 Please follow the on-screen instructions.
- 8. The full user guide can be downloaded at: http://www.dk-technologies/dkmeter