CITATION X | COLD TO ENGINES

One-glance checklist: the minimum sequence, not a replacement for the full procedure

1 POWER ON

Parking brake SET. STBY PWR ON; emergency lights ARM; BATT 1 + BATT 2 ON.
EICAS POWER ON. LH fuel boost NORM.

REAL PHOTO: APU control panel

Open the real Citation X cockpit photograph

2 APU START

APU MASTER ON; TEST PUSH; APU GENERATOR ON; check at least 22 V.
Hold APU START until relay engaged; wait for READY TO LOAD.
APU BLEED AIR ON.

3 AVIONICS + FLIGHT DATA

AVIONICS POWER ON; align IRS (NAV); initialise FMS position.
Enter departure/route and obtain V1, VR, V2 from TAKEOFF DATA.
Check fuel/weight, runway, departure altitude and flight director.

4 ENGINES (RIGHT, THEN LEFT)

PAC ISOL VALVE CLOSED; start duct pressure at least 30 PSI.
Press RIGHT ENGINE START; move right throttle to IDLE by 10% N2.
Check N1, oil pressure, ITT and hydraulics. Repeat for LEFT ENGINE.
Both generators ON. APU bleed OFF after engine starts; verify bleed setup.

STOP if starter indications, ITT, oil pressure or hydraulics are abnormal.

CITATION X | TAXI TO TAKE-OFF

Your CM3 throttles: forward thrust. CP3 lever: speedbrakes must be fully stowed.

5 TAXI CONFIGURATION

Flight controls FREE/CORRECT. Set flaps/slats for take-off.
Speedbrakes checked and STOWED (0%); reversers STOWED.
IRS aligned; EICAS advisories resolved; trim in correct take-off band.
Remove chocks through tablet. Close cabin door; check steering and brakes.

REAL PHOTO: Citation X cockpit and throttle quadrant

Open the real Citation X cockpit photograph

6 BEFORE ENTERING RUNWAY

Flaps TAKE-OFF; trim SET; speedbrakes 0%; yaw damper + Mach trim ON.
Pitot/static anti-ice ON, other anti-ice as required; lights SET.
Transponder TA/RA. Verify EICAS, fuel, take-off speeds and runway.

7 TAKE-OFF

Apply TO/MC thrust; release brakes; check engine indications.
Maintain runway centreline; ROTATE at calculated VR toward ~13 degrees pitch.
Positive climb: gear UP. Retract flaps when appropriate and above 170 KIAS.
Set CLB thrust; follow flight director and published departure.

Do not use a fixed VR: it depends on weight and conditions.

Official procedures: FlightFX Citation X manual, checklist pages 131-134.