# Lab 6

# ICS 423: Internet Of Things

## Jayant Kolapkar - 2021BCS0132

**Task 1:** Design an alarm system that triggers warning if a package gets damaged. Use force sensor and a buzzer alarm.

#### **Algorithm**

- 1. Initialize Components
  - Define force sensor pin (Analog A0).
  - Define buzzer pin (Digital 9).
  - Define LED pin (Digital 7).
  - Set the threshold value for the force sensor.
- 2. Setup Function (Runs Once)
  - Start the Serial Monitor for debugging.
  - Set LED and Buzzer as OUTPUT.
- 3. Loop Function (Repeats Continuously)
  - Read the force sensor value from A0.
  - Print the sensor value to the Serial Monitor.
  - Compare the sensor value with the threshold:
    - If the value is greater than the threshold:
      - Turn ON the LED.
      - Turn ON the Buzzer.
    - Else:
      - Turn OFF the LED.
      - Turn OFF the Buzzer.

• Add a small delay for stability.

## <u>Code</u>


```
const int forceSensorPin = A0;
const int buzzerPin = 9;
const int ledPin = 7;
const int threshold = 400;
void setup() {
       Serial.begin(9600);
       pinMode(buzzerPin, OUTPUT);
       pinMode(ledPin, OUTPUT);
}
void loop() {
      int sensorValue = analogRead(forceSensorPin);
       Serial.println(sensorValue);
       if (sensorValue > threshold) {
       digitalWrite(buzzerPin, HIGH);
```

```
digitalWrite(ledPin, HIGH);
} else {
    digitalWrite(buzzerPin, LOW);
    digitalWrite(ledPin, LOW);
}

delay(100);
}
```

## Output

The alarm and the LED bulb are off when the force applied is below the threshold.



The alarm rings and the LED bulb glows when the force crosses the threshold limit.

**Task 2:** Develop a smoke detecting system for a building consisting of three floors. Notify the real-time value of the floors to thingspeak IoT cloud platform.

#### 1. Initialize Components:

- Start Serial Communication at 115200 baud.
- Connect ESP8266 to WiFi using AT+CWJAP.
- Set up pin modes:
  - A0, A1, A2 → Smoke sensors for Floors 1, 2, and 3.
  - Pin 7 → Buzzer.

#### Read Sensor Data:

- Collect readings from A0, A1, and A2.
- Display sensor values on the Serial Monitor.

## Send Data to ThingSpeak:

- Establish a TCP connection using AT+CIPSTART.
- Construct an HTTP GET request including the API key and sensor values.
- · Transmit the request using AT+CIPSEND.

## 4. Activate Buzzer on High Smoke Detection:


- If any sensor reading exceeds 85, activate the buzzer (tone(7, 1000)).
- Otherwise, turn OFF the buzzer (noTone(7)).

## 5. Close Connection & Repeat:


- Terminate the TCP connection using AT+CIPCLOSE.
- Wait 10 seconds (due to ThingSpeak's free-tier limit).
- · Repeat the process continuously.

```
int val1 = 0, val2 = 0, val3 = 0;
void setup() {
 delay(100);
 Serial.begin(115200);
 Serial.println("AT+CWJAP=\"Simulator Wifi\",\"\"\r\n");
 delay(3000);
 pinMode(7, OUTPUT);
 pinMode(A0, INPUT);
 pinMode(A1, INPUT);
 pinMode(A2, INPUT);
void loop() {
 val1 = analogRead(A0);
 val2 = analogRead(A1);
 val3 = analogRead(A2);
 Serial.print("Floor 1 Smoke: "); Serial.println(val1);
 Serial.print("Floor 2 Smoke: "); Serial.println(val2);
 Serial.print("Floor 3 Smoke: "); Serial.println(val3);
 delay(1000);
 Serial.println("AT+CIPSTART=\"TCP\",\"api.thingspeak.com\",80\r\n");
 delay(3000);
 String request = "GET /update?api_key=7FMOOFSORT938HZF&field1=";
 request += String(val1) + "&field2=" + String(val2) + "&field3=" + String(val3);
 Serial.print("AT+CIPSEND=");
 Serial.println(request.length() + 2);
 delay(1000);
 Serial.print(request);
 delay(1000);
 if (val1 > 85 | | val2 > 85 | | val3 > 85) {
  tone(7, 1000);
 } else {
  noTone(7);
 }
 Serial.println("AT+CIPCLOSE=0\r\n");
 delay(10000);
```

## **Output**



#### Simulation



Graph visualization on ThingSpeak

