

Informed by Science. Inspired by Love.



Welcome to the Hälsa Baby Family!



Download the Hälsa Baby App to Get Started





For more information or to view the product manuals, visit www.HalsaBaby.com

Warnings & Important Safety Information

PRODUCT NOTES

- 1. Requires 2.4 GHz wireless internet.
- Transmission range and reception may be affected by nearby electronics or home construction.
- Works with Apple iOS 12.4 or later and Android 5.0 or later devices; all features, functionality and other

specifications are subject to change without notice from Hälsa Baby.



Children have STRANGLED in cords. Always use protective covering when used within 3 feet of crib. Check before each use to ensure the cord is not exposed to your child. Immediately discontinue use if the protective covering is damaged or broken. Do not remove tag from cord or protective covering.

Apple, iPhone and the Apple logo are trademarks of Apple Inc. App Store is a service mark of Apple Inc. Android, Google Play and the Google Play logo are trademarks of Google Inc.

IMPORTANT SAFFTY INSTRUCTIONS

- The Hälsa Baby All-In-One Wellness Camera is not a medical device. It is not intended for use
 as a medical device or to replace a medical device. It does not and is not intended to diagnose,
 cure, treat, mitigate or prevent any disease or health condition or affect the structure or
 function of any body part or physiological process. Please contact your licensed healthcare
 professional for any medical needs.
- For indoor use only. To reduce the risk of fire or electrical shock, DO NOT expose this product to water or moisture. DO NOT use the camera near water (such as bathtub, sink, etc.) or submerge in water.
- The use of this camera should not replace proper adult/parental supervision. You should check your child's activity at regular intervals, as the camera will not alert parents to the silent activities of a child.
- NEVER attempt to disassemble the product. This is dangerous and will void the warranty.
- · The user should not attempt to service/repair camera.
- Use only the adapter supplied with this product. Incorrect adapter polarity or voltage can seriously damage the product.
- · To prevent entanglement and overheating, DO NOT use extension cords.
- $\bullet \ \, \text{The adapter may become slightly warm to the touch during operation.} \ \, \text{This is normal}.$
- ALWAYS unplug the AC adapter from the wall during extended periods of non use.
- Check to make sure wall outlet plates are not unusually hot to the touch. If they are, immediately unplug cords from these outlets. Check that all outlet connections are in good condition so that adapter is not loose or that no wiring is exposed. Have a qualified, licensed electrician check that no wiring is exposed.
- DO NOT place adapter/wall plug under a window where a child might use it to step on and/or reach something that might be dangerous.
- Adult assembly is required. Keep small parts away from children when assembling to avoid risk of choking. Exercise care when unpacking the product.
- This product is not a toy. DO NOT allow children to play with it.
- · Always remember to password-protect your WiFi router.

ADDITIONAL SAFETY INSTRUCTIONS



CAUTION: VENTILATION: DO NOT block openings. DO NOT place on a bed, sofa, rug or similar surface. DO NOT place in bookcase or cabinet that may restrict air flow.



CAUTION: HEAT: the camera should be situated away from heat sources, such as radiations, heat registers, stoves or other appliances that produce heat. Also, keep these components out of direct sunlight.



CAUTION: POWER CORD PROTECTION: The power supply cord should be routed so that it is not likely to be walked on or pinched by items placed upon or against it. Pay particular attention to the cord at the plug and at the point it exits from the camera.

LIMITED WARRANTY

Hälsa Baby proudly stands by its products. Our warranties are found at: halsababy.com/pages/warranty-disclaimers.

FCC COMPLIANCE STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interferences, and (2) this device must accept any interference received, including interferences that may cause undesired operation.

Changes or modifications to this product not authorized by party responsible for compliance could void the electromagnetic compatibility (EMC) and wireless compliance and negate your authority to operate the product.

Please ONLY use the supplied power adapter. Failure to do so may void our limited warranty.

Note: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Camera FCC ID: 2AG7C-MINI7

INPUT: 100-240V ~ 50/60Hz 0.5A Max OUTPUT: DC 5.0V/3A