1. Introduction to Cable Sizing :

Cable sizing is a critical aspect of electrical installation design. It involves determining the appropriate cross-sectional area (CSA) of an electrical conductor to safely and efficiently transmit power from a source to a load. Incorrect cable sizing can lead to several serious problems, including:

Overheating: Undersized cables can overheat due to excessive current, leading to insulation degradation, fire hazards, and power outages.

Voltage Drop: Oversized resistance in long or undersized cables causes a reduction in voltage at the load, leading to inefficient operation of appliances, reduced motor torque, and dim lighting.

Energy Losses: Excessive voltage drop implies greater power loss (I^2R losses) in the cable, resulting in higher electricity bills.

Damage to Equipment: Prolonged low voltage can damage sensitive electronic equipment and reduce the lifespan of motors.

Failure of Protection: An undersized cable might not allow sufficient fault current to flow to trip a protective device (e.g., circuit breaker) quickly enough, posing a safety risk.

The primary objective of cable sizing is to ensure that the chosen cable can: Safely carry the design current without exceeding its temperature limits (Current Carrying Capacity). Have a voltage drop within acceptable limits. Withstand short-circuit currents for a specified duration (though often a secondary check for simple domestic circuits). This guide will focus on the first two primary criteria, which are crucial for fundamental electrical design.

cable, several electrical principles and formulas are applied:

2.1. Power (P): The rate at which electrical energy is transferred or consumed. Units: Watts (W) or Kilowatts (kW). Single-Phase AC Power: $P = V \times I \times \text{PF}$ Three-Phase AC Power: $P = \sqrt{3} \times V_{L} \times I_{L} \times \text{PF}$ Where: P = Power in Watts (W) V = Phase voltage (Line to Neutral) in Volts (V) for single phase V_{L} = Line-to-line voltage in Volts (V) for three phase I = Current in Amperes (A) for single phase I_{L} = Line current in Amperes (A) for three phase PF = Power Factor (dimensionless, between 0 and 1)

2.2. Current (I): The flow of electric charge. This is the most critical parameter for determining cable thickness. Units: Amperes (A). Single-Phase AC Current: $I = P / (V \times \text{PF})$ Three-Phase AC Current: $I = P / (\sqrt{3} \times V_{L} \times \text{PF})$

2.3. Voltage Drop (ΔV): The reduction in voltage along the length of the cable due to its resistance. Units: Volts (V) or as a percentage of the supply voltage (%). Formula (Simplified for Copper/Aluminum, AC Single-Phase): $\Delta V = (2 \times I \times L \times \rho) / A$ Where: ΔV = Voltage drop in Volts I = Design current in Amperes (A) L = One-way length of the cable in meters (m) ρ = Resistivity of conductor material in ($\Omega\ mm^2/m$) Copper (Cu): Typically taken as 0.018 to $0.022\ \Omega\ mm^2/m$ (depending on temperature and standard; 0.018 for ambient, higher for operating). Aluminum (Al): Typically 0.028 to $0.032\ \Omega\ mm^2/m$. A = Cross-sectional area of the conductor in mm^2 Percentage Voltage Drop ($\%VD$): $\%VD = (\Delta V / V_{\text{supply}}) \times 100$ Common

2.5% to 3%Power circuits: 4% to 5%These limits are specified by national electrical codes (e.g., IEC 60364, NEC, BS 7671).

3. Step-by-Step Cable Sizing Methodology

The cable sizing process typically follows these sequential steps:

Step 1: Determine the Design Current (I_b)Identify all loads connected to the circuit (lighting, receptacles, appliances).Sum their power ratings (Watts).Use the appropriate current formula (single-phase or three-phase) with the system voltage and an estimated power factor. For simple resistive loads (heaters, incandescent lights), $\text{PF} = 1$. For mixed loads (motors, electronics), $\text{PF} = 0.8 \text{ to } 0.95$ is common.

Step 2: Select the Nominal Rating of the Protective Device (I_n)The protective device (circuit breaker or fuse) must be rated to protect the cable from overcurrent.The rating (I_n) must be equal to or greater than the design current (I_b).Choose the next standard rating available above I_b. For example, if $I_b = 14.49 \text{ A}$, the next standard breaker is typically 16 A.

Step 3: Determine the Required Current Carrying Capacity of the Cable (I_z)The actual current-carrying capacity (I_z) of a cable (its ampacity) depends heavily on its installation environment.I_z is derived from standard tables (e.g., national electrical codes) which provide base ampacity values under reference conditions.These base values are then adjusted using correction factors (also called

Temperature Factor (C_a): Cables rated for a reference ambient temperature (e.g., $30^\circ C$). If the actual ambient temperature is higher, $C_a < 1$; if lower, $C_a > 1$. Grouping Factor (C_g): If multiple cables are grouped together in a conduit, tray, or buried, their heat dissipation is reduced. More cables in a group mean lower individual ampacity ($C_g < 1$). Insulation Type (C_i): Different insulation materials (PVC, XLPE) have different temperature ratings, affecting ampacity. Depth of Burial Factor (C_d): For buried cables, affects heat dissipation. Harmonic Factor (C_h): If loads generate significant harmonics, the neutral conductor might carry current, requiring adjustments. The required ampacity of the cable, after considering these factors, must be: $I_z \ge I_b / (C_a \times C_g \times \dots)$ Also, the ampacity must be sufficient for the protective device: $I_z \ge I_n$ (in some codes, $I_z \ge I_n / C_g$ or other combinations)

Step 4: Select an Initial Cable Size Based on Current Carrying Capacity Using the calculated minimum required I_z, refer to the standard cable ampacity tables provided by electrical codes. Choose the smallest standard cable cross-sectional area (mm^2) whose ampacity ($I_{z_\{\text{table}\}}$) is equal to or greater than your calculated required I_z

.

Step 5: Verify Voltage Drop (ΔV) Once an initial cable size (A) is selected based on current carrying capacity, it is crucial to check if it also satisfies the voltage drop requirements. Using the voltage drop formula ($\Delta V = (2 \times I_b \times L \times \rho) / A$), calculate the

calculated ΔV (or $\%\Delta$) with the permissible limits specified by the electrical code (e.g., 3% for lighting, 5% for power). If the calculated voltage drop exceeds the limit, a larger cross-sectional area cable must be selected (go back to Step 4 with a larger A) and the voltage drop re-verified. This iterative process continues until both current carrying capacity and voltage drop criteria are met.

Step 6: Short Circuit Withstand Check (Advanced / For Larger Installations)For critical circuits or larger installations, the cable must also be able to withstand the thermal and mechanical stresses caused by a short-circuit fault current for the duration it takes for the protective device to clear the fault.This involves calculating the prospective short-circuit current and using formulas to determine the minimum CSA to prevent damage. For simple domestic circuits, if the cable is sized correctly for current and voltage drop, it often inherently meets short-circuit requirements due to the relatively lower fault currents and faster protection.

4. Detailed Example: Cable Sizing for a Small Workshop Circuit Let's work through a more detailed example for a small workshop circuit, which might include power tools. Scenario: A homeowner wants to install a new circuit to a detached small workshop from their main distribution board. The workshop will house a few power tools (drill, saw, grinder) and some LED lighting. Required Parameters: Total Connected Load (P): Drill: 750 W Saw: 1200 W Grinder: 800 W LED Lights (5 x 15W): 75 W Total = 750 + 1200 + 800 + 75 = 2825 W (Assume not all tools run simultaneously for continuous design current, but account

design current, we'll sum up some commonly used together. Let's assume saw and grinder together, plus lights: $1200 + 800 + 75 = 2075 W$. Let's round up to a design load of 2.1 kW (2100 W) to give some headroom.System Voltage (V): 230 V (Single Phase)Cable Length (L): 35 meters (from main board to workshop sub-panel)Power Factor (PF): 0.85 (due to inductive loads from motors)Cable Material: Copper (PVC insulated)Installation Method: Buried direct in ground, then in conduit for entry to buildings. (We will simplify this to "buried direct" for correction factor selection).Ambient Ground Temperature: $25^\circ C$Permissible Voltage Drop: 4% (for a power circuit with potential motor loads)Step-by-Step Calculation:Step 1: Calculate Design Current (I_b)$I_b = P / (V \times \text{PF})$$$I_b = 2100 \text{ W} / (230 \text{ V} \times 0.85)$$$I_b = 2100 / 195.5 \approx \mathbf{10.74 \text{ Amperes}}$$Step 2: Select the Nominal Rating of the Protective Device (I_n)The next standard circuit breaker rating above 10.74 A is 16 A.So, $I_n = 16 \text{ Amperes}$.Step 3: Determine the Required Current Carrying Capacity of the Cable (I_z)We need to apply correction factors based on the installation method and ambient temperature.Ambient Ground Temperature Factor (C_a): For PVC insulated copper cable buried direct, standard tables might give a C_a for a reference of $20^\circ C$. If operating at $25^\circ C$, a typical C_a might be around 0.96 to 0.98. Let's assume $C_a = 0.97$ (referencing a generic table).Grouping Factor (C_g): Assuming only this single circuit cable is buried, $C_g = 1.0$.Required $I_z = I_b / (C_a \times C_g)$Required $I_z = 10.74 \text{ A} / (0.97 \times 1.0)$Required $I_z \approx \mathbf{11.07 \text{ Amperes}}$$Also, the cable must be able to carry the

\ge I__n = 16 \text{ A}$ (This is usually the primary driver for cable ampacity)Therefore, the cable's ampacity ($I__z$) must be at least 16 A (to safely protect the circuit with a 16A breaker) and also accommodate the derated design current.Step 4: Select an Initial Cable Size Based on Current Carrying CapacityReferencing a generic table for PVC insulated copper cables buried direct in the ground (these values vary slightly by standard):CSA (mm2)Ampacity (A) at 20°C1.5~172.5~234.0~30Since we need an $I__z \ge 16 \text{ A}$ (and also considering the derated $I__b \approx 11.07 \text{ A}$), a 1.5 mm^2 Copper cable has a listed ampacity of $\approx 17 \text{ A}$, which is greater than 16 A. This looks like a candidate.Step 5: Verify Voltage Drop (ΔV)First, calculate the maximum permissible voltage drop:$\Delta V__{max} = 4\% \text{ of } 230 \text{ V} = 0.04 \times 230 \text{ V} = \mathbf{9.2 \text{ Volts}}$$Now, calculate the actual voltage drop for the selected 1.5 mm^2 cable:Using the resistivity of Copper $\rho = 0.018 \Omega mm^2/m$ (a common value at typical operating temperatures for this type of calculation).$\Delta V = (2 \times I__b \times L \times \rho) / A$$\Delta V = (2 \times 10.74 \text{ A} \times 35 \text{ m} \times 0.018 \Omega mm^2/m) / 1.5 \text{ mm}^2$$\Delta V = (13.5324) / 1.5$$\Delta V \approx$

Conclusion :Cable sizing is a methodical process that balances safety, efficiency, and cost. By systematically calculating the design current, applying relevant correction factors, selecting an initial cable size from ampacity tables, and rigorously checking the voltage drop, engineers and electricians can ensure that electrical installations are robust and reliable. Always refer to specific national and local

permissible voltage drop, and correction factors can vary.