



### **TABLE OF CONTENTS**

Lhapter 1. Difference between the driver and runtime APIs	
Chapter 2. API synchronization behavior	3
Chapter 3. Stream synchronization behavior	
Chapter 4. Modules	7
4.1. Device Management	
cudaChooseDevice	
cudaDeviceGetAttribute	
cudaDeviceGetByPCIBusId	
cudaDeviceGetCacheConfig	
cudaDeviceGetLimit	
cudaDeviceGetP2PAttribute	
cudaDeviceGetPCIBusId	
cudaDeviceGetSharedMemConfig	
cudaDeviceGetStreamPriorityRange	
cudaDeviceReset	
cudaDeviceSetCacheConfig	
cudaDeviceSetLimit	
cudaDeviceSetSharedMemConfig	
cudaDeviceSynchronize	
cudaGetDevice	
cudaGetDeviceCount	
cudaGetDeviceFlags	
cudaGetDeviceProperties	
cudalpcCloseMemHandle	
cudalpcGetEventHandle	
cudalpcGetMemHandle	
cudalpcOpenEventHandle	
cudalpcOpenMemHandle	
cudaSetDevice	
cudaSetDeviceFlags	
cudaSetValidDevices	
4.2. Thread Management [DEPRECATED]	
cudaThreadExit	
cudaThreadGetCacheConfig	
cudaThreadGetLimit	
cudaThreadSetCacheConfig	
cudaThreadSetLimit	
cudaThreadSynchronize	
4.3. Error Handling	
cudaGetErrorName	44

	cudaGetErrorString	44
	cudaGetLastError	45
	cudaPeekAtLastError	45
4.	4. Stream Management	46
	cudaStreamCallback_t	46
	cudaStreamAddCallback	46
	cudaStreamAttachMemAsync	48
	cudaStreamCreate	50
	cudaStreamCreateWithFlags	50
	cudaStreamCreateWithPriority	51
	cudaStreamDestroy	52
	cudaStreamGetFlags	53
	cudaStreamGetPriority	. 54
	cudaStreamQuery	
	cudaStreamSynchronize	55
	cudaStreamWaitEvent	
4.	5. Event Management	57
	cudaEventCreate	.57
	cudaEventCreateWithFlags	
	cudaEventDestroy	.58
	cudaEventElapsedTime	59
	cudaEventQuery	.60
	cudaEventRecord	61
	cudaEventSynchronize	62
4.	6. Execution Control	63
	cudaFuncGetAttributes	63
	cudaFuncSetCacheConfig	64
	cudaFuncSetSharedMemConfig	
	cudaGetParameterBuffer	
	cudaGetParameterBufferV2	
	cudaLaunchKernel	68
	cudaSetDoubleForDevice	
	cudaSetDoubleForHost	70
4.	7. Occupancy	
	cudaOccupancyMaxActiveBlocksPerMultiprocessor	
	cuda Occupan cy Max Active Blocks Per Multiprocessor With Flags	71
4.	8. Execution Control [DEPRECATED]	
	cudaConfigureCall	
	cudaLaunch	
	cudaSetupArgument	
4.	9. Memory Management	
	cudaArrayGetInfo	
	cudaFree	76

cudaFreeArray	77
cudaFreeHost	78
cudaFreeMipmappedArray	78
cudaGetMipmappedArrayLevel	79
cudaGetSymbolAddress	80
cudaGetSymbolSize	80
cudaHostAlloc	81
cudaHostGetDevicePointer	83
cudaHostGetFlags	84
cudaHostRegister	84
cudaHostUnregister	86
cudaMalloc	87
cudaMalloc3D	88
cudaMalloc3DArray	89
cudaMallocArray	91
cudaMallocHost	93
cudaMallocManaged	94
cudaMallocMipmappedArray	96
cudaMallocPitch	98
cudaMemAdvise	100
cudaMemcpy	102
cudaMemcpy2D	103
cudaMemcpy2DArrayToArray	104
cudaMemcpy2DAsync	106
cudaMemcpy2DFromArray	107
cudaMemcpy2DFromArrayAsync	109
cudaMemcpy2DToArray	110
cudaMemcpy2DToArrayAsync	112
cudaMemcpy3D	114
cudaMemcpy3DAsync	116
cudaMemcpy3DPeer	118
cudaMemcpy3DPeerAsync	119
cudaMemcpyArrayToArray	119
cudaMemcpyAsync	121
cudaMemcpyFromArray	122
cudaMemcpyFromArrayAsync	123
cudaMemcpyFromSymbol	125
cudaMemcpyFromSymbolAsync	126
cudaMemcpyPeer	127
cudaMemcpyPeerAsync	128
cudaMemcpyToArray	129
cudaMemcpyToArrayAsync	130
cudaMemcpyToSymbol	132

	cudaMemcpyToSymbolAsync	122
	cudaMemGetInfo	
	cudaMemPrefetchAsync	
	·	
	cudaMemRangeGetAttribute	
	cudaMemRangeGetAttributes	
	cudaMemset	
	cudaMemset2D	
	cudaMemset2DAsync	
	cudaMemset3D	
	cudaMemset3DAsync	
	cudaMemsetAsync	
	make_cudaExtent	
	make_cudaPitchedPtr	147
	make_cudaPos	
4.	10. Unified Addressing	.148
	cudaPointerGetAttributes	. 149
4.	11. Peer Device Memory Access	151
	cudaDeviceCanAccessPeer	151
	cudaDeviceDisablePeerAccess	152
	cudaDeviceEnablePeerAccess	152
4.	12. OpenGL Interoperability	.153
	cudaGLDeviceList	.153
	cudaGLGetDevices	154
	cudaGraphicsGLRegisterBuffer	155
	cudaGraphicsGLRegisterImage	156
	cudaWGLGetDevice	157
4.	13. OpenGL Interoperability [DEPRECATED]	158
	cudaGLMapFlags	
	cudaGLMapBufferObject	
	cudaGLMapBufferObjectAsync	
	cudaGLRegisterBufferObject	
	cudaGLSetBufferObjectMapFlags	
	cudaGLSetGLDevice.	
	cudaGLUnmapBufferObject	
	cudaGLUnmapBufferObjectAsync	
	cudaGLUnregisterBufferObject	
4	14. Direct3D 9 Interoperability	
т.	cudaD3D9DeviceList	
	cudaD3D9GetDevice	
	cudaD3D9GetDevices	
	cudaD3D9GetDevices	
	cudaD3D9SetDirect3DDevice	
	cudaGraphicsD3D9RegisterResource	168

4.	15. Direct3D 9 Interoperability [DEPRECATED]	170
	cudaD3D9MapFlags	170
	cudaD3D9RegisterFlags	171
	cudaD3D9MapResources	171
	cudaD3D9RegisterResource	172
	cudaD3D9ResourceGetMappedArray	174
	cudaD3D9ResourceGetMappedPitch	175
	cudaD3D9ResourceGetMappedPointer	.176
	cudaD3D9ResourceGetMappedSize	177
	cudaD3D9ResourceGetSurfaceDimensions	178
	cudaD3D9ResourceSetMapFlags	180
	cudaD3D9UnmapResources	.181
	cudaD3D9UnregisterResource	182
4.	16. Direct3D 10 Interoperability	182
	cudaD3D10DeviceList	182
	cudaD3D10GetDevice	183
	cudaD3D10GetDevices	183
	cudaGraphicsD3D10RegisterResource	185
4.	17. Direct3D 10 Interoperability [DEPRECATED]	187
	cudaD3D10MapFlags	.187
	cudaD3D10RegisterFlags	.187
	cudaD3D10GetDirect3DDevice	
	cudaD3D10MapResources	188
	cudaD3D10RegisterResource	189
	cudaD3D10ResourceGetMappedArray	
	cudaD3D10ResourceGetMappedPitch	191
	cudaD3D10ResourceGetMappedPointer	193
	cudaD3D10ResourceGetMappedSize	194
	cudaD3D10ResourceGetSurfaceDimensions	.195
	cudaD3D10ResourceSetMapFlags	
	cudaD3D10SetDirect3DDevice	197
	cudaD3D10UnmapResources	
	cudaD3D10UnregisterResource	
4.	18. Direct3D 11 Interoperability	
	cudaD3D11DeviceList	199
	cudaD3D11GetDevice	
	cudaD3D11GetDevices	200
	cudaGraphicsD3D11RegisterResource	
4	19. Direct3D 11 Interoperability [DEPRECATED]	
	cudaD3D11GetDirect3DDevice	
	cudaD3D11SetDirect3DDevice	
4.	20. VDPAU Interoperability	
	cudaGraphicsVDPAURegisterOutputSurface	205

cudaGraphicsVDPAURegisterVideoSurface	206
cudaVDPAUGetDevice	207
cudaVDPAUSetVDPAUDevice	208
4.21. EGL Interoperability	209
cudaEGLStreamConsumerAcquireFrame	209
cudaEGLStreamConsumerConnect	210
cudaEGLStreamConsumerConnectWithFlags	210
cudaEGLStreamConsumerReleaseFrame	211
cudaEGLStreamProducerConnect	212
cudaEGLStreamProducerDisconnect	213
cudaEGLStreamProducerPresentFrame	213
cudaEGLStreamProducerReturnFrame	214
cudaGraphicsEGLRegisterImage	215
cudaGraphicsResourceGetMappedEglFrame	216
4.22. Graphics Interoperability	217
cudaGraphicsMapResources	217
cudaGraphicsResourceGetMappedMipmappedArray	218
cudaGraphicsResourceGetMappedPointer	219
cudaGraphicsResourceSetMapFlags	220
cudaGraphicsSubResourceGetMappedArray	221
cudaGraphicsUnmapResources	222
cudaGraphicsUnregisterResource	223
4.23. Texture Reference Management	223
cudaBindTexture	224
cudaBindTexture2D	225
cudaBindTextureToArray	226
cudaBindTextureToMipmappedArray	227
cudaCreateChannelDesc	228
cudaGetChannelDesc	229
cudaGetTextureAlignmentOffset	229
cudaGetTextureReference	230
cudaUnbindTexture	231
4.24. Surface Reference Management	231
cudaBindSurfaceToArray	232
cudaGetSurfaceReference	232
4.25. Texture Object Management	233
cudaCreateTextureObject	233
cudaDestroyTextureObject	238
cudaGetTextureObjectResourceDesc	239
cudaGetTextureObjectResourceViewDesc	239
cudaGetTextureObjectTextureDesc	240
4.26. Surface Object Management	240
cudaCreateSurfaceObject	241

	cudaDestroySurfaceObject	.241
	cudaGetSurfaceObjectResourceDesc	242
4.	27. Version Management	242
	cudaDriverGetVersion	.242
	cudaRuntimeGetVersion	243
4.	28. C++ API Routines	244
	cudaOccupancyB2DHelper	244
	cudaBindSurfaceToArray	.244
	cudaBindSurfaceToArray	.245
	cudaBindTexture	. 245
	cudaBindTexture	. 246
	cudaBindTexture2D	.247
	cudaBindTexture2D	.249
	cudaBindTextureToArray	250
	cudaBindTextureToArray	251
	cudaBindTextureToMipmappedArray	.252
	cudaBindTextureToMipmappedArray	.253
	cudaCreateChannelDesc	.254
	cudaEventCreate	254
	cudaFuncGetAttributes	. 255
	cudaFuncSetCacheConfig	256
	cudaGetSymbolAddress	. 257
	cudaGetSymbolSize	258
	cudaGetTextureAlignmentOffset	. 258
	cudaLaunch	.259
	cudaLaunchKernel	. 260
	cudaMallocHost	261
	cudaMallocManaged	. 263
	cudaMemcpyFromSymbol	265
	cudaMemcpyFromSymbolAsync	.266
	cudaMemcpyToSymbol	267
	cudaMemcpyToSymbolAsync	268
	${\it cuda} Occupancy {\it MaxActiveBlocksPerMultiprocessor}$	270
	cuda Occupancy Max Active Blocks Per Multiprocessor With Flags	. 271
	cudaOccupancyMaxPotentialBlockSize	272
	cudaOccupancyMaxPotentialBlockSizeVariableSMem	273
	cuda Occupancy Max Potential Block Size Variable SMem With Flags	274
	cuda Occupancy Max Potential Block Size With Flags	276
	cudaSetupArgument	278
	cudaStreamAttachMemAsync	278
	cudaUnbindTexture	280
4.	29. Interactions with the CUDA Driver API	281
4	30. Profiler Control	283

	cudaProfilerInitialize	283
	cudaProfilerStart	284
	cudaProfilerStop	284
4.	31. Data types used by CUDA Runtime	285
	cudaChannelFormatDesc	286
	cudaDeviceProp	286
	cudaEglFrame	286
	cudaEglPlaneDesc	286
	cudaExtent	286
	cudaFuncAttributes	286
	cudalpcEventHandle_t	286
	cudalpcMemHandle_t	286
	cudaMemcpy3DParms	286
	cudaMemcpy3DPeerParms	.286
	cudaPitchedPtr	286
	cudaPointerAttributes	286
	cudaPos	286
	cudaResourceDesc	286
	cudaResourceViewDesc	286
	cudaTextureDesc	286
	surfaceReference	286
	textureReference	.286
	cudaChannelFormatKind	287
	cudaComputeMode	287
	cudaDeviceAttr	287
	cudaDeviceP2PAttr	292
	cudaEglColorFormat	292
	cudaEglFrameType	
	cudaEglResourceLocationFlags	
	cudaError	293
	cudaFuncCache	300
	cudaGraphicsCubeFace	301
	cudaGraphicsMapFlags	.301
	cudaGraphicsRegisterFlags	301
	cudaLimit	302
	cudaMemcpyKind	302
	cudaMemoryAdvise	303
	cudaMemoryType	
	cudaMemRangeAttribute	
	cudaOutputMode	
	cudaResourceType	
	cudaResourceViewFormat	
	cudaSharedMemConfig	

cudaSurfaceBoundaryMode	306
cudaSurfaceFormatMode	306
cudaTextureAddressMode	307
cudaTextureFilterMode	307
cudaTextureReadMode	307
cudaArray_const_t	307
cudaArray_t	308
cudaEglStreamConnection	308
cudaError_t	308
cudaEvent_t	308
cudaGraphicsResource_t	308
cudaMipmappedArray_const_t	308
cudaMipmappedArray_t	308
cudaOutputMode_t	308
cudaStream_t	308
cudaSurfaceObject_t	308
cudaTextureObject_t	309
cudaUUID_t	309
CUDA_EGL_MAX_PLANES	309
CUDA_IPC_HANDLE_SIZE	309
cudaArrayCubemap	309
cudaArrayDefault	309
cudaArrayLayered	309
cudaArraySurfaceLoadStore	309
cudaArrayTextureGather	309
cudaCpuDeviceId	309
cudaDeviceBlockingSync	310
cudaDeviceLmemResizeToMax	310
cudaDeviceMapHost	310
cudaDeviceMask	310
cudaDevicePropDontCare	310
cudaDeviceScheduleAuto	
cudaDeviceScheduleBlockingSync	310
cudaDeviceScheduleMask	310
cudaDeviceScheduleSpin	310
cudaDeviceScheduleYield	310
cudaEventBlockingSync	311
cudaEventDefault	311
cudaEventDisableTiming	311
cuda Event Interprocess	311
cudaHostAllocDefault	311
cudaHostAllocMapped	311
cudaHostAllocPortable	311

cudaHostAllocWriteCo	Combined	311
cudaHostRegisterDefa	ault	311
cudaHostRegisterIoMe	emory	311
cudaHostRegisterMap	pped	311
cudaHostRegisterPort	table	312
cudalnvalidDeviceId		312
cudalpcMemLazyEnab	blePeerAccessblePeerAccess	312
cudaMemAttachGloba	al	312
cudaMemAttachHost.		312
cudaMemAttachSingle	e	312
cudaOccupancyDefau	ult	312
cudaOccupancyDisabl	oleCachingOverride	312
cudaPeerAccessDefau	ult	312
cudaStreamDefault		312
cudaStreamLegacy		312
cudaStreamNonBlocki	king	313
cudaStreamPerThread	ıd	313
Chapter 5. Data Structur	res	314
cudaOccupancyB2DHe	elper	314
cudaChannelFormatDesc	SC	315
f		315
W		315
y		315
cudaDeviceProp		315
asyncEngineCount		315
canMapHostMemory		315
clockRate		315
computeMode		316
concurrentKernels		316
concurrentManagedAd	Access	316
deviceOverlap		316
ECCEnabled		316
globalL1CacheSuppor	rted	316
hostNativeAtomicSup	pported	316
integrated		316
isMultiGpuBoard		316
kernelExecTimeoutEn	nabled	316
l2CacheSize		316
localL1CacheSupporte	ed	317
major		317
managedMemory		317

maxGridSize	317
maxSurface1D	317
maxSurface1DLayered	317
maxSurface2D	317
maxSurface2DLayered	317
maxSurface3D	317
maxSurfaceCubemap	317
maxSurfaceCubemapLayered	317
maxTexture1D	318
maxTexture1DLayered	318
maxTexture1DLinear	318
maxTexture1DMipmap	318
maxTexture2D	318
maxTexture2DGather	318
maxTexture2DLayered	318
maxTexture2DLinear	318
maxTexture2DMipmap	318
maxTexture3D	318
maxTexture3DAlt	318
maxTextureCubemap	319
maxTextureCubemapLayered	319
maxThreadsDim	319
maxThreadsPerBlock	319
maxThreadsPerMultiProcessor	319
memoryBusWidth	319
memoryClockRate	319
memPitch	319
minor	319
multiGpuBoardGroupID	319
multiProcessorCount	319
name	320
pageableMemoryAccess	320
pciBusID	320
pciDeviceID	320
pciDomainID	320
regsPerBlock	320
regsPerMultiprocessor	320
sharedMemPerBlock	320
sharedMemPerMultiprocessor	320
singleToDoublePrecisionPerfRatio	320
streamPrioritiesSupported	320
surfaceAlignment	321
tccDriver	321

	textureAlignment	
	texturePitchAlignment	
	totalConstMem	
	totalGlobalMem	
	unifiedAddressing	
	warpSize	321
Cι	ıdaEglFrame	
	eglColorFormat	
	frameType	
	pArray	322
	planeCount	322
	planeDesc	. 322
	pPitch	322
cι	ıdaEglPlaneDesc	322
	channelDesc	. 322
	depth	323
	height	323
	numChannels	. 323
	pitch	. 323
	reserved	323
	width	323
cι	ıdaExtent	323
	depth	323
	height	323
	width	
cι	ıdaFuncAttributes	
	binaryVersion	
	cacheModeCA	
	constSizeBytes	
	localSizeBytes	
	maxThreadsPerBlock	
	numRegs	
	ptxVersion	
	sharedSizeBytes	
CI	idalpcEventHandle_t	
	ıdalpcMemHandle_t	
	IdaMemcpy3DParms	
CC	dstArray	
	dstPos.	
	dstPtr	
	extent	
	kind	
	srcArray	. 325 325
	NI ALIGV	1/7

srcPos	226
srcPtr	
cudaMemcpy3DPeerParms	
dstArray	
dstDevice	
dstPos	
dstPtr	
extent	
srcArray	
srcDevice	
srcPos	
srcPtr	
cudaPitchedPtr	
pitch	
ptr	
xsize	
ysize	327
cudaPointerAttributes	327
device	327
devicePointer	328
hostPointer	328
isManaged	328
memoryType	328
cudaPos	328
X	328
у	328
Z	
cudaResourceDesc	329
array	
desc	
devPtr	
height	
mipmap	
pitchInBytes	
resType	
sizeInBytes	
width	
cudaResourceViewDesc	
depth	
firstLayer	
firstMipmapLevel	
format	
height	330

lastLayer	330
lastMipmapLevel	330
width	330
cudaTextureDesc	330
addressMode	331
borderColor	331
filterModefilterMode	331
maxAnisotropy	331
maxMipmapLevelClamp	331
minMipmapLevelClamp	331
mipmapFilterMode	331
mipmapLevelBias	331
normalizedCoords	331
readMode	331
sRGB	332
surfaceReference	332
channelDesc	332
textureReference	332
addressMode	332
channelDesc	332
filterModefilterMode	332
maxAnisotropy	332
maxMipmapLevelClamp	332
minMipmapLevelClamp	333
mipmapFilterMode	333
mipmapLevelBias	333
normalized	333
sRGB	333
Chapter 6. Data Fields	334
Chapter 7. Deprecated List	343

# Chapter 1. DIFFERENCE BETWEEN THE DRIVER AND RUNTIME APIS

The driver and runtime APIs are very similar and can for the most part be used interchangeably. However, there are some key differences worth noting between the two.

#### Complexity vs. control

The runtime API eases device code management by providing implicit initialization, context management, and module management. This leads to simpler code, but it also lacks the level of control that the driver API has.

In comparison, the driver API offers more fine-grained control, especially over contexts and module loading. Kernel launches are much more complex to implement, as the execution configuration and kernel parameters must be specified with explicit function calls. However, unlike the runtime, where all the kernels are automatically loaded during initialization and stay loaded for as long as the program runs, with the driver API it is possible to only keep the modules that are currently needed loaded, or even dynamically reload modules. The driver API is also language-independent as it only deals with cubin objects.

#### Context management

Context management can be done through the driver API, but is not exposed in the runtime API. Instead, the runtime API decides itself which context to use for a thread: if a context has been made current to the calling thread through the driver API, the runtime will use that, but if there is no such context, it uses a "primary context." Primary contexts are created as needed, one per device per process, are reference-counted, and are then destroyed when there are no more references to them. Within one process, all users of the runtime API will share the primary context, unless a context has been made current to each thread. The context that the runtime uses, i.e, either the current

context or primary context, can be synchronized with **cudaDeviceSynchronize()**, and destroyed with **cudaDeviceReset()**.

Using the runtime API with primary contexts has its tradeoffs, however. It can cause trouble for users writing plug-ins for larger software packages, for example, because if all plug-ins run in the same process, they will all share a context but will likely have no way to communicate with each other. So, if one of them calls <code>cudaDeviceReset()</code> after finishing all its CUDA work, the other plug-ins will fail because the context they were using was destroyed without their knowledge. To avoid this issue, CUDA clients can use the driver API to create and set the current context, and then use the runtime API to work with it. However, contexts may consume significant resources, such as device memory, extra host threads, and performance costs of context switching on the device. This runtime-driver context sharing is important when using the driver API in conjunction with libraries built on the runtime API, such as cuBLAS or cuFFT.

# Chapter 2. API SYNCHRONIZATION BEHAVIOR

The API provides memcpy/memset functions in both synchronous and asynchronous forms, the latter having an "Async" suffix. This is a misnomer as each function may exhibit synchronous or asynchronous behavior depending on the arguments passed to the function. In the reference documentation, each memcpy function is categorized as synchronous or asynchronous, corresponding to the definitions below.

#### Memcpy

The API provides memcpy/memset functions in both synchronous and asynchronous forms, the latter having an "Async" suffix. This is a misnomer as each function may exhibit synchronous or asynchronous behavior depending on the arguments passed to the function. In the reference documentation, each memcpy function is categorized as synchronous or asynchronous, corresponding to the definitions below.

#### **Synchronous**

- 1. All transfers involving Unified Memory regions are fully synchronous with respect to the host.
- For transfers from pageable host memory to device memory, a stream sync is performed before the copy is initiated. The function will return once the pageable buffer has been copied to the staging memory for DMA transfer to device memory, but the DMA to final destination may not have completed.
- 3. For transfers from pinned host memory to device memory, the function is synchronous with respect to the host.
- 4. For transfers from device to either pageable or pinned host memory, the function returns only once the copy has completed.
- 5. For transfers from device memory to device memory, no host-side synchronization is performed.

6. For transfers from any host memory to any host memory, the function is fully synchronous with respect to the host.

#### Asynchronous

- 1. For transfers from device memory to pageable host memory, the function will return only once the copy has completed.
- 2. For transfers from any host memory to any host memory, the function is fully synchronous with respect to the host.
- 3. For all other transfers, the function is fully asynchronous. If pageable memory must first be staged to pinned memory, this will be handled asynchronously with a worker thread.

#### Memset

The synchronous memset functions are asynchronous with respect to the host except when the target is pinned host memory or a Unified Memory region, in which case they are fully synchronous. The Async versions are always asynchronous with respect to the host.

#### **Kernel Launches**

Kernel launches are asynchronous with respect to the host. Details of concurrent kernel execution and data transfers can be found in the CUDA Programmers Guide.

# Chapter 3. STREAM SYNCHRONIZATION BEHAVIOR

#### Default stream

The default stream, used when **0** is passed as a **cudaStream\_t** or by APIs that operate on a stream implicitly, can be configured to have either legacy or per-thread synchronization behavior as described below.

The behavior can be controlled per compilation unit with the --default-stream nvcc option. Alternatively, per-thread behavior can be enabled by defining the CUDA\_API\_PER\_THREAD\_DEFAULT\_STREAM macro before including any CUDA headers. Either way, the CUDA\_API\_PER\_THREAD\_DEFAULT\_STREAM macro will be defined in compilation units using per-thread synchronization behavior.

#### Legacy default stream

The legacy default stream is an implicit stream which synchronizes with all other streams in the same CUcontext except for non-blocking streams, described below. (For applications using the runtime APIs only, there will be one context per device.) When an action is taken in the legacy stream such as a kernel launch or cudaStreamWaitEvent(), the legacy stream first waits on all blocking streams, the action is queued in the legacy stream, and then all blocking streams wait on the legacy stream.

For example, the following code launches a kernel  $k_1$  in stream s, then  $k_2$  in the legacy stream, then  $k_3$  in stream s:

```
k_1<<<1, 1, 0, s>>>();
k_2<<<1, 1>>>();
k_3<<<1, 1, 0, s>>>();
```

The resulting behavior is that  $k_2$  will block on  $k_1$  and  $k_3$  will block on  $k_2$ .

Non-blocking streams which do not synchronize with the legacy stream can be created using the **cudaStreamNonBlocking** flag with the stream creation APIs.

The legacy default stream can be used explicitly with the CUstream (cudaStream\_t) handle CU\_STREAM\_LEGACY (cudaStreamLegacy).

#### Per-thread default stream

The per-thread default stream is an implicit stream local to both the thread and the CUcontext, and which does not synchronize with other streams (just like explcitly created streams). The per-thread default stream is not a non-blocking stream and will synchronize with the legacy default stream if both are used in a program.

The per-thread default stream can be used explicitly with the CUstream (cudaStream\_t) handle CU\_STREAM\_PER\_THREAD (cudaStreamPerThread).

# Chapter 4. MODULES

#### Here is a list of all modules:

- Device Management
- Thread Management [DEPRECATED]
- Error Handling
- Stream Management
- Event Management
- Execution Control
- Occupancy
- Execution Control [DEPRECATED]
- Memory Management
- Unified Addressing
- Peer Device Memory Access
- OpenGL Interoperability
- OpenGL Interoperability [DEPRECATED]
- Direct3D 9 Interoperability
- Direct3D 9 Interoperability [DEPRECATED]
- Direct3D 10 Interoperability
- ► Direct3D 10 Interoperability [DEPRECATED]
- ► Direct3D 11 Interoperability
- Direct3D 11 Interoperability [DEPRECATED]
- VDPAU Interoperability
- ► EGL Interoperability
- Graphics Interoperability
- ► Texture Reference Management
- Surface Reference Management
- Texture Object Management
- Surface Object Management

- Version Management
- C++ API Routines
- Interactions with the CUDA Driver API
- ► Profiler Control
- Data types used by CUDA Runtime

### 4.1. Device Management

#### CUDART\_DEVICE

This section describes the device management functions of the CUDA runtime application programming interface.

### \_\_host\_\_cudaError\_t cudaChooseDevice (int \*device, const cudaDeviceProp \*prop)

Select compute-device which best matches criteria.

#### **Parameters**

#### device

- Device with best match

#### prop

- Desired device properties

#### Returns

cudaSuccess, cudaErrorInvalidValue

#### Description

Returns in \*device the device which has properties that best match \*prop.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGetDeviceCount, cudaGetDevice, cudaSetDevice, cudaGetDeviceProperties

## \_\_host\_\_\_\_device\_\_cudaError\_t cudaDeviceGetAttribute (int \*value, cudaDeviceAttr attr, int device)

Returns information about the device.

#### **Parameters**

#### value

- Returned device attribute value

#### attr

- Device attribute to query

#### device

- Device number to query

#### **Returns**

cudaSuccess, cudaErrorInvalidDevice, cudaErrorInvalidValue

#### Description

Returns in \*value the integer value of the attribute attr on device device. The supported attributes are:

- cudaDevAttrMaxThreadsPerBlock: Maximum number of threads per block;
- cudaDevAttrMaxBlockDimX: Maximum x-dimension of a block;
- cudaDevAttrMaxBlockDimY: Maximum y-dimension of a block;
- cudaDevAttrMaxBlockDimZ: Maximum z-dimension of a block;
- cudaDevAttrMaxGridDimX: Maximum x-dimension of a grid;
- cudaDevAttrMaxGridDimY: Maximum y-dimension of a grid;
- cudaDevAttrMaxGridDimZ: Maximum z-dimension of a grid;
- cudaDevAttrMaxSharedMemoryPerBlock: Maximum amount of shared memory available to a thread block in bytes;
- cudaDevAttrTotalConstantMemory: Memory available on device for \_\_constant\_\_ variables in a CUDA C kernel in bytes;
- cudaDevAttrWarpSize: Warp size in threads;
- cudaDevAttrMaxPitch: Maximum pitch in bytes allowed by the memory copy functions that involve memory regions allocated through cudaMallocPitch();
- cudaDevAttrMaxTexture1DWidth: Maximum 1D texture width;
- cudaDevAttrMaxTexture1DLinearWidth: Maximum width for a 1D texture bound to linear memory;
- cudaDevAttrMaxTexture1DMipmappedWidth: Maximum mipmapped 1D texture width;
- cudaDevAttrMaxTexture2DWidth: Maximum 2D texture width;
- cudaDevAttrMaxTexture2DHeight: Maximum 2D texture height;

- cudaDevAttrMaxTexture2DLinearWidth: Maximum width for a 2D texture bound to linear memory;
- cudaDevAttrMaxTexture2DLinearHeight: Maximum height for a 2D texture bound to linear memory;
- cudaDevAttrMaxTexture2DLinearPitch: Maximum pitch in bytes for a 2D texture bound to linear memory;
- cudaDevAttrMaxTexture2DMipmappedWidth: Maximum mipmapped 2D texture width;
- cudaDevAttrMaxTexture2DMipmappedHeight: Maximum mipmapped 2D texture height;
- cudaDevAttrMaxTexture3DWidth: Maximum 3D texture width;
- cudaDevAttrMaxTexture3DHeight: Maximum 3D texture height;
- cudaDevAttrMaxTexture3DDepth: Maximum 3D texture depth;
- cudaDevAttrMaxTexture3DWidthAlt: Alternate maximum 3D texture width, 0 if no alternate maximum 3D texture size is supported;
- cudaDevAttrMaxTexture3DHeightAlt: Alternate maximum 3D texture height, 0 if no alternate maximum 3D texture size is supported;
- cudaDevAttrMaxTexture3DDepthAlt: Alternate maximum 3D texture depth, 0 if no alternate maximum 3D texture size is supported;
- cudaDevAttrMaxTextureCubemapWidth: Maximum cubemap texture width or height;
- cudaDevAttrMaxTexture1DLayeredWidth: Maximum 1D layered texture width;
- cudaDevAttrMaxTexture1DLayeredLayers: Maximum layers in a 1D layered texture;
- cudaDevAttrMaxTexture2DLayeredWidth: Maximum 2D layered texture width;
- cudaDevAttrMaxTexture2DLayeredHeight: Maximum 2D layered texture height;
- cudaDevAttrMaxTexture2DLayeredLayers: Maximum layers in a 2D layered texture;
- cudaDevAttrMaxTextureCubemapLayeredWidth: Maximum cubemap layered texture width or height;
- cudaDevAttrMaxTextureCubemapLayeredLayers: Maximum layers in a cubemap layered texture;
- cudaDevAttrMaxSurface1DWidth: Maximum 1D surface width;
- cudaDevAttrMaxSurface2DWidth: Maximum 2D surface width;
- cudaDevAttrMaxSurface2DHeight: Maximum 2D surface height;
- cudaDevAttrMaxSurface3DWidth: Maximum 3D surface width;
- cudaDevAttrMaxSurface3DHeight: Maximum 3D surface height;
- cudaDevAttrMaxSurface3DDepth: Maximum 3D surface depth;
- cudaDevAttrMaxSurface1DLayeredWidth: Maximum 1D layered surface width;
- cudaDevAttrMaxSurface1DLayeredLayers: Maximum layers in a 1D layered surface;

- cudaDevAttrMaxSurface2DLayeredWidth: Maximum 2D layered surface width;
- cudaDevAttrMaxSurface2DLayeredHeight: Maximum 2D layered surface height;
- cudaDevAttrMaxSurface2DLayeredLayers: Maximum layers in a 2D layered surface;
- cudaDevAttrMaxSurfaceCubemapWidth: Maximum cubemap surface width;
- cudaDevAttrMaxSurfaceCubemapLayeredWidth: Maximum cubemap layered surface width;
- cudaDevAttrMaxSurfaceCubemapLayeredLayers: Maximum layers in a cubemap layered surface;
- cudaDevAttrMaxRegistersPerBlock: Maximum number of 32-bit registers available to a thread block;
- cudaDevAttrClockRate: Peak clock frequency in kilohertz;
- cudaDevAttrTextureAlignment: Alignment requirement; texture base addresses aligned to textureAlign bytes do not need an offset applied to texture fetches;
- cudaDevAttrTexturePitchAlignment: Pitch alignment requirement for 2D texture references bound to pitched memory;
- cudaDevAttrGpuOverlap: 1 if the device can concurrently copy memory between host and device while executing a kernel, or 0 if not;
- cudaDevAttrMultiProcessorCount: Number of multiprocessors on the device;
- cudaDevAttrKernelExecTimeout: 1 if there is a run time limit for kernels executed on the device, or 0 if not;
- cudaDevAttrIntegrated: 1 if the device is integrated with the memory subsystem, or 0 if not;
- cudaDevAttrCanMapHostMemory: 1 if the device can map host memory into the CUDA address space, or 0 if not;
- cudaDevAttrComputeMode: Compute mode is the compute mode that the device is currently in. Available modes are as follows:
  - cudaComputeModeDefault: Default mode Device is not restricted and multiple threads can use cudaSetDevice() with this device.
  - cudaComputeModeExclusive: Compute-exclusive mode Only one thread will be able to use cudaSetDevice() with this device.
  - cudaComputeModeProhibited: Compute-prohibited mode No threads can use cudaSetDevice() with this device.
  - cudaComputeModeExclusiveProcess: Compute-exclusive-process mode Many threads in one process will be able to use cudaSetDevice() with this device.
- cudaDevAttrConcurrentKernels: 1 if the device supports executing multiple kernels within the same context simultaneously, or 0 if not. It is not guaranteed that multiple kernels will be resident on the device concurrently so this feature should not be relied upon for correctness;
- cudaDevAttrEccEnabled: 1 if error correction is enabled on the device, 0 if error correction is disabled or not supported by the device;

- cudaDevAttrPciBusId: PCI bus identifier of the device;
- cudaDevAttrPciDeviceId: PCI device (also known as slot) identifier of the device;
- cudaDevAttrTccDriver: 1 if the device is using a TCC driver. TCC is only available on Tesla hardware running Windows Vista or later;
- cudaDevAttrMemoryClockRate: Peak memory clock frequency in kilohertz;
- cudaDevAttrGlobalMemoryBusWidth: Global memory bus width in bits;
- cudaDevAttrL2CacheSize: Size of L2 cache in bytes. 0 if the device doesn't have L2 cache;
- cudaDevAttrMaxThreadsPerMultiProcessor: Maximum resident threads per multiprocessor;
- cudaDevAttrUnifiedAddressing: 1 if the device shares a unified address space with the host, or 0 if not;
- cudaDevAttrComputeCapabilityMajor: Major compute capability version number;
- cudaDevAttrComputeCapabilityMinor: Minor compute capability version number;
- cudaDevAttrStreamPrioritiesSupported: 1 if the device supports stream priorities, or 0 if not;
- cudaDevAttrGlobalL1CacheSupported: 1 if device supports caching globals in L1 cache, 0 if not;
- cudaDevAttrGlobalL1CacheSupported: 1 if device supports caching locals in L1 cache, 0 if not;
- cudaDevAttrMaxSharedMemoryPerMultiprocessor: Maximum amount of shared memory available to a multiprocessor in bytes; this amount is shared by all thread blocks simultaneously resident on a multiprocessor;
- ► cudaDevAttrMaxRegistersPerMultiprocessor: Maximum number of 32-bit registers available to a multiprocessor; this number is shared by all thread blocks simultaneously resident on a multiprocessor;
- cudaDevAttrManagedMemSupported: 1 if device supports allocating managed memory, 0 if not;
- cudaDevAttrIsMultiGpuBoard: 1 if device is on a multi-GPU board, 0 if not;
- cudaDevAttrMultiGpuBoardGroupID: Unique identifier for a group of devices on the same multi-GPU board;
- cudaDevAttrHostNativeAtomicSupported: 1 if the link between the device and the host supports native atomic operations;
- cudaDevAttrSingleToDoublePrecisionPerfRatio: Ratio of single precision performance (in floating-point operations per second) to double precision performance;
- cudaDevAttrPageableMemoryAccess: 1 if the device supports coherently accessing pageable memory without calling cudaHostRegister on it, and 0 otherwise.
- cudaDevAttrConcurrentManagedAccess: 1 if the device can coherently access managed memory concurrently with the CPU, and 0 otherwise.

- cudaDevAttrComputePreemptionSupported: 1 if the device supports Compute Preemption, 0 if not.
- cudaDevAttrCanUseHostPointerForRegisteredMem: 1 if the device can access host registered memory at the same virtual address as the CPU, and 0 otherwise.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cuda Get Device Count, cuda Get Device, cuda Set Device, cuda Get Device Properties

### \_\_host\_\_cudaError\_t cudaDeviceGetByPClBusId (int \*device, const char \*pciBusId)

Returns a handle to a compute device.

#### **Parameters**

#### device

- Returned device ordinal

#### pciBusId

- String in one of the following forms: [domain]:[bus]:[device].[function] [domain]: [bus]:[device] [bus]:[device].[function] where domain, bus, device, and function are all hexadecimal values

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevice

#### Description

Returns in \*device a device ordinal given a PCI bus ID string.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaDeviceGetPCIBusId

# \_\_host\_\_\_\_device\_\_cudaError\_t cudaDeviceGetCacheConfig (cudaFuncCache \*pCacheConfig)

Returns the preferred cache configuration for the current device.

#### **Parameters**

#### pCacheConfig

- Returned cache configuration

#### Returns

cudaSuccess, cudaErrorInitializationError

#### Description

On devices where the L1 cache and shared memory use the same hardware resources, this returns through pCacheConfig the preferred cache configuration for the current device. This is only a preference. The runtime will use the requested configuration if possible, but it is free to choose a different configuration if required to execute functions.

This will return a pCacheConfig of cudaFuncCachePreferNone on devices where the size of the L1 cache and shared memory are fixed.

The supported cache configurations are:

- cudaFuncCachePreferNone: no preference for shared memory or L1 (default)
- cudaFuncCachePreferShared: prefer larger shared memory and smaller L1 cache
- cudaFuncCachePreferL1: prefer larger L1 cache and smaller shared memory
- cudaFuncCachePreferEqual: prefer equal size L1 cache and shared memory



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaDeviceSetCacheConfig, cudaFuncSetCacheConfig ( C API), cudaFuncSetCacheConfig ( C++ API)

## \_\_host\_\_\_\_device\_\_cudaError\_t cudaDeviceGetLimit (size\_t \*pValue, cudaLimit limit)

Returns resource limits.

#### **Parameters**

#### pValue

- Returned size of the limit

#### limit

- Limit to query

#### Returns

cudaSuccess, cudaErrorUnsupportedLimit, cudaErrorInvalidValue

#### Description

Returns in \*pValue the current size of limit. The supported cudaLimit values are:

- cudaLimitStackSize: stack size in bytes of each GPU thread;
- cudaLimitPrintfFifoSize: size in bytes of the shared FIFO used by the printf() and fprintf() device system calls.
- cudaLimitMallocHeapSize: size in bytes of the heap used by the malloc() and free() device system calls;
- cudaLimitDevRuntimeSyncDepth: maximum grid depth at which a thread can isssue the device runtime call cudaDeviceSynchronize() to wait on child grid launches to complete.
- cudaLimitDevRuntimePendingLaunchCount: maximum number of outstanding device runtime launches.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaDeviceSetLimit

### \_\_host\_\_cudaError\_t cudaDeviceGetP2PAttribute (int \*value, cudaDeviceP2PAttr attr, int srcDevice, int dstDevice)

Oueries attributes of the link between two devices.

#### **Parameters**

#### value

- Returned value of the requested attribute

#### attr

#### srcDevice

- The source device of the target link.

#### dstDevice

- The destination device of the target link.

#### **Returns**

cudaSuccess, cudaErrorInvalidDevice, cudaErrorInvalidValue

#### Description

Returns in \*value the value of the requested attribute attrib of the link between srcDevice and dstDevice. The supported attributes are:

- ► CudaDevP2PAttrPerformanceRank: A relative value indicating the performance of the link between two devices. Lower value means better performance (0 being the value used for most performant link).
- ► CudaDevP2PAttrAccessSupported: 1 if peer access is enabled.
- CudaDevP2PAttrNativeAtomicSupported: 1 if native atomic operations over the link are supported.

Returns cudaErrorInvalidDevice if srcDevice or dstDevice are not valid or if they represent the same device.

Returns cudaErrorInvalidValue if attrib is not valid or if value is a null pointer.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaCtxEnablePeerAccess, cudaCtxDisablePeerAccess, cudaCtxCanAccessPeer

### \_\_host\_\_cudaError\_t cudaDeviceGetPCIBusId (char \*pciBusId, int len, int device)

Returns a PCI Bus Id string for the device.

#### **Parameters**

#### pciBusId

- Returned identifier string for the device in the following format [domain]:[bus]: [device].[function] where domain, bus, device, and function are all hexadecimal values. pciBusId should be large enough to store 13 characters including the NULL-terminator.

#### len

- Maximum length of string to store in name

#### device

- Device to get identifier string for

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevice

#### Description

Returns an ASCII string identifying the device dev in the NULL-terminated string pointed to by pciBusId. len specifies the maximum length of the string that may be returned.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaDeviceGetByPCIBusId

\_\_host\_\_\_\_device\_\_cudaError\_t
cudaDeviceGetSharedMemConfig
(cudaSharedMemConfig \*pConfig)

Returns the shared memory configuration for the current device.

#### **Parameters**

#### pConfig

- Returned cache configuration

#### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInitializationError

#### Description

This function will return in pConfig the current size of shared memory banks on the current device. On devices with configurable shared memory banks, cudaDeviceSetSharedMemConfig can be used to change this setting, so that all subsequent kernel launches will by default use the new bank size. When cudaDeviceGetSharedMemConfig is called on devices without configurable shared memory, it will return the fixed bank size of the hardware.

The returned bank configurations can be either:

- cudaSharedMemBankSizeFourByte shared memory bank width is four bytes.
- cudaSharedMemBankSizeEightByte shared memory bank width is eight bytes.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaDeviceSetCacheConfig, cudaDeviceGetCacheConfig, cudaDeviceSetSharedMemConfig, cudaFuncSetCacheConfig

# \_\_host\_\_cudaError\_t cudaDeviceGetStreamPriorityRange (int \*leastPriority, int \*greatestPriority)

Returns numerical values that correspond to the least and greatest stream priorities.

#### **Parameters**

#### leastPriority

- Pointer to an int in which the numerical value for least stream priority is returned **greatestPriority** 
  - Pointer to an int in which the numerical value for greatest stream priority is returned

#### **Returns**

cudaSuccess, cudaErrorInvalidValue

#### Description

Returns in \*leastPriority and \*greatestPriority the numerical values that correspond to the least and greatest stream priorities respectively. Stream priorities follow a convention where lower numbers imply greater priorities. The range of meaningful stream priorities is given by [\*greatestPriority, \*leastPriority]. If the user attempts to create a stream with a priority value that is outside the the meaningful range as specified by this API, the priority is automatically clamped down or up to either \*leastPriority or \*greatestPriority respectively. See cudaStreamCreateWithPriority for details on creating a priority stream. A NULL may be passed in for \*leastPriority or \*greatestPriority if the value is not desired.

This function will return '0' in both \*leastPriority and \*greatestPriority if the current context's device does not support stream priorities (see cudaDeviceGetAttribute).



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaStreamCreateWithPriority, cudaStreamGetPriority

### \_\_host\_\_cudaError\_t cudaDeviceReset (void)

Destroy all allocations and reset all state on the current device in the current process.

#### Returns

cudaSuccess

#### Description

Explicitly destroys and cleans up all resources associated with the current device in the current process. Any subsequent API call to this device will reinitialize the device.

Note that this function will reset the device immediately. It is the caller's responsibility to ensure that the device is not being accessed by any other host threads from the process when this function is called.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

#### cudaDeviceSynchronize

## \_\_host\_\_cudaError\_t cudaDeviceSetCacheConfig (cudaFuncCache cacheConfig)

Sets the preferred cache configuration for the current device.

#### **Parameters**

#### cacheConfig

- Requested cache configuration

#### Returns

cudaSuccess, cudaErrorInitializationError

#### Description

On devices where the L1 cache and shared memory use the same hardware resources, this sets through cacheConfig the preferred cache configuration for the current device. This is only a preference. The runtime will use the requested configuration if possible, but it is free to choose a different configuration if required to execute the function. Any function preference set via cudaFuncSetCacheConfig ( C API) or cudaFuncSetCacheConfig ( C++ API) will be preferred over this device-wide setting. Setting the device-wide cache configuration to cudaFuncCachePreferNone will cause subsequent kernel launches to prefer to not change the cache configuration unless required to launch the kernel.

This setting does nothing on devices where the size of the L1 cache and shared memory are fixed.

Launching a kernel with a different preference than the most recent preference setting may insert a device-side synchronization point.

The supported cache configurations are:

- cudaFuncCachePreferNone: no preference for shared memory or L1 (default)
- cudaFuncCachePreferShared: prefer larger shared memory and smaller L1 cache
- cudaFuncCachePreferL1: prefer larger L1 cache and smaller shared memory
- cudaFuncCachePreferEqual: prefer equal size L1 cache and shared memory



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaDeviceGetCacheConfig, cudaFuncSetCacheConfig ( C API), cudaFuncSetCacheConfig ( C++ API)

### \_\_host\_\_cudaError\_t cudaDeviceSetLimit (cudaLimit limit, size\_t value)

Set resource limits.

#### **Parameters**

#### limit

- Limit to set

#### value

- Size of limit

#### **Returns**

cudaSuccess, cudaErrorUnsupportedLimit, cudaErrorInvalidValue, cudaErrorMemoryAllocation

#### Description

Setting limit to value is a request by the application to update the current limit maintained by the device. The driver is free to modify the requested value to meet h/w requirements (this could be clamping to minimum or maximum values, rounding up to nearest element size, etc). The application can use cudaDeviceGetLimit() to find out exactly what the limit has been set to.

Setting each cudaLimit has its own specific restrictions, so each is discussed here.

- cudaLimitStackSize controls the stack size in bytes of each GPU thread.
- cudaLimitPrintfFifoSize controls the size in bytes of the shared FIFO used by the printf() and fprintf() device system calls. Setting cudaLimitPrintfFifoSize must not be performed after launching any kernel that uses the printf() or fprintf() device system calls - in such case cudaErrorInvalidValue will be returned.
- cudaLimitMallocHeapSize controls the size in bytes of the heap used by the malloc() and free() device system calls. Setting cudaLimitMallocHeapSize must not be performed after launching any kernel that uses the malloc() or free() device system calls in such case cudaErrorInvalidValue will be returned.
- cudaLimitDevRuntimeSyncDepth controls the maximum nesting depth of a grid at which a thread can safely call cudaDeviceSynchronize(). Setting this limit must be performed before any launch of a kernel that uses the device runtime and calls cudaDeviceSynchronize() above the default sync depth, two levels of grids. Calls to cudaDeviceSynchronize() will fail with error code cudaErrorSyncDepthExceeded if the limitation is violated. This limit can be set smaller than the default or up the

maximum launch depth of 24. When setting this limit, keep in mind that additional levels of sync depth require the runtime to reserve large amounts of device memory which can no longer be used for user allocations. If these reservations of device memory fail, cudaDeviceSetLimit will return cudaErrorMemoryAllocation, and the limit can be reset to a lower value. This limit is only applicable to devices of compute capability 3.5 and higher. Attempting to set this limit on devices of compute capability less than 3.5 will result in the error cudaErrorUnsupportedLimit being returned.

cudaLimitDevRuntimePendingLaunchCount controls the maximum number of outstanding device runtime launches that can be made from the current device. A grid is outstanding from the point of launch up until the grid is known to have been completed. Device runtime launches which violate this limitation fail and return cudaErrorLaunchPendingCountExceeded when cudaGetLastError() is called after launch. If more pending launches than the default (2048 launches) are needed for a module using the device runtime, this limit can be increased. Keep in mind that being able to sustain additional pending launches will require the runtime to reserve larger amounts of device memory upfront which can no longer be used for allocations. If these reservations fail, cudaDeviceSetLimit will return cudaErrorMemoryAllocation, and the limit can be reset to a lower value. This limit is only applicable to devices of compute capability 3.5 and higher. Attempting to set this limit on devices of compute capability less than 3.5 will result in the error cudaErrorUnsupportedLimit being returned.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaDeviceGetLimit

# \_\_host\_\_cudaError\_t cudaDeviceSetSharedMemConfig (cudaSharedMemConfig config)

Sets the shared memory configuration for the current device.

#### **Parameters**

#### config

- Requested cache configuration

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInitializationError

#### Description

On devices with configurable shared memory banks, this function will set the shared memory bank size which is used for all subsequent kernel launches. Any per-function setting of shared memory set via cudaFuncSetSharedMemConfig will override the device wide setting.

Changing the shared memory configuration between launches may introduce a device side synchronization point.

Changing the shared memory bank size will not increase shared memory usage or affect occupancy of kernels, but may have major effects on performance. Larger bank sizes will allow for greater potential bandwidth to shared memory, but will change what kinds of accesses to shared memory will result in bank conflicts.

This function will do nothing on devices with fixed shared memory bank size.

The supported bank configurations are:

- cudaSharedMemBankSizeDefault: set bank width the device default (currently, four bytes)
- cudaSharedMemBankSizeFourByte: set shared memory bank width to be four bytes natively.
- cudaSharedMemBankSizeEightByte: set shared memory bank width to be eight bytes natively.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaDeviceSetCacheConfig, cudaDeviceGetCacheConfig, cudaDeviceGetSharedMemConfig, cudaFuncSetCacheConfig

# \_\_host\_\_\_\_device\_\_cudaError\_t cudaDeviceSynchronize (void)

Wait for compute device to finish.

#### Returns

cudaSuccess

#### Description

Blocks until the device has completed all preceding requested tasks. cudaDeviceSynchronize() returns an error if one of the preceding tasks has failed. If the

cudaDeviceScheduleBlockingSync flag was set for this device, the host thread will block until the device has finished its work.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaDeviceReset

\_\_host\_\_\_\_device\_\_cudaError\_t cudaGetDevice (int \*device)

Returns which device is currently being used.

#### **Parameters**

#### device

- Returns the device on which the active host thread executes the device code.

#### Returns

cudaSuccess

#### Description

Returns in \*device the current device for the calling host thread.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGetDeviceCount, cudaSetDevice, cudaGetDeviceProperties, cudaChooseDevice

\_\_host\_\_\_\_device\_\_cudaError\_t cudaGetDeviceCount
(int \*count)

Returns the number of compute-capable devices.

#### **Parameters**

#### count

- Returns the number of devices with compute capability greater or equal to 2.0

#### **Returns**

cudaSuccess, cudaErrorNoDevice, cudaErrorInsufficientDriver

#### Description

Returns in \*count the number of devices with compute capability greater or equal to 2.0 that are available for execution. If there is no such device then cudaGetDeviceCount() will return cudaErrorNoDevice. If no driver can be loaded to determine if any such devices exist then cudaGetDeviceCount() will return cudaErrorInsufficientDriver.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGetDevice, cudaSetDevice, cudaGetDeviceProperties, cudaChooseDevice

### \_\_host\_\_cudaError\_t cudaGetDeviceFlags (unsigned int \*flags)

Gets the flags for the current device.

#### **Parameters**

#### flags

- Pointer to store the device flags

#### Returns

cudaSuccess, cudaErrorInvalidDevice

#### Description

Returns in flags the flags for the current device. If there is a current device for the calling thread, and the device has been initialized or flags have been set on that device specifically, the flags for the device are returned. If there is no current device, but flags have been set for the thread with cudaSetDeviceFlags, the thread flags are returned. Finally, if there is no current device and no thread flags, the flags for the first device are returned, which may be the default flags. Compare to the behavior of cudaSetDeviceFlags.

Typically, the flags returned should match the behavior that will be seen if the calling thread uses a device after this call, without any change to the flags or current device inbetween by this or another thread. Note that if the device is not initialized, it is possible for another thread to change the flags for the current device before it is

initialized. Additionally, when using exclusive mode, if this thread has not requested a specific device, it may use a device other than the first device, contrary to the assumption made by this function.

If a context has been created via the driver API and is current to the calling thread, the flags for that context are always returned.

Flags returned by this function may specifically include cudaDeviceMapHost even though it is not accepted by cudaSetDeviceFlags because it is implicit in runtime API flags. The reason for this is that the current context may have been created via the driver API in which case the flag is not implicit and may be unset.

#### See also:

cudaGetDevice, cudaGetDeviceProperties, cudaSetDevice, cudaSetDeviceFlags

## \_\_host\_\_cudaError\_t cudaGetDeviceProperties (cudaDeviceProp \*prop, int device)

Returns information about the compute-device.

#### **Parameters**

#### prop

- Properties for the specified device

#### device

- Device number to get properties for

#### Returns

cudaSuccess, cudaErrorInvalidDevice

#### Description

Returns in \*prop the properties of device dev. The cudaDeviceProp structure is defined as:

```
struct cudaDeviceProp {
              char name[256];
              size_t totalGlobalMem;
              size_t sharedMemPerBlock;
              int regsPerBlock;
              int warpSize;
              size_t memPitch;
              int maxThreadsPerBlock;
              int maxThreadsDim[3];
              int maxGridSize[3];
              int clockRate;
              size t totalConstMem;
              int major;
              int minor;
              size t textureAlignment;
              size t texturePitchAlignment;
              int deviceOverlap;
              int multiProcessorCount;
              int kernelExecTimeoutEnabled;
              int integrated;
              int canMapHostMemory;
              int computeMode;
              int maxTexture1D;
              int maxTexture1DMipmap;
              int maxTexture1DLinear;
              int maxTexture2D[2];
              int maxTexture2DMipmap[2];
              int maxTexture2DLinear[3];
              int maxTexture2DGather[2];
              int maxTexture3D[3];
              int maxTexture3DAlt[3];
              int maxTextureCubemap;
              int maxTexture1DLayered[2];
              int maxTexture2DLayered[3];
              int maxTextureCubemapLayered[2];
              int maxSurface1D;
              int maxSurface2D[2];
              int maxSurface3D[3];
              int maxSurface1DLayered[2];
              int maxSurface2DLayered[3];
              int maxSurfaceCubemap;
              int maxSurfaceCubemapLayered[2];
              size_t surfaceAlignment;
              int concurrentKernels;
              int ECCEnabled;
              int pciBusID;
              int pciDeviceID;
              int pciDomainID;
              int tccDriver;
              int asyncEngineCount;
              int unifiedAddressing;
              int memoryClockRate;
              int memoryBusWidth;
              int 12CacheSize;
              int maxThreadsPerMultiProcessor;
              int streamPrioritiesSupported;
              int globalL1CacheSupported;
              int localL1CacheSupported;
              size_t sharedMemPerMultiprocessor;
              int regsPerMultiprocessor;
              int managedMemSupported;
              int isMultiGpuBoard;
              int multiGpuBoardGroupID;
              int singleToDoublePrecisionPerfRatio;
              int pageableMemoryAccess;
              int concurrentManagedAccess;
CUDA Runtime ÁPI
                                                                             v8.0 | 27
```

#### where:

- name[256] is an ASCII string identifying the device;
- totalGlobalMem is the total amount of global memory available on the device in bytes;
- sharedMemPerBlock is the maximum amount of shared memory available to a thread block in bytes;
- regsPerBlock is the maximum number of 32-bit registers available to a thread block;
- warpSize is the warp size in threads;
- memPitch is the maximum pitch in bytes allowed by the memory copy functions that involve memory regions allocated through cudaMallocPitch();
- maxThreadsPerBlock is the maximum number of threads per block;
- maxThreadsDim[3] contains the maximum size of each dimension of a block;
- maxGridSize[3] contains the maximum size of each dimension of a grid;
- clockRate is the clock frequency in kilohertz;
- totalConstMem is the total amount of constant memory available on the device in bytes;
- major, minor are the major and minor revision numbers defining the device's compute capability;
- textureAlignment is the alignment requirement; texture base addresses that are aligned to textureAlignment bytes do not need an offset applied to texture fetches;
- texturePitchAlignment is the pitch alignment requirement for 2D texture references that are bound to pitched memory;
- deviceOverlap is 1 if the device can concurrently copy memory between host and device while executing a kernel, or 0 if not. Deprecated, use instead asyncEngineCount.
- multiProcessorCount is the number of multiprocessors on the device;
- ▶ kernelExecTimeoutEnabled is 1 if there is a run time limit for kernels executed on the device, or 0 if not.
- integrated is 1 if the device is an integrated (motherboard) GPU and 0 if it is a discrete (card) component.
- canMapHostMemory is 1 if the device can map host memory into the CUDA address space for use with cudaHostAlloc()/cudaHostGetDevicePointer(), or 0 if not;
- computeMode is the compute mode that the device is currently in. Available modes are as follows:
  - cudaComputeModeDefault: Default mode Device is not restricted and multiple threads can use cudaSetDevice() with this device.
  - cudaComputeModeExclusive: Compute-exclusive mode Only one thread will be able to use cudaSetDevice() with this device.
  - cudaComputeModeProhibited: Compute-prohibited mode No threads can use cudaSetDevice() with this device.

- cudaComputeModeExclusiveProcess: Compute-exclusive-process mode Many threads in one process will be able to use cudaSetDevice() with this device.
  - If cudaSetDevice() is called on an already occupied device with computeMode cudaComputeModeExclusive, cudaErrorDeviceAlreadyInUse will be immediately returned indicating the device cannot be used. When an occupied exclusive mode device is chosen with cudaSetDevice, all subsequent non-device management runtime functions will return cudaErrorDevicesUnavailable.
- maxTexture1D is the maximum 1D texture size.
- ▶ maxTexture1DMipmap is the maximum 1D mipmapped texture texture size.
- maxTexture1DLinear is the maximum 1D texture size for textures bound to linear memory.
- maxTexture2D[2] contains the maximum 2D texture dimensions.
- maxTexture2DMipmap[2] contains the maximum 2D mipmapped texture dimensions.
- maxTexture2DLinear[3] contains the maximum 2D texture dimensions for 2D textures bound to pitch linear memory.
- ► maxTexture2DGather[2] contains the maximum 2D texture dimensions if texture gather operations have to be performed.
- ► maxTexture3D[3] contains the maximum 3D texture dimensions.
- ▶ maxTexture3DAlt[3] contains the maximum alternate 3D texture dimensions.
- ▶ maxTextureCubemap is the maximum cubemap texture width or height.
- ► maxTexture1DLayered[2] contains the maximum 1D layered texture dimensions.
- maxTexture2DLayered[3] contains the maximum 2D layered texture dimensions.
- maxTextureCubemapLayered[2] contains the maximum cubemap layered texture dimensions.
- maxSurface1D is the maximum 1D surface size.
- ▶ maxSurface2D[2] contains the maximum 2D surface dimensions.
- ▶ maxSurface3D[3] contains the maximum 3D surface dimensions.
- maxSurface1DLayered[2] contains the maximum 1D layered surface dimensions.
- maxSurface2DLayered[3] contains the maximum 2D layered surface dimensions.
- maxSurfaceCubemap is the maximum cubemap surface width or height.
- maxSurfaceCubemapLayered[2] contains the maximum cubemap layered surface dimensions.
- surfaceAlignment specifies the alignment requirements for surfaces.
- concurrentKernels is 1 if the device supports executing multiple kernels within the same context simultaneously, or 0 if not. It is not guaranteed that multiple kernels will be resident on the device concurrently so this feature should not be relied upon for correctness;
- ▶ ECCEnabled is 1 if the device has ECC support turned on, or 0 if not.
- pciBusID is the PCI bus identifier of the device.

- pciDeviceID is the PCI device (sometimes called slot) identifier of the device.
- pciDomainID is the PCI domain identifier of the device.
- ▶ tccDriver is 1 if the device is using a TCC driver or 0 if not.
- ▶ asyncEngineCount is 1 when the device can concurrently copy memory between host and device while executing a kernel. It is 2 when the device can concurrently copy memory between host and device in both directions and execute a kernel at the same time. It is 0 if neither of these is supported.
- unifiedAddressing is 1 if the device shares a unified address space with the host and 0 otherwise.
- memoryClockRate is the peak memory clock frequency in kilohertz.
- memoryBusWidth is the memory bus width in bits.
- ▶ 12CacheSize is L2 cache size in bytes.
- maxThreadsPerMultiProcessor is the number of maximum resident threads per multiprocessor.
- streamPrioritiesSupported is 1 if the device supports stream priorities, or 0 if it is not supported.
- globalL1CacheSupported is 1 if the device supports caching of globals in L1 cache, or 0 if it is not supported.
- ▶ localL1CacheSupported is 1 if the device supports caching of locals in L1 cache, or 0 if it is not supported.
- sharedMemPerMultiprocessor is the maximum amount of shared memory available to a multiprocessor in bytes; this amount is shared by all thread blocks simultaneously resident on a multiprocessor;
- regsPerMultiprocessor is the maximum number of 32-bit registers available to a multiprocessor; this number is shared by all thread blocks simultaneously resident on a multiprocessor;
- ▶ managedMemory is 1 if the device supports allocating managed memory on this system, or 0 if it is not supported.
- ▶ isMultiGpuBoard is 1 if the device is on a multi-GPU board (e.g. Gemini cards), and 0 if not;
- multiGpuBoardGroupID is a unique identifier for a group of devices associated with the same board. Devices on the same multi-GPU board will share the same identifier;
- singleToDoublePrecisionPerfRatio is the ratio of single precision performance (in floating-point operations per second) to double precision performance.
- pageableMemoryAccess is 1 if the device supports coherently accessing pageable memory without calling cudaHostRegister on it, and 0 otherwise.
- ▶ concurrentManagedAccess is 1 if the device can coherently access managed memory concurrently with the CPU, and 0 otherwise.

#### See also:

cudaGetDeviceCount, cudaGetDevice, cudaSetDevice, cudaChooseDevice, cudaDeviceGetAttribute

### \_\_host\_\_cudaError\_t cudaIpcCloseMemHandle (void \*devPtr)

Close memory mapped with cudalpcOpenMemHandle.

#### **Parameters**

#### devPtr

- Device pointer returned by cudaIpcOpenMemHandle

#### **Returns**

cudaSuccess, cudaErrorMapBufferObjectFailed, cudaErrorInvalidResourceHandle,

#### Description

Unmaps memory returnd by cudalpcOpenMemHandle. The original allocation in the exporting process as well as imported mappings in other processes will be unaffected.

Any resources used to enable peer access will be freed if this is the last mapping using them.

IPC functionality is restricted to devices with support for unified addressing on Linux operating systems.

#### See also:

cudaMalloc, cudaFree, cudaIpcGetEventHandle, cudaIpcOpenEventHandle, cudaIpcGetMemHandle, cudaIpcOpenMemHandle,

### \_\_host\_\_cudaError\_t cudaIpcGetEventHandle (cudaIpcEventHandle\_t \*handle, cudaEvent\_t event)

Gets an interprocess handle for a previously allocated event.

#### **Parameters**

#### handle

- Pointer to a user allocated cudalpcEventHandle in which to return the opaque event handle

#### event

- Event allocated with cudaEventInterprocess and cudaEventDisableTiming flags.

#### Returns

cudaSuccess, cudaErrorInvalidResourceHandle, cudaErrorMemoryAllocation, cudaErrorMapBufferObjectFailed

#### Description

Takes as input a previously allocated event. This event must have been created with the cudaEventInterprocess and cudaEventDisableTiming flags set. This opaque handle may be copied into other processes and opened with cudaIpcOpenEventHandle to allow efficient hardware synchronization between GPU work in different processes.

After the event has been been opened in the importing process, cudaEventRecord, cudaEventSynchronize, cudaStreamWaitEvent and cudaEventQuery may be used in either process. Performing operations on the imported event after the exported event has been freed with cudaEventDestroy will result in undefined behavior.

IPC functionality is restricted to devices with support for unified addressing on Linux operating systems.

#### See also:

cudaEventCreate, cudaEventDestroy, cudaEventSynchronize, cudaEventQuery, cudaStreamWaitEvent, cudaIpcOpenEventHandle, cudaIpcGetMemHandle, cudaIpcOpenMemHandle, cudaIpcCloseMemHandle

# \_\_host\_\_cudaError\_t cudaIpcGetMemHandle (cudaIpcMemHandle\_t \*handle, void \*devPtr)

Gets an interprocess memory handle for an existing device memory allocation.

#### **Parameters**

#### handle

- Pointer to user allocated cudalpcMemHandle to return the handle in.

#### devPtr

- Base pointer to previously allocated device memory

#### Returns

cudaSuccess, cudaErrorInvalidResourceHandle, cudaErrorMemoryAllocation, cudaErrorMapBufferObjectFailed,

#### Description

Takes a pointer to the base of an existing device memory allocation created with cudaMalloc and exports it for use in another process. This is a lightweight operation and may be called multiple times on an allocation without adverse effects.

If a region of memory is freed with cudaFree and a subsequent call to cudaMalloc returns memory with the same device address, cudaIpcGetMemHandle will return a unique handle for the new memory.

IPC functionality is restricted to devices with support for unified addressing on Linux operating systems.

#### See also:

cudaMalloc, cudaFree, cudaIpcGetEventHandle, cudaIpcOpenEventHandle, cudaIpcOpenMemHandle, cudaIpcCloseMemHandle

### \_\_host\_\_cudaError\_t cudaIpcOpenEventHandle (cudaEvent\_t \*event, cudaIpcEventHandle\_t handle)

Opens an interprocess event handle for use in the current process.

#### **Parameters**

#### event

- Returns the imported event

#### handle

- Interprocess handle to open

#### Returns

cudaSuccess, cudaErrorMapBufferObjectFailed, cudaErrorInvalidResourceHandle

#### Description

Opens an interprocess event handle exported from another process with cudaIpcGetEventHandle. This function returns a cudaEvent\_t that behaves like a locally created event with the cudaEventDisableTiming flag specified. This event must be freed with cudaEventDestroy.

Performing operations on the imported event after the exported event has been freed with cudaEventDestroy will result in undefined behavior.

IPC functionality is restricted to devices with support for unified addressing on Linux operating systems.

#### See also:

cudaEventCreate, cudaEventDestroy, cudaEventSynchronize, cudaEventQuery, cudaStreamWaitEvent, cudaIpcGetEventHandle, cudaIpcGetMemHandle, cudaIpcOpenMemHandle, cudaIpcCloseMemHandle

# \_\_host\_\_cudaError\_t cudaIpcOpenMemHandle (void \*\*devPtr, cudaIpcMemHandle\_t handle, unsigned int flags)

Opens an interprocess memory handle exported from another process and returns a device pointer usable in the local process.

#### **Parameters**

#### devPtr

- Returned device pointer

#### handle

- cudaIpcMemHandle to open

#### flags

- Flags for this operation. Must be specified as cudalpcMemLazyEnablePeerAccess

#### Returns

cuda Success, cuda Error Map Buffer Object Failed, cuda Error Invalid Resource Handle, cuda Error Too Many Peers

#### **Description**

Maps memory exported from another process with cudaIpcGetMemHandle into the current device address space. For contexts on different devices cudaIpcOpenMemHandle can attempt to enable peer access between the devices as if the user called cudaDeviceEnablePeerAccess. This behavior is controlled by the cudaIpcMemLazyEnablePeerAccess flag. cudaDeviceCanAccessPeer can determine if a mapping is possible.

Contexts that may open cudalpcMemHandles are restricted in the following way. cudalpcMemHandles from each device in a given process may only be opened by one context per device per other process.

Memory returned from cudaIpcOpenMemHandle must be freed with cudaIpcCloseMemHandle.

Calling cudaFree on an exported memory region before calling cudaIpcCloseMemHandle in the importing context will result in undefined behavior.

IPC functionality is restricted to devices with support for unified addressing on Linux operating systems.



No guarantees are made about the address returned in \*devPtr. In particular, multiple processes may not receive the same address for the same handle.

#### See also:

cudaMalloc, cudaFree, cudaIpcGetEventHandle, cudaIpcOpenEventHandle, cudaIpcGetMemHandle, cudaIpcCloseMemHandle, cudaDeviceEnablePeerAccess, cudaDeviceCanAccessPeer,

### \_\_host\_\_cudaError\_t cudaSetDevice (int device)

Set device to be used for GPU executions.

#### **Parameters**

#### device

- Device on which the active host thread should execute the device code.

#### **Returns**

cudaSuccess, cudaErrorInvalidDevice, cudaErrorDeviceAlreadyInUse

#### Description

Sets device as the current device for the calling host thread. Valid device id's are 0 to (cudaGetDeviceCount() - 1).

Any device memory subsequently allocated from this host thread using cudaMalloc(), cudaMallocPitch() or cudaMallocArray() will be physically resident on device. Any host memory allocated from this host thread using cudaMallocHost() or cudaHostAlloc() or cudaHostRegister() will have its lifetime associated with device. Any streams or events created from this host thread will be associated with device. Any kernels launched from this host thread using the <>>> operator or cudaLaunchKernel() will be executed on device.

This call may be made from any host thread, to any device, and at any time. This function will do no synchronization with the previous or new device, and should be considered a very low overhead call.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGetDeviceCount, cudaGetDevice, cudaGetDeviceProperties, cudaChooseDevice

### \_\_host\_\_cudaError\_t cudaSetDeviceFlags (unsigned int flags)

Sets flags to be used for device executions.

#### **Parameters**

#### flags

- Parameters for device operation

#### **Returns**

cudaSuccess, cudaErrorInvalidDevice, cudaErrorSetOnActiveProcess

#### Description

Records flags as the flags to use when initializing the current device. If no device has been made current to the calling thread, then flags will be applied to the initialization of any device initialized by the calling host thread, unless that device has had its initialization flags set explicitly by this or any host thread.

If the current device has been set and that device has already been initialized then this call will fail with the error cudaErrorSetOnActiveProcess. In this case it is necessary to reset device using cudaDeviceReset() before the device's initialization flags may be set.

The two LSBs of the flags parameter can be used to control how the CPU thread interacts with the OS scheduler when waiting for results from the device.

- ► cudaDeviceScheduleAuto: The default value if the flags parameter is zero, uses a heuristic based on the number of active CUDA contexts in the process C and the number of logical processors in the system P. If C > P, then CUDA will yield to other OS threads when waiting for the device, otherwise CUDA will not yield while waiting for results and actively spin on the processor.
- cudaDeviceScheduleSpin: Instruct CUDA to actively spin when waiting for results from the device. This can decrease latency when waiting for the device, but may lower the performance of CPU threads if they are performing work in parallel with the CUDA thread.
- cudaDeviceScheduleYield: Instruct CUDA to yield its thread when waiting for results from the device. This can increase latency when waiting for the device, but can increase the performance of CPU threads performing work in parallel with the device.
- cudaDeviceScheduleBlockingSync: Instruct CUDA to block the CPU thread on a synchronization primitive when waiting for the device to finish work.
- cudaDeviceBlockingSync: Instruct CUDA to block the CPU thread on a synchronization primitive when waiting for the device to finish work.

Deprecated: This flag was deprecated as of CUDA 4.0 and replaced with cudaDeviceScheduleBlockingSync.

- cudaDeviceMapHost: This flag enables allocating pinned host memory that is accessible to the device. It is implicit for the runtime but may be absent if a context is created using the driver API. If this flag is not set, cudaHostGetDevicePointer() will always return a failure code.
- cudaDeviceLmemResizeToMax: Instruct CUDA to not reduce local memory after resizing local memory for a kernel. This can prevent thrashing by local memory allocations when launching many kernels with high local memory usage at the cost of potentially increased memory usage.

#### See also:

cudaGetDeviceFlags, cudaGetDeviceCount, cudaGetDevice, cudaGetDeviceProperties, cudaSetDevice, cudaSetValidDevices, cudaChooseDevice

### \_\_host\_\_cudaError\_t cudaSetValidDevices (int \*device\_arr, int len)

Set a list of devices that can be used for CUDA.

#### **Parameters**

#### device\_arr

- List of devices to try

#### len

Number of devices in specified list

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevice

#### Description

Sets a list of devices for CUDA execution in priority order using device\_arr. The parameter len specifies the number of elements in the list. CUDA will try devices from the list sequentially until it finds one that works. If this function is not called, or if it is called with a len of 0, then CUDA will go back to its default behavior of trying devices sequentially from a default list containing all of the available CUDA devices in the system. If a specified device ID in the list does not exist, this function will return cudaErrorInvalidDevice. If len is not 0 and device\_arr is NULL or if len exceeds the number of devices in the system, then cudaErrorInvalidValue is returned.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGetDeviceCount, cudaSetDevice, cudaGetDeviceProperties, cudaSetDeviceFlags, cudaChooseDevice

### 4.2. Thread Management [DEPRECATED]

This section describes deprecated thread management functions of the CUDA runtime application programming interface.

### \_\_host\_\_cudaError\_t cudaThreadExit (void)

Exit and clean up from CUDA launches.

#### Returns

cudaSuccess

#### Description

#### Deprecated

Note that this function is deprecated because its name does not reflect its behavior. Its functionality is identical to the non-deprecated function cudaDeviceReset(), which should be used instead.

Explicitly destroys all cleans up all resources associated with the current device in the current process. Any subsequent API call to this device will reinitialize the device.

Note that this function will reset the device immediately. It is the caller's responsibility to ensure that the device is not being accessed by any other host threads from the process when this function is called.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaDeviceReset

## \_\_host\_\_cudaError\_t cudaThreadGetCacheConfig (cudaFuncCache \*pCacheConfig)

Returns the preferred cache configuration for the current device.

#### **Parameters**

#### pCacheConfig

- Returned cache configuration

#### Returns

cudaSuccess, cudaErrorInitializationError

#### Description

#### Deprecated

Note that this function is deprecated because its name does not reflect its behavior. Its functionality is identical to the non-deprecated function cudaDeviceGetCacheConfig(), which should be used instead.

On devices where the L1 cache and shared memory use the same hardware resources, this returns through pCacheConfig the preferred cache configuration for the current device. This is only a preference. The runtime will use the requested configuration if possible, but it is free to choose a different configuration if required to execute functions.

This will return a pCacheConfig of cudaFuncCachePreferNone on devices where the size of the L1 cache and shared memory are fixed.

The supported cache configurations are:

- cudaFuncCachePreferNone: no preference for shared memory or L1 (default)
- cudaFuncCachePreferShared: prefer larger shared memory and smaller L1 cache
- cudaFuncCachePreferL1: prefer larger L1 cache and smaller shared memory



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaDeviceGetCacheConfig

## \_\_host\_\_cudaError\_t cudaThreadGetLimit (size\_t \*pValue, cudaLimit limit)

Returns resource limits.

#### **Parameters**

#### pValue

- Returned size in bytes of limit

#### limit

- Limit to query

#### Returns

cudaSuccess, cudaErrorUnsupportedLimit, cudaErrorInvalidValue

#### Description

#### Deprecated

Note that this function is deprecated because its name does not reflect its behavior. Its functionality is identical to the non-deprecated function cudaDeviceGetLimit(), which should be used instead.

Returns in \*pValue the current size of limit. The supported cudaLimit values are:

- cudaLimitStackSize: stack size of each GPU thread;
- cudaLimitPrintfFifoSize: size of the shared FIFO used by the printf() and fprintf() device system calls.
- cudaLimitMallocHeapSize: size of the heap used by the malloc() and free() device system calls;



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaDeviceGetLimit

# \_\_host\_\_cudaError\_t cudaThreadSetCacheConfig (cudaFuncCache cacheConfig)

Sets the preferred cache configuration for the current device.

#### **Parameters**

#### cacheConfig

- Requested cache configuration

#### Returns

cudaSuccess, cudaErrorInitializationError

#### Description

#### Deprecated

Note that this function is deprecated because its name does not reflect its behavior. Its functionality is identical to the non-deprecated function cudaDeviceSetCacheConfig(), which should be used instead.

On devices where the L1 cache and shared memory use the same hardware resources, this sets through cacheConfig the preferred cache configuration for the current device. This is only a preference. The runtime will use the requested configuration if possible, but it is free to choose a different configuration if required to execute the function. Any function preference set via cudaFuncSetCacheConfig ( C API) or cudaFuncSetCacheConfig ( C++ API) will be preferred over this device-wide setting. Setting the device-wide cache configuration to cudaFuncCachePreferNone will cause subsequent kernel launches to prefer to not change the cache configuration unless required to launch the kernel.

This setting does nothing on devices where the size of the L1 cache and shared memory are fixed.

Launching a kernel with a different preference than the most recent preference setting may insert a device-side synchronization point.

The supported cache configurations are:

- cudaFuncCachePreferNone: no preference for shared memory or L1 (default)
- cudaFuncCachePreferShared: prefer larger shared memory and smaller L1 cache
- cudaFuncCachePreferL1: prefer larger L1 cache and smaller shared memory



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaDeviceSetCacheConfig

# \_\_host\_\_cudaError\_t cudaThreadSetLimit (cudaLimit limit, size\_t value)

Set resource limits.

#### **Parameters**

#### limit

- Limit to set

#### value

- Size in bytes of limit

#### Returns

cudaSuccess, cudaErrorUnsupportedLimit, cudaErrorInvalidValue

#### Description

#### Deprecated

Note that this function is deprecated because its name does not reflect its behavior. Its functionality is identical to the non-deprecated function cudaDeviceSetLimit(), which should be used instead.

Setting limit to value is a request by the application to update the current limit maintained by the device. The driver is free to modify the requested value to meet h/w requirements (this could be clamping to minimum or maximum values, rounding up to nearest element size, etc). The application can use cudaThreadGetLimit() to find out exactly what the limit has been set to.

Setting each cudaLimit has its own specific restrictions, so each is discussed here.

- cudaLimitStackSize controls the stack size of each GPU thread.
- cudaLimitPrintfFifoSize controls the size of the shared FIFO used by the printf() and fprintf() device system calls. Setting cudaLimitPrintfFifoSize must be performed before launching any kernel that uses the printf() or fprintf() device system calls, otherwise cudaErrorInvalidValue will be returned.
- cudaLimitMallocHeapSize controls the size of the heap used by the malloc() and free() device system calls. Setting cudaLimitMallocHeapSize must be performed before launching any kernel that uses the malloc() or free() device system calls, otherwise cudaErrorInvalidValue will be returned.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaDeviceSetLimit

### \_\_host\_\_cudaError\_t cudaThreadSynchronize (void)

Wait for compute device to finish.

#### Returns

cudaSuccess

#### Description

#### Deprecated

Note that this function is deprecated because its name does not reflect its behavior. Its functionality is similar to the non-deprecated function cudaDeviceSynchronize(), which should be used instead.

Blocks until the device has completed all preceding requested tasks. cudaThreadSynchronize() returns an error if one of the preceding tasks has failed. If the cudaDeviceScheduleBlockingSync flag was set for this device, the host thread will block until the device has finished its work.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaDeviceSynchronize

### 4.3. Error Handling

This section describes the error handling functions of the CUDA runtime application programming interface.

# \_\_host\_\_\_\_device\_\_const char \*cudaGetErrorName (cudaError\_t error)

Returns the string representation of an error code enum name.

#### **Parameters**

#### error

- Error code to convert to string

#### Returns

char\* pointer to a NULL-terminated string

#### Description

Returns a string containing the name of an error code in the enum. If the error code is not recognized, "unrecognized error code" is returned.

#### See also:

cudaGetErrorString, cudaGetLastError, cudaPeekAtLastError, cudaError

### \_\_host\_\_\_\_device\_\_const char \*cudaGetErrorString (cudaError\_t error)

Returns the description string for an error code.

#### **Parameters**

#### error

- Error code to convert to string

#### Returns

char\* pointer to a NULL-terminated string

#### Description

Returns the description string for an error code. If the error code is not recognized, "unrecognized error code" is returned.

#### See also:

cudaGetErrorName, cudaGetLastError, cudaPeekAtLastError, cudaError

### \_\_host\_\_\_\_device\_\_cudaError\_t cudaGetLastError (void)

Returns the last error from a runtime call.

#### Returns

cudaSuccess, cudaErrorMissingConfiguration, cudaErrorMemoryAllocation, cudaErrorInitializationError, cudaErrorLaunchFailure, cudaErrorLaunchTimeout, cudaErrorLaunchOutOfResources, cudaErrorInvalidDeviceFunction, cudaErrorInvalidConfiguration, cudaErrorInvalidDevice, cudaErrorInvalidValue, cudaErrorInvalidPitchValue, cudaErrorInvalidSymbol, cudaErrorInvalidDevicePointer, cudaErrorInvalidHostPointer, cudaErrorInvalidDevicePointer, cudaErrorInvalidTexture, cudaErrorInvalidTextureBinding, cudaErrorInvalidChannelDescriptor, cudaErrorInvalidMemcpyDirection, cudaErrorInvalidFilterSetting, cudaErrorInvalidNormSetting, cudaErrorUnknown, cudaErrorInvalidResourceHandle, cudaErrorInsufficientDriver, cudaErrorSetOnActiveProcess, cudaErrorStartupFailure,

#### Description

Returns the last error that has been produced by any of the runtime calls in the same host thread and resets it to cudaSuccess.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaPeekAtLastError, cudaGetErrorName, cudaGetErrorString, cudaError

# \_\_host\_\_\_\_device\_\_cudaError\_t cudaPeekAtLastError (void)

Returns the last error from a runtime call.

#### Returns

cudaSuccess, cudaErrorMissingConfiguration, cudaErrorMemoryAllocation, cudaErrorInitializationError, cudaErrorLaunchFailure, cudaErrorLaunchTimeout, cudaErrorLaunchOutOfResources, cudaErrorInvalidDeviceFunction, cudaErrorInvalidConfiguration, cudaErrorInvalidDevice, cudaErrorInvalidValue, cudaErrorInvalidPitchValue, cudaErrorInvalidSymbol, cudaErrorUnmapBufferObjectFailed, cudaErrorInvalidHostPointer, cudaErrorInvalidDevicePointer, cudaErrorInvalidTexture, cudaErrorInvalidTextureBinding, cudaErrorInvalidChannelDescriptor,

cudaErrorInvalidMemcpyDirection, cudaErrorInvalidFilterSetting, cudaErrorInvalidNormSetting, cudaErrorUnknown, cudaErrorInvalidResourceHandle, cudaErrorInsufficientDriver, cudaErrorSetOnActiveProcess, cudaErrorStartupFailure,

#### Description

Returns the last error that has been produced by any of the runtime calls in the same host thread. Note that this call does not reset the error to cudaSuccess like cudaGetLastError().



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGetLastError, cudaGetErrorName, cudaGetErrorString, cudaError

### 4.4. Stream Management

This section describes the stream management functions of the CUDA runtime application programming interface.

typedef void (CUDART\_CB \*cudaStreamCallback\_t)
(cudaStream\_t stream, cudaError\_t status, void\*
userData)

Type of stream callback functions.

\_\_host\_\_cudaError\_t cudaStreamAddCallback (cudaStream\_t stream, cudaStreamCallback\_t callback, void \*userData, unsigned int flags)

Add a callback to a compute stream.

#### **Parameters**

#### stream

- Stream to add callback to

#### callback

- The function to call once preceding stream operations are complete **userData** 
  - User specified data to be passed to the callback function

#### flags

- Reserved for future use, must be 0

#### Returns

cuda Success, cuda Error Invalid Resource Handle, cuda Error Not Supported

#### Description

Adds a callback to be called on the host after all currently enqueued items in the stream have completed. For each cudaStreamAddCallback call, a callback will be executed exactly once. The callback will block later work in the stream until it is finished.

The callback may be passed cudaSuccess or an error code. In the event of a device error, all subsequently executed callbacks will receive an appropriate cudaError\_t.

Callbacks must not make any CUDA API calls. Attempting to use CUDA APIs will result in cudaErrorNotPermitted. Callbacks must not perform any synchronization that may depend on outstanding device work or other callbacks that are not mandated to run earlier. Callbacks without a mandated order (in independent streams) execute in undefined order and may be serialized.

For the purposes of Unified Memory, callback execution makes a number of guarantees:

- ► The callback stream is considered idle for the duration of the callback. Thus, for example, a callback may always use memory attached to the callback stream.
- ► The start of execution of a callback has the same effect as synchronizing an event recorded in the same stream immediately prior to the callback. It thus synchronizes streams which have been "joined" prior to the callback.
- Adding device work to any stream does not have the effect of making the stream active until all preceding callbacks have executed. Thus, for example, a callback might use global attached memory even if work has been added to another stream, if it has been properly ordered with an event.
- Completion of a callback does not cause a stream to become active except as described above. The callback stream will remain idle if no device work follows the callback, and will remain idle across consecutive callbacks without device work in between. Thus, for example, stream synchronization can be done by signaling from a callback at the end of the stream.



- This function uses standard default stream semantics.
- Note that this function may also return error codes from previous, asynchronous launches.

See also:

cudaStreamCreate, cudaStreamCreateWithFlags, cudaStreamQuery, cudaStreamSynchronize, cudaStreamWaitEvent, cudaStreamDestroy, cudaMallocManaged, cudaStreamAttachMemAsync

# \_\_host\_\_cudaError\_t cudaStreamAttachMemAsync (cudaStream\_t stream, void \*devPtr, size\_t length, unsigned int flags)

Attach memory to a stream asynchronously.

#### **Parameters**

#### stream

- Stream in which to enqueue the attach operation

#### devPtr

- Pointer to memory (must be a pointer to managed memory)

#### length

- Length of memory (must be zero, defaults to zero)

#### flags

- Must be one of cudaMemAttachGlobal, cudaMemAttachHost or cudaMemAttachSingle (defaults to cudaMemAttachSingle)

#### Returns

cudaSuccess, cudaErrorNotReady, cudaErrorInvalidValue cudaErrorInvalidResourceHandle

#### Description

Enqueues an operation in stream to specify stream association of length bytes of memory starting from devPtr. This function is a stream-ordered operation, meaning that it is dependent on, and will only take effect when, previous work in stream has completed. Any previous association is automatically replaced.

devPtr must point to an address within managed memory space declared using the \_\_managed\_\_ keyword or allocated with cudaMallocManaged.

length must be zero, to indicate that the entire allocation's stream association is being changed. Currently, it's not possible to change stream association for a portion of an allocation. The default value for length is zero.

The stream association is specified using flags which must be one of cudaMemAttachGlobal, cudaMemAttachHost or cudaMemAttachSingle. The default value for flags is cudaMemAttachSingle If the cudaMemAttachGlobal flag is specified, the memory can be accessed by any stream on any device. If the cudaMemAttachHost flag is specified, the program makes a guarantee that it won't access the memory on the device from any stream on a device that has a zero value for the device attribute

cudaDevAttrConcurrentManagedAccess. If the cudaMemAttachSingle flag is specified and stream is associated with a device that has a zero value for the device attribute cudaDevAttrConcurrentManagedAccess, the program makes a guarantee that it will only access the memory on the device from stream. It is illegal to attach singly to the NULL stream, because the NULL stream is a virtual global stream and not a specific stream. An error will be returned in this case.

When memory is associated with a single stream, the Unified Memory system will allow CPU access to this memory region so long as all operations in stream have completed, regardless of whether other streams are active. In effect, this constrains exclusive ownership of the managed memory region by an active GPU to per-stream activity instead of whole-GPU activity.

Accessing memory on the device from streams that are not associated with it will produce undefined results. No error checking is performed by the Unified Memory system to ensure that kernels launched into other streams do not access this region.

It is a program's responsibility to order calls to cudaStreamAttachMemAsync via events, synchronization or other means to ensure legal access to memory at all times. Data visibility and coherency will be changed appropriately for all kernels which follow a stream-association change.

If stream is destroyed while data is associated with it, the association is removed and the association reverts to the default visibility of the allocation as specified at cudaMallocManaged. For \_\_managed\_\_ variables, the default association is always cudaMemAttachGlobal. Note that destroying a stream is an asynchronous operation, and as a result, the change to default association won't happen until all work in the stream has completed.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cuda Stream Create, cuda Stream Create With Flags, cuda Stream Wait Event, cuda Stream Synchronize, cuda Stream Add Callback, cuda Stream Destroy, cuda Malloc Managed

# \_\_host\_\_cudaError\_t cudaStreamCreate (cudaStream\_t \*pStream)

Create an asynchronous stream.

#### **Parameters**

#### pStream

- Pointer to new stream identifier

#### Returns

cudaSuccess, cudaErrorInvalidValue

#### Description

Creates a new asynchronous stream.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaStreamCreateWithPriority, cudaStreamCreateWithFlags, cudaStreamGetPriority, cudaStreamGetFlags, cudaStreamQuery, cudaStreamSynchronize, cudaStreamWaitEvent, cudaStreamAddCallback, cudaStreamDestroy

\_\_host\_\_\_\_device\_\_cudaError\_t
cudaStreamCreateWithFlags (cudaStream\_t \*pStream,
unsigned int flags)

Create an asynchronous stream.

#### **Parameters**

#### pStream

- Pointer to new stream identifier

#### flags

- Parameters for stream creation

#### **Returns**

cudaSuccess, cudaErrorInvalidValue

#### Description

Creates a new asynchronous stream. The flags argument determines the behaviors of the stream. Valid values for flags are

- cudaStreamDefault: Default stream creation flag.
- cudaStreamNonBlocking: Specifies that work running in the created stream may run concurrently with work in stream 0 (the NULL stream), and that the created stream should perform no implicit synchronization with stream 0.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaStreamCreate, cudaStreamCreateWithPriority, cudaStreamGetFlags, cudaStreamQuery, cudaStreamSynchronize, cudaStreamWaitEvent, cudaStreamAddCallback, cudaStreamDestroy

# \_\_host\_\_cudaError\_t cudaStreamCreateWithPriority (cudaStream\_t \*pStream, unsigned int flags, int priority)

Create an asynchronous stream with the specified priority.

#### **Parameters**

#### pStream

- Pointer to new stream identifier

#### flags

- Flags for stream creation. See cudaStreamCreateWithFlags for a list of valid flags that can be passed

#### priority

- Priority of the stream. Lower numbers represent higher priorities. See cudaDeviceGetStreamPriorityRange for more information about the meaningful stream priorities that can be passed.

#### Returns

cudaSuccess, cudaErrorInvalidValue

#### Description

Creates a stream with the specified priority and returns a handle in pStream. This API alters the scheduler priority of work in the stream. Work in a higher priority stream may preempt work already executing in a low priority stream.

priority follows a convention where lower numbers represent higher priorities. '0' represents default priority. The range of meaningful numerical priorities can be queried using cudaDeviceGetStreamPriorityRange. If the specified priority is outside the numerical range returned by cudaDeviceGetStreamPriorityRange, it will automatically be clamped to the lowest or the highest number in the range.



- Note that this function may also return error codes from previous, asynchronous launches.
- Stream priorities are supported only on GPUs with compute capability 3.5 or higher.
- In the current implementation, only compute kernels launched in priority streams are affected by the stream's priority. Stream priorities have no effect on host-to-device and device-to-host memory operations.

#### See also:

cudaStreamCreate, cudaStreamCreateWithFlags, cudaDeviceGetStreamPriorityRange, cudaStreamGetPriority, cudaStreamQuery, cudaStreamWaitEvent, cudaStreamAddCallback, cudaStreamSynchronize, cudaStreamDestroy

# \_\_host\_\_\_\_device\_\_cudaError\_t cudaStreamDestroy (cudaStream\_t stream)

Destroys and cleans up an asynchronous stream.

#### **Parameters**

#### stream

- Stream identifier

#### **Returns**

cudaSuccess, cudaErrorInvalidResourceHandle

#### Description

Destroys and cleans up the asynchronous stream specified by stream.

In case the device is still doing work in the stream stream when cudaStreamDestroy() is called, the function will return immediately and the resources associated with stream will be released automatically once the device has completed all work in stream.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaStreamCreate, cudaStreamCreateWithFlags, cudaStreamQuery, cudaStreamWaitEvent, cudaStreamSynchronize, cudaStreamAddCallback

## \_\_host\_\_cudaError\_t cudaStreamGetFlags (cudaStream\_t hStream, unsigned int \*flags)

Query the flags of a stream.

#### **Parameters**

#### **hStream**

- Handle to the stream to be queried

#### flags

- Pointer to an unsigned integer in which the stream's flags are returned

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidResourceHandle

#### Description

Query the flags of a stream. The flags are returned in flags. See cudaStreamCreateWithFlags for a list of valid flags.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaStreamCreateWithPriority, cudaStreamCreateWithFlags, cudaStreamGetPriority

## \_\_host\_\_cudaError\_t cudaStreamGetPriority (cudaStream\_t hStream, int \*priority)

Query the priority of a stream.

#### **Parameters**

#### hStream

- Handle to the stream to be queried **priority** 

- Pointer to a signed integer in which the stream's priority is returned

#### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidResourceHandle

#### Description

Query the priority of a stream. The priority is returned in in priority. Note that if the stream was created with a priority outside the meaningful numerical range returned by cudaDeviceGetStreamPriorityRange, this function returns the clamped priority. See cudaStreamCreateWithPriority for details about priority clamping.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

 $cuda Stream Create With Priority, cuda Device Get Stream Priority Range, \\ cuda Stream Get Flags$ 

## \_\_host\_\_cudaError\_t cudaStreamQuery (cudaStream\_t stream)

Queries an asynchronous stream for completion status.

#### **Parameters**

#### stream

- Stream identifier

#### Returns

cudaSuccess, cudaErrorNotReady, cudaErrorInvalidResourceHandle

#### Description

Returns cudaSuccess if all operations in stream have completed, or cudaErrorNotReady if not.

For the purposes of Unified Memory, a return value of cudaSuccess is equivalent to having called cudaStreamSynchronize().



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaStreamCreate, cudaStreamCreateWithFlags, cudaStreamWaitEvent, cudaStreamSynchronize, cudaStreamAddCallback, cudaStreamDestroy

## \_\_host\_\_cudaError\_t cudaStreamSynchronize (cudaStream\_t stream)

Waits for stream tasks to complete.

#### **Parameters**

#### stream

- Stream identifier

#### Returns

cudaSuccess, cudaErrorInvalidResourceHandle

#### Description

Blocks until stream has completed all operations. If the cudaDeviceScheduleBlockingSync flag was set for this device, the host thread will block until the stream is finished with all of its tasks.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaStreamCreate, cudaStreamCreateWithFlags, cudaStreamQuery, cudaStreamWaitEvent, cudaStreamAddCallback, cudaStreamDestroy

# \_\_host\_\_\_\_device\_\_cudaError\_t cudaStreamWaitEvent (cudaStream\_t stream, cudaEvent\_t event, unsigned int flags)

Make a compute stream wait on an event.

#### **Parameters**

#### stream

- Stream to wait

#### event

- Event to wait on

#### flags

- Parameters for the operation (must be 0)

#### **Returns**

cudaSuccess, cudaErrorInvalidResourceHandle

#### Description

Makes all future work submitted to stream wait until event reports completion before beginning execution. This synchronization will be performed efficiently on the device. The event event may be from a different context than stream, in which case this function will perform cross-device synchronization.

The stream stream will wait only for the completion of the most recent host call to cudaEventRecord() on event. Once this call has returned, any functions (including cudaEventRecord() and cudaEventDestroy()) may be called on event again, and the subsequent calls will not have any effect on stream.

If cudaEventRecord() has not been called on event, this call acts as if the record has already completed, and so is a functional no-op.



- This function uses standard default stream semantics.
- Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaStreamCreate, cudaStreamCreateWithFlags, cudaStreamQuery, cudaStreamSynchronize, cudaStreamAddCallback, cudaStreamDestroy

### 4.5. Event Management

This section describes the event management functions of the CUDA runtime application programming interface.

## \_\_host\_\_cudaError\_t cudaEventCreate (cudaEvent\_t \*event)

Creates an event object.

#### **Parameters**

#### event

- Newly created event

#### Returns

cudaSuccess, cudaErrorInitializationError, cudaErrorInvalidValue, cudaErrorLaunchFailure, cudaErrorMemoryAllocation

#### Description

Creates an event object using cudaEventDefault.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaEventCreate (C++ API), cudaEventCreateWithFlags, cudaEventRecord, cudaEventQuery, cudaEventSynchronize, cudaEventDestroy, cudaEventElapsedTime, cudaStreamWaitEvent

\_\_host\_\_\_\_device\_\_cudaError\_t
cudaEventCreateWithFlags (cudaEvent\_t \*event,
unsigned int flags)

Creates an event object with the specified flags.

#### **Parameters**

#### event

- Newly created event

#### flags

- Flags for new event

#### Returns

cudaSuccess, cudaErrorInitializationError, cudaErrorInvalidValue, cudaErrorLaunchFailure, cudaErrorMemoryAllocation

#### Description

Creates an event object with the specified flags. Valid flags include:

- cudaEventDefault: Default event creation flag.
- cudaEventBlockingSync: Specifies that event should use blocking synchronization. A host thread that uses cudaEventSynchronize() to wait on an event created with this flag will block until the event actually completes.
- cudaEventDisableTiming: Specifies that the created event does not need to record timing data. Events created with this flag specified and the cudaEventBlockingSync flag not specified will provide the best performance when used with cudaStreamWaitEvent() and cudaEventQuery().
- cudaEventInterprocess: Specifies that the created event may be used as an interprocess event by cudaIpcGetEventHandle(). cudaEventInterprocess must be specified along with cudaEventDisableTiming.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

 $cuda Event Create \ (\ C\ API), cuda Event Synchronize, cuda Event Destroy, cuda Event Elapsed Time, cuda Stream Wait Event$ 

\_\_host\_\_\_\_device\_\_cudaError\_t cudaEventDestroy (cudaEvent\_t event)

Destroys an event object.

#### **Parameters**

#### event

- Event to destroy

#### **Returns**

cudaSuccess, cudaErrorInitializationError, cudaErrorInvalidValue, cudaErrorLaunchFailure

#### Description

Destroys the event specified by event.

In case event has been recorded but has not yet been completed when cudaEventDestroy() is called, the function will return immediately and the resources associated with event will be released automatically once the device has completed event.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaEventCreate ( C API), cudaEventCreateWithFlags, cudaEventQuery, cudaEventSynchronize, cudaEventRecord, cudaEventElapsedTime

### \_\_host\_\_cudaError\_t cudaEventElapsedTime (float \*ms, cudaEvent\_t start, cudaEvent\_t end)

Computes the elapsed time between events.

#### **Parameters**

#### ms

- Time between start and end in ms

#### start

- Starting event

#### end

- Ending event

#### Returns

cudaSuccess, cudaErrorNotReady, cudaErrorInvalidValue, cudaErrorInitializationError, cudaErrorInvalidResourceHandle, cudaErrorLaunchFailure

#### Description

Computes the elapsed time between two events (in milliseconds with a resolution of around 0.5 microseconds).

If either event was last recorded in a non-NULL stream, the resulting time may be greater than expected (even if both used the same stream handle). This happens because the cudaEventRecord() operation takes place asynchronously and there is no guarantee that the measured latency is actually just between the two events. Any number of other different stream operations could execute in between the two measured events, thus altering the timing in a significant way.

If cudaEventRecord() has not been called on either event, then cudaErrorInvalidResourceHandle is returned. If cudaEventRecord() has been called on both events but one or both of them has not yet been completed (that is, cudaEventQuery() would return cudaErrorNotReady on at least one of the events), cudaErrorNotReady is returned. If either event was created with the cudaEventDisableTiming flag, then this function will return cudaErrorInvalidResourceHandle.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaEventCreate ( C API), cudaEventCreateWithFlags, cudaEventQuery, cudaEventSynchronize, cudaEventDestroy, cudaEventRecord

## \_\_host\_\_cudaError\_t cudaEventQuery (cudaEvent\_t event)

Queries an event's status.

#### **Parameters**

#### event

- Event to query

#### Returns

cuda Success, cuda Error Not Ready, cuda Error Initialization Error, cuda Error Invalid Value, cuda Error Invalid Resource Handle, cuda Error Launch Failure

#### Description

Query the status of all device work preceding the most recent call to cudaEventRecord() (in the appropriate compute streams, as specified by the arguments to cudaEventRecord()).

If this work has successfully been completed by the device, or if cudaEventRecord() has not been called on event, then cudaSuccess is returned. If this work has not yet been completed by the device then cudaErrorNotReady is returned.

For the purposes of Unified Memory, a return value of cudaSuccess is equivalent to having called cudaEventSynchronize().



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaEventCreate ( C API), cudaEventCreateWithFlags, cudaEventRecord, cudaEventSynchronize, cudaEventDestroy, cudaEventElapsedTime

\_\_host\_\_\_\_device\_\_cudaError\_t cudaEventRecord (cudaEvent\_t event, cudaStream\_t stream)

Records an event.

#### **Parameters**

#### event

- Event to record

#### stream

- Stream in which to record event

#### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInitializationError, cudaErrorInvalidResourceHandle, cudaErrorLaunchFailure

#### Description

Records an event. See note about NULL stream behavior. Since operation is asynchronous, cudaEventQuery() or cudaEventSynchronize() must be used to determine when the event has actually been recorded.

If cudaEventRecord() has previously been called on event, then this call will overwrite any existing state in event. Any subsequent calls which examine the status of event will only examine the completion of this most recent call to cudaEventRecord().



This function uses standard default stream semantics.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaEventCreate ( C API), cudaEventCreateWithFlags, cudaEventQuery, cudaEventSynchronize, cudaEventDestroy, cudaEventElapsedTime, cudaStreamWaitEvent

## \_\_host\_\_cudaError\_t cudaEventSynchronize (cudaEvent\_t event)

Waits for an event to complete.

#### **Parameters**

#### event

- Event to wait for

#### Returns

cudaSuccess, cudaErrorInitializationError, cudaErrorInvalidValue, cudaErrorInvalidResourceHandle, cudaErrorLaunchFailure

#### Description

Wait until the completion of all device work preceding the most recent call to cudaEventRecord() (in the appropriate compute streams, as specified by the arguments to cudaEventRecord()).

If cudaEventRecord() has not been called on event, cudaSuccess is returned immediately.

Waiting for an event that was created with the cudaEventBlockingSync flag will cause the calling CPU thread to block until the event has been completed by the device. If the cudaEventBlockingSync flag has not been set, then the CPU thread will busy-wait until the event has been completed by the device.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaEventCreate ( C API), cudaEventCreateWithFlags, cudaEventRecord, cudaEventQuery, cudaEventDestroy, cudaEventElapsedTime

### 4.6. Execution Control

This section describes the execution control functions of the CUDA runtime application programming interface.

Some functions have overloaded C++ API template versions documented separately in the C++ API Routines module.

## \_\_host\_\_\_\_device\_\_cudaError\_t cudaFuncGetAttributes (cudaFuncAttributes \*attr, const void \*func)

Find out attributes for a given function.

#### **Parameters**

#### attr

- Return pointer to function's attributes

#### func

- Device function symbol

#### **Returns**

cudaSuccess, cudaErrorInitializationError, cudaErrorInvalidDeviceFunction

#### Description

This function obtains the attributes of a function specified via func. func is a device function symbol and must be declared as a \_\_global\_\_ function. The fetched attributes are placed in attr. If the specified function does not exist, then cudaErrorInvalidDeviceFunction is returned. For templated functions, pass the function symbol as follows: func\_name<template\_arg\_0,...,template\_arg\_N>

Note that some function attributes such as maxThreadsPerBlock may vary based on the device that is currently being used.



- Note that this function may also return error codes from previous, asynchronous launches.
- Use of a string naming a function as the func paramater was deprecated in CUDA 4.1 and removed in CUDA 5.0.

#### See also:

cudaConfigureCall, cudaFuncSetCacheConfig ( C API), cudaFuncGetAttributes ( C++ API), cudaLaunchKernel ( C API), cudaSetDoubleForDevice, cudaSetDoubleForHost, cudaSetupArgument ( C API)

### \_\_host\_\_cudaError\_t cudaFuncSetCacheConfig (const void \*func, cudaFuncCache cacheConfig)

Sets the preferred cache configuration for a device function.

#### **Parameters**

#### func

- Device function symbol

#### cacheConfig

- Requested cache configuration

#### Returns

cudaSuccess, cudaErrorInitializationError, cudaErrorInvalidDeviceFunction

#### Description

On devices where the L1 cache and shared memory use the same hardware resources, this sets through cacheConfig the preferred cache configuration for the function specified via func. This is only a preference. The runtime will use the requested configuration if possible, but it is free to choose a different configuration if required to execute func.

func is a device function symbol and must be declared as a \_\_global\_\_ function. If the specified function does not exist, then cudaErrorInvalidDeviceFunction is returned. For templated functions, pass the function symbol as follows: func\_name<template\_arg\_0,...,template\_arg\_N>

This setting does nothing on devices where the size of the L1 cache and shared memory are fixed.

Launching a kernel with a different preference than the most recent preference setting may insert a device-side synchronization point.

The supported cache configurations are:

- cudaFuncCachePreferNone: no preference for shared memory or L1 (default)
- cudaFuncCachePreferShared: prefer larger shared memory and smaller L1 cache
- cudaFuncCachePreferL1: prefer larger L1 cache and smaller shared memory
- cudaFuncCachePreferEqual: prefer equal size L1 cache and shared memory



- Note that this function may also return error codes from previous, asynchronous launches.
- Use of a string naming a function as the func paramater was deprecated in CUDA 4.1 and removed in CUDA 5.0.

#### See also:

cudaConfigureCall, cudaFuncSetCacheConfig (C++ API), cudaFuncGetAttributes (C API), cudaLaunchKernel (C API), cudaSetDoubleForDevice, cudaSetDoubleForHost, cudaSetupArgument (C API), cudaThreadGetCacheConfig, cudaThreadSetCacheConfig

## \_\_host\_\_cudaError\_t cudaFuncSetSharedMemConfig (const void \*func, cudaSharedMemConfig config)

Sets the shared memory configuration for a device function.

#### **Parameters**

#### func

- Device function symbol

#### config

- Requested shared memory configuration

#### Returns

cudaSuccess, cudaErrorInitializationError, cudaErrorInvalidDeviceFunction, cudaErrorInvalidValue,

#### Description

On devices with configurable shared memory banks, this function will force all subsequent launches of the specified device function to have the given shared memory bank size configuration. On any given launch of the function, the shared memory configuration of the device will be temporarily changed if needed to suit the function's preferred configuration. Changes in shared memory configuration between subsequent launches of functions, may introduce a device side synchronization point.

Any per-function setting of shared memory bank size set via cudaFuncSetSharedMemConfig will override the device wide setting set by cudaDeviceSetSharedMemConfig.

Changing the shared memory bank size will not increase shared memory usage or affect occupancy of kernels, but may have major effects on performance. Larger bank sizes will allow for greater potential bandwidth to shared memory, but will change what kinds of accesses to shared memory will result in bank conflicts.

This function will do nothing on devices with fixed shared memory bank size.

For templated functions, pass the function symbol as follows: func\_name<template\_arg\_0,...,template\_arg\_N>

The supported bank configurations are:

- cudaSharedMemBankSizeDefault: use the device's shared memory configuration when launching this function.
- cudaSharedMemBankSizeFourByte: set shared memory bank width to be four bytes natively when launching this function.
- cudaSharedMemBankSizeEightByte: set shared memory bank width to be eight bytes natively when launching this function.



- Note that this function may also return error codes from previous, asynchronous launches.
- Use of a string naming a function as the func paramater was deprecated in CUDA 4.1 and removed in CUDA 5.0.

#### See also:

cudaConfigureCall, cudaDeviceSetSharedMemConfig, cudaDeviceGetSharedMemConfig, cudaDeviceSetCacheConfig, cudaDeviceGetCacheConfig, cudaFuncSetCacheConfig

## \_\_device\_\_ void \*cudaGetParameterBuffer (size\_t alignment, size\_t size)

Obtains a parameter buffer.

#### **Parameters**

#### alignment

- Specifies alignment requirement of the parameter buffer

#### size

Specifies size requirement in bytes

#### Returns

Returns pointer to the allocated parameterBuffer

#### Description

Obtains a parameter buffer which can be filled with parameters for a kernel launch. Parameters passed to cudaLaunchDevice must be allocated via this function.

This is a low level API and can only be accessed from Parallel Thread Execution (PTX). CUDA user code should use <<<>>>> to launch kernels.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaLaunchDevice

\_\_device\_\_ void \*cudaGetParameterBufferV2 (void \*func, dim3 gridDimension, dim3 blockDimension, unsigned int sharedMemSize)

Launches a specified kernel.

#### **Parameters**

#### func

- Pointer to the kernel to be launched

#### gridDimension

- Specifies grid dimensions

#### blockDimension

- Specifies block dimensions

#### sharedMemSize

- Specifies size of shared memory

#### **Returns**

cuda Success, cuda Error Invalid Device, cuda Error Launch Max Depth Exceeded, cuda Error Invalid Configuration, cuda Error Startup Failure, cuda Error Launch Pending Count Exceeded, cuda Error Launch Out Of Resources and the success of the cuda Error Launch Pending Count Exceeded, cuda Error Launch Pending Count Exceeded Exceede

#### Description

Launches a specified kernel with the specified parameter buffer. A parameter buffer can be obtained by calling cudaGetParameterBuffer().

This is a low level API and can only be accessed from Parallel Thread Execution (PTX). CUDA user code should use <<<>>>> to launch the kernels.



Note that this function may also return error codes from previous, asynchronous launches.



Please refer to Execution Configuration and Parameter Buffer Layout from the CUDA Programming Guide for the detailed descriptions of launch configuration and parameter layout respectively.

#### See also:

cudaGetParameterBuffer

\_\_host\_\_cudaError\_t cudaLaunchKernel (const void
\*func, dim3 gridDim, dim3 blockDim, void \*\*args, size\_t
sharedMem, cudaStream\_t stream)

Launches a device function.

#### **Parameters**

#### func

- Device function symbol

#### gridDim

- Grid dimentions

#### blockDim

- Block dimentions

#### args

- Arguments

#### sharedMem

- Shared memory

#### stream

- Stream identifier

#### Returns

cuda Success, cuda Error Invalid Device Function, cuda Error Invalid Configuration, cuda Error Launch Failure, cuda Error Launch Timeout, cuda Error Launch Out Of Resources, cuda Error Shared Object Init Failed

#### Description

The function invokes kernel func on gridDim (gridDim.x × gridDim.y × gridDim.z) grid of blocks. Each block contains blockDim (blockDim.x × blockDim.y × blockDim.z) threads.

If the kernel has N parameters the args should point to array of N pointers. Each pointer, from args[0] to args[N-1], point to the region of memory from which the actual parameter will be copied.

For templated functions, pass the function symbol as follows: func\_name<template\_arg\_0,...,template\_arg\_N>

sharedMem sets the amount of dynamic shared memory that will be available to each thread block.

stream specifies a stream the invocation is associated to.



- This function uses standard default stream semantics.
- Note that this function may also return error codes from previous, asynchronous launches.

cudaLaunchKernel (C++ API)

## \_\_host\_\_cudaError\_t cudaSetDoubleForDevice (double \*d)

Converts a double argument to be executed on a device.

#### **Parameters**

d

- Double to convert

#### Returns

cudaSuccess

#### Description

Deprecated This function is deprecated as of CUDA 7.5

Converts the double value of d to an internal float representation if the device does not support double arithmetic. If the device does natively support doubles, then this function does nothing.



Note that this function may also return error codes from previous, asynchronous launches.

cudaLaunch ( C API), cudaFuncSetCacheConfig ( C API), cudaFuncGetAttributes ( C API), cudaSetDoubleForHost, cudaSetupArgument ( C API)

### \_host\_\_cudaError\_t cudaSetDoubleForHost (double \*d)

Converts a double argument after execution on a device.

#### **Parameters**

d

- Double to convert

#### Returns

cudaSuccess

#### Description

Deprecated This function is deprecated as of CUDA 7.5

Converts the double value of d from a potentially internal float representation if the device does not support double arithmetic. If the device does natively support doubles, then this function does nothing.



Note that this function may also return error codes from previous, asynchronous launches.

cudaLaunch ( C API), cudaFuncSetCacheConfig ( C API), cudaFuncGetAttributes ( C API), cudaSetDoubleForDevice, cudaSetupArgument ( C API)

### 4.7. Occupancy

This section describes the occupancy calculation functions of the CUDA runtime application programming interface.

Besides the occupancy calculator functions (cudaOccupancyMaxActiveBlocksPerMultiprocessor and cudaOccupancyMaxActiveBlocksPerMultiprocessorWithFlags), there are also C++ only occupancy-based launch configuration functions documented in C++ API Routines module.

See cudaOccupancyMaxPotentialBlockSize ( C++ API), cudaOccupancyMaxPotentialBlockSize ( C++ API), cudaOccupancyMaxPotentialBlockSizeVariableSMem ( C++ API), cudaOccupancyMaxPotentialBlockSizeVariableSMem ( C++ API),

\_\_host\_\_\_\_device\_\_cudaError\_t cudaOccupancyMaxActiveBlocksPerMultiprocessor (int \*numBlocks, const void \*func, int blockSize, size\_t dynamicSMemSize)

Returns occupancy for a device function.

#### **Parameters**

#### numBlocks

- Returned occupancy

#### func

- Kernel function for which occupancy is calculated

#### blockSize

- Block size the kernel is intended to be launched with

#### dynamicSMemSize

- Per-block dynamic shared memory usage intended, in bytes

#### **Returns**

cudaSuccess, cudaErrorCudartUnloading, cudaErrorInitializationError, cudaErrorInvalidDevice, cudaErrorInvalidDeviceFunction, cudaErrorInvalidValue, cudaErrorUnknown,

#### Description

Returns in \*numBlocks the maximum number of active blocks per streaming multiprocessor for the device function.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaOccupancyMaxActiveBlocksPerMultiprocessorWithFlags, cudaOccupancyMaxPotentialBlockSize ( C++ API), cudaOccupancyMaxPotentialBlockSizeWithFlags ( C++ API), cudaOccupancyMaxPotentialBlockSizeVariableSMem ( C++ API) cudaOccupancyMaxPotentialBlockSizeVariableSMemWithFlags ( C++ API)

\_\_host\_\_cudaError\_t cudaOccupancyMaxActiveBlocksPerMultiprocessorWithFlags

## (int \*numBlocks, const void \*func, int blockSize, size\_t dynamicSMemSize, unsigned int flags)

Returns occupancy for a device function with the specified flags.

#### **Parameters**

#### numBlocks

- Returned occupancy

#### func

- Kernel function for which occupancy is calculated

#### blockSize

- Block size the kernel is intended to be launched with

#### dynamicSMemSize

- Per-block dynamic shared memory usage intended, in bytes

#### flags

- Requested behavior for the occupancy calculator

#### **Returns**

cudaSuccess, cudaErrorCudartUnloading, cudaErrorInitializationError, cudaErrorInvalidDevice, cudaErrorInvalidDeviceFunction, cudaErrorInvalidValue, cudaErrorUnknown,

#### Description

Returns in \*numBlocks the maximum number of active blocks per streaming multiprocessor for the device function.

The flags parameter controls how special cases are handled. Valid flags include:

- cudaOccupancyDefault: keeps the default behavior as cudaOccupancyMaxActiveBlocksPerMultiprocessor
- cudaOccupancyDisableCachingOverride: This flag suppresses the default behavior on platform where global caching affects occupancy. On such platforms, if caching is enabled, but per-block SM resource usage would result in zero occupancy, the occupancy calculator will calculate the occupancy as if caching is disabled. Setting this flag makes the occupancy calculator to return 0 in such cases. More information can be found about this feature in the "Unified L1/Texture Cache" section of the Maxwell tuning guide.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaOccupancyMaxActiveBlocksPerMultiprocessor, cudaOccupancyMaxPotentialBlockSize ( C++ API), cudaOccupancyMaxPotentialBlockSizeWithFlags ( C++ API), cudaOccupancyMaxPotentialBlockSizeVariableSMem ( C++ API) cudaOccupancyMaxPotentialBlockSizeVariableSMemWithFlags ( C++ API)

### 4.8. Execution Control [DEPRECATED]

This section describes the deprecated execution control functions of the CUDA runtime application programming interface.

Some functions have overloaded C++ API template versions documented separately in the C++ API Routines module.

\_\_host\_\_cudaError\_t cudaConfigureCall (dim3 gridDim, dim3 blockDim, size\_t sharedMem, cudaStream\_t stream)

Configure a device-launch.

#### **Parameters**

#### gridDim

- Grid dimensions

#### blockDim

- Block dimensions

#### sharedMem

- Shared memory

#### stream

- Stream identifier

#### Returns

cudaSuccess, cudaErrorInvalidConfiguration

#### Description

Deprecated This function is deprecated as of CUDA 7.0

Specifies the grid and block dimensions for the device call to be executed similar to the execution configuration syntax. cudaConfigureCall() is stack based. Each call pushes data on top of an execution stack. This data contains the dimension for the grid and thread blocks, together with any arguments for the call.



- This function uses standard default stream semantics.
- Note that this function may also return error codes from previous, asynchronous launches.

cudaLaunchKernel ( C API), cudaFuncSetCacheConfig ( C API), cudaFuncGetAttributes ( C API), cudaLaunch ( C API), cudaSetDoubleForDevice, cudaSetDoubleForHost, cudaSetupArgument ( C API),

### \_host\_\_cudaError\_t cudaLaunch (const void \*func)

Launches a device function.

#### **Parameters**

#### func

- Device function symbol

#### **Returns**

cuda Success, cuda Error Invalid Device Function, cuda Error Invalid Configuration, cuda Error Launch Failure, cuda Error Launch Timeout, cuda Error Launch Out Of Resources, cuda Error Shared Object Init Failed

#### Description

Deprecated This function is deprecated as of CUDA 7.0

Launches the function func on the device. The parameter func must be a device function symbol. The parameter specified by func must be declared as a \_\_global\_\_ function. For templated functions, pass the function symbol as follows: func\_name<template\_arg\_0,...,template\_arg\_N> cudaLaunch() must be preceded by a call to cudaConfigureCall() since it pops the data that was pushed by cudaConfigureCall() from the execution stack.



- Note that this function may also return error codes from previous, asynchronous launches.
- Use of a string naming a variable as the symbol paramater was removed in CUDA 5.0.

cudaLaunchKernel ( C API), cudaFuncSetCacheConfig ( C API), cudaFuncGetAttributes ( C API), cudaLaunch ( C++ API), cudaSetDoubleForDevice, cudaSetDoubleForHost, cudaSetupArgument ( C API), cudaThreadGetCacheConfig, cudaThreadSetCacheConfig

## \_\_host\_\_cudaError\_t cudaSetupArgument (const void \*arg, size\_t size, size\_t offset)

Configure a device launch.

#### **Parameters**

#### arg

- Argument to push for a kernel launch

#### size

- Size of argument

#### offset

- Offset in argument stack to push new arg

#### Returns

cudaSuccess

#### Description

Deprecated This function is deprecated as of CUDA 7.0

Pushes size bytes of the argument pointed to by arg at offset bytes from the start of the parameter passing area, which starts at offset 0. The arguments are stored in the top of the execution stack. cudaSetupArgument() must be preceded by a call to cudaConfigureCall().



Note that this function may also return error codes from previous, asynchronous launches.

cudaLaunchKernel ( C API), cudaFuncSetCacheConfig ( C API), cudaFuncGetAttributes ( C API), cudaLaunch ( C API), cudaSetDoubleForDevice, cudaSetDoubleForHost, cudaSetupArgument ( C++ API),

### 4.9. Memory Management

This section describes the memory management functions of the CUDA runtime application programming interface.

Some functions have overloaded C++ API template versions documented separately in the C++ API Routines module.

# \_\_host\_\_cudaError\_t cudaArrayGetInfo (cudaChannelFormatDesc \*desc, cudaExtent \*extent, unsigned int \*flags, cudaArray\_t array)

Gets info about the specified cudaArray.

#### **Parameters**

#### desc

- Returned array type

#### extent

- Returned array shape. 2D arrays will have depth of zero

#### flags

- Returned array flags

#### array

- The cudaArray to get info for

#### **Returns**

cudaSuccess, cudaErrorInvalidValue

#### Description

Returns in \*desc, \*extent and \*flags respectively, the type, shape and flags of array.

Any of \*desc, \*extent and \*flags may be specified as NULL.



Note that this function may also return error codes from previous, asynchronous launches.

\_\_host\_\_\_\_device\_\_cudaError\_t cudaFree (void \*devPtr)

Frees memory on the device.

#### **Parameters**

#### devPtr

- Device pointer to memory to free

#### Returns

cudaSuccess, cudaErrorInvalidDevicePointer, cudaErrorInitializationError

#### Description

Frees the memory space pointed to by devPtr, which must have been returned by a previous call to cudaMalloc() or cudaMallocPitch(). Otherwise, or if cudaFree(devPtr) has already been called before, an error is returned. If devPtr is 0, no operation is performed. cudaFree() returns cudaErrorInvalidDevicePointer in case of failure.

The device version of cudaFree cannot be used with a \*devPtr allocated using the host API, and vice versa.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaMalloc, cudaMallocPitch, cudaMallocArray, cudaFreeArray, cudaMallocHost ( C API), cudaFreeHost, cudaMalloc3D, cudaMalloc3DArray, cudaHostAlloc

\_\_host\_\_cudaError\_t cudaFreeArray (cudaArray\_t array)

Frees an array on the device.

#### **Parameters**

#### array

- Pointer to array to free

#### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInitializationError

#### Description

Frees the CUDA array array, which must have been \* returned by a previous call to cudaMallocArray(). If cudaFreeArray(array) has already been called before, cudaErrorInvalidValue is returned. If devPtr is 0, no operation is performed.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaMalloc, cudaMallocPitch, cudaFree, cudaMallocArray, cudaMallocHost ( C API), cudaFreeHost, cudaHostAlloc

### \_\_host\_\_cudaError\_t cudaFreeHost (void \*ptr)

Frees page-locked memory.

#### **Parameters**

#### ptr

- Pointer to memory to free

#### Returns

cudaSuccess, cudaErrorInitializationError

#### Description

Frees the memory space pointed to by hostPtr, which must have been returned by a previous call to cudaMallocHost() or cudaHostAlloc().



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaMalloc, cudaMallocPitch, cudaFree, cudaMallocArray, cudaFreeArray, cudaMallocHost ( C API), cudaMalloc3D, cudaMalloc3DArray, cudaHostAlloc

## \_\_host\_\_cudaError\_t cudaFreeMipmappedArray (cudaMipmappedArray\_t mipmappedArray)

Frees a mipmapped array on the device.

#### **Parameters**

#### mipmappedArray

- Pointer to mipmapped array to free

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInitializationError

#### Description

Frees the CUDA mipmapped array mipmappedArray, which must have been returned by a previous call to cudaMallocMipmappedArray(). If cudaFreeMipmappedArray(mipmappedArray) has already been called before, cudaErrorInvalidValue is returned.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaMalloc, cudaMallocPitch, cudaFree, cudaMallocArray, cudaMallocHost ( C API), cudaFreeHost, cudaHostAlloc

\_\_host\_\_cudaError\_t cudaGetMipmappedArrayLevel (cudaArray\_t \*levelArray, cudaMipmappedArray\_const\_t mipmappedArray, unsigned int level)

Gets a mipmap level of a CUDA mipmapped array.

#### **Parameters**

#### levelArray

- Returned mipmap level CUDA array

#### mipmappedArray

- CUDA mipmapped array

#### level

- Mipmap level

#### Returns

cudaSuccess, cudaErrorInvalidValue

#### Description

Returns in \*levelArray a CUDA array that represents a single mipmap level of the CUDA mipmapped array mipmappedArray.

If level is greater than the maximum number of levels in this mipmapped array, cudaErrorInvalidValue is returned.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaMalloc3D, cudaMalloc, cudaMallocPitch, cudaFree, cudaFreeArray, cudaMallocHost ( C API), cudaFreeHost, cudaHostAlloc, make\_cudaExtent

## \_\_host\_\_cudaError\_t cudaGetSymbolAddress (void \*\*devPtr, const void \*symbol)

Finds the address associated with a CUDA symbol.

#### **Parameters**

#### devPtr

- Return device pointer associated with symbol **symbol** 

- Device symbol address

#### Returns

cudaSuccess, cudaErrorInvalidSymbol

#### Description

Returns in \*devPtr the address of symbol symbol on the device. symbol is a variable that resides in global or constant memory space. If symbol cannot be found, or if symbol is not declared in the global or constant memory space, \*devPtr is unchanged and the error cudaErrorInvalidSymbol is returned.



- Note that this function may also return error codes from previous, asynchronous launches.
- Use of a string naming a variable as the symbol paramater was deprecated in CUDA 4.1 and removed in CUDA 5.0.

#### See also:

cudaGetSymbolAddress (C++ API), cudaGetSymbolSize (C API)

### \_\_host\_\_cudaError\_t cudaGetSymbolSize (size\_t \*size, const void \*symbol)

Finds the size of the object associated with a CUDA symbol.

#### **Parameters**

#### size

- Size of object associated with symbol

#### symbol

- Device symbol address

#### **Returns**

cudaSuccess, cudaErrorInvalidSymbol

#### Description

Returns in \*size the size of symbol symbol symbol is a variable that resides in global or constant memory space. If symbol cannot be found, or if symbol is not declared in global or constant memory space, \*size is unchanged and the error cudaErrorInvalidSymbol is returned.



- Note that this function may also return error codes from previous, asynchronous launches.
- ▶ Use of a string naming a variable as the symbol paramater was deprecated in CUDA 4.1 and removed in CUDA 5.0.

#### See also:

cudaGetSymbolAddress ( C API), cudaGetSymbolSize ( C++ API)

## \_\_host\_\_cudaError\_t cudaHostAlloc (void \*\*pHost, size\_t size, unsigned int flags)

Allocates page-locked memory on the host.

#### **Parameters**

#### pHost

- Device pointer to allocated memory

#### size

- Requested allocation size in bytes

#### flags

- Requested properties of allocated memory

#### Returns

cudaSuccess, cudaErrorMemoryAllocation

#### Description

Allocates size bytes of host memory that is page-locked and accessible to the device. The driver tracks the virtual memory ranges allocated with this function and automatically accelerates calls to functions such as cudaMemcpy(). Since the memory can be accessed directly by the device, it can be read or written with much higher bandwidth than pageable memory obtained with functions such as malloc(). Allocating excessive amounts of pinned memory may degrade system performance, since it reduces

the amount of memory available to the system for paging. As a result, this function is best used sparingly to allocate staging areas for data exchange between host and device.

The flags parameter enables different options to be specified that affect the allocation, as follows.

- cudaHostAllocDefault: This flag's value is defined to be 0 and causes cudaHostAlloc() to emulate cudaMallocHost().
- cudaHostAllocPortable: The memory returned by this call will be considered as pinned memory by all CUDA contexts, not just the one that performed the allocation.
- cudaHostAllocMapped: Maps the allocation into the CUDA address space. The device pointer to the memory may be obtained by calling cudaHostGetDevicePointer().
- cudaHostAllocWriteCombined: Allocates the memory as write-combined (WC). WC memory can be transferred across the PCI Express bus more quickly on some system configurations, but cannot be read efficiently by most CPUs. WC memory is a good option for buffers that will be written by the CPU and read by the device via mapped pinned memory or host->device transfers.

All of these flags are orthogonal to one another: a developer may allocate memory that is portable, mapped and/or write-combined with no restrictions.

cudaSetDeviceFlags() must have been called with the cudaDeviceMapHost flag in order for the cudaHostAllocMapped flag to have any effect.

The cudaHostAllocMapped flag may be specified on CUDA contexts for devices that do not support mapped pinned memory. The failure is deferred to cudaHostGetDevicePointer() because the memory may be mapped into other CUDA contexts via the cudaHostAllocPortable flag.

Memory allocated by this function must be freed with cudaFreeHost().



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaSetDeviceFlags, cudaMallocHost ( C API), cudaFreeHost

## \_\_host\_\_cudaError\_t cudaHostGetDevicePointer (void \*\*pDevice, void \*pHost, unsigned int flags)

Passes back device pointer of mapped host memory allocated by cudaHostAlloc or registered by cudaHostRegister.

#### **Parameters**

#### pDevice

- Returned device pointer for mapped memory

#### pHost

Requested host pointer mapping

#### flags

- Flags for extensions (must be 0 for now)

#### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorMemoryAllocation

#### Description

Passes back the device pointer corresponding to the mapped, pinned host buffer allocated by cudaHostAlloc() or registered by cudaHostRegister().

cudaHostGetDevicePointer() will fail if the cudaDeviceMapHost flag was not specified before deferred context creation occurred, or if called on a device that does not support mapped, pinned memory.

For devices that have a non-zero value for the device attribute cudaDevAttrCanUseHostPointerForRegisteredMem, the memory can also be accessed from the device using the host pointer pHost. The device pointer returned by cudaHostGetDevicePointer() may or may not match the original host pointer pHost and depends on the devices visible to the application. If all devices visible to the application have a non-zero value for the device attribute, the device pointer returned by cudaHostGetDevicePointer() will match the original pointer pHost. If any device visible to the application has a zero value for the device attribute, the device pointer returned by cudaHostGetDevicePointer() will not match the original host pointer pHost, but it will be suitable for use on all devices provided Unified Virtual Addressing is enabled. In such systems, it is valid to access the memory using either pointer on devices that have a non-zero value for the device attribute. Note however that such devices should access the memory using only of the two pointers and not both.

flags provides for future releases. For now, it must be set to 0.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaSetDeviceFlags, cudaHostAlloc

## \_\_host\_\_cudaError\_t cudaHostGetFlags (unsigned int \*pFlags, void \*pHost)

Passes back flags used to allocate pinned host memory allocated by cudaHostAlloc.

#### **Parameters**

#### pFlags

- Returned flags word

#### pHost

- Host pointer

#### Returns

cudaSuccess, cudaErrorInvalidValue

#### Description

cudaHostGetFlags() will fail if the input pointer does not reside in an address range allocated by cudaHostAlloc().



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaHostAlloc

## \_\_host\_\_cudaError\_t cudaHostRegister (void \*ptr, size\_t size, unsigned int flags)

Registers an existing host memory range for use by CUDA.

#### **Parameters**

#### ptr

- Host pointer to memory to page-lock

#### size

- Size in bytes of the address range to page-lock in bytes

#### flags

- Flags for allocation request

#### **Returns**

 $cuda Success, cuda Error Invalid Value, cuda Error Memory Allocation, \\ cuda Error Host Memory Already Registered$ 

#### Description

Page-locks the memory range specified by ptr and size and maps it for the device(s) as specified by flags. This memory range also is added to the same tracking mechanism as cudaHostAlloc() to automatically accelerate calls to functions such as cudaMemcpy(). Since the memory can be accessed directly by the device, it can be read or written with much higher bandwidth than pageable memory that has not been registered. Page-locking excessive amounts of memory may degrade system performance, since it reduces the amount of memory available to the system for paging. As a result, this function is best used sparingly to register staging areas for data exchange between host and device.

The flags parameter enables different options to be specified that affect the allocation, as follows.

- cudaHostRegisterDefault: On a system with unified virtual addressing, the memory will be both mapped and portable. On a system with no unified virtual addressing, the memory will be neither mapped nor portable.
- cudaHostRegisterPortable: The memory returned by this call will be considered as pinned memory by all CUDA contexts, not just the one that performed the allocation.
- cudaHostRegisterMapped: Maps the allocation into the CUDA address space. The device pointer to the memory may be obtained by calling cudaHostGetDevicePointer().
- cudaHostRegisterIoMemory: The passed memory pointer is treated as pointing to some memory-mapped I/O space, e.g. belonging to a third-party PCIe device, and it will marked as non cache-coherent and contiguous.

All of these flags are orthogonal to one another: a developer may page-lock memory that is portable or mapped with no restrictions.

The CUDA context must have been created with the cudaMapHost flag in order for the cudaHostRegisterMapped flag to have any effect.

The cudaHostRegisterMapped flag may be specified on CUDA contexts for devices that do not support mapped pinned memory. The failure is deferred to

cudaHostGetDevicePointer() because the memory may be mapped into other CUDA contexts via the cudaHostRegisterPortable flag.

For devices that have a non-zero value for the device attribute cudaDevAttrCanUseHostPointerForRegisteredMem, the memory can also be accessed from the device using the host pointer ptr. The device pointer returned by cudaHostGetDevicePointer() may or may not match the original host pointer ptr and depends on the devices visible to the application. If all devices visible to the application have a non-zero value for the device attribute, the device pointer returned by cudaHostGetDevicePointer() will match the original pointer ptr. If any device visible to the application has a zero value for the device attribute, the device pointer returned by cudaHostGetDevicePointer() will not match the original host pointer ptr, but it will be suitable for use on all devices provided Unified Virtual Addressing is enabled. In such systems, it is valid to access the memory using either pointer on devices that have a non-zero value for the device attribute. Note however that such devices should access the memory using only of the two pointers and not both.

The memory page-locked by this function must be unregistered with cudaHostUnregister().



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaHostUnregister, cudaHostGetFlags, cudaHostGetDevicePointer

### 

Unregisters a memory range that was registered with cudaHostRegister.

#### **Parameters**

ptr

- Host pointer to memory to unregister

#### Returns

cudaSuccess, cudaErrorInvalidValue

#### Description

Unmaps the memory range whose base address is specified by ptr, and makes it pageable again.

The base address must be the same one specified to cudaHostRegister().



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaHostUnregister

## \_\_host\_\_\_\_device\_\_cudaError\_t cudaMalloc (void \*\*devPtr, size\_t size)

Allocate memory on the device.

#### **Parameters**

#### devPtr

- Pointer to allocated device memory

#### size

- Requested allocation size in bytes

#### **Returns**

cudaSuccess, cudaErrorMemoryAllocation

#### Description

Allocates size bytes of linear memory on the device and returns in \*devPtr a pointer to the allocated memory. The allocated memory is suitably aligned for any kind of variable. The memory is not cleared. cudaMalloc() returns cudaErrorMemoryAllocation in case of failure.

The device version of cudaFree cannot be used with a \*devPtr allocated using the host API, and vice versa.

#### See also:

cudaMallocPitch, cudaFree, cudaMallocArray, cudaFreeArray, cudaMalloc3D, cudaMalloc3DArray, cudaMallocHost ( C API), cudaFreeHost, cudaHostAlloc

## \_\_host\_\_cudaError\_t cudaMalloc3D (cudaPitchedPtr \*pitchedDevPtr, cudaExtent extent)

Allocates logical 1D, 2D, or 3D memory objects on the device.

#### **Parameters**

#### pitchedDevPtr

- Pointer to allocated pitched device memory

#### extent

- Requested allocation size (width field in bytes)

#### Returns

cudaSuccess, cudaErrorMemoryAllocation

#### Description

Allocates at least width \* height \* depth bytes of linear memory on the device and returns a cudaPitchedPtr in which ptr is a pointer to the allocated memory. The function may pad the allocation to ensure hardware alignment requirements are met. The pitch returned in the pitch field of pitchedDevPtr is the width in bytes of the allocation.

The returned cudaPitchedPtr contains additional fields xsize and ysize, the logical width and height of the allocation, which are equivalent to the width and height extent parameters provided by the programmer during allocation.

For allocations of 2D and 3D objects, it is highly recommended that programmers perform allocations using cudaMalloc3D() or cudaMallocPitch(). Due to alignment restrictions in the hardware, this is especially true if the application will be performing memory copies involving 2D or 3D objects (whether linear memory or CUDA arrays).



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaMallocPitch, cudaFree, cudaMemcpy3D, cudaMemset3D, cudaMalloc3DArray, cudaMallocArray, cudaFreeArray, cudaMallocHost ( C API), cudaFreeHost, cudaHostAlloc, make\_cudaPitchedPtr, make\_cudaExtent

# \_\_host\_\_cudaError\_t cudaMalloc3DArray (cudaArray\_t \*array, const cudaChannelFormatDesc \*desc, cudaExtent extent, unsigned int flags)

Allocate an array on the device.

#### **Parameters**

#### array

- Pointer to allocated array in device memory

#### desc

- Requested channel format

#### extent

- Requested allocation size (width field in elements)

#### flags

- Flags for extensions

#### Returns

cudaSuccess, cudaErrorMemoryAllocation

#### Description

Allocates a CUDA array according to the cudaChannelFormatDesc structure desc and returns a handle to the new CUDA array in \*array.

The cudaChannelFormatDesc is defined as:

```
f struct cudaChannelFormatDesc {
    int x, y, z, w;
    enum cudaChannelFormatKind
    f;
};
```

where cudaChannelFormatKind is one of cudaChannelFormatKindSigned, cudaChannelFormatKindUnsigned, or cudaChannelFormatKindFloat.

cudaMalloc3DArray() can allocate the following:

- ► A 1D array is allocated if the height and depth extents are both zero.
- ► A 2D array is allocated if only the depth extent is zero.
- ► A 3D array is allocated if all three extents are non-zero.
- ▶ A 1D layered CUDA array is allocated if only the height extent is zero and the cudaArrayLayered flag is set. Each layer is a 1D array. The number of layers is determined by the depth extent.
- ▶ A 2D layered CUDA array is allocated if all three extents are non-zero and the cudaArrayLayered flag is set. Each layer is a 2D array. The number of layers is determined by the depth extent.

- A cubemap CUDA array is allocated if all three extents are non-zero and the cudaArrayCubemap flag is set. Width must be equal to height, and depth must be six. A cubemap is a special type of 2D layered CUDA array, where the six layers represent the six faces of a cube. The order of the six layers in memory is the same as that listed in cudaGraphicsCubeFace.
- A cubemap layered CUDA array is allocated if all three extents are non-zero, and both, cudaArrayCubemap and cudaArrayLayered flags are set. Width must be equal to height, and depth must be a multiple of six. A cubemap layered CUDA array is a special type of 2D layered CUDA array that consists of a collection of cubemaps. The first six layers represent the first cubemap, the next six layers form the second cubemap, and so on.

The flags parameter enables different options to be specified that affect the allocation, as follows.

- cudaArrayDefault: This flag's value is defined to be 0 and provides default array allocation
- cudaArrayLayered: Allocates a layered CUDA array, with the depth extent indicating the number of layers
- cudaArrayCubemap: Allocates a cubemap CUDA array. Width must be equal to height, and depth must be six. If the cudaArrayLayered flag is also set, depth must be a multiple of six.
- cudaArraySurfaceLoadStore: Allocates a CUDA array that could be read from or written to using a surface reference.
- cudaArrayTextureGather: This flag indicates that texture gather operations will be performed on the CUDA array. Texture gather can only be performed on 2D CUDA arrays.

The width, height and depth extents must meet certain size requirements as listed in the following table. All values are specified in elements.

Note that 2D CUDA arrays have different size requirements if the cudaArrayTextureGather flag is set. In that case, the valid range for (width, height, depth) is ((1,maxTexture2DGather[0]), (1,maxTexture2DGather[1]), 0).

CUDA array type	Valid extents that must always be met {(width range in elements), (height range), (depth range)}	Valid extents with cudaArraySurfaceLoadStore set {(width range in elements), (height range), (depth range)}
1D	{ (1,maxTexture1D), 0, 0 }	{ (1,maxSurface1D), 0, 0 }
2D	{ (1,maxTexture2D[0]), (1,maxTexture2D[1]), 0 }	{ (1,maxSurface2D[0]), (1,maxSurface2D[1]), 0 }

CUDA array type	Valid extents that must always be met {(width range in elements), (height range), (depth range)}	Valid extents with cudaArraySurfaceLoadStore set {(width range in elements), (height range), (depth range)}
3D	{ (1,maxTexture3D[0]), (1,maxTexture3D[1]), (1,maxTexture3D[2]) } OR { (1,maxTexture3DAlt[0]), (1,maxTexture3DAlt[1]), (1,maxTexture3DAlt[2]) }	{ (1,maxSurface3D[0]), (1,maxSurface3D[1]), (1,maxSurface3D[2]) }
1D Layered	{ (1,maxTexture1DLayered[0]), 0, (1,maxTexture1DLayered[1]) }	{ (1,maxSurface1DLayered[0]), 0, (1,maxSurface1DLayered[1]) }
2D Layered	{ (1,maxTexture2DLayered[0]), (1,maxTexture2DLayered[1]), (1,maxTexture2DLayered[2]) }	{ (1,maxSurface2DLayered[0]), (1,maxSurface2DLayered[1]), (1,maxSurface2DLayered[2]) }
Cubemap	{ (1,maxTextureCubemap), (1,maxTextureCubemap), 6 }	{ (1,maxSurfaceCubemap), (1,maxSurfaceCubemap), 6 }
Cubemap Layered	{ (1,maxTextureCubemapLayered[0]), (1,maxTextureCubemapLayered[0]), (1,maxTextureCubemapLayered[1]) }	{ (1,maxSurfaceCubemapLayered[0]), (1,maxSurfaceCubemapLayered[0]), (1,maxSurfaceCubemapLayered[1]) }



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaMalloc3D, cudaMalloc, cudaMallocPitch, cudaFree, cudaFreeArray, cudaMallocHost ( C API), cudaFreeHost, cudaHostAlloc, make\_cudaExtent

\_\_host\_\_cudaError\_t cudaMallocArray (cudaArray\_t \*array, const cudaChannelFormatDesc \*desc, size\_t width, size\_t height, unsigned int flags)

Allocate an array on the device.

#### **Parameters**

#### array

- Pointer to allocated array in device memory

#### desc

- Requested channel format

#### width

- Requested array allocation width

#### height

- Requested array allocation height

#### flags

- Requested properties of allocated array

#### Returns

cudaSuccess, cudaErrorMemoryAllocation

#### Description

Allocates a CUDA array according to the cudaChannelFormatDesc structure desc and returns a handle to the new CUDA array in \*array.

The cudaChannelFormatDesc is defined as:

where cudaChannelFormatKind is one of cudaChannelFormatKindSigned, cudaChannelFormatKindUnsigned, or cudaChannelFormatKindFloat.

The flags parameter enables different options to be specified that affect the allocation, as follows.

- cudaArrayDefault: This flag's value is defined to be 0 and provides default array
- cudaArraySurfaceLoadStore: Allocates an array that can be read from or written to using a surface reference
- cudaArrayTextureGather: This flag indicates that texture gather operations will be performed on the array.

width and height must meet certain size requirements. See cudaMalloc3DArray() for more details.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaMalloc, cudaMallocPitch, cudaFree, cudaFreeArray, cudaMallocHost ( C API), cudaFreeHost, cudaMalloc3D, cudaMalloc3DArray, cudaHostAlloc

## \_\_host\_\_cudaError\_t cudaMallocHost (void \*\*ptr, size\_t size)

Allocates page-locked memory on the host.

#### **Parameters**

#### ptr

- Pointer to allocated host memory

#### size

- Requested allocation size in bytes

#### **Returns**

cudaSuccess, cudaErrorMemoryAllocation

#### Description

Allocates size bytes of host memory that is page-locked and accessible to the device. The driver tracks the virtual memory ranges allocated with this function and automatically accelerates calls to functions such as cudaMemcpy\*(). Since the memory can be accessed directly by the device, it can be read or written with much higher bandwidth than pageable memory obtained with functions such as malloc(). Allocating excessive amounts of memory with cudaMallocHost() may degrade system performance, since it reduces the amount of memory available to the system for paging. As a result, this function is best used sparingly to allocate staging areas for data exchange between host and device.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaMalloc, cudaMallocPitch, cudaMallocArray, cudaMalloc3D, cudaMalloc3DArray, cudaHostAlloc, cudaFree, cudaFreeArray, cudaMallocHost (C++ API), cudaFreeHost, cudaHostAlloc

## \_\_host\_\_cudaError\_t cudaMallocManaged (void \*\*devPtr, size\_t size, unsigned int flags)

Allocates memory that will be automatically managed by the Unified Memory system.

#### **Parameters**

#### devPtr

- Pointer to allocated device memory

#### size

- Requested allocation size in bytes

#### flags

- Must be either cudaMemAttachGlobal or cudaMemAttachHost (defaults to cudaMemAttachGlobal)

#### **Returns**

cudaSuccess, cudaErrorMemoryAllocation cudaErrorNotSupported cudaErrorInvalidValue

#### Description

Allocates size bytes of managed memory on the device and returns in \*devPtr a pointer to the allocated memory. If the device doesn't support allocating managed memory, cudaErrorNotSupported is returned. Support for managed memory can be queried using the device attribute cudaDevAttrManagedMemory. The allocated memory is suitably aligned for any kind of variable. The memory is not cleared. If size is 0, cudaMallocManaged returns cudaErrorInvalidValue. The pointer is valid on the CPU and on all GPUs in the system that support managed memory. All accesses to this pointer must obey the Unified Memory programming model.

flags specifies the default stream association for this allocation. flags must be one of cudaMemAttachGlobal or cudaMemAttachHost. The default value for flags is cudaMemAttachGlobal. If cudaMemAttachGlobal is specified, then this memory is accessible from any stream on any device. If cudaMemAttachHost is specified, then the allocation should not be accessed from devices that have a zero value for the device attribute cudaDevAttrConcurrentManagedAccess; an explicit call to cudaStreamAttachMemAsync will be required to enable access on such devices.

If the association is later changed via cudaStreamAttachMemAsync to a single stream, the default association, as specifed during cudaMallocManaged, is restored when that stream is destroyed. For \_\_managed\_\_ variables, the default association is always cudaMemAttachGlobal. Note that destroying a stream is an asynchronous operation, and as a result, the change to default association won't happen until all work in the stream has completed.

Memory allocated with cudaMallocManaged should be released with cudaFree.

Device memory oversubscription is possible for GPUs that have a non-zero value for the device attribute cudaDevAttrConcurrentManagedAccess. Managed memory on such GPUs may be evicted from device memory to host memory at any time by the Unified Memory driver in order to make room for other allocations.

In a multi-GPU system where all GPUs have a non-zero value for the device attribute cudaDevAttrConcurrentManagedAccess, managed memory may not be populated when this API returns and instead may be populated on access. In such systems, managed memory can migrate to any processor's memory at any time. The Unified Memory driver will employ heuristics to maintain data locality and prevent excessive page faults to the extent possible. The application can also guide the driver about memory usage patterns via cudaMemAdvise. The application can also explicitly migrate memory to a desired processor's memory via cudaMemPrefetchAsync.

In a multi-GPU system where all of the GPUs have a zero value for the device attribute cudaDevAttrConcurrentManagedAccess and all the GPUs have peer-to-peer support with each other, the physical storage for managed memory is created on the GPU which is active at the time cudaMallocManaged is called. All other GPUs will reference the data at reduced bandwidth via peer mappings over the PCIe bus. The Unified Memory driver does not migrate memory among such GPUs.

In a multi-GPU system where not all GPUs have peer-to-peer support with each other and where the value of the device attribute cudaDevAttrConcurrentManagedAccess is zero for at least one of those GPUs, the location chosen for physical storage of managed memory is system-dependent.

- On Linux, the location chosen will be device memory as long as the current set of active contexts are on devices that either have peer-to-peer support with each other or have a non-zero value for the device attribute cudaDevAttrConcurrentManagedAccess. If there is an active context on a GPU that does not have a non-zero value for that device attribute and it does not have peer-to-peer support with the other devices that have active contexts on them, then the location for physical storage will be 'zero-copy' or host memory. Note that this means that managed memory that is located in device memory is migrated to host memory if a new context is created on a GPU that doesn't have a non-zero value for the device attribute and does not support peer-to-peer with at least one of the other devices that has an active context. This in turn implies that context creation may fail if there is insufficient host memory to migrate all managed allocations.
- On Windows, the physical storage is always created in 'zero-copy' or host memory. All GPUs will reference the data at reduced bandwidth over the PCIe bus. In these circumstances, use of the environment variable CUDA\_VISIBLE\_DEVICES is recommended to restrict CUDA to only use those GPUs that have peer-to-peer support. Alternatively, users can also set CUDA\_MANAGED\_FORCE\_DEVICE\_ALLOC to a non-zero value to force the

driver to always use device memory for physical storage. When this environment variable is set to a non-zero value, all devices used in that process that support managed memory have to be peer-to-peer compatible with each other. The error cudaErrorInvalidDevice will be returned if a device that supports managed memory is used and it is not peer-to-peer compatible with any of the other managed memory supporting devices that were previously used in that process, even if cudaDeviceReset has been called on those devices. These environment variables are described in the CUDA programming guide under the "CUDA environment variables" section.

#### See also:

cudaMallocPitch, cudaFree, cudaMallocArray, cudaFreeArray, cudaMalloc3D, cudaMalloc3DArray, cudaMallocHost ( C API), cudaFreeHost, cudaHostAlloc, cudaDeviceGetAttribute, cudaStreamAttachMemAsync

\_\_host\_\_cudaError\_t cudaMallocMipmappedArray (cudaMipmappedArray\_t \*mipmappedArray, const cudaChannelFormatDesc \*desc, cudaExtent extent, unsigned int numLevels, unsigned int flags)

Allocate a mipmapped array on the device.

#### **Parameters**

#### mipmappedArray

- Pointer to allocated mipmapped array in device memory

#### desc

- Requested channel format

#### extent

- Requested allocation size (width field in elements)

#### numLevels

- Number of mipmap levels to allocate

#### flags

Flags for extensions

#### Returns

cudaSuccess, cudaErrorMemoryAllocation

#### Description

Allocates a CUDA mipmapped array according to the cudaChannelFormatDesc structure desc and returns a handle to the new CUDA mipmapped array in

\*mipmappedArray. numLevels specifies the number of mipmap levels to be allocated. This value is clamped to the range [1, 1 + floor(log2(max(width, height, depth)))].

The cudaChannelFormatDesc is defined as:

```
f struct cudaChannelFormatDesc {
    int x, y, z, w;
    enum cudaChannelFormatKind
    f;
};
```

where cudaChannelFormatKind is one of cudaChannelFormatKindSigned, cudaChannelFormatKindUnsigned, or cudaChannelFormatKindFloat.

cudaMallocMipmappedArray() can allocate the following:

- ▶ A 1D mipmapped array is allocated if the height and depth extents are both zero.
- A 2D mipmapped array is allocated if only the depth extent is zero.
- ► A 3D mipmapped array is allocated if all three extents are non-zero.
- ▶ A 1D layered CUDA mipmapped array is allocated if only the height extent is zero and the cudaArrayLayered flag is set. Each layer is a 1D mipmapped array. The number of layers is determined by the depth extent.
- A 2D layered CUDA mipmapped array is allocated if all three extents are non-zero and the cudaArrayLayered flag is set. Each layer is a 2D mipmapped array. The number of layers is determined by the depth extent.
- A cubemap CUDA mipmapped array is allocated if all three extents are non-zero and the cudaArrayCubemap flag is set. Width must be equal to height, and depth must be six. The order of the six layers in memory is the same as that listed in cudaGraphicsCubeFace.
- A cubemap layered CUDA mipmapped array is allocated if all three extents are non-zero, and both, cudaArrayCubemap and cudaArrayLayered flags are set. Width must be equal to height, and depth must be a multiple of six. A cubemap layered CUDA mipmapped array is a special type of 2D layered CUDA mipmapped array that consists of a collection of cubemap mipmapped arrays. The first six layers represent the first cubemap mipmapped array, the next six layers form the second cubemap mipmapped array, and so on.

The flags parameter enables different options to be specified that affect the allocation, as follows.

- cudaArrayDefault: This flag's value is defined to be 0 and provides default mipmapped array allocation
- cudaArrayLayered: Allocates a layered CUDA mipmapped array, with the depth extent indicating the number of layers
- cudaArrayCubemap: Allocates a cubemap CUDA mipmapped array. Width must be equal to height, and depth must be six. If the cudaArrayLayered flag is also set, depth must be a multiple of six.

- cudaArraySurfaceLoadStore: This flag indicates that individual mipmap levels
  of the CUDA mipmapped array will be read from or written to using a surface
  reference.
- cudaArrayTextureGather: This flag indicates that texture gather operations will be performed on the CUDA array. Texture gather can only be performed on 2D CUDA mipmapped arrays, and the gather operations are performed only on the most detailed mipmap level.

The width, height and depth extents must meet certain size requirements as listed in the following table. All values are specified in elements.

CUDA array type	Valid extents {(width range in elements), (height range), (depth range)}
1D	{ (1,maxTexture1DMipmap), 0, 0 }
2D	{ (1,maxTexture2DMipmap[0]), (1,maxTexture2DMipmap[1]), 0 }
3D	{ (1,maxTexture3D[0]), (1,maxTexture3D[1]), (1,maxTexture3D[2]) }
1D Layered	{ (1,maxTexture1DLayered[0]), 0, (1,maxTexture1DLayered[1]) }
2D Layered	{ (1,maxTexture2DLayered[0]), (1,maxTexture2DLayered[1]), (1,maxTexture2DLayered[2]) }
Cubemap	{ (1,maxTextureCubemap), (1,maxTextureCubemap), 6 }
Cubemap Layered	{ (1,maxTextureCubemapLayered[0]), (1,maxTextureCubemapLayered[0]), (1,maxTextureCubemapLayered[1]) }



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaMalloc3D, cudaMalloc, cudaMallocPitch, cudaFree, cudaFreeArray, cudaMallocHost ( C API), cudaFreeHost, cudaHostAlloc, make\_cudaExtent

\_\_host\_\_cudaError\_t cudaMallocPitch (void \*\*devPtr,
size\_t \*pitch, size\_t width, size\_t height)

Allocates pitched memory on the device.

#### **Parameters**

#### devPtr

- Pointer to allocated pitched device memory

#### pitch

- Pitch for allocation

#### width

- Requested pitched allocation width (in bytes)

#### height

- Requested pitched allocation height

#### **Returns**

cudaSuccess, cudaErrorMemoryAllocation

#### Description

Allocates at least width (in bytes) \* height bytes of linear memory on the device and returns in \*devPtr a pointer to the allocated memory. The function may pad the allocation to ensure that corresponding pointers in any given row will continue to meet the alignment requirements for coalescing as the address is updated from row to row. The pitch returned in \*pitch by cudaMallocPitch() is the width in bytes of the allocation. The intended usage of pitch is as a separate parameter of the allocation, used to compute addresses within the 2D array. Given the row and column of an array element of type T, the address is computed as:

```
T* pElement = (T*)((char*)BaseAddress + Row * pitch) + Column;
```

For allocations of 2D arrays, it is recommended that programmers consider performing pitch allocations using cudaMallocPitch(). Due to pitch alignment restrictions in the hardware, this is especially true if the application will be performing 2D memory copies between different regions of device memory (whether linear memory or CUDA arrays).



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaMalloc, cudaFree, cudaMallocArray, cudaFreeArray, cudaMallocHost ( C API), cudaFreeHost, cudaMalloc3D, cudaMalloc3DArray, cudaHostAlloc

# \_\_host\_\_cudaError\_t cudaMemAdvise (const void \*devPtr, size\_t count, cudaMemoryAdvise advice, int device)

Advise about the usage of a given memory range.

#### **Parameters**

#### devPtr

- Pointer to memory to set the advice for

#### count

- Size in bytes of the memory range

#### advice

- Advice to be applied for the specified memory range

#### device

- Device to apply the advice for

#### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevice

#### Description

Advise the Unified Memory subsystem about the usage pattern for the memory range starting at devPtr with a size of count bytes. The start address and end address of the memory range will be rounded down and rounded up respectively to be aligned to CPU page size before the advice is applied. The memory range must refer to managed memory allocated via cudaMallocManaged or declared via \_\_managed\_\_ variables.

The advice parameter can take the following values:

cudaMemAdviseSetReadMostly: This implies that the data is mostly going to be read from and only occasionally written to. Any read accesses from any processor to this region will create a read-only copy of at least the accessed pages in that processor's memory. Additionally, if cudaMemPrefetchAsync is called on this region, it will create a read-only copy of the data on the destination processor. If any processor writes to this region, all copies of the corresponding page will be invalidated except for the one where the write occurred. The device argument is ignored for this advice. Note that for a page to be read-duplicated, the accessing processor must either be the CPU or a GPU that has a non-zero value for the device attribute cudaDevAttrConcurrentManagedAccess. Also, if a context is created on a device that does not have the device attribute cudaDevAttrConcurrentManagedAccess set, then read-duplication will not occur until all such contexts are destroyed.

- cudaMemAdviceUnsetReadMostly: Undoes the effect of cudaMemAdviceReadMostly and also prevents the Unified Memory driver from attempting heuristic read-duplication on the memory range. Any read-duplicated copies of the data will be collapsed into a single copy. The location for the collapsed copy will be the preferred location if the page has a preferred location and one of the read-duplicated copies was resident at that location. Otherwise, the location chosen is arbitrary.
- cudaMemAdviseSetPreferredLocation: This advice sets the preferred location for the data to be the memory belonging to device. Passing in cudaCpuDeviceId for device sets the preferred location as host memory. If device is a GPU, then it must have a non-zero value for the device attribute cudaDevAttrConcurrentManagedAccess. Setting the preferred location does not cause data to migrate to that location immediately. Instead, it guides the migration policy when a fault occurs on that memory region. If the data is already in its preferred location and the faulting processor can establish a mapping without requiring the data to be migrated, then data migration will be avoided. On the other hand, if the data is not in its preferred location or if a direct mapping cannot be established, then it will be migrated to the processor accessing it. It is important to note that setting the preferred location does not prevent data prefetching done using cudaMemPrefetchAsync. Having a preferred location can override the page thrash detection and resolution logic in the Unified Memory driver. Normally, if a page is detected to be constantly thrashing between for example host and device memory, the page may eventually be pinned to host memory by the Unified Memory driver. But if the preferred location is set as device memory, then the page will continue to thrash indefinitely. If cudaMemAdviseSetReadMostly is also set on this memory region or any subset of it, then the policies associated with that advice will override the policies of this advice.
- cudaMemAdviseUnsetPreferredLocation: Undoes the effect of cudaMemAdviseSetPreferredLocation and changes the preferred location to none.
- be accessed by device. Passing in cudaCpuDeviceId for device will set the advice for the CPU. If device is a GPU, then the device attribute cudaDevAttrConcurrentManagedAccess must be non-zero. This advice does not cause data migration and has no impact on the location of the data per se. Instead, it causes the data to always be mapped in the specified processor's page tables, as long as the location of the data permits a mapping to be established. If the data gets migrated for any reason, the mappings are updated accordingly. This advice is recommended in scenarios where data locality is not important, but avoiding faults is. Consider for example a system containing multiple GPUs with peer-to-peer access enabled, where the data located on one GPU is occasionally accessed by peer GPUs. In such scenarios, migrating data over to the other GPUs is not as important because the accesses are infrequent and the overhead of migration may be too high. But preventing faults can still help improve performance, and so having

a mapping set up in advance is useful. Note that on CPU access of this data, the data may be migrated to host memory because the CPU typically cannot access device memory directly. Any GPU that had the cudaMemAdviceSetAccessedBy flag set for this data will now have its mapping updated to point to the page in host memory. If cudaMemAdviseSetReadMostly is also set on this memory region or any subset of it, then the policies associated with that advice will override the policies of this advice. Additionally, if the preferred location of this memory region or any subset of it is also device, then the policies associated with cudaMemAdviseSetPreferredLocation will override the policies of this advice.

cudaMemAdviseUnsetAccessedBy: Undoes the effect of cudaMemAdviseSetAccessedBy. Any mappings to the data from device may be removed at any time causing accesses to result in non-fatal page faults.



- Note that this function may also return error codes from previous, asynchronous launches.
- ▶ This function exhibits asynchronous behavior for most use cases.
- This function uses standard default stream semantics.

#### See also:

cudaMemcpy, cudaMemcpyPeer, cudaMemcpyAsync, cudaMemcpy3DPeerAsync, cudaMemPrefetchAsync

### \_\_host\_\_cudaError\_t cudaMemcpy (void \*dst, const void \*src, size\_t count, cudaMemcpyKind kind)

Copies data between host and device.

#### **Parameters**

#### dst

- Destination memory address

#### src

- Source memory address

#### count

- Size in bytes to copy

#### kind

- Type of transfer

#### **Returns**

cuda Success, cuda Error Invalid Value, cuda Error Invalid Device Pointer, cuda Error Invalid Memcpy Direction

#### Description

Copies count bytes from the memory area pointed to by src to the memory area pointed to by dst, where kind specifies the direction of the copy, and must be one of cudaMemcpyHostToHost, cudaMemcpyHostToDevice, cudaMemcpyDeviceToHost, cudaMemcpyDeviceToDevice, or cudaMemcpyDefault. Passing cudaMemcpyDefault is recommended, in which case the type of transfer is inferred from the pointer values. However, cudaMemcpyDefault is only allowed on systems that support unified virtual addressing. Calling cudaMemcpy() with dst and src pointers that do not match the direction of the copy results in an undefined behavior.



- Note that this function may also return error codes from previous, asynchronous launches.
- This function exhibits synchronous behavior for most use cases.

#### See also:

cudaMemcpy2D, cudaMemcpyToArray, cudaMemcpy2DToArray, cudaMemcpyFromArray, cudaMemcpyPromArray, cudaMemcpy2DFromArray, cudaMemcpyPromSymbol, cudaMemcpy2DArrayToArray, cudaMemcpyToSymbol, cudaMemcpyAsync, cudaMemcpy2DAsync, cudaMemcpyToArrayAsync, cudaMemcpy2DToArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpy2DFromArrayAsync, cudaMemcpyToSymbolAsync, cudaMemcpyFromSymbolAsync, cudaMemcpyFromSymbolAsync

\_\_host\_\_cudaError\_t cudaMemcpy2D (void \*dst, size\_t dpitch, const void \*src, size\_t spitch, size\_t width, size\_t height, cudaMemcpyKind kind)

Copies data between host and device.

#### **Parameters**

#### dst

- Destination memory address

#### dpitch

- Pitch of destination memory

#### src

- Source memory address

#### spitch

- Pitch of source memory

#### width

- Width of matrix transfer (columns in bytes)

#### height

- Height of matrix transfer (rows)

#### kind

- Type of transfer

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidPitchValue, cudaErrorInvalidDevicePointer, cudaErrorInvalidMemcpyDirection

#### Description

Copies a matrix (height rows of width bytes each) from the memory area pointed to by src to the memory area pointed to by dst, where kind specifies the direction of the copy, and must be one of cudaMemcpyHostToHost, cudaMemcpyHostToDevice, cudaMemcpyDeviceToHost, cudaMemcpyDeviceToDevice, or cudaMemcpyDefault. Passing cudaMemcpyDefault is recommended, in which case the type of transfer is inferred from the pointer values. However, cudaMemcpyDefault is only allowed on systems that support unified virtual addressing. dpitch and spitch are the widths in memory in bytes of the 2D arrays pointed to by dst and src, including any padding added to the end of each row. The memory areas may not overlap. width must not exceed either dpitch or spitch. Calling cudaMemcpy2D() with dst and src pointers that do not match the direction of the copy results in an undefined behavior. cudaMemcpy2D() returns an error if dpitch or spitch exceeds the maximum allowed.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaMemcpy, cudaMemcpyToArray, cudaMemcpy2DToArray, cudaMemcpyFromArray, cudaMemcpy2DFromArray, cudaMemcpyArrayToArray, cudaMemcpy2DArrayToArray, cudaMemcpyToSymbol, cudaMemcpyFromSymbol, cudaMemcpyAsync, cudaMemcpy2DAsync, cudaMemcpyToArrayAsync, cudaMemcpy2DToArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpy2DFromArrayAsync, cudaMemcpyToSymbolAsync, cudaMemcpyFromSymbolAsync

\_\_host\_\_cudaError\_t cudaMemcpy2DArrayToArray (cudaArray\_t dst, size\_t wOffsetDst, size\_t hOffsetDst, cudaArray\_const\_t src, size\_t wOffsetSrc,

### size\_t hOffsetSrc, size\_t width, size\_t height, cudaMemcpyKind kind)

Copies data between host and device.

#### **Parameters**

#### dst

- Destination memory address

#### wOffsetDst

- Destination starting X offset

#### hOffsetDst

- Destination starting Y offset

#### src

- Source memory address

#### wOffsetSrc

- Source starting X offset

#### hOffsetSrc

- Source starting Y offset

#### width

- Width of matrix transfer (columns in bytes)

#### height

- Height of matrix transfer (rows)

#### kind

- Type of transfer

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidMemcpyDirection

#### Description

Copies a matrix (height rows of width bytes each) from the CUDA array srcArray starting at the upper left corner (wOffsetSrc, hOffsetSrc) to the CUDA array dst starting at the upper left corner (wOffsetDst, hOffsetDst), where kind specifies the direction of the copy, and must be one of cudaMemcpyHostToHost, cudaMemcpyHostToDevice, cudaMemcpyDeviceToHost, cudaMemcpyDeviceToDevice, or cudaMemcpyDefault. Passing cudaMemcpyDefault is recommended, in which case the type of transfer is inferred from the pointer values. However, cudaMemcpyDefault is only allowed on systems that support unified virtual addressing. wOffsetDst + width must not exceed the width of the CUDA array dst. wOffsetSrc + width must not exceed the width of the CUDA array dst.



- Note that this function may also return error codes from previous, asynchronous launches.
- This function exhibits synchronous behavior for most use cases.

#### See also:

cudaMemcpy, cudaMemcpy2D, cudaMemcpyToArray, cudaMemcpy2DToArray, cudaMemcpyFromArray, cudaMemcpy2DFromArray, cudaMemcpyArrayToArray, cudaMemcpyToSymbol, cudaMemcpyFromSymbol, cudaMemcpyAsync, cudaMemcpy2DAsync, cudaMemcpyToArrayAsync, cudaMemcpy2DToArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpy2DFromArrayAsync, cudaMemcpyToSymbolAsync, cudaMemcpyFromSymbolAsync

\_\_host\_\_\_\_device\_\_cudaError\_t cudaMemcpy2DAsync (void \*dst, size\_t dpitch, const void \*src, size\_t spitch, size\_t width, size\_t height, cudaMemcpyKind kind, cudaStream\_t stream)

Copies data between host and device.

#### **Parameters**

#### dst

Destination memory address

#### dpitch

- Pitch of destination memory

#### src

- Source memory address

#### spitch

- Pitch of source memory

#### width

- Width of matrix transfer (columns in bytes)

#### height

- Height of matrix transfer (rows)

#### kind

- Type of transfer

#### stream

- Stream identifier

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidPitchValue, cudaErrorInvalidDevicePointer, cudaErrorInvalidMemcpyDirection

#### Description

Copies a matrix (height rows of width bytes each) from the memory area pointed to by src to the memory area pointed to by dst, where kind specifies the direction of the copy, and must be one of cudaMemcpyHostToHost, cudaMemcpyHostToDevice, cudaMemcpyDeviceToHost, cudaMemcpyDeviceToDevice, or cudaMemcpyDefault. Passing cudaMemcpyDefault is recommended, in which case the type of transfer is inferred from the pointer values. However, cudaMemcpyDefault is only allowed on systems that support unified virtual addressing. dpitch and spitch are the widths in memory in bytes of the 2D arrays pointed to by dst and src, including any padding added to the end of each row. The memory areas may not overlap. width must not exceed either dpitch or spitch.

Calling cudaMemcpy2DAsync() with dst and src pointers that do not match the direction of the copy results in an undefined behavior. cudaMemcpy2DAsync() returns an error if dpitch or spitch is greater than the maximum allowed.

cudaMemcpy2DAsync() is asynchronous with respect to the host, so the call may return before the copy is complete. The copy can optionally be associated to a stream by passing a non-zero stream argument. If kind is cudaMemcpyHostToDevice or cudaMemcpyDeviceToHost and stream is non-zero, the copy may overlap with operations in other streams.

The device version of this function only handles device to device copies and cannot be given local or shared pointers.



- Note that this function may also return error codes from previous, asynchronous launches
- ► This function exhibits asynchronous behavior for most use cases.
- ► This function uses standard default stream semantics.

#### See also:

cudaMemcpy, cudaMemcpy2D, cudaMemcpyToArray, cudaMemcpy2DToArray, cudaMemcpyFromArray, cudaMemcpy2DFromArray, cudaMemcpy4rrayToArray, cudaMemcpy2DArrayToArray, cudaMemcpyToSymbol, cudaMemcpyFromSymbol, cudaMemcpyAsync, cudaMemcpyToArrayAsync, cudaMemcpy2DToArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpy2DFromArrayAsync, cudaMemcpyToSymbolAsync, cudaMemcpyFromSymbolAsync

\_\_host\_\_cudaError\_t cudaMemcpy2DFromArray (void \*dst, size\_t dpitch, cudaArray\_const\_t src, size\_t

## wOffset, size\_t hOffset, size\_t width, size\_t height, cudaMemcpyKind kind)

Copies data between host and device.

#### **Parameters**

#### dst

- Destination memory address

#### dpitch

- Pitch of destination memory

#### src

- Source memory address

#### wOffset

- Source starting X offset

#### **hOffset**

- Source starting Y offset

#### width

- Width of matrix transfer (columns in bytes)

#### height

- Height of matrix transfer (rows)

#### kind

- Type of transfer

#### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevicePointer, cudaErrorInvalidPitchValue, cudaErrorInvalidMemcpyDirection

#### Description

Copies a matrix (height rows of width bytes each) from the CUDA array srcArray starting at the upper left corner (wOffset, hOffset) to the memory area pointed to by dst, where kind specifies the direction of the copy, and must be one of cudaMemcpyHostToHost, cudaMemcpyHostToDevice, cudaMemcpyDeviceToHost, cudaMemcpyDefault. Passing cudaMemcpyDefault is recommended, in which case the type of transfer is inferred from the pointer values. However, cudaMemcpyDefault is only allowed on systems that support unified virtual addressing. dpitch is the width in memory in bytes of the 2D array pointed to by dst, including any padding added to the end of each row. wOffset + width must not exceed the width of the CUDA array src. width must not exceed dpitch. cudaMemcpy2DFromArray() returns an error if dpitch exceeds the maximum allowed.



- Note that this function may also return error codes from previous, asynchronous launches.
- This function exhibits synchronous behavior for most use cases.

#### See also:

cudaMemcpy, cudaMemcpy2D, cudaMemcpyToArray, cudaMemcpy2DToArray, cudaMemcpyFromArray, cudaMemcpyArrayToArray, cudaMemcpy2DArrayToArray, cudaMemcpyToSymbol, cudaMemcpyFromSymbol, cudaMemcpyAsync, cudaMemcpy2DAsync, cudaMemcpyToArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpyToSymbolAsync, cudaMemcpyFromSymbolAsync, cudaMemcpyToSymbolAsync, cudaMemcpyFromSymbolAsync

\_\_host\_\_cudaError\_t cudaMemcpy2DFromArrayAsync (void \*dst, size\_t dpitch, cudaArray\_const\_t src, size\_t wOffset, size\_t hOffset, size\_t width, size\_t height, cudaMemcpyKind kind, cudaStream\_t stream)

#### **Parameters**

#### dst

- Destination memory address

Copies data between host and device.

#### dpitch

- Pitch of destination memory

#### src

- Source memory address

#### wOffset

- Source starting X offset

#### hOffset

- Source starting Y offset

#### width

- Width of matrix transfer (columns in bytes)

#### height

- Height of matrix transfer (rows)

#### kind

- Type of transfer

#### stream

- Stream identifier

#### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevicePointer, cudaErrorInvalidPitchValue, cudaErrorInvalidMemcpyDirection

#### Description

Copies a matrix (height rows of width bytes each) from the CUDA array srcArray starting at the upper left corner (wOffset, hOffset) to the memory area pointed to by dst, where kind specifies the direction of the copy, and must be one of cudaMemcpyHostToHost, cudaMemcpyHostToDevice, cudaMemcpyDeviceToHost, cudaMemcpyDeviceToDevice, or cudaMemcpyDefault. Passing cudaMemcpyDefault is recommended, in which case the type of transfer is inferred from the pointer values. However, cudaMemcpyDefault is only allowed on systems that support unified virtual addressing. dpitch is the width in memory in bytes of the 2D array pointed to by dst, including any padding added to the end of each row. wOffset + width must not exceed the width of the CUDA array src. width must not exceed dpitch. cudaMemcpy2DFromArrayAsync() returns an error if dpitch exceeds the maximum allowed.

cudaMemcpy2DFromArrayAsync() is asynchronous with respect to the host, so the call may return before the copy is complete. The copy can optionally be associated to a stream by passing a non-zero stream argument. If kind is cudaMemcpyHostToDevice or cudaMemcpyDeviceToHost and stream is non-zero, the copy may overlap with operations in other streams.



- Note that this function may also return error codes from previous, asynchronous launches.
- This function exhibits asynchronous behavior for most use cases.
- ► This function uses standard default stream semantics.

#### See also:

cudaMemcpy, cudaMemcpy2D, cudaMemcpyToArray, cudaMemcpy2DToArray, cudaMemcpyFromArray, cudaMemcpy2DFromArray, cudaMemcpyArrayToArray, cudaMemcpyToSymbol, cudaMemcpyFromSymbol, cudaMemcpyAsync, cudaMemcpy2DAsync, cudaMemcpyToArrayAsync, cudaMemcpy2DToArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpyToSymbolAsync, cudaMemcpyFromSymbolAsync

\_\_host\_\_cudaError\_t cudaMemcpy2DToArray
(cudaArray\_t dst, size\_t wOffset, size\_t hOffset, const

## void \*src, size\_t spitch, size\_t width, size\_t height, cudaMemcpyKind kind)

Copies data between host and device.

#### **Parameters**

#### dst

- Destination memory address

#### wOffset

- Destination starting X offset

#### hOffset

- Destination starting Y offset

#### src

- Source memory address

#### spitch

- Pitch of source memory

#### width

- Width of matrix transfer (columns in bytes)

#### height

- Height of matrix transfer (rows)

#### kind

- Type of transfer

#### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevicePointer, cudaErrorInvalidPitchValue, cudaErrorInvalidMemcpyDirection

#### Description

Copies a matrix (height rows of width bytes each) from the memory area pointed to by src to the CUDA array dst starting at the upper left corner (wOffset, hOffset) where kind specifies the direction of the copy, and must be one of cudaMemcpyHostToHost, cudaMemcpyHostToDevice, cudaMemcpyDeviceToHost, cudaMemcpyDeviceToDevice, or cudaMemcpyDefault. Passing cudaMemcpyDefault is recommended, in which case the type of transfer is inferred from the pointer values. However, cudaMemcpyDefault is only allowed on systems that support unified virtual addressing. spitch is the width in memory in bytes of the 2D array pointed to by src, including any padding added to the end of each row. wOffset + width must not exceed the width of the CUDA array dst. width must not exceed spitch. cudaMemcpy2DToArray() returns an error if spitch exceeds the maximum allowed.



- Note that this function may also return error codes from previous, asynchronous launches.
- This function exhibits synchronous behavior for most use cases.

#### See also:

cudaMemcpy, cudaMemcpy2D, cudaMemcpyToArray, cudaMemcpyFromArray, cudaMemcpy2DFromArray, cudaMemcpyArrayToArray, cudaMemcpy2DArrayToArray, cudaMemcpyToSymbol, cudaMemcpyFromSymbol, cudaMemcpyAsync, cudaMemcpy2DAsync, cudaMemcpyToArrayAsync, cudaMemcpy2DToArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpy2DFromArrayAsync, cudaMemcpyToSymbolAsync, cudaMemcpyFromSymbolAsync

\_\_host\_\_cudaError\_t cudaMemcpy2DToArrayAsync (cudaArray\_t dst, size\_t wOffset, size\_t hOffset, const void \*src, size\_t spitch, size\_t width, size\_t height, cudaMemcpyKind kind, cudaStream\_t stream)

Copies data between host and device.

#### **Parameters**

#### dst

- Destination memory address

#### wOffset

- Destination starting X offset

#### hOffset

- Destination starting Y offset

#### src

- Source memory address

#### spitch

- Pitch of source memory

#### width

- Width of matrix transfer (columns in bytes)

#### height

- Height of matrix transfer (rows)

#### kind

- Type of transfer

#### stream

- Stream identifier

#### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevicePointer, cudaErrorInvalidPitchValue, cudaErrorInvalidMemcpyDirection

#### Description

Copies a matrix (height rows of width bytes each) from the memory area pointed to by src to the CUDA array dst starting at the upper left corner (wOffset, hOffset) where kind specifies the direction of the copy, and must be one of cudaMemcpyHostToHost, cudaMemcpyHostToDevice, cudaMemcpyDeviceToHost, cudaMemcpyDeviceToDevice, or cudaMemcpyDefault. Passing cudaMemcpyDefault is recommended, in which case the type of transfer is inferred from the pointer values. However, cudaMemcpyDefault is only allowed on systems that support unified virtual addressing. spitch is the width in memory in bytes of the 2D array pointed to by src, including any padding added to the end of each row. wOffset + width must not exceed the width of the CUDA array dst. width must not exceed spitch. cudaMemcpy2DToArrayAsync() returns an error if spitch exceeds the maximum allowed.

cudaMemcpy2DToArrayAsync() is asynchronous with respect to the host, so the call may return before the copy is complete. The copy can optionally be associated to a stream by passing a non-zero stream argument. If kind is cudaMemcpyHostToDevice or cudaMemcpyDeviceToHost and stream is non-zero, the copy may overlap with operations in other streams.



- Note that this function may also return error codes from previous, asynchronous launches.
- This function exhibits asynchronous behavior for most use cases.
- ► This function uses standard default stream semantics.

#### See also:

cudaMemcpy, cudaMemcpy2D, cudaMemcpyToArray, cudaMemcpy2DToArray, cudaMemcpyFromArray, cudaMemcpy2DFromArray, cudaMemcpyArrayToArray, cudaMemcpy2DArrayToArray, cudaMemcpyToSymbol, cudaMemcpyFromSymbol, cudaMemcpyAsync, cudaMemcpy2DAsync, cudaMemcpyToArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpyToSymbolAsync, cudaMemcpyFromSymbolAsync

### \_\_host\_\_cudaError\_t cudaMemcpy3D (const cudaMemcpy3DParms \*p)

Copies data between 3D objects.

#### **Parameters**

p

- 3D memory copy parameters

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevicePointer, cudaErrorInvalidPitchValue, cudaErrorInvalidMemcpyDirection

#### Description

```
| struct cudaExtent {
       size t width;
       size t height;
       size t depth;
     struct cudaExtent
          make_cudaExtent(size_t w, size_t h, size_t d);
     struct cudaPos {
       size t x;
       size t y;
       size_t z;
     struct cudaPos
                make cudaPos(size t x, size t y, size t z);
     struct cudaMemcpy3DParms {
       cudaArray_t
                 srcArray;
       struct cudaPos
                srcPos;
       struct cudaPitchedPtr
                 srcPtr;
       cudaArray_t
                 dstArray;
       struct cudaPos
                dstPos;
       struct cudaPitchedPtr
                dstPtr;
       struct cudaExtent
                extent;
       enum cudaMemcpyKind
             kind;
```

cudaMemcpy3D() copies data betwen two 3D objects. The source and destination objects may be in either host memory, device memory, or a CUDA array. The source, destination, extent, and kind of copy performed is specified by the cudaMemcpy3DParms struct which should be initialized to zero before use:

```
| cudaMemcpy3DParms myParms = {0};
```

The struct passed to cudaMemcpy3D() must specify one of srcArray or srcPtr and one of dstArray or dstPtr. Passing more than one non-zero source or destination will cause cudaMemcpy3D() to return an error.

The srcPos and dstPos fields are optional offsets into the source and destination objects and are defined in units of each object's elements. The element for a host or device pointer is assumed to be **unsigned char**. For CUDA arrays, positions must be in the range [0, 2048) for any dimension.

The extent field defines the dimensions of the transferred area in elements. If a CUDA array is participating in the copy, the extent is defined in terms of that array's elements. If no CUDA array is participating in the copy then the extents are defined in elements of **unsigned char**.

The kind field defines the direction of the copy. It must be one of cudaMemcpyHostToHost, cudaMemcpyHostToDevice, cudaMemcpyDeviceToHost, cudaMemcpyDeviceToDevice, or cudaMemcpyDefault. Passing cudaMemcpyDefault is recommended, in which case the type of transfer is inferred from the pointer values. However, cudaMemcpyDefault is only allowed on systems that support unified virtual addressing.

If the source and destination are both arrays, cudaMemcpy3D() will return an error if they do not have the same element size.

The source and destination object may not overlap. If overlapping source and destination objects are specified, undefined behavior will result.

The source object must lie entirely within the region defined by srcPos and extent. The destination object must lie entirely within the region defined by dstPos and extent.

cudaMemcpy3D() returns an error if the pitch of srcPtr or dstPtr exceeds the maximum allowed. The pitch of a cudaPitchedPtr allocated with cudaMalloc3D() will always be valid.



- Note that this function may also return error codes from previous, asynchronous launches.
- ▶ This function exhibits synchronous behavior for most use cases.

#### See also:

cudaMalloc3D, cudaMalloc3DArray, cudaMemset3D, cudaMemcpy3DAsync, cudaMemcpy, cudaMemcpy2D, cudaMemcpyToArray, cudaMemcpy2DToArray, cudaMemcpyFromArray, cudaMemcpy2DFromArray, cudaMemcpy4ToArray, cudaMemcpy2DArrayToArray, cudaMemcpyToSymbol, cudaMemcpyFromSymbol, cudaMemcpyAsync, cudaMemcpy2DAsync, cudaMemcpyToArrayAsync,

cudaMemcpy2DToArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpy2DFromArrayAsync, cudaMemcpyToSymbolAsync, cudaMemcpyFromSymbolAsync, make\_cudaExtent, make\_cudaPos

\_\_host\_\_\_\_device\_\_cudaError\_t cudaMemcpy3DAsync (const cudaMemcpy3DParms \*p, cudaStream\_t stream) Copies data between 3D objects.

#### **Parameters**

p

- 3D memory copy parameters

#### stream

- Stream identifier

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevicePointer, cudaErrorInvalidPitchValue, cudaErrorInvalidMemcpyDirection

#### Description

```
| struct cudaExtent {
      size t width;
       size_t height;
       size t depth;
     struct cudaExtent
                make_cudaExtent(size_t w, size_t h, size_t d);
     struct cudaPos {
       size t x;
       size t y;
      size_t z;
     struct cudaPos
                make cudaPos(size t x, size t y, size t z);
     struct cudaMemcpy3DParms {
      cudaArray_t
                 srcArray;
       struct cudaPos
                srcPos;
       struct cudaPitchedPtr
                srcPtr;
       cudaArray_t
                 dstArray;
       struct cudaPos
                dstPos;
       struct cudaPitchedPtr
                 dstPtr;
       struct cudaExtent
                 extent;
       enum cudaMemcpyKind
               kind;
```

cudaMemcpy3DAsync() copies data betwen two 3D objects. The source and destination objects may be in either host memory, device memory, or a CUDA array. The source, destination, extent, and kind of copy performed is specified by the cudaMemcpy3DParms struct which should be initialized to zero before use:

```
| cudaMemcpy3DParms myParms = {0};
```

The struct passed to cudaMemcpy3DAsync() must specify one of srcArray or srcPtr and one of dstArray or dstPtr. Passing more than one non-zero source or destination will cause cudaMemcpy3DAsync() to return an error.

The srcPos and dstPos fields are optional offsets into the source and destination objects and are defined in units of each object's elements. The element for a host or device pointer is assumed to be **unsigned char**. For CUDA arrays, positions must be in the range [0, 2048) for any dimension.

The extent field defines the dimensions of the transferred area in elements. If a CUDA array is participating in the copy, the extent is defined in terms of that array's elements. If no CUDA array is participating in the copy then the extents are defined in elements of **unsigned char**.

The kind field defines the direction of the copy. It must be one of cudaMemcpyHostToHost, cudaMemcpyHostToDevice, cudaMemcpyDeviceToHost, cudaMemcpyDeviceToDevice, or cudaMemcpyDefault. Passing cudaMemcpyDefault is recommended, in which case the type of transfer is inferred from the pointer values. However, cudaMemcpyDefault is only allowed on systems that support unified virtual addressing.

If the source and destination are both arrays, cudaMemcpy3DAsync() will return an error if they do not have the same element size.

The source and destination object may not overlap. If overlapping source and destination objects are specified, undefined behavior will result.

The source object must lie entirely within the region defined by srcPos and extent. The destination object must lie entirely within the region defined by dstPos and extent.

cudaMemcpy3DAsync() returns an error if the pitch of srcPtr or dstPtr exceeds the maximum allowed. The pitch of a cudaPitchedPtr allocated with cudaMalloc3D() will always be valid.

cudaMemcpy3DAsync() is asynchronous with respect to the host, so the call may return before the copy is complete. The copy can optionally be associated to a stream by passing a non-zero stream argument. If kind is cudaMemcpyHostToDevice or cudaMemcpyDeviceToHost and stream is non-zero, the copy may overlap with operations in other streams.

The device version of this function only handles device to device copies and cannot be given local or shared pointers.



- Note that this function may also return error codes from previous, asynchronous launches.
- This function exhibits asynchronous behavior for most use cases.
- This function uses standard default stream semantics.

#### See also:

cudaMalloc3D, cudaMalloc3DArray, cudaMemset3D, cudaMemcpy3D, cudaMemcpy, cudaMemcpy2D, cudaMemcpyToArray, cudaMemcpy2DToArray, cudaMemcpyFromArray, cudaMemcpy2DFromArray, cudaMemcpyArrayToArray, cudaMemcpy2DArrayToArray, cudaMemcpyToSymbol, cudaMemcpyFromSymbol, cudaMemcpyAsync, cudaMemcpy2DAsync, cudaMemcpyToArrayAsync, cudaMemcpy2DToArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpy2DFromArrayAsync, cudaMemcpyToSymbolAsync, cudaMemcpyFromSymbolAsync, cudaMemcpyFromSymbolAsync, make\_cudaExtent, make\_cudaPos

### \_\_host\_\_cudaError\_t cudaMemcpy3DPeer (const cudaMemcpy3DPeerParms \*p)

Copies memory between devices.

#### **Parameters**

p

- Parameters for the memory copy

#### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevice

#### Description

Perform a 3D memory copy according to the parameters specified in p. See the definition of the cudaMemcpy3DPeerParms structure for documentation of its parameters.

Note that this function is synchronous with respect to the host only if the source or destination of the transfer is host memory. Note also that this copy is serialized with respect to all pending and future asynchronous work in to the current device, the copy's source device, and the copy's destination device (use cudaMemcpy3DPeerAsync to avoid this synchronization).



Note that this function may also return error codes from previous, asynchronous launches.



This function exhibits synchronous behavior for most use cases.

#### See also:

cudaMemcpy, cudaMemcpyPeer, cudaMemcpyAsync, cudaMemcpyPeerAsync, cudaMemcpy3DPeerAsync

### \_\_host\_\_cudaError\_t cudaMemcpy3DPeerAsync (const cudaMemcpy3DPeerParms \*p, cudaStream\_t stream)

Copies memory between devices asynchronously.

#### **Parameters**

p

- Parameters for the memory copy

#### stream

- Stream identifier

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevice

#### Description

Perform a 3D memory copy according to the parameters specified in p. See the definition of the cudaMemcpy3DPeerParms structure for documentation of its parameters.



- Note that this function may also return error codes from previous, asynchronous launches.
- ► This function exhibits asynchronous behavior for most use cases.
- This function uses standard default stream semantics.

#### See also:

cuda Memcpy, cuda Memcpy Peer, cuda Memcpy Async, cuda Memcpy Peer Async, cuda Memcpy 3D Peer Async

\_\_host\_\_cudaError\_t cudaMemcpyArrayToArray
(cudaArray\_t dst, size\_t wOffsetDst, size\_t hOffsetDst,

## cudaArray\_const\_t src, size\_t wOffsetSrc, size\_t hOffsetSrc, size\_t count, cudaMemcpyKind kind)

Copies data between host and device.

#### **Parameters**

#### dst

- Destination memory address

#### wOffsetDst

- Destination starting X offset

#### hOffsetDst

- Destination starting Y offset

#### src

- Source memory address

#### wOffsetSrc

- Source starting X offset

#### hOffsetSrc

- Source starting Y offset

#### count

- Size in bytes to copy

#### kind

- Type of transfer

#### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidMemcpyDirection

#### Description

Copies count bytes from the CUDA array src starting at the upper left corner (wOffsetSrc, hOffsetSrc) to the CUDA array dst starting at the upper left corner (wOffsetDst, hOffsetDst) where kind specifies the direction of the copy, and must be one of cudaMemcpyHostToHost, cudaMemcpyHostToDevice, cudaMemcpyDeviceToHost, cudaMemcpyDeviceToDevice, or cudaMemcpyDefault. Passing cudaMemcpyDefault is recommended, in which case the type of transfer is inferred from the pointer values. However, cudaMemcpyDefault is only allowed on systems that support unified virtual addressing.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaMemcpy, cudaMemcpy2D, cudaMemcpyToArray, cudaMemcpy2DToArray, cudaMemcpyFromArray, cudaMemcpy2DFromArray, cudaMemcpy2DArrayToArray, cudaMemcpyToSymbol, cudaMemcpyFromSymbol, cudaMemcpyAsync, cudaMemcpy2DAsync, cudaMemcpyToArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpyToSymbolAsync, cudaMemcpyFromSymbolAsync

\_\_host\_\_\_\_device\_\_cudaError\_t cudaMemcpyAsync (void \*dst, const void \*src, size\_t count, cudaMemcpyKind kind, cudaStream\_t stream)

Copies data between host and device.

#### **Parameters**

dst

Destination memory address

src

- Source memory address

count

- Size in bytes to copy

kind

- Type of transfer

stream

- Stream identifier

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevicePointer, cudaErrorInvalidMemcpyDirection

#### Description

Copies count bytes from the memory area pointed to by src to the memory area pointed to by dst, where kind specifies the direction of the copy, and must be one of cudaMemcpyHostToHost, cudaMemcpyHostToDevice, cudaMemcpyDeviceToHost, cudaMemcpyDeviceToDevice, or cudaMemcpyDefault. Passing cudaMemcpyDefault is recommended, in which case the type of transfer is inferred from the pointer values. However, cudaMemcpyDefault is only allowed on systems that support unified virtual addressing.

The memory areas may not overlap. Calling cudaMemcpyAsync() with dst and src pointers that do not match the direction of the copy results in an undefined behavior.

cudaMemcpyAsync() is asynchronous with respect to the host, so the call may return before the copy is complete. The copy can optionally be associated to a stream by

passing a non-zero stream argument. If kind is cudaMemcpyHostToDevice or cudaMemcpyDeviceToHost and the stream is non-zero, the copy may overlap with operations in other streams.

The device version of this function only handles device to device copies and cannot be given local or shared pointers.



- Note that this function may also return error codes from previous, asynchronous launches
- This function exhibits asynchronous behavior for most use cases.
- This function uses standard default stream semantics.

#### See also:

cudaMemcpy, cudaMemcpy2D, cudaMemcpyToArray, cudaMemcpy2DToArray, cudaMemcpyFromArray, cudaMemcpy2DFromArray, cudaMemcpyArrayToArray, cudaMemcpy2DArrayToArray, cudaMemcpyToSymbol, cudaMemcpyFromSymbol, cudaMemcpy2DAsync, cudaMemcpyToArrayAsync, cudaMemcpy2DToArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpyToSymbolAsync, cudaMemcpyFromSymbolAsync

\_\_host\_\_cudaError\_t cudaMemcpyFromArray (void \*dst, cudaArray\_const\_t src, size\_t wOffset, size\_t hOffset, size\_t count, cudaMemcpyKind kind)

Copies data between host and device.

#### **Parameters**

#### dst

- Destination memory address

#### src

- Source memory address

#### wOffset

- Source starting X offset

#### hOffset

- Source starting Y offset

#### count

- Size in bytes to copy

#### kind

- Type of transfer

#### **Returns**

cuda Success, cuda Error Invalid Value, cuda Error Invalid Device Pointer, cuda Error Invalid Memcpy Direction

#### Description

Copies count bytes from the CUDA array src starting at the upper left corner (wOffset, hOffset) to the memory area pointed to by dst, where kind specifies the direction of the copy, and must be one of cudaMemcpyHostToHost, cudaMemcpyHostToDevice, cudaMemcpyDeviceToHost, cudaMemcpyDeviceToDevice, or cudaMemcpyDefault. Passing cudaMemcpyDefault is recommended, in which case the type of transfer is inferred from the pointer values. However, cudaMemcpyDefault is only allowed on systems that support unified virtual addressing.



- Note that this function may also return error codes from previous, asynchronous launches.
- This function exhibits synchronous behavior for most use cases.

#### See also:

cudaMemcpy, cudaMemcpy2D, cudaMemcpyToArray, cudaMemcpy2DToArray, cudaMemcpy2DFromArray, cudaMemcpyArrayToArray, cudaMemcpy2DArrayToArray, cudaMemcpyToSymbol, cudaMemcpyFromSymbol, cudaMemcpyAsync, cudaMemcpy2DAsync, cudaMemcpyToArrayAsync, cudaMemcpy2DToArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpy2DFromArrayAsync, cudaMemcpyToSymbolAsync, cudaMemcpyFromSymbolAsync

\_\_host\_\_cudaError\_t cudaMemcpyFromArrayAsync (void \*dst, cudaArray\_const\_t src, size\_t wOffset, size\_t hOffset, size\_t count, cudaMemcpyKind kind, cudaStream\_t stream)

Copies data between host and device.

#### **Parameters**

#### dst

Destination memory address

#### src

- Source memory address

#### wOffset

- Source starting X offset

#### hOffset

- Source starting Y offset

#### count

- Size in bytes to copy

#### kind

- Type of transfer

#### stream

- Stream identifier

#### **Returns**

cuda Success, cuda Error Invalid Value, cuda Error Invalid Device Pointer, cuda Error Invalid Memcpy Direction

#### Description

Copies count bytes from the CUDA array src starting at the upper left corner (wOffset, hOffset) to the memory area pointed to by dst, where kind specifies the direction of the copy, and must be one of cudaMemcpyHostToHost, cudaMemcpyHostToDevice, cudaMemcpyDeviceToHost, cudaMemcpyDeviceToDevice, or cudaMemcpyDefault. Passing cudaMemcpyDefault is recommended, in which case the type of transfer is inferred from the pointer values. However, cudaMemcpyDefault is only allowed on systems that support unified virtual addressing.

cudaMemcpyFromArrayAsync() is asynchronous with respect to the host, so the call may return before the copy is complete. The copy can optionally be associated to a stream by passing a non-zero stream argument. If kind is cudaMemcpyHostToDevice or cudaMemcpyDeviceToHost and stream is non-zero, the copy may overlap with operations in other streams.



- Note that this function may also return error codes from previous, asynchronous launches.
- This function exhibits asynchronous behavior for most use cases.
- This function uses standard default stream semantics.

#### See also:

cudaMemcpy, cudaMemcpy2D, cudaMemcpyToArray, cudaMemcpy2DToArray, cudaMemcpyFromArray, cudaMemcpy2DFromArray, cudaMemcpyArrayToArray, cudaMemcpy2DArrayToArray, cudaMemcpyToSymbol, cudaMemcpyFromSymbol, cudaMemcpyAsync, cudaMemcpy2DAsync, cudaMemcpyToArrayAsync, cudaMemcpy2DToArrayAsync, cudaMemcpy2DFromArrayAsync, cudaMemcpyToSymbolAsync, cudaMemcpyFromSymbolAsync

### \_\_host\_\_cudaError\_t cudaMemcpyFromSymbol (void \*dst, const void \*symbol, size\_t count, size\_t offset, cudaMemcpyKind kind)

Copies data from the given symbol on the device.

#### **Parameters**

#### dst

- Destination memory address

#### symbol

- Device symbol address

#### count

- Size in bytes to copy

#### offset

- Offset from start of symbol in bytes

#### kind

- Type of transfer

#### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidSymbol, cudaErrorInvalidDevicePointer, cudaErrorInvalidMemcpyDirection

#### Description

Copies count bytes from the memory area pointed to by offset bytes from the start of symbol symbol to the memory area pointed to by dst. The memory areas may not overlap. symbol is a variable that resides in global or constant memory space. kind can be either cudaMemcpyDeviceToHost, cudaMemcpyDeviceToDevice, or cudaMemcpyDefault. Passing cudaMemcpyDefault is recommended, in which case the type of transfer is inferred from the pointer values. However, cudaMemcpyDefault is only allowed on systems that support unified virtual addressing.



- Note that this function may also return error codes from previous, asynchronous launches.
- This function exhibits synchronous behavior for most use cases.
- Use of a string naming a variable as the symbol paramater was deprecated in CUDA 4.1 and removed in CUDA 5.0.

#### See also:

cudaMemcpy, cudaMemcpy2D, cudaMemcpyToArray, cudaMemcpy2DToArray, cudaMemcpyFromArray, cudaMemcpy2DFromArray, cudaMemcpyArrayToArray, cudaMemcpy2DArrayToArray, cudaMemcpyToSymbol, cudaMemcpyAsync, cudaMemcpy2DAsync, cudaMemcpyToArrayAsync, cudaMemcpy2DToArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpyDFromArrayAsync, cudaMemcpyToSymbolAsync, cudaMemcpyFromSymbolAsync

\_\_host\_\_cudaError\_t cudaMemcpyFromSymbolAsync (void \*dst, const void \*symbol, size\_t count, size\_t offset, cudaMemcpyKind kind, cudaStream\_t stream)
Copies data from the given symbol on the device.

#### **Parameters**

#### dst

- Destination memory address

#### symbol

- Device symbol address

#### count

- Size in bytes to copy

#### offset

- Offset from start of symbol in bytes

#### kind

- Type of transfer

#### stream

- Stream identifier

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidSymbol, cudaErrorInvalidDevicePointer, cudaErrorInvalidMemcpyDirection

#### Description

Copies count bytes from the memory area pointed to by offset bytes from the start of symbol symbol to the memory area pointed to by dst. The memory areas may not overlap. symbol is a variable that resides in global or constant memory space. kind can be either cudaMemcpyDeviceToHost, cudaMemcpyDeviceToDevice, or cudaMemcpyDefault. Passing cudaMemcpyDefault is recommended, in which case the type of transfer is inferred from the pointer values. However, cudaMemcpyDefault is only allowed on systems that support unified virtual addressing.

cudaMemcpyFromSymbolAsync() is asynchronous with respect to the host, so the call may return before the copy is complete. The copy can optionally be associated to a

stream by passing a non-zero stream argument. If kind is cudaMemcpyDeviceToHost and stream is non-zero, the copy may overlap with operations in other streams.



- Note that this function may also return error codes from previous, asynchronous launches.
- ► This function exhibits asynchronous behavior for most use cases.
- ▶ This function uses standard default stream semantics.
- Use of a string naming a variable as the symbol paramater was deprecated in CUDA 4.1 and removed in CUDA 5.0.

#### See also:

cudaMemcpy, cudaMemcpy2D, cudaMemcpyToArray, cudaMemcpy2DToArray, cudaMemcpyFromArray, cudaMemcpy2DFromArray, cudaMemcpy4ToArray, cudaMemcpy2DArrayToArray, cudaMemcpyToSymbol, cudaMemcpyFromSymbol, cudaMemcpyAsync, cudaMemcpy2DAsync, cudaMemcpyToArrayAsync, cudaMemcpy2DToArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpy2DFromArrayAsync, cudaMemcpyToSymbolAsync

\_\_host\_\_cudaError\_t cudaMemcpyPeer (void \*dst, int dstDevice, const void \*src, int srcDevice, size\_t count)
Copies memory between two devices.

#### **Parameters**

#### dst

- Destination device pointer

#### dstDevice

- Destination device

#### src

- Source device pointer

#### srcDevice

- Source device

#### count

- Size of memory copy in bytes

#### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevice

#### Description

Copies memory from one device to memory on another device. dst is the base device pointer of the destination memory and dstDevice is the destination device. src is the base device pointer of the source memory and srcDevice is the source device. count specifies the number of bytes to copy.

Note that this function is asynchronous with respect to the host, but serialized with respect all pending and future asynchronous work in to the current device, srcDevice, and dstDevice (use cudaMemcpyPeerAsync to avoid this synchronization).



- Note that this function may also return error codes from previous, asynchronous launches.
- This function exhibits synchronous behavior for most use cases.

#### See also:

cudaMemcpy, cudaMemcpyAsync, cudaMemcpyPeerAsync, cudaMemcpy3DPeerAsync

\_\_host\_\_cudaError\_t cudaMemcpyPeerAsync (void \*dst,
int dstDevice, const void \*src, int srcDevice, size\_t
count, cudaStream\_t stream)

Copies memory between two devices asynchronously.

#### **Parameters**

#### dst

- Destination device pointer

#### dstDevice

- Destination device

#### src

- Source device pointer

#### srcDevice

- Source device

#### count

- Size of memory copy in bytes

#### stream

- Stream identifier

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevice

#### Description

Copies memory from one device to memory on another device. dst is the base device pointer of the destination memory and dstDevice is the destination device. src is the base device pointer of the source memory and srcDevice is the source device. count specifies the number of bytes to copy.

Note that this function is asynchronous with respect to the host and all work on other devices.



- Note that this function may also return error codes from previous, asynchronous launches.
- This function exhibits asynchronous behavior for most use cases.
- This function uses standard default stream semantics.

#### See also:

cudaMemcpy, cudaMemcpyPeer, cudaMemcpyAsync, cudaMemcpy3DPeerAsync

\_\_host\_\_cudaError\_t cudaMemcpyToArray (cudaArray\_t dst, size\_t wOffset, size\_t hOffset, const void \*src, size\_t count, cudaMemcpyKind kind)

Copies data between host and device.

#### **Parameters**

#### dst

- Destination memory address

#### wOffset

- Destination starting X offset

#### hOffset

- Destination starting Y offset

#### src

- Source memory address

#### count

- Size in bytes to copy

#### kind

- Type of transfer

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevicePointer, cudaErrorInvalidMemcpyDirection

#### Description

Copies count bytes from the memory area pointed to by src to the CUDA array dst starting at the upper left corner (wOffset, hOffset), where kind specifies the direction of the copy, and must be one of cudaMemcpyHostToHost, cudaMemcpyHostToDevice, cudaMemcpyDeviceToHost, cudaMemcpyDeviceToDevice, or cudaMemcpyDefault. Passing cudaMemcpyDefault is recommended, in which case the type of transfer is inferred from the pointer values. However, cudaMemcpyDefault is only allowed on systems that support unified virtual addressing.



- Note that this function may also return error codes from previous, asynchronous launches.
- ► This function exhibits synchronous behavior for most use cases.

#### See also:

cudaMemcpy, cudaMemcpy2D, cudaMemcpy2DToArray, cudaMemcpyFromArray, cudaMemcpyPromArray, cudaMemcpyDFromArray, cudaMemcpyToSymbol, cudaMemcpyFromSymbol, cudaMemcpyAsync, cudaMemcpy2DAsync, cudaMemcpyToArrayAsync, cudaMemcpy2DToArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpy2DFromArrayAsync, cudaMemcpyToSymbolAsync, cudaMemcpyFromSymbolAsync, cudaMemcpyFromSymbolAsync

\_\_host\_\_cudaError\_t cudaMemcpyToArrayAsync (cudaArray\_t dst, size\_t wOffset, size\_t hOffset, const void \*src, size\_t count, cudaMemcpyKind kind, cudaStream\_t stream)

Copies data between host and device.

#### **Parameters**

#### dst

- Destination memory address

#### wOffset

Destination starting X offset

#### hOffset

- Destination starting Y offset

#### sro

- Source memory address

#### count

- Size in bytes to copy

#### kind

- Type of transfer

#### stream

- Stream identifier

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevicePointer, cudaErrorInvalidMemcpyDirection

#### Description

Copies count bytes from the memory area pointed to by src to the CUDA array dst starting at the upper left corner (wOffset, hOffset), where kind specifies the direction of the copy, and must be one of cudaMemcpyHostToHost, cudaMemcpyHostToDevice, cudaMemcpyDeviceToHost, cudaMemcpyDeviceToDevice, or cudaMemcpyDefault. Passing cudaMemcpyDefault is recommended, in which case the type of transfer is inferred from the pointer values. However, cudaMemcpyDefault is only allowed on systems that support unified virtual addressing.

cudaMemcpyToArrayAsync() is asynchronous with respect to the host, so the call may return before the copy is complete. The copy can optionally be associated to a stream by passing a non-zero stream argument. If kind is cudaMemcpyHostToDevice or cudaMemcpyDeviceToHost and stream is non-zero, the copy may overlap with operations in other streams.



- Note that this function may also return error codes from previous, asynchronous launches.
- This function exhibits asynchronous behavior for most use cases.
- ► This function uses standard default stream semantics.

#### See also:

cudaMemcpy, cudaMemcpy2D, cudaMemcpyToArray, cudaMemcpy2DToArray, cudaMemcpyFromArray, cudaMemcpy2DFromArray, cudaMemcpyArrayToArray, cudaMemcpy2DArrayToArray, cudaMemcpyToSymbol, cudaMemcpyFromSymbol, cudaMemcpyAsync, cudaMemcpy2DToArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpyToSymbolAsync, cudaMemcpyFromSymbolAsync, cudaMemcpyToSymbolAsync, cudaMemcpyFromSymbolAsync

# \_\_host\_\_cudaError\_t cudaMemcpyToSymbol (const void \*symbol, const void \*src, size\_t count, size\_t offset, cudaMemcpyKind kind)

Copies data to the given symbol on the device.

#### **Parameters**

#### symbol

- Device symbol address

#### src

- Source memory address

#### count

- Size in bytes to copy

#### offset

- Offset from start of symbol in bytes

#### kind

- Type of transfer

#### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidSymbol, cudaErrorInvalidDevicePointer, cudaErrorInvalidMemcpyDirection

#### Description

Copies count bytes from the memory area pointed to by src to the memory area pointed to by offset bytes from the start of symbol symbol. The memory areas may not overlap. symbol is a variable that resides in global or constant memory space. kind can be either cudaMemcpyHostToDevice, cudaMemcpyDeviceToDevice, or cudaMemcpyDefault. Passing cudaMemcpyDefault is recommended, in which case the type of transfer is inferred from the pointer values. However, cudaMemcpyDefault is only allowed on systems that support unified virtual addressing.



- Note that this function may also return error codes from previous, asynchronous launches.
- This function exhibits synchronous behavior for most use cases.
- Use of a string naming a variable as the symbol paramater was deprecated in CUDA 4.1 and removed in CUDA 5.0.

#### See also:

cudaMemcpy, cudaMemcpy2D, cudaMemcpyToArray, cudaMemcpy2DToArray, cudaMemcpyFromArray, cudaMemcpy2DFromArray, cudaMemcpyArrayToArray, cudaMemcpy2DArrayToArray, cudaMemcpyFromSymbol, cudaMemcpyAsync, cudaMemcpy2DAsync, cudaMemcpyToArrayAsync, cudaMemcpy2DToArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpyToSymbolAsync, cudaMemcpyFromSymbolAsync, cudaMemcpyToSymbolAsync, cudaMemcpyFromSymbolAsync

\_\_host\_\_cudaError\_t cudaMemcpyToSymbolAsync (const void \*symbol, const void \*src, size\_t count, size\_t offset, cudaMemcpyKind kind, cudaStream\_t stream)

Copies data to the given symbol on the device.

#### **Parameters**

#### symbol

- Device symbol address

#### src

- Source memory address

#### count

- Size in bytes to copy

#### offset

- Offset from start of symbol in bytes

#### kind

- Type of transfer

#### stream

- Stream identifier

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidSymbol, cudaErrorInvalidDevicePointer, cudaErrorInvalidMemcpyDirection

#### Description

Copies count bytes from the memory area pointed to by src to the memory area pointed to by offset bytes from the start of symbol symbol. The memory areas may not overlap. symbol is a variable that resides in global or constant memory space. kind can be either cudaMemcpyHostToDevice, cudaMemcpyDeviceToDevice, or cudaMemcpyDefault. Passing cudaMemcpyDefault is recommended, in which case the type of transfer is inferred from the pointer values. However, cudaMemcpyDefault is only allowed on systems that support unified virtual addressing.

cudaMemcpyToSymbolAsync() is asynchronous with respect to the host, so the call may return before the copy is complete. The copy can optionally be associated to a stream

by passing a non-zero stream argument. If kind is cudaMemcpyHostToDevice and stream is non-zero, the copy may overlap with operations in other streams.



- Note that this function may also return error codes from previous, asynchronous launches.
- ► This function exhibits asynchronous behavior for most use cases.
- ► This function uses standard default stream semantics.
- Use of a string naming a variable as the symbol paramater was deprecated in CUDA 4.1 and removed in CUDA 5.0.

#### See also:

cudaMemcpy, cudaMemcpy2D, cudaMemcpyToArray, cudaMemcpy2DToArray, cudaMemcpyFromArray, cudaMemcpy2DFromArray, cudaMemcpy4ToArray, cudaMemcpy2DArrayToArray, cudaMemcpyToSymbol, cudaMemcpyFromSymbol, cudaMemcpyAsync, cudaMemcpy2DAsync, cudaMemcpyToArrayAsync, cudaMemcpy2DToArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpy2DFromArrayAsync, cudaMemcpyFromSymbolAsync

# \_\_host\_\_cudaError\_t cudaMemGetInfo (size\_t \*free, size\_t \*total)

Gets free and total device memory.

#### **Parameters**

#### free

- Returned free memory in bytes

#### total

- Returned total memory in bytes

#### Returns

cudaSuccess, cudaErrorInitializationError, cudaErrorInvalidValue, cudaErrorLaunchFailure

#### Description

Returns in \*free and \*total respectively, the free and total amount of memory available for allocation by the device in bytes.



Note that this function may also return error codes from previous, asynchronous launches.

### \_\_host\_\_cudaError\_t cudaMemPrefetchAsync (const void \*devPtr, size\_t count, int dstDevice, cudaStream\_t stream)

Prefetches memory to the specified destination device.

#### **Parameters**

#### devPtr

- Pointer to be prefetched

#### count

- Size in bytes

#### dstDevice

- Destination device to prefetch to

#### stream

- Stream to enqueue prefetch operation

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevice

#### Description

Prefetches memory to the specified destination device. devPtr is the base device pointer of the memory to be prefetched and dstDevice is the destination device. count specifies the number of bytes to copy. stream is the stream in which the operation is enqueued. The memory range must refer to managed memory allocated via cudaMallocManaged or declared via \_\_managed\_\_ variables.

Passing in cudaCpuDeviceId for dstDevice will prefetch the data to host memory. If dstDevice is a GPU, then the device attribute cudaDevAttrConcurrentManagedAccess must be non-zero. Additionally, stream must be associated with a device that has a non-zero value for the device attribute cudaDevAttrConcurrentManagedAccess.

The start address and end address of the memory range will be rounded down and rounded up respectively to be aligned to CPU page size before the prefetch operation is enqueued in the stream.

If no physical memory has been allocated for this region, then this memory region will be populated and mapped on the destination device. If there's insufficient memory to prefetch the desired region, the Unified Memory driver may evict pages from other cudaMallocManaged allocations to host memory in order to make room. Device memory allocated using cudaMalloc or cudaMallocArray will not be evicted.

By default, any mappings to the previous location of the migrated pages are removed and mappings for the new location are only setup on dstDevice. The exact behavior however also depends on the settings applied to this memory range via cudaMemAdvise as described below:

If cudaMemAdviseSetReadMostly was set on any subset of this memory range, then that subset will create a read-only copy of the pages on dstDevice.

If cudaMemAdviseSetPreferredLocation was called on any subset of this memory range, then the pages will be migrated to dstDevice even if dstDevice is not the preferred location of any pages in the memory range.

If cudaMemAdviseSetAccessedBy was called on any subset of this memory range, then mappings to those pages from all the appropriate processors are updated to refer to the new location if establishing such a mapping is possible. Otherwise, those mappings are cleared.

Note that this API is not required for functionality and only serves to improve performance by allowing the application to migrate data to a suitable location before it is accessed. Memory accesses to this range are always coherent and are allowed even when the data is actively being migrated.

Note that this function is asynchronous with respect to the host and all work on other devices.



- Note that this function may also return error codes from previous, asynchronous launches.
- ► This function exhibits asynchronous behavior for most use cases.
- This function uses standard default stream semantics.

#### See also:

cudaMemcpy, cudaMemcpyPeer, cudaMemcpyAsync, cudaMemcpy3DPeerAsync, cudaMemAdvise

### \_\_host\_\_cudaError\_t cudaMemRangeGetAttribute (void \*data, size\_t dataSize, cudaMemRangeAttribute attribute, const void \*devPtr, size\_t count)

Query an attribute of a given memory range.

#### **Parameters**

#### data

- A pointers to a memory location where the result of each attribute query will be written to.

#### dataSize

- Array containing the size of data

#### attribute

- The attribute to query

#### devPtr

- Start of the range to query

#### count

- Size of the range to query

#### Returns

cudaSuccess, cudaErrorInvalidValue

#### Description

Query an attribute about the memory range starting at devPtr with a size of count bytes. The memory range must refer to managed memory allocated via cudaMallocManaged or declared via \_\_managed\_\_ variables.

The attribute parameter can take the following values:

- cudaMemRangeAttributeReadMostly: If this attribute is specified, data will be interpreted as a 32-bit integer, and dataSize must be 4. The result returned will be 1 if all pages in the given memory range have read-duplication enabled, or 0 otherwise.
- be interpreted as a 32-bit integer, and dataSize must be 4. The result returned will be a GPU device id if all pages in the memory range have that GPU as their preferred location, or it will be cudaCpuDeviceId if all pages in the memory range have the CPU as their preferred location, or it will be cudaInvalidDeviceId if either all the pages don't have the same preferred location or some of the pages don't have a preferred location at all. Note that the actual location of the pages in the memory range at the time of the query may be different from the preferred location.

- be interpreted as an array of 32-bit integers, and dataSize must be a non-zero multiple of 4. The result returned will be a list of device ids that had cudaMemAdviceSetAccessedBy set for that entire memory range. If any device does not have that advice set for the entire memory range, that device will not be included. If data is larger than the number of devices that have that advice set for that memory range, cudaInvalidDeviceId will be returned in all the extra space provided. For ex., if dataSize is 12 (i.e. data has 3 elements) and only device 0 has the advice set, then the result returned will be { 0, cudaInvalidDeviceId, cudaInvalidDeviceId }. If data is smaller than the number of devices that have that advice set, then only as many devices will be returned as can fit in the array. There is no guarantee on which specific devices will be returned, however.
- cudaMemRangeAttributeLastPrefetchLocation: If this attribute is specified, data will be interpreted as a 32-bit integer, and dataSize must be 4. The result returned will be the last location to which all pages in the memory range were prefetched explicitly via cudaMemPrefetchAsync. This will either be a GPU id or cudaCpuDeviceId depending on whether the last location for prefetch was a GPU or the CPU respectively. If any page in the memory range was never explicitly prefetched or if all pages were not prefetched to the same location, cudaInvalidDeviceId will be returned. Note that this simply returns the last location that the application requested to prefetch the memory range to. It gives no indication as to whether the prefetch operation to that location has completed or even begun.



- Note that this function may also return error codes from previous, asynchronous launches.
- This function exhibits asynchronous behavior for most use cases.
- This function uses standard default stream semantics.

#### See also:

cudaMemRangeGetAttributes, cudaMemPrefetchAsync, cudaMemAdvise

\_\_host\_\_cudaError\_t cudaMemRangeGetAttributes
(void \*\*data, size\_t \*dataSizes, cudaMemRangeAttribute)

# \*attributes, size\_t numAttributes, const void \*devPtr, size\_t count)

Query attributes of a given memory range.

#### **Parameters**

#### data

- A two-dimensional array containing pointers to memory locations where the result of each attribute query will be written to.

#### dataSizes

- Array containing the sizes of each result

#### attributes

- An array of attributes to query (numAttributes and the number of attributes in this array should match)

#### numAttributes

- Number of attributes to query

#### devPtr

- Start of the range to query

#### count

- Size of the range to query

#### Returns

cudaSuccess, cudaErrorInvalidValue

#### Description

Query attributes of the memory range starting at devPtr with a size of count bytes. The memory range must refer to managed memory allocated via cudaMallocManaged or declared via \_\_managed\_\_ variables. The attributes array will be interpreted to have numAttributes entries. The dataSizes array will also be interpreted to have numAttributes entries. The results of the query will be stored in data.

The list of supported attributes are given below. Please refer to cudaMemRangeGetAttribute for attribute descriptions and restrictions.

- cudaMemRangeAttributeReadMostly
- cudaMemRangeAttributePreferredLocation
- cudaMemRangeAttributeAccessedBy
- cudaMemRangeAttributeLastPrefetchLocation



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

 $cuda Mem Range Get Attribute, cuda Mem Advise\ cuda Mem Prefetch Async$ 

# \_\_host\_\_cudaError\_t cudaMemset (void \*devPtr, int value, size\_t count)

Initializes or sets device memory to a value.

#### **Parameters**

#### devPtr

- Pointer to device memory

#### value

- Value to set for each byte of specified memory

#### count

- Size in bytes to set

#### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevicePointer

#### Description

Fills the first count bytes of the memory area pointed to by devPtr with the constant byte value value.

Note that this function is asynchronous with respect to the host unless devPtr refers to pinned host memory.



- Note that this function may also return error codes from previous, asynchronous launches.
- See also memset synchronization details.

#### See also:

cudaMemset2D, cudaMemset3D, cudaMemset4DAsync, cudaMemset3DAsync

# \_\_host\_\_cudaError\_t cudaMemset2D (void \*devPtr, size\_t pitch, int value, size\_t width, size\_t height)

Initializes or sets device memory to a value.

#### **Parameters**

#### devPtr

- Pointer to 2D device memory

#### pitch

- Pitch in bytes of 2D device memory

#### value

- Value to set for each byte of specified memory

#### width

- Width of matrix set (columns in bytes)

#### height

- Height of matrix set (rows)

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevicePointer

#### Description

Sets to the specified value value a matrix (height rows of width bytes each) pointed to by dstPtr. pitch is the width in bytes of the 2D array pointed to by dstPtr, including any padding added to the end of each row. This function performs fastest when the pitch is one that has been passed back by cudaMallocPitch().

Note that this function is asynchronous with respect to the host unless devPtr refers to pinned host memory.



- Note that this function may also return error codes from previous, asynchronous launches.
- See also memset synchronization details.

#### See also:

cudaMemset, cudaMemset3D, cudaMemsetAsync, cudaMemset2DAsync, cudaMemset3DAsync

\_\_host\_\_\_\_device\_\_cudaError\_t cudaMemset2DAsync (void \*devPtr, size\_t pitch, int value, size\_t width, size\_t height, cudaStream\_t stream)

Initializes or sets device memory to a value.

#### **Parameters**

#### devPtr

- Pointer to 2D device memory

#### pitch

- Pitch in bytes of 2D device memory

#### value

- Value to set for each byte of specified memory

#### width

- Width of matrix set (columns in bytes)

#### height

- Height of matrix set (rows)

#### stream

- Stream identifier

#### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevicePointer

#### Description

Sets to the specified value value a matrix (height rows of width bytes each) pointed to by dstPtr. pitch is the width in bytes of the 2D array pointed to by dstPtr, including any padding added to the end of each row. This function performs fastest when the pitch is one that has been passed back by cudaMallocPitch().

cudaMemset2DAsync() is asynchronous with respect to the host, so the call may return before the memset is complete. The operation can optionally be associated to a stream by passing a non-zero stream argument. If stream is non-zero, the operation may overlap with operations in other streams.

The device version of this function only handles device to device copies and cannot be given local or shared pointers.



- Note that this function may also return error codes from previous, asynchronous launches.
- See also memset synchronization details.
- ▶ This function uses standard default stream semantics.

#### See also:

cudaMemset, cudaMemset2D, cudaMemset3D, cudaMemsetAsync, cudaMemset3DAsync

# \_\_host\_\_cudaError\_t cudaMemset3D (cudaPitchedPtr pitchedDevPtr, int value, cudaExtent extent)

Initializes or sets device memory to a value.

#### **Parameters**

#### pitchedDevPtr

- Pointer to pitched device memory

#### value

- Value to set for each byte of specified memory

#### extent

- Size parameters for where to set device memory (width field in bytes)

#### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevicePointer

#### Description

Initializes each element of a 3D array to the specified value value. The object to initialize is defined by pitchedDevPtr. The pitch field of pitchedDevPtr is the width in memory in bytes of the 3D array pointed to by pitchedDevPtr, including any padding added to the end of each row. The xsize field specifies the logical width of each row in bytes, while the ysize field specifies the height of each 2D slice in rows.

The extents of the initialized region are specified as a width in bytes, a height in rows, and a depth in slices.

Extents with width greater than or equal to the xsize of pitchedDevPtr may perform significantly faster than extents narrower than the xsize. Secondarily, extents with height equal to the ysize of pitchedDevPtr will perform faster than when the height is shorter than the ysize.

This function performs fastest when the pitchedDevPtr has been allocated by cudaMalloc3D().

Note that this function is asynchronous with respect to the host unless pitchedDevPtr refers to pinned host memory.



- Note that this function may also return error codes from previous, asynchronous launches.
- See also memset synchronization details.

#### See also:

cudaMemset, cudaMemset2D, cudaMemsetAsync, cudaMemset2DAsync, cudaMemset3DAsync, cudaMalloc3D, make\_cudaPitchedPtr, make\_cudaExtent

\_\_host\_\_\_\_device\_\_cudaError\_t cudaMemset3DAsync (cudaPitchedPtr pitchedDevPtr, int value, cudaExtent extent, cudaStream\_t stream)

Initializes or sets device memory to a value.

#### **Parameters**

#### pitchedDevPtr

- Pointer to pitched device memory

#### value

- Value to set for each byte of specified memory

#### extent

- Size parameters for where to set device memory (width field in bytes)

#### stream

- Stream identifier

#### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevicePointer

#### Description

Initializes each element of a 3D array to the specified value value. The object to initialize is defined by pitchedDevPtr. The pitch field of pitchedDevPtr is the width in memory in bytes of the 3D array pointed to by pitchedDevPtr, including any padding added to the end of each row. The xsize field specifies the logical width of each row in bytes, while the ysize field specifies the height of each 2D slice in rows.

The extents of the initialized region are specified as a width in bytes, a height in rows, and a depth in slices.

Extents with width greater than or equal to the xsize of pitchedDevPtr may perform significantly faster than extents narrower than the xsize. Secondarily, extents with height equal to the ysize of pitchedDevPtr will perform faster than when the height is shorter than the ysize.

This function performs fastest when the pitchedDevPtr has been allocated by cudaMalloc3D().

cudaMemset3DAsync() is asynchronous with respect to the host, so the call may return before the memset is complete. The operation can optionally be associated to a stream by passing a non-zero stream argument. If stream is non-zero, the operation may overlap with operations in other streams.

The device version of this function only handles device to device copies and cannot be given local or shared pointers.



- Note that this function may also return error codes from previous, asynchronous launches.
- See also memset synchronization details.
- This function uses standard default stream semantics.

#### See also:

cudaMemset, cudaMemset2D, cudaMemset3D, cudaMemsetAsync, cudaMemset2DAsync, cudaMalloc3D, make\_cudaPitchedPtr, make\_cudaExtent

\_\_host\_\_\_\_device\_\_cudaError\_t cudaMemsetAsync (void \*devPtr, int value, size\_t count, cudaStream\_t stream)
Initializes or sets device memory to a value.

#### **Parameters**

#### devPtr

- Pointer to device memory

#### value

- Value to set for each byte of specified memory

#### count

- Size in bytes to set

#### stream

- Stream identifier

#### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevicePointer

#### Description

Fills the first count bytes of the memory area pointed to by devPtr with the constant byte value value.

cudaMemsetAsync() is asynchronous with respect to the host, so the call may return before the memset is complete. The operation can optionally be associated to a stream by passing a non-zero stream argument. If stream is non-zero, the operation may overlap with operations in other streams.

The device version of this function only handles device to device copies and cannot be given local or shared pointers.



- Note that this function may also return error codes from previous, asynchronous launches.
- See also memset synchronization details.
- ▶ This function uses standard default stream semantics.

#### See also:

cudaMemset, cudaMemset2D, cudaMemset2DAsync, cudaMemset3DAsync

### \_\_host\_\_make\_cudaExtent (size\_t w, size\_t h, size\_t d)

Returns a cudaExtent based on input parameters.

#### **Parameters**

W

- Width in elements when referring to array memory, in bytes when referring to linear memory

h

- Height in elements

d

- Depth in elements

#### Returns

cudaExtent specified by w, h, and d

#### Description

Returns a cudaExtent based on the specified input parameters w, h, and d.

#### See also:

make\_cudaPitchedPtr, make\_cudaPos

# \_\_host\_\_make\_cudaPitchedPtr (void \*d, size\_t p, size\_t xsz, size\_t ysz)

Returns a cudaPitchedPtr based on input parameters.

#### **Parameters**

d

- Pointer to allocated memory

p

- Pitch of allocated memory in bytes

XS7

- Logical width of allocation in elements

ysz

- Logical height of allocation in elements

#### **Returns**

cudaPitchedPtr specified by d, p, xsz, and ysz

#### **Description**

Returns a cudaPitchedPtr based on the specified input parameters d, p, xsz, and ysz.

#### See also:

make\_cudaExtent, make\_cudaPos

### \_\_host\_\_make\_cudaPos (size\_t x, size\_t y, size\_t z)

Returns a cudaPos based on input parameters.

#### **Parameters**

X

- X position

y

- Y position

Z

- Z position

#### Returns

cudaPos specified by x, y, and z

#### Description

Returns a cudaPos based on the specified input parameters x, y, and z.

#### See also:

make\_cudaExtent, make\_cudaPitchedPtr

### 4.10. Unified Addressing

This section describes the unified addressing functions of the CUDA runtime application programming interface.

#### Overview

CUDA devices can share a unified address space with the host. For these devices there is no distinction between a device pointer and a host pointer -- the same pointer value may be used to access memory from the host program and from a kernel running on the device (with exceptions enumerated below).

#### **Supported Platforms**

Whether or not a device supports unified addressing may be queried by calling cudaGetDeviceProperties() with the device property cudaDeviceProp::unifiedAddressing.

Unified addressing is automatically enabled in 64-bit processes.

Unified addressing is not yet supported on Windows Vista or Windows 7 for devices that do not use the TCC driver model.

#### **Looking Up Information from Pointer Values**

It is possible to look up information about the memory which backs a pointer value. For instance, one may want to know if a pointer points to host or device memory. As another example, in the case of device memory, one may want to know on which CUDA device the memory resides. These properties may be queried using the function cudaPointerGetAttributes()

Since pointers are unique, it is not necessary to specify information about the pointers specified to cudaMemcpy() and other copy functions. The copy direction cudaMemcpyDefault may be used to specify that the CUDA runtime should infer the location of the pointer from its value.

#### **Automatic Mapping of Host Allocated Host Memory**

All host memory allocated through all devices using cudaMallocHost() and cudaHostAlloc() is always directly accessible from all devices that support unified

addressing. This is the case regardless of whether or not the flags cudaHostAllocPortable and cudaHostAllocMapped are specified.

The pointer value through which allocated host memory may be accessed in kernels on all devices that support unified addressing is the same as the pointer value through which that memory is accessed on the host. It is not necessary to call cudaHostGetDevicePointer() to get the device pointer for these allocations.

Note that this is not the case for memory allocated using the flag cudaHostAllocWriteCombined, as discussed below.

#### **Direct Access of Peer Memory**

Upon enabling direct access from a device that supports unified addressing to another peer device that supports unified addressing using cudaDeviceEnablePeerAccess() all memory allocated in the peer device using cudaMalloc() and cudaMallocPitch() will immediately be accessible by the current device. The device pointer value through which any peer's memory may be accessed in the current device is the same pointer value through which that memory may be accessed from the peer device.

#### **Exceptions, Disjoint Addressing**

Not all memory may be accessed on devices through the same pointer value through which they are accessed on the host. These exceptions are host memory registered using cudaHostRegister() and host memory allocated using the flag cudaHostAllocWriteCombined. For these exceptions, there exists a distinct host and device address for the memory. The device address is guaranteed to not overlap any valid host pointer range and is guaranteed to have the same value across all devices that support unified addressing.

This device address may be queried using cudaHostGetDevicePointer() when a device using unified addressing is current. Either the host or the unified device pointer value may be used to refer to this memory in cudaMemcpy() and similar functions using the cudaMemcpyDefault memory direction.

## \_\_host\_\_cudaError\_t cudaPointerGetAttributes (cudaPointerAttributes \*attributes, const void \*ptr)

Returns attributes about a specified pointer.

#### **Parameters**

#### attributes

- Attributes for the specified pointer

#### ptr

- Pointer to get attributes for

#### Returns

cudaSuccess, cudaErrorInvalidDevice, cudaErrorInvalidValue

#### Description

Returns in \*attributes the attributes of the pointer ptr. If pointer was not allocated in, mapped by or registered with context supporting unified addressing cudaErrorInvalidValue is returned.

The cudaPointerAttributes structure is defined as:

```
struct cudaPointerAttributes {
    enum cudaMemoryType
        memoryType;
    int device;
    void *devicePointer;
    void *hostPointer;
    int isManaged;
}
```

In this structure, the individual fields mean

- memoryType identifies the physical location of the memory associated with pointer ptr. It can be cudaMemoryTypeHost for host memory or cudaMemoryTypeDevice for device memory.
- device is the device against which ptr was allocated. If ptr has memory type cudaMemoryTypeDevice then this identifies the device on which the memory referred to by ptr physically resides. If ptr has memory type cudaMemoryTypeHost then this identifies the device which was current when the allocation was made (and if that device is deinitialized then this allocation will vanish with that device's state).
- devicePointer is the device pointer alias through which the memory referred to by ptr may be accessed on the current device. If the memory referred to by ptr cannot be accessed directly by the current device then this is NULL.
- hostPointer is the host pointer alias through which the memory referred to by ptr may be accessed on the host. If the memory referred to by ptr cannot be accessed directly by the host then this is NULL.
- ▶ isManaged indicates if the pointer ptr points to managed memory or not.

#### See also:

cudaGetDeviceCount, cudaGetDevice, cudaSetDevice, cudaChooseDevice

### 4.11. Peer Device Memory Access

This section describes the peer device memory access functions of the CUDA runtime application programming interface.

# \_\_host\_\_cudaError\_t cudaDeviceCanAccessPeer (int \*canAccessPeer, int device, int peerDevice)

Queries if a device may directly access a peer device's memory.

#### **Parameters**

#### canAccessPeer

- Returned access capability

#### device

- Device from which allocations on peerDevice are to be directly accessed. **peerDevice** 
  - Device on which the allocations to be directly accessed by device reside.

#### Returns

cudaSuccess, cudaErrorInvalidDevice

#### Description

Returns in \*canAccessPeer a value of 1 if device device is capable of directly accessing memory from peerDevice and 0 otherwise. If direct access of peerDevice from device is possible, then access may be enabled by calling cudaDeviceEnablePeerAccess().



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaDeviceEnablePeerAccess, cudaDeviceDisablePeerAccess

### \_\_host\_\_cudaError\_t cudaDeviceDisablePeerAccess (int peerDevice)

Disables direct access to memory allocations on a peer device.

#### **Parameters**

#### peerDevice

- Peer device to disable direct access to

#### **Returns**

cudaSuccess, cudaErrorPeerAccessNotEnabled, cudaErrorInvalidDevice

#### Description

Returns cudaErrorPeerAccessNotEnabled if direct access to memory on peerDevice has not yet been enabled from the current device.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaDeviceCanAccessPeer, cudaDeviceEnablePeerAccess

### \_\_host\_\_cudaError\_t cudaDeviceEnablePeerAccess (int peerDevice, unsigned int flags)

Enables direct access to memory allocations on a peer device.

#### **Parameters**

#### peerDevice

- Peer device to enable direct access to from the current device

#### flags

- Reserved for future use and must be set to 0

#### **Returns**

 $cuda Success, cuda Error Invalid Device, cuda Error Peer Access Already Enabled, \\ cuda Error Invalid Value$ 

#### Description

On success, all allocations from peerDevice will immediately be accessible by the current device. They will remain accessible until access is explicitly disabled using cudaDeviceDisablePeerAccess() or either device is reset using cudaDeviceReset().

Note that access granted by this call is unidirectional and that in order to access memory on the current device from peerDevice, a separate symmetric call to cudaDeviceEnablePeerAccess() is required.

Each device can support a system-wide maximum of eight peer connections.

Peer access is not supported in 32 bit applications.

Returns cudaErrorInvalidDevice if cudaDeviceCanAccessPeer() indicates that the current device cannot directly access memory from peerDevice.

Returns cudaErrorPeerAccessAlreadyEnabled if direct access of peerDevice from the current device has already been enabled.

Returns cudaErrorInvalidValue if flags is not 0.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaDeviceCanAccessPeer, cudaDeviceDisablePeerAccess

### 4.12. OpenGL Interoperability

This section describes the OpenGL interoperability functions of the CUDA runtime application programming interface. Note that mapping of OpenGL resources is performed with the graphics API agnostic, resource mapping interface described in Graphics Interopability.

#### enum cudaGLDeviceList

CUDA devices corresponding to the current OpenGL context

#### **Values**

#### cudaGLDeviceListAll = 1

The CUDA devices for all GPUs used by the current OpenGL context cudaGLDeviceListCurrentFrame = 2

The CUDA devices for the GPUs used by the current OpenGL context in its currently rendering frame

#### cudaGLDeviceListNextFrame = 3

The CUDA devices for the GPUs to be used by the current OpenGL context in the next frame

\_\_host\_\_cudaError\_t cudaGLGetDevices (unsigned int \*pCudaDeviceCount, int \*pCudaDevices, unsigned int cudaDeviceCount, cudaGLDeviceList deviceList)

Gets the CUDA devices associated with the current OpenGL context.

#### **Parameters**

#### pCudaDeviceCount

- Returned number of CUDA devices corresponding to the current OpenGL context pCudaDevices
- Returned CUDA devices corresponding to the current OpenGL context  ${\bf cudaDeviceCount}$ 
  - The size of the output device array pCudaDevices

#### deviceList

- The set of devices to return. This set may be cudaGLDeviceListAll for all devices, cudaGLDeviceListCurrentFrame for the devices used to render the current frame (in SLI), or cudaGLDeviceListNextFrame for the devices used to render the next frame (in SLI).

#### **Returns**

cudaSuccess, cudaErrorNoDevice, cudaErrorInvalidGraphicsContext, cudaErrorUnknown

#### Description

Returns in \*pCudaDeviceCount the number of CUDA-compatible devices corresponding to the current OpenGL context. Also returns in \*pCudaDevices at most cudaDeviceCount of the CUDA-compatible devices corresponding to the current OpenGL context. If any of the GPUs being used by the current OpenGL context are not CUDA capable then the call will return cudaErrorNoDevice.



- This function is not supported on Mac OS X.
- Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGraphicsUnregisterResource, cudaGraphicsMapResources, cudaGraphicsSubResourceGetMappedArray, cudaGraphicsResourceGetMappedPointer

# \_\_host\_\_cudaError\_t cudaGraphicsGLRegisterBuffer (cudaGraphicsResource \*\*resource, GLuint buffer, unsigned int flags)

Registers an OpenGL buffer object.

#### **Parameters**

#### resource

- Pointer to the returned object handle

#### buffer

- name of buffer object to be registered

#### flags

Register flags

#### Returns

cudaSuccess, cudaErrorInvalidDevice, cudaErrorInvalidValue, cudaErrorInvalidResourceHandle, cudaErrorUnknown

#### Description

Registers the buffer object specified by buffer for access by CUDA. A handle to the registered object is returned as resource. The register flags flags specify the intended usage, as follows:

- cudaGraphicsRegisterFlagsNone: Specifies no hints about how this resource will be used. It is therefore assumed that this resource will be read from and written to by CUDA. This is the default value.
- cudaGraphicsRegisterFlagsReadOnly: Specifies that CUDA will not write to this resource.
- cudaGraphicsRegisterFlagsWriteDiscard: Specifies that CUDA will not read from this resource and will write over the entire contents of the resource, so none of the data previously stored in the resource will be preserved.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGraphicsUnregisterResource, cudaGraphicsMapResources, cudaGraphicsResourceGetMappedPointer

# \_\_host\_\_cudaError\_t cudaGraphicsGLRegisterImage (cudaGraphicsResource \*\*resource, GLuint image, GLenum target, unsigned int flags)

Register an OpenGL texture or renderbuffer object.

#### **Parameters**

#### resource

- Pointer to the returned object handle

#### image

- name of texture or renderbuffer object to be registered

#### target

- Identifies the type of object specified by image

#### flags

- Register flags

#### **Returns**

cudaSuccess, cudaErrorInvalidDevice, cudaErrorInvalidValue, cudaErrorInvalidResourceHandle, cudaErrorUnknown

#### Description

Registers the texture or renderbuffer object specified by image for access by CUDA. A handle to the registered object is returned as resource.

target must match the type of the object, and must be one of GL\_TEXTURE\_2D, GL\_TEXTURE\_RECTANGLE, GL\_TEXTURE\_CUBE\_MAP, GL\_TEXTURE\_3D, GL\_TEXTURE\_2D\_ARRAY, or GL\_RENDERBUFFER.

The register flags flags specify the intended usage, as follows:

- cudaGraphicsRegisterFlagsNone: Specifies no hints about how this resource will be used. It is therefore assumed that this resource will be read from and written to by CUDA. This is the default value.
- cudaGraphicsRegisterFlagsReadOnly: Specifies that CUDA will not write to this resource.
- ► cudaGraphicsRegisterFlagsWriteDiscard: Specifies that CUDA will not read from this resource and will write over the entire contents of the resource, so none of the data previously stored in the resource will be preserved.
- cudaGraphicsRegisterFlagsSurfaceLoadStore: Specifies that CUDA will bind this resource to a surface reference.

 cudaGraphicsRegisterFlagsTextureGather: Specifies that CUDA will perform texture gather operations on this resource.

The following image formats are supported. For brevity's sake, the list is abbreviated. For ex., {GL\_R, GL\_RG} X {8, 16} would expand to the following 4 formats {GL\_R8, GL\_R16, GL\_RG8, GL\_RG16}:

- GL\_RED, GL\_RG, GL\_RGBA, GL\_LUMINANCE, GL\_ALPHA, GL\_LUMINANCE\_ALPHA, GL\_INTENSITY
- ► {GL\_R, GL\_RG, GL\_RGBA} X {8, 16, 16F, 32F, 8UI, 16UI, 32UI, 8I, 16I, 32I}
- ► {GL\_LUMINANCE, GL\_ALPHA, GL\_LUMINANCE\_ALPHA, GL\_INTENSITY} X {8, 16, 16F\_ARB, 32F\_ARB, 8UI\_EXT, 16UI\_EXT, 32UI\_EXT, 8I\_EXT, 16I\_EXT, 32I\_EXT}

The following image classes are currently disallowed:

- Textures with borders
- Multisampled renderbuffers



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

 $cuda Graphics Unregister Resource, cuda Graphics Map Resources, \\ cuda Graphics Sub Resource Get Mapped Array$ 

# \_\_host\_\_cudaError\_t cudaWGLGetDevice (int \*device, HGPUNV hGpu)

Gets the CUDA device associated with hGpu.

#### **Parameters**

#### device

- Returns the device associated with hGpu, or -1 if hGpu is not a compute device.

#### hGpu

- Handle to a GPU, as queried via WGL\_NV\_gpu\_affinity

#### **Returns**

cudaSuccess

#### Description

Returns the CUDA device associated with a hGpu, if applicable.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

WGL\_NV\_gpu\_affinity

### 4.13. OpenGL Interoperability [DEPRECATED]

This section describes deprecated OpenGL interoperability functionality.

### enum cudaGLMapFlags

CUDA GL Map Flags

#### **Values**

#### cudaGLMapFlagsNone = 0

Default; Assume resource can be read/written

#### cudaGLMapFlagsReadOnly = 1

CUDA kernels will not write to this resource

#### cudaGLMapFlagsWriteDiscard = 2

CUDA kernels will only write to and will not read from this resource

# \_\_host\_\_cudaError\_t cudaGLMapBufferObject (void \*\*devPtr, GLuint bufObj)

Maps a buffer object for access by CUDA.

#### **Parameters**

#### devPtr

- Returned device pointer to CUDA object

#### bufObj

- Buffer object ID to map

#### **Returns**

cudaSuccess, cudaErrorMapBufferObjectFailed

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Maps the buffer object of ID bufObj into the address space of CUDA and returns in \*devPtr the base pointer of the resulting mapping. The buffer must have previously been registered by calling cudaGLRegisterBufferObject(). While a buffer is mapped by CUDA, any OpenGL operation which references the buffer will result in undefined behavior. The OpenGL context used to create the buffer, or another context from the same share group, must be bound to the current thread when this is called.

All streams in the current thread are synchronized with the current GL context.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cuda Graphics Map Resources

## \_\_host\_\_cudaError\_t cudaGLMapBufferObjectAsync (void \*\*devPtr, GLuint bufObj, cudaStream\_t stream)

Maps a buffer object for access by CUDA.

#### **Parameters**

#### devPtr

Returned device pointer to CUDA object

#### bufObj

- Buffer object ID to map

#### stream

- Stream to synchronize

#### Returns

cudaSuccess, cudaErrorMapBufferObjectFailed

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Maps the buffer object of ID bufObj into the address space of CUDA and returns in \*devPtr the base pointer of the resulting mapping. The buffer must have previously been registered by calling cudaGLRegisterBufferObject(). While a buffer is mapped by CUDA, any OpenGL operation which references the buffer will result in undefined behavior. The OpenGL context used to create the buffer, or another context from the same share group, must be bound to the current thread when this is called.

Stream /p stream is synchronized with the current GL context.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cuda Graphics Map Resources

## \_\_host\_\_cudaError\_t cudaGLRegisterBufferObject (GLuint bufObj)

Registers a buffer object for access by CUDA.

#### **Parameters**

#### bufObj

- Buffer object ID to register

#### Returns

cudaSuccess, cudaErrorInitializationError

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Registers the buffer object of ID bufobj for access by CUDA. This function must be called before CUDA can map the buffer object. The OpenGL context used to create the buffer, or another context from the same share group, must be bound to the current thread when this is called.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGraphicsGLRegisterBuffer

# \_\_host\_\_cudaError\_t cudaGLSetBufferObjectMapFlags (GLuint bufObj, unsigned int flags)

Set usage flags for mapping an OpenGL buffer.

#### **Parameters**

#### bufObj

- Registered buffer object to set flags for

#### flags

- Parameters for buffer mapping

#### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidResourceHandle, cudaErrorUnknown

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Set flags for mapping the OpenGL buffer buf0bj

Changes to flags will take effect the next time bufObj is mapped. The flags argument may be any of the following:

- cudaGLMapFlagsNone: Specifies no hints about how this buffer will be used. It is therefore assumed that this buffer will be read from and written to by CUDA kernels. This is the default value.
- cudaGLMapFlagsReadOnly: Specifies that CUDA kernels which access this buffer will not write to the buffer.
- cudaGLMapFlagsWriteDiscard: Specifies that CUDA kernels which access this buffer will not read from the buffer and will write over the entire contents of the buffer, so none of the data previously stored in the buffer will be preserved.

If bufObj has not been registered for use with CUDA, then cudaErrorInvalidResourceHandle is returned. If bufObj is presently mapped for access by CUDA, then cudaErrorUnknown is returned.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGraphicsResourceSetMapFlags

### \_\_host\_\_cudaError\_t cudaGLSetGLDevice (int device)

Sets a CUDA device to use OpenGL interoperability.

#### **Parameters**

#### device

- Device to use for OpenGL interoperability

#### Returns

cudaSuccess, cudaErrorInvalidDevice, cudaErrorSetOnActiveProcess

#### Description

Deprecated This function is deprecated as of CUDA 5.0.

This function is deprecated and should no longer be used. It is no longer necessary to associate a CUDA device with an OpenGL context in order to achieve maximum interoperability performance.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGraphicsGLRegisterBuffer, cudaGraphicsGLRegisterImage

## \_\_host\_\_cudaError\_t cudaGLUnmapBufferObject (GLuint bufObj)

Unmaps a buffer object for access by CUDA.

#### **Parameters**

#### bufObj

- Buffer object to unmap

#### **Returns**

cudaSuccess, cudaErrorInvalidDevicePointer, cudaErrorUnmapBufferObjectFailed

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Unmaps the buffer object of ID bufObj for access by CUDA. When a buffer is unmapped, the base address returned by cudaGLMapBufferObject() is invalid and subsequent references to the address result in undefined behavior. The OpenGL context used to create the buffer, or another context from the same share group, must be bound to the current thread when this is called.

All streams in the current thread are synchronized with the current GL context.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGraphicsUnmapResources

# \_\_host\_\_cudaError\_t cudaGLUnmapBufferObjectAsync (GLuint bufObj, cudaStream\_t stream)

Unmaps a buffer object for access by CUDA.

#### **Parameters**

#### bufObj

- Buffer object to unmap

#### stream

- Stream to synchronize

#### **Returns**

cudaSuccess, cudaErrorInvalidDevicePointer, cudaErrorUnmapBufferObjectFailed

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Unmaps the buffer object of ID bufObj for access by CUDA. When a buffer is unmapped, the base address returned by cudaGLMapBufferObject() is invalid and subsequent references to the address result in undefined behavior. The OpenGL context used to create the buffer, or another context from the same share group, must be bound to the current thread when this is called.

Stream /p stream is synchronized with the current GL context.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGraphicsUnmapResources

# \_\_host\_\_cudaError\_t cudaGLUnregisterBufferObject (GLuint bufObj)

Unregisters a buffer object for access by CUDA.

#### **Parameters**

#### bufObj

- Buffer object to unregister

#### **Returns**

cudaSuccess

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Unregisters the buffer object of ID bufObj for access by CUDA and releases any CUDA resources associated with the buffer. Once a buffer is unregistered, it may no longer be mapped by CUDA. The GL context used to create the buffer, or another context from the same share group, must be bound to the current thread when this is called.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGraphicsUnregisterResource

### 4.14. Direct3D 9 Interoperability

This section describes the Direct3D 9 interoperability functions of the CUDA runtime application programming interface. Note that mapping of Direct3D 9 resources is

performed with the graphics API agnostic, resource mapping interface described in Graphics Interopability.

#### enum cudaD3D9DeviceList

CUDA devices corresponding to a D3D9 device

#### **Values**

#### cudaD3D9DeviceListAll = 1

The CUDA devices for all GPUs used by a D3D9 device

#### cudaD3D9DeviceListCurrentFrame = 2

The CUDA devices for the GPUs used by a D3D9 device in its currently rendering frame

#### cudaD3D9DeviceListNextFrame = 3

The CUDA devices for the GPUs to be used by a D3D9 device in the next frame

### \_\_host\_\_cudaError\_t cudaD3D9GetDevice (int \*device, const char \*pszAdapterName)

Gets the device number for an adapter.

#### **Parameters**

#### device

- Returns the device corresponding to pszAdapterName

#### pszAdapterName

- D3D9 adapter to get device for

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorUnknown

#### Description

Returns in \*device the CUDA-compatible device corresponding to the adapter name pszAdapterName obtained from EnumDisplayDevices or IDirect3D9::GetAdapterIdentifier(). If no device on the adapter with name pszAdapterName is CUDA-compatible then the call will fail.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaD3D9SetDirect3DDevice, cudaGraphicsD3D9RegisterResource,

\_\_host\_\_cudaError\_t cudaD3D9GetDevices (unsigned int \*pCudaDeviceCount, int \*pCudaDevices, unsigned int cudaDeviceCount, IDirect3DDevice9 \*pD3D9Device, cudaD3D9DeviceList deviceList)

Gets the CUDA devices corresponding to a Direct3D 9 device.

#### **Parameters**

#### pCudaDeviceCount

- Returned number of CUDA devices corresponding to pD3D9Device pCudaDevices

- Returned CUDA devices corresponding to pD3D9Device

#### cudaDeviceCount

- The size of the output device array pCudaDevices

#### pD3D9Device

- Direct3D 9 device to query for CUDA devices

#### deviceList

- The set of devices to return. This set may be cudaD3D9DeviceListAll for all devices, cudaD3D9DeviceListCurrentFrame for the devices used to render the current frame (in SLI), or cudaD3D9DeviceListNextFrame for the devices used to render the next frame (in SLI).

#### **Returns**

cudaSuccess, cudaErrorNoDevice, cudaErrorUnknown

#### Description

Returns in \*pCudaDeviceCount the number of CUDA-compatible devices corresponding to the Direct3D 9 device pD3D9Device. Also returns in \*pCudaDevices at most cudaDeviceCount of the the CUDA-compatible devices corresponding to the Direct3D 9 device pD3D9Device.

If any of the GPUs being used to render pDevice are not CUDA capable then the call will return cudaErrorNoDevice.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGraphicsUnregisterResource, cudaGraphicsMapResources, cudaGraphicsSubResourceGetMappedArray, cudaGraphicsResourceGetMappedPointer

# \_\_host\_\_cudaError\_t cudaD3D9GetDirect3DDevice (IDirect3DDevice9 \*\*ppD3D9Device)

Gets the Direct3D device against which the current CUDA context was created.

#### **Parameters**

#### ppD3D9Device

- Returns the Direct3D device for this thread

#### **Returns**

cudaSuccess, cudaErrorInvalidGraphicsContext, cudaErrorUnknown

#### Description

Returns in \*ppD3D9Device the Direct3D device against which this CUDA context was created in cudaD3D9SetDirect3DDevice().



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaD3D9SetDirect3DDevice

# \_\_host\_\_cudaError\_t cudaD3D9SetDirect3DDevice (IDirect3DDevice9 \*pD3D9Device, int device)

Sets the Direct3D 9 device to use for interoperability with a CUDA device.

#### **Parameters**

#### pD3D9Device

- Direct3D device to use for this thread

#### device

- The CUDA device to use. This device must be among the devices returned when querying cudaD3D9DeviceListAll from cudaD3D9GetDevices, may be set to -1 to automatically select an appropriate CUDA device.

#### Returns

cudaSuccess, cudaErrorInitializationError, cudaErrorInvalidValue, cudaErrorSetOnActiveProcess

#### Description

Records pD3D9Device as the Direct3D 9 device to use for Direct3D 9 interoperability with the CUDA device device and sets device as the current device for the calling host thread.

If device has already been initialized then this call will fail with the error cudaErrorSetOnActiveProcess. In this case it is necessary to reset device using cudaDeviceReset() before Direct3D 9 interoperability on device may be enabled.

Successfully initializing CUDA interoperability with pD3D9Device will increase the internal reference count on pD3D9Device. This reference count will be decremented when device is reset using cudaDeviceReset().

Note that this function is never required for correct functionality. Use of this function will result in accelerated interoperability only when the operating system is Windows Vista or Windows 7, and the device pD3DDdevice is not an IDirect3DDevice9Ex. In all other cirumstances, this function is not necessary.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaD3D9GetDevice, cudaGraphicsD3D9RegisterResource, cudaDeviceReset

\_\_host\_\_cudaError\_t cudaGraphicsD3D9RegisterResource (cudaGraphicsResource \*\*resource, IDirect3DResource9 \*pD3DResource, unsigned int flags)

Register a Direct3D 9 resource for access by CUDA.

#### **Parameters**

#### resource

- Pointer to returned resource handle

#### pD3DResource

- Direct3D resource to register

#### flags

- Parameters for resource registration

#### Returns

cudaSuccess, cudaErrorInvalidDevice, cudaErrorInvalidValue, cudaErrorInvalidResourceHandle, cudaErrorUnknown

#### Description

Registers the Direct3D 9 resource pD3DResource for access by CUDA.

If this call is successful then the application will be able to map and unmap this resource until it is unregistered through cudaGraphicsUnregisterResource(). Also on success, this call will increase the internal reference count on pD3DResource. This reference count will be decremented when this resource is unregistered through cudaGraphicsUnregisterResource().

This call potentially has a high-overhead and should not be called every frame in interactive applications.

The type of pD3DResource must be one of the following.

- IDirect3DVertexBuffer9: may be accessed through a device pointer
- ▶ IDirect3DIndexBuffer9: may be accessed through a device pointer
- ▶ IDirect3DSurface9: may be accessed through an array. Only stand-alone objects of type IDirect3DSurface9 may be explicitly shared. In particular, individual mipmap levels and faces of cube maps may not be registered directly. To access individual surfaces associated with a texture, one must register the base texture object.
- ► IDirect3DBaseTexture9: individual surfaces on this texture may be accessed through an array.

The flags argument may be used to specify additional parameters at register time. The valid values for this parameter are

- cudaGraphicsRegisterFlagsNone: Specifies no hints about how this resource will be used.
- cudaGraphicsRegisterFlagsSurfaceLoadStore: Specifies that CUDA will bind this resource to a surface reference.
- cudaGraphicsRegisterFlagsTextureGather: Specifies that CUDA will perform texture gather operations on this resource.

Not all Direct3D resources of the above types may be used for interoperability with CUDA. The following are some limitations.

- ▶ The primary rendertarget may not be registered with CUDA.
- Resources allocated as shared may not be registered with CUDA.
- ► Textures which are not of a format which is 1, 2, or 4 channels of 8, 16, or 32-bit integer or floating-point data cannot be shared.
- Surfaces of depth or stencil formats cannot be shared.

A complete list of supported formats is as follows:

- ► D3DFMT\_L8
- ▶ D3DFMT L16
- D3DFMT A8R8G8B8
- ► D3DFMT\_X8R8G8B8
- ▶ D3DFMT\_G16R16
- D3DFMT\_A8B8G8R8
- D3DFMT\_A8
- D3DFMT\_A8L8
- ► D3DFMT\_Q8W8V8U8
- D3DFMT\_V16U16
- D3DFMT\_A16B16G16R16F
- D3DFMT\_A16B16G16R16
- D3DFMT\_R32F
- ► D3DFMT\_G16R16F
- D3DFMT\_A32B32G32R32F
- D3DFMT\_G32R32F
- D3DFMT\_R16F

If pD3DResource is of incorrect type or is already registered, then cudaErrorInvalidResourceHandle is returned. If pD3DResource cannot be registered, then cudaErrorUnknown is returned.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

 $cuda D3D9 Set Direct 3D Device, cuda Graphics Unregister Resource,\\ cuda Graphics Map Resources, cuda Graphics Sub Resource Get Mapped Array,\\ cuda Graphics Resource Get Mapped Pointer$ 

# 4.15. Direct3D 9 Interoperability [DEPRECATED]

This section describes deprecated Direct3D 9 interoperability functions.

### enum cudaD3D9MapFlags

CUDA D3D9 Map Flags

#### **Values**

#### cudaD3D9MapFlagsNone = 0

Default; Assume resource can be read/written

#### cudaD3D9MapFlagsReadOnly = 1

CUDA kernels will not write to this resource

#### cudaD3D9MapFlagsWriteDiscard = 2

CUDA kernels will only write to and will not read from this resource

### enum cudaD3D9RegisterFlags

CUDA D3D9 Register Flags

#### **Values**

#### cudaD3D9RegisterFlagsNone = 0

Default; Resource can be accessed througa void\*

#### cudaD3D9RegisterFlagsArray = 1

Resource can be accessed through a CUarray\*

# \_\_host\_\_cudaError\_t cudaD3D9MapResources (int count, IDirect3DResource9 \*\*ppResources)

Map Direct3D resources for access by CUDA.

#### **Parameters**

#### count

- Number of resources to map for CUDA

#### ppResources

- Resources to map for CUDA

#### Returns

cudaSuccess, cudaErrorInvalidResourceHandle, cudaErrorUnknown

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Maps the count Direct3D resources in ppResources for access by CUDA.

The resources in ppResources may be accessed in CUDA kernels until they are unmapped. Direct3D should not access any resources while they are mapped by CUDA. If an application does so, the results are undefined.

This function provides the synchronization guarantee that any Direct3D calls issued before cudaD3D9MapResources() will complete before any CUDA kernels issued after cudaD3D9MapResources() begin.

If any of ppResources have not been registered for use with CUDA or if ppResources contains any duplicate entries then cudaErrorInvalidResourceHandle is returned. If any of ppResources are presently mapped for access by CUDA then cudaErrorUnknown is returned.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGraphicsMapResources

# \_\_host\_\_cudaError\_t cudaD3D9RegisterResource (IDirect3DResource9 \*pResource, unsigned int flags)

Registers a Direct3D resource for access by CUDA.

#### **Parameters**

#### pResource

- Resource to register

#### flags

- Parameters for resource registration

#### **Returns**

cuda Success, cuda Error Invalid Value, cuda Error Invalid Resource Handle, cuda Error Unknown

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Registers the Direct3D resource pResource for access by CUDA.

If this call is successful, then the application will be able to map and unmap this resource until it is unregistered through cudaD3D9UnregisterResource(). Also on success, this call will increase the internal reference count on pResource. This reference count will be decremented when this resource is unregistered through cudaD3D9UnregisterResource().

This call potentially has a high-overhead and should not be called every frame in interactive applications.

The type of pResource must be one of the following.

IDirect3DVertexBuffer9: No notes.

- ▶ IDirect3DIndexBuffer9: No notes.
- ▶ IDirect3DSurface9: Only stand-alone objects of type IDirect3DSurface9 may be explicitly shared. In particular, individual mipmap levels and faces of cube maps may not be registered directly. To access individual surfaces associated with a texture, one must register the base texture object.
- ▶ IDirect3DBaseTexture9: When a texture is registered, all surfaces associated with all mipmap levels of all faces of the texture will be accessible to CUDA.

The flags argument specifies the mechanism through which CUDA will access the Direct3D resource. The following value is allowed:

cudaD3D9RegisterFlagsNone: Specifies that CUDA will access this resource through a void\*. The pointer, size, and pitch for each subresource of this resource may be queried through cudaD3D9ResourceGetMappedPointer(), cudaD3D9ResourceGetMappedSize(), and cudaD3D9ResourceGetMappedPitch() respectively. This option is valid for all resource types.

Not all Direct3D resources of the above types may be used for interoperability with CUDA. The following are some limitations:

- ▶ The primary rendertarget may not be registered with CUDA.
- ▶ Resources allocated as shared may not be registered with CUDA.
- ▶ Any resources allocated in D3DPOOL\_SYSTEMMEM or D3DPOOL\_MANAGED may not be registered with CUDA.
- ► Textures which are not of a format which is 1, 2, or 4 channels of 8, 16, or 32-bit integer or floating-point data cannot be shared.
- Surfaces of depth or stencil formats cannot be shared.

If Direct3D interoperability is not initialized on this context, then cudaErrorInvalidDevice is returned. If presource is of incorrect type (e.g., is a non-stand-alone IDirect3DSurface9) or is already registered, then cudaErrorInvalidResourceHandle is returned. If presource cannot be registered then cudaErrorUnknown is returned.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGraphicsD3D9RegisterResource

# \_\_host\_\_cudaError\_t cudaD3D9ResourceGetMappedArray (cudaArray \*\*ppArray, IDirect3DResource9 \*pResource, unsigned int face, unsigned int level)

Get an array through which to access a subresource of a Direct3D resource which has been mapped for access by CUDA.

#### **Parameters**

#### ppArray

- Returned array corresponding to subresource

#### pResource

- Mapped resource to access

#### face

- Face of resource to access

#### level

- Level of resource to access

#### Returns

cudaSuccess, cudaErrorInvalidResourceHandle, cudaErrorUnknown

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Returns in \*pArray an array through which the subresource of the mapped Direct3D resource pResource, which corresponds to face and level may be accessed. The value set in pArray may change every time that pResource is mapped.

If pResource is not registered then cudaErrorInvalidResourceHandle is returned. If pResource was not registered with usage flags cudaD3D9RegisterFlagsArray, then cudaErrorInvalidResourceHandle is returned. If pResource is not mapped, then cudaErrorUnknown is returned.

For usage requirements of face and level parameters, see cudaD3D9ResourceGetMappedPointer().



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGraphicsSubResourceGetMappedArray

# \_\_host\_\_cudaError\_t cudaD3D9ResourceGetMappedPitch (size\_t \*pPitch, size\_t \*pPitchSlice, IDirect3DResource9 \*pResource, unsigned int face, unsigned int level)

Get the pitch of a subresource of a Direct3D resource which has been mapped for access by CUDA.

#### **Parameters**

#### pPitch

- Returned pitch of subresource

#### pPitchSlice

- Returned Z-slice pitch of subresource

#### pResource

- Mapped resource to access

#### face

- Face of resource to access

#### level

- Level of resource to access

#### Returns

cuda Success, cuda Error Invalid Value, cuda Error Invalid Resource Handle, cuda Error Unknown

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Returns in \*pPitch and \*pPitchSlice the pitch and Z-slice pitch of the subresource of the mapped Direct3D resource pResource, which corresponds to face and level. The values set in pPitch and pPitchSlice may change every time that pResource is mapped.

The pitch and Z-slice pitch values may be used to compute the location of a sample on a surface as follows.

For a 2D surface, the byte offset of the sample at position **x**, **y** from the base pointer of the surface is:

```
y * pitch + (bytes per pixel) * x
```

For a 3D surface, the byte offset of the sample at position  $\mathbf{x}$ ,  $\mathbf{y}$ ,  $\mathbf{z}$  from the base pointer of the surface is:

#### z\* slicePitch + y \* pitch + (bytes per pixel) \* x

Both parameters pPitch and pPitchSlice are optional and may be set to NULL.

If pResource is not of type IDirect3DBaseTexture9 or one of its subtypes or if pResource has not been registered for use with CUDA, then cudaErrorInvalidResourceHandle is returned. If pResource was not registered with usage flags cudaD3D9RegisterFlagsNone, then cudaErrorInvalidResourceHandle is returned. If pResource is not mapped for access by CUDA then cudaErrorUnknown is returned.

For usage requirements of face and level parameters, see cudaD3D9ResourceGetMappedPointer().



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cuda Graphics Resource Get Mapped Pointer

# \_\_host\_\_cudaError\_t cudaD3D9ResourceGetMappedPointer (void \*\*pPointer, IDirect3DResource9 \*pResource, unsigned int face, unsigned int level)

Get a pointer through which to access a subresource of a Direct3D resource which has been mapped for access by CUDA.

#### **Parameters**

#### **pPointer**

- Returned pointer corresponding to subresource

#### pResource

- Mapped resource to access

#### face

- Face of resource to access

#### level

- Level of resource to access

#### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidResourceHandle, cudaErrorUnknown

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Returns in \*pPointer the base pointer of the subresource of the mapped Direct3D resource pResource, which corresponds to face and level. The value set in pPointer may change every time that pResource is mapped.

If pResource is not registered, then cudaErrorInvalidResourceHandle is returned. If pResource was not registered with usage flags cudaD3D9RegisterFlagsNone, then cudaErrorInvalidResourceHandle is returned. If pResource is not mapped, then cudaErrorUnknown is returned.

If pResource is of type IDirect3DCubeTexture9, then face must one of the values enumerated by type D3DCUBEMAP\_FACES. For all other types, face must be 0. If face is invalid, then cudaErrorInvalidValue is returned.

If pResource is of type IDirect3DBaseTexture9, then level must correspond to a valid mipmap level. Only mipmap level 0 is supported for now. For all other types level must be 0. If level is invalid, then cudaErrorInvalidValue is returned.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cuda Graphics Resource Get Mapped Pointer

# \_\_host\_\_cudaError\_t cudaD3D9ResourceGetMappedSize (size\_t \*pSize, IDirect3DResource9 \*pResource, unsigned int face, unsigned int level)

Get the size of a subresource of a Direct3D resource which has been mapped for access by CUDA.

#### **Parameters**

#### pSize

- Returned size of subresource

#### pResource

- Mapped resource to access

#### face

- Face of resource to access

#### level

- Level of resource to access

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidResourceHandle, cudaErrorUnknown

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Returns in \*pSize the size of the subresource of the mapped Direct3D resource pResource, which corresponds to face and level. The value set in pSize may change every time that pResource is mapped.

If pResource has not been registered for use with CUDA then cudaErrorInvalidResourceHandle is returned. If pResource was not registered with usage flags cudaD3D9RegisterFlagsNone, then cudaErrorInvalidResourceHandle is returned. If pResource is not mapped for access by CUDA then cudaErrorUnknown is returned.

For usage requirements of face and level parameters, see cudaD3D9ResourceGetMappedPointer().



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cuda Graphics Resource Get Mapped Pointer

\_\_host\_\_cudaError\_t cudaD3D9ResourceGetSurfaceDimensions (size\_t \*pWidth, size\_t \*pHeight, size\_t \*pDepth, IDirect3DResource9 \*pResource, unsigned int face, unsigned int level)

Get the dimensions of a registered Direct3D surface.

#### **Parameters**

#### pWidth

- Returned width of surface

#### pHeight

- Returned height of surface

#### pDepth

- Returned depth of surface

#### pResource

- Registered resource to access

#### face

- Face of resource to access

#### level

- Level of resource to access

#### Returns

cuda Success, cuda Error Invalid Value, cuda Error Invalid Resource Handle,

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Returns in \*pWidth, \*pHeight, and \*pDepth the dimensions of the subresource of the mapped Direct3D resource pResource which corresponds to face and level.

Since anti-aliased surfaces may have multiple samples per pixel, it is possible that the dimensions of a resource will be an integer factor larger than the dimensions reported by the Direct3D runtime.

The parameters pWidth, pHeight, and pDepth are optional. For 2D surfaces, the value returned in \*pDepth will be 0.

If pResource is not of type IDirect3DBaseTexture9 or IDirect3DSurface9 or if pResource has not been registered for use with CUDA, then cudaErrorInvalidResourceHandle is returned.

For usage requirements of face and level parameters, see cudaD3D9ResourceGetMappedPointer.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGraphicsSubResourceGetMappedArray

# \_\_host\_\_cudaError\_t cudaD3D9ResourceSetMapFlags (IDirect3DResource9 \*pResource, unsigned int flags)

Set usage flags for mapping a Direct3D resource.

#### **Parameters**

#### pResource

- Registered resource to set flags for

#### flags

- Parameters for resource mapping

#### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidResourceHandle, cudaErrorUnknown

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Set flags for mapping the Direct3D resource pResource.

Changes to flags will take effect the next time presource is mapped. The flags argument may be any of the following:

- cudaD3D9MapFlagsNone: Specifies no hints about how this resource will be used. It is therefore assumed that this resource will be read from and written to by CUDA kernels. This is the default value.
- cudaD3D9MapFlagsReadOnly: Specifies that CUDA kernels which access this resource will not write to this resource.
- cudaD3D9MapFlagsWriteDiscard: Specifies that CUDA kernels which access this
  resource will not read from this resource and will write over the entire contents of
  the resource, so none of the data previously stored in the resource will be preserved.

If pResource has not been registered for use with CUDA, then cudaErrorInvalidResourceHandle is returned. If pResource is presently mapped for access by CUDA, then cudaErrorUnknown is returned.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaInteropResourceSetMapFlags

## \_\_host\_\_cudaError\_t cudaD3D9UnmapResources (int count, IDirect3DResource9 \*\*ppResources)

Unmap Direct3D resources for access by CUDA.

#### **Parameters**

#### count

- Number of resources to unmap for CUDA

#### ppResources

- Resources to unmap for CUDA

#### Returns

cudaSuccess, cudaErrorInvalidResourceHandle, cudaErrorUnknown

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Unmaps the count Direct3D resources in ppResources.

This function provides the synchronization guarantee that any CUDA kernels issued before cudaD3D9UnmapResources() will complete before any Direct3D calls issued after cudaD3D9UnmapResources() begin.

If any of ppResources have not been registered for use with CUDA or if ppResources contains any duplicate entries, then cudaErrorInvalidResourceHandle is returned. If any of ppResources are not presently mapped for access by CUDA then cudaErrorUnknown is returned.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGraphicsUnmapResources

# \_\_host\_\_cudaError\_t cudaD3D9UnregisterResource (IDirect3DResource9 \*pResource)

Unregisters a Direct3D resource for access by CUDA.

#### **Parameters**

#### pResource

- Resource to unregister

#### Returns

cudaSuccess, cudaErrorInvalidResourceHandle, cudaErrorUnknown

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Unregisters the Direct3D resource pResource so it is not accessible by CUDA unless registered again.

If pResource is not registered, then cudaErrorInvalidResourceHandle is returned.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGraphicsUnregisterResource

## 4.16. Direct3D 10 Interoperability

This section describes the Direct3D 10 interoperability functions of the CUDA runtime application programming interface. Note that mapping of Direct3D 10 resources is performed with the graphics API agnostic, resource mapping interface described in Graphics Interopability.

### enum cudaD3D10DeviceList

CUDA devices corresponding to a D3D10 device

#### **Values**

cudaD3D10DeviceListAll = 1

The CUDA devices for all GPUs used by a D3D10 device

#### cudaD3D10DeviceListCurrentFrame = 2

The CUDA devices for the GPUs used by a D3D10 device in its currently rendering frame

#### cudaD3D10DeviceListNextFrame = 3

The CUDA devices for the GPUs to be used by a D3D10 device in the next frame

### \_\_host\_\_cudaError\_t cudaD3D10GetDevice (int \*device, IDXGIAdapter \*pAdapter)

Gets the device number for an adapter.

#### **Parameters**

#### device

- Returns the device corresponding to pAdapter

#### pAdapter

- D3D10 adapter to get device for

#### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorUnknown

#### Description

Returns in \*device the CUDA-compatible device corresponding to the adapter pAdapter obtained from IDXGIFactory::EnumAdapters. This call will succeed only if a device on adapter pAdapter is CUDA-compatible.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGraphicsD3D10RegisterResource,

\_\_host\_\_cudaError\_t cudaD3D10GetDevices (unsigned int \*pCudaDeviceCount, int \*pCudaDevices, unsigned

## int cudaDeviceCount, ID3D10Device \*pD3D10Device, cudaD3D10DeviceList deviceList)

Gets the CUDA devices corresponding to a Direct3D 10 device.

#### **Parameters**

#### pCudaDeviceCount

- Returned number of CUDA devices corresponding to pD3D10Device pCudaDevices
  - Returned CUDA devices corresponding to pD3D10Device

#### cudaDeviceCount

- The size of the output device array pCudaDevices

#### pD3D10Device

- Direct3D 10 device to query for CUDA devices

#### deviceList

- The set of devices to return. This set may be cudaD3D10DeviceListAll for all devices, cudaD3D10DeviceListCurrentFrame for the devices used to render the current frame (in SLI), or cudaD3D10DeviceListNextFrame for the devices used to render the next frame (in SLI).

#### Returns

cudaSuccess, cudaErrorNoDevice, cudaErrorUnknown

#### Description

Returns in \*pCudaDeviceCount the number of CUDA-compatible devices corresponding to the Direct3D 10 device pD3D10Device. Also returns in \*pCudaDevices at most cudaDeviceCount of the the CUDA-compatible devices corresponding to the Direct3D 10 device pD3D10Device.

If any of the GPUs being used to render pDevice are not CUDA capable then the call will return cudaErrorNoDevice.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGraphicsUnregisterResource, cudaGraphicsMapResources, cudaGraphicsSubResourceGetMappedArray, cudaGraphicsResourceGetMappedPointer

\_\_host\_\_cudaError\_t cudaGraphicsD3D10RegisterResource (cudaGraphicsResource \*\*resource, ID3D10Resource \*pD3DResource, unsigned int flags)

Registers a Direct3D 10 resource for access by CUDA.

#### **Parameters**

#### resource

- Pointer to returned resource handle

#### pD3DResource

- Direct3D resource to register

#### flags

- Parameters for resource registration

#### Returns

cudaSuccess, cudaErrorInvalidDevice, cudaErrorInvalidValue, cudaErrorInvalidResourceHandle, cudaErrorUnknown

#### Description

Registers the Direct3D 10 resource pD3DResource for access by CUDA.

If this call is successful, then the application will be able to map and unmap this resource until it is unregistered through cudaGraphicsUnregisterResource(). Also on success, this call will increase the internal reference count on pD3DResource. This reference count will be decremented when this resource is unregistered through cudaGraphicsUnregisterResource().

This call potentially has a high-overhead and should not be called every frame in interactive applications.

The type of pD3DResource must be one of the following.

- ▶ ID3D10Buffer: may be accessed via a device pointer
- ▶ ID3D10Texture1D: individual subresources of the texture may be accessed via arrays
- ▶ ID3D10Texture2D: individual subresources of the texture may be accessed via arrays
- ▶ ID3D10Texture3D: individual subresources of the texture may be accessed via arrays

The flags argument may be used to specify additional parameters at register time. The valid values for this parameter are

cudaGraphicsRegisterFlagsNone: Specifies no hints about how this resource will be used.

- cudaGraphicsRegisterFlagsSurfaceLoadStore: Specifies that CUDA will bind this resource to a surface reference.
- cudaGraphicsRegisterFlagsTextureGather: Specifies that CUDA will perform texture gather operations on this resource.

Not all Direct3D resources of the above types may be used for interoperability with CUDA. The following are some limitations.

- ▶ The primary rendertarget may not be registered with CUDA.
- Resources allocated as shared may not be registered with CUDA.
- ► Textures which are not of a format which is 1, 2, or 4 channels of 8, 16, or 32-bit integer or floating-point data cannot be shared.
- Surfaces of depth or stencil formats cannot be shared.

A complete list of supported DXGI formats is as follows. For compactness the notation A\_{B,C,D} represents A\_B, A\_C, and A\_D.

- DXGI\_FORMAT\_A8\_UNORM
- DXGI\_FORMAT\_B8G8R8A8\_UNORM
- DXGI FORMAT B8G8R8X8 UNORM
- DXGI\_FORMAT\_R16\_FLOAT
- ▶ DXGI FORMAT R16G16B16A16 {FLOAT,SINT,SNORM,UINT,UNORM}
- DXGI\_FORMAT\_R16G16\_{FLOAT,SINT,SNORM,UINT,UNORM}
- DXGI\_FORMAT\_R16\_{SINT,SNORM,UINT,UNORM}
- DXGI\_FORMAT\_R32\_FLOAT
- DXGI\_FORMAT\_R32G32B32A32\_{FLOAT,SINT,UINT}
- DXGI\_FORMAT\_R32G32\_{FLOAT,SINT,UINT}
- DXGI\_FORMAT\_R32\_{SINT,UINT}
- DXGI\_FORMAT\_R8G8B8A8\_{SINT,SNORM,UINT,UNORM,UNORM\_SRGB}
- DXGI\_FORMAT\_R8G8\_{SINT,SNORM,UINT,UNORM}
- DXGI\_FORMAT\_R8\_{SINT,SNORM,UINT,UNORM}

If pD3DResource is of incorrect type or is already registered, then cudaErrorInvalidResourceHandle is returned. If pD3DResource cannot be registered, then cudaErrorUnknown is returned.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGraphicsUnregisterResource, cudaGraphicsMapResources, cudaGraphicsSubResourceGetMappedArray, cudaGraphicsResourceGetMappedPointer

# 4.17. Direct3D 10 Interoperability [DEPRECATED]

This section describes deprecated Direct3D 10 interoperability functions.

### enum cudaD3D10MapFlags

CUDA D3D10 Map Flags

#### **Values**

#### cudaD3D10MapFlagsNone = 0

Default; Assume resource can be read/written

#### cudaD3D10MapFlagsReadOnly = 1

CUDA kernels will not write to this resource

#### cudaD3D10MapFlagsWriteDiscard = 2

CUDA kernels will only write to and will not read from this resource

### enum cudaD3D10RegisterFlags

CUDA D3D10 Register Flags

#### **Values**

#### cudaD3D10RegisterFlagsNone = 0

Default; Resource can be accessed through a void\*

#### cudaD3D10RegisterFlagsArray = 1

Resource can be accessed through a CUarray\*

# \_\_host\_\_cudaError\_t cudaD3D10GetDirect3DDevice (ID3D10Device \*\*ppD3D10Device)

Gets the Direct3D device against which the current CUDA context was created.

#### **Parameters**

#### ppD3D10Device

- Returns the Direct3D device for this thread

#### **Returns**

cudaSuccess, cudaErrorUnknown

#### Description

Deprecated This function is deprecated as of CUDA 5.0.

This function is deprecated and should no longer be used. It is no longer necessary to associate a CUDA device with a D3D10 device in order to achieve maximum interoperability performance.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaD3D10SetDirect3DDevice

## \_\_host\_\_cudaError\_t cudaD3D10MapResources (int count, ID3D10Resource \*\*ppResources)

Maps Direct3D Resources for access by CUDA.

#### **Parameters**

#### count

- Number of resources to map for CUDA

#### ppResources

- Resources to map for CUDA

#### Returns

cudaSuccess, cudaErrorInvalidResourceHandle, cudaErrorUnknown

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Maps the count Direct3D resources in ppResources for access by CUDA.

The resources in ppResources may be accessed in CUDA kernels until they are unmapped. Direct3D should not access any resources while they are mapped by CUDA. If an application does so, the results are undefined.

This function provides the synchronization guarantee that any Direct3D calls issued before cudaD3D10MapResources() will complete before any CUDA kernels issued after cudaD3D10MapResources() begin.

If any of ppResources have not been registered for use with CUDA or if ppResources contains any duplicate entries then cudaErrorInvalidResourceHandle is returned. If any of ppResources are presently mapped for access by CUDA then cudaErrorUnknown is returned.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGraphicsMapResources

# \_\_host\_\_cudaError\_t cudaD3D10RegisterResource (ID3D10Resource \*pResource, unsigned int flags)

Registers a Direct3D 10 resource for access by CUDA.

#### **Parameters**

#### pResource

- Resource to register

#### flags

- Parameters for resource registration

#### Returns

cudaSuccess, cudaErrorInvalidDevice, cudaErrorInvalidValue, cudaErrorInvalidResourceHandle, cudaErrorUnknown

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Registers the Direct3D resource pResource for access by CUDA.

If this call is successful, then the application will be able to map and unmap this resource until it is unregistered through cudaD3D10UnregisterResource(). Also on success, this call will increase the internal reference count on pResource. This reference count will be decremented when this resource is unregistered through cudaD3D10UnregisterResource().

This call potentially has a high-overhead and should not be called every frame in interactive applications.

The type of pResource must be one of the following:

- ► ID3D10Buffer: Cannot be used with flags set to cudaD3D10RegisterFlagsArray.
- ▶ ID3D10Texture1D: No restrictions.
- ID3D10Texture2D: No restrictions.
- ID3D10Texture3D: No restrictions.

The flags argument specifies the mechanism through which CUDA will access the Direct3D resource. The following values are allowed.

- cudaD3D10RegisterFlagsNone: Specifies that CUDA will access this resource through a void\*. The pointer, size, and pitch for each subresource of this resource may be queried through cudaD3D10ResourceGetMappedPointer(), cudaD3D10ResourceGetMappedSize(), and cudaD3D10ResourceGetMappedPitch() respectively. This option is valid for all resource types.
- cudaD3D10RegisterFlagsArray: Specifies that CUDA will access this resource through a CUarray queried on a sub-resource basis through cudaD3D10ResourceGetMappedArray(). This option is only valid for resources of type ID3D10Texture1D, ID3D10Texture2D, and ID3D10Texture3D.

Not all Direct3D resources of the above types may be used for interoperability with CUDA. The following are some limitations.

- The primary rendertarget may not be registered with CUDA.
- ▶ Resources allocated as shared may not be registered with CUDA.
- ► Textures which are not of a format which is 1, 2, or 4 channels of 8, 16, or 32-bit integer or floating-point data cannot be shared.
- Surfaces of depth or stencil formats cannot be shared.

If Direct3D interoperability is not initialized on this context then cudaErrorInvalidDevice is returned. If pResource is of incorrect type or is already registered then cudaErrorInvalidResourceHandle is returned. If pResource cannot be registered then cudaErrorUnknown is returned.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGraphicsD3D10RegisterResource

\_\_host\_\_cudaError\_t cudaD3D10ResourceGetMappedArray (cudaArray

# \*\*ppArray, ID3D10Resource \*pResource, unsigned int subResource)

Gets an array through which to access a subresource of a Direct3D resource which has been mapped for access by CUDA.

#### **Parameters**

#### ppArray

- Returned array corresponding to subresource

#### pResource

- Mapped resource to access

#### subResource

- Subresource of pResource to access

#### **Returns**

cuda Success, cuda Error Invalid Value, cuda Error Invalid Resource Handle, cuda Error Unknown

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Returns in \*ppArray an array through which the subresource of the mapped Direct3D resource pResource which corresponds to subResource may be accessed. The value set in ppArray may change every time that pResource is mapped.

If pResource is not registered, then cudaErrorInvalidResourceHandle is returned. If pResource was not registered with usage flags cudaD3D10RegisterFlagsArray, then cudaErrorInvalidResourceHandle is returned. If pResource is not mapped then cudaErrorUnknown is returned.

For usage requirements of the subResource parameter, see cudaD3D10ResourceGetMappedPointer().



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cuda Graphics Sub Resource Get Mapped Array

\_\_host\_\_cudaError\_t
cudaD3D10ResourceGetMappedPitch (size\_t \*pPitch,

## size\_t \*pPitchSlice, ID3D10Resource \*pResource, unsigned int subResource)

Gets the pitch of a subresource of a Direct3D resource which has been mapped for access by CUDA.

#### **Parameters**

#### pPitch

- Returned pitch of subresource

#### pPitchSlice

- Returned Z-slice pitch of subresource

#### pResource

- Mapped resource to access

#### subResource

- Subresource of pResource to access

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidResourceHandle, cudaErrorUnknown

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Returns in \*pPitch and \*pPitchSlice the pitch and Z-slice pitch of the subresource of the mapped Direct3D resource pResource, which corresponds to subResource. The values set in pPitch and pPitchSlice may change every time that pResource is mapped.

The pitch and Z-slice pitch values may be used to compute the location of a sample on a surface as follows.

For a 2D surface, the byte offset of the sample at position **x**, **y** from the base pointer of the surface is:

```
y * pitch + (bytes per pixel) * x
```

For a 3D surface, the byte offset of the sample at position  $\mathbf{x}$ ,  $\mathbf{y}$ ,  $\mathbf{z}$  from the base pointer of the surface is:

#### z\* slicePitch + y \* pitch + (bytes per pixel) \* x

Both parameters pPitch and pPitchSlice are optional and may be set to NULL.

If pResource is not of type ID3D10Texture1D, ID3D10Texture2D, or ID3D10Texture3D, or if pResource has not been registered for use with CUDA, then cudaErrorInvalidResourceHandle is returned. If pResource was not registered with usage flags cudaD3D10RegisterFlagsNone, then cudaErrorInvalidResourceHandle is

returned. If pResource is not mapped for access by CUDA then cudaErrorUnknown is returned.

For usage requirements of the subResource parameter see cudaD3D10ResourceGetMappedPointer().



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cuda Graphics SubResource Get Mapped Array

# \_\_host\_\_cudaError\_t cudaD3D10ResourceGetMappedPointer (void \*\*pPointer, ID3D10Resource \*pResource, unsigned int subResource)

Gets a pointer through which to access a subresource of a Direct3D resource which has been mapped for access by CUDA.

#### **Parameters**

#### pPointer

- Returned pointer corresponding to subresource

#### pResource

- Mapped resource to access

#### subResource

- Subresource of pResource to access

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidResourceHandle, cudaErrorUnknown

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Returns in \*pPointer the base pointer of the subresource of the mapped Direct3D resource pResource which corresponds to subResource. The value set in pPointer may change every time that pResource is mapped.

If pResource is not registered, then cudaErrorInvalidResourceHandle is returned. If pResource was not registered with usage flags cudaD3D9RegisterFlagsNone, then cudaErrorInvalidResourceHandle is returned. If pResource is not mapped then cudaErrorUnknown is returned.

If pResource is of type ID3D10Buffer then subResource must be 0. If pResource is of any other type, then the value of subResource must come from the subresource calculation in D3D10CalcSubResource().



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cuda Graphics Resource Get Mapped Pointer

# \_\_host\_\_cudaError\_t cudaD3D10ResourceGetMappedSize (size\_t \*pSize, ID3D10Resource \*pResource, unsigned int subResource)

Gets the size of a subresource of a Direct3D resource which has been mapped for access by CUDA.

#### **Parameters**

#### pSize

- Returned size of subresource

#### pResource

- Mapped resource to access

#### subResource

- Subresource of pResource to access

#### Returns

cuda Success, cuda Error Invalid Value, cuda Error Invalid Resource Handle, cuda Error Unknown

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Returns in \*pSize the size of the subresource of the mapped Direct3D resource pResource which corresponds to subResource. The value set in pSize may change every time that pResource is mapped.

If pResource has not been registered for use with CUDA then cudaErrorInvalidHandle is returned. If pResource was not registered with usage flags cudaD3D10RegisterFlagsNone, then cudaErrorInvalidResourceHandle is returned. If pResource is not mapped for access by CUDA then cudaErrorUnknown is returned.

For usage requirements of the subResource parameter see cudaD3D10ResourceGetMappedPointer().



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cuda Graphics Resource Get Mapped Pointer

Gets the dimensions of a registered Direct3D surface.

\_\_host\_\_cudaError\_t cudaD3D10ResourceGetSurfaceDimensions (size\_t \*pWidth, size\_t \*pHeight, size\_t \*pDepth, ID3D10Resource \*pResource, unsigned int subResource)

#### **Parameters**

#### pWidth

- Returned width of surface

#### pHeight

- Returned height of surface

#### pDepth

- Returned depth of surface

#### pResource

- Registered resource to access

#### subResource

- Subresource of pResource to access

#### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidResourceHandle,

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Returns in \*pWidth, \*pHeight, and \*pDepth the dimensions of the subresource of the mapped Direct3D resource pResource which corresponds to subResource.

Since anti-aliased surfaces may have multiple samples per pixel, it is possible that the dimensions of a resource will be an integer factor larger than the dimensions reported by the Direct3D runtime.

The parameters pWidth, pHeight, and pDepth are optional. For 2D surfaces, the value returned in \*pDepth will be 0.

If pResource is not of type ID3D10Texture1D, ID3D10Texture2D, or ID3D10Texture3D, or if pResource has not been registered for use with CUDA, then cudaErrorInvalidHandle is returned.

For usage requirements of subResource parameters see cudaD3D10ResourceGetMappedPointer().



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cuda Graphics SubResource Get Mapped Array

# \_\_host\_\_cudaError\_t cudaD3D10ResourceSetMapFlags (ID3D10Resource \*pResource, unsigned int flags)

Set usage flags for mapping a Direct3D resource.

#### **Parameters**

#### pResource

- Registered resource to set flags for

#### flags

- Parameters for resource mapping

#### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidResourceHandle, cudaErrorUnknown,

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Set usage flags for mapping the Direct3D resource pResource.

Changes to flags will take effect the next time presource is mapped. The flags argument may be any of the following:

cudaD3D10MapFlagsNone: Specifies no hints about how this resource will be used. It is therefore assumed that this resource will be read from and written to by CUDA kernels. This is the default value.

- cudaD3D10MapFlagsReadOnly: Specifies that CUDA kernels which access this resource will not write to this resource.
- cudaD3D10MapFlagsWriteDiscard: Specifies that CUDA kernels which access this resource will not read from this resource and will write over the entire contents of the resource, so none of the data previously stored in the resource will be preserved.

If pResource has not been registered for use with CUDA then cudaErrorInvalidHandle is returned. If pResource is presently mapped for access by CUDA then cudaErrorUnknown is returned.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cuda Graphics Resource Set Map Flags

# \_\_host\_\_cudaError\_t cudaD3D10SetDirect3DDevice (ID3D10Device \*pD3D10Device, int device)

Sets the Direct3D 10 device to use for interoperability with a CUDA device.

#### **Parameters**

#### pD3D10Device

- Direct3D device to use for interoperability

#### device

- The CUDA device to use. This device must be among the devices returned when querying cudaD3D10DeviceListAll from cudaD3D10GetDevices, may be set to -1 to automatically select an appropriate CUDA device.

#### Returns

cudaSuccess, cudaErrorInitializationError, cudaErrorInvalidValue, cudaErrorSetOnActiveProcess

#### Description

Deprecated This function is deprecated as of CUDA 5.0.

This function is deprecated and should no longer be used. It is no longer necessary to associate a CUDA device with a D3D10 device in order to achieve maximum interoperability performance.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaD3D10GetDevice, cudaGraphicsD3D10RegisterResource, cudaDeviceReset

### \_\_host\_\_cudaError\_t cudaD3D10UnmapResources (int count, ID3D10Resource \*\*ppResources)

Unmaps Direct3D resources.

#### **Parameters**

#### count

- Number of resources to unmap for CUDA

#### ppResources

- Resources to unmap for CUDA

#### **Returns**

cudaSuccess, cudaErrorInvalidResourceHandle, cudaErrorUnknown

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Unmaps the count Direct3D resource in ppResources.

This function provides the synchronization guarantee that any CUDA kernels issued before cudaD3D10UnmapResources() will complete before any Direct3D calls issued after cudaD3D10UnmapResources() begin.

If any of ppResources have not been registered for use with CUDA or if ppResources contains any duplicate entries, then cudaErrorInvalidResourceHandle is returned. If any of ppResources are not presently mapped for access by CUDA then cudaErrorUnknown is returned.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGraphicsUnmapResources

# \_\_host\_\_cudaError\_t cudaD3D10UnregisterResource (ID3D10Resource \*pResource)

Unregisters a Direct3D resource.

#### **Parameters**

#### pResource

- Resource to unregister

#### **Returns**

cudaSuccess, cudaErrorInvalidResourceHandle, cudaErrorUnknown

#### Description

Deprecated This function is deprecated as of CUDA 3.0.

Unregisters the Direct3D resource resource so it is not accessible by CUDA unless registered again.

If pResource is not registered, then cudaErrorInvalidResourceHandle is returned.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGraphicsUnregisterResource

### 4.18. Direct3D 11 Interoperability

This section describes the Direct3D 11 interoperability functions of the CUDA runtime application programming interface. Note that mapping of Direct3D 11 resources is performed with the graphics API agnostic, resource mapping interface described in Graphics Interopability.

#### enum cudaD3D11DeviceList

CUDA devices corresponding to a D3D11 device

#### **Values**

cudaD3D11DeviceListAll = 1

The CUDA devices for all GPUs used by a D3D11 device

#### cudaD3D11DeviceListCurrentFrame = 2

The CUDA devices for the GPUs used by a D3D11 device in its currently rendering frame

#### cudaD3D11DeviceListNextFrame = 3

The CUDA devices for the GPUs to be used by a D3D11 device in the next frame

## \_\_host\_\_cudaError\_t cudaD3D11GetDevice (int \*device, IDXGIAdapter \*pAdapter)

Gets the device number for an adapter.

#### **Parameters**

#### device

- Returns the device corresponding to pAdapter

#### pAdapter

- D3D11 adapter to get device for

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorUnknown

#### Description

Returns in \*device the CUDA-compatible device corresponding to the adapter pAdapter obtained from IDXGIFactory::EnumAdapters. This call will succeed only if a device on adapter pAdapter is CUDA-compatible.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaGraphicsUnregisterResource, cudaGraphicsMapResources, cudaGraphicsSubResourceGetMappedArray, cudaGraphicsResourceGetMappedPointer

\_\_host\_\_cudaError\_t cudaD3D11GetDevices (unsigned int \*pCudaDeviceCount, int \*pCudaDevices, unsigned

### int cudaDeviceCount, ID3D11Device \*pD3D11Device, cudaD3D11DeviceList deviceList)

Gets the CUDA devices corresponding to a Direct3D 11 device.

### **Parameters**

### pCudaDeviceCount

- Returned number of CUDA devices corresponding to pD3D11Device pCudaDevices
  - Returned CUDA devices corresponding to pD3D11Device

### cudaDeviceCount

- The size of the output device array pCudaDevices

### pD3D11Device

- Direct3D 11 device to query for CUDA devices

### deviceList

- The set of devices to return. This set may be cudaD3D11DeviceListAll for all devices, cudaD3D11DeviceListCurrentFrame for the devices used to render the current frame (in SLI), or cudaD3D11DeviceListNextFrame for the devices used to render the next frame (in SLI).

### **Returns**

cudaSuccess, cudaErrorNoDevice, cudaErrorUnknown

### Description

Returns in \*pCudaDeviceCount the number of CUDA-compatible devices corresponding to the Direct3D 11 device pD3D11Device. Also returns in \*pCudaDevices at most cudaDeviceCount of the the CUDA-compatible devices corresponding to the Direct3D 11 device pD3D11Device.

If any of the GPUs being used to render pDevice are not CUDA capable then the call will return cudaErrorNoDevice.



Note that this function may also return error codes from previous, asynchronous launches.

### See also:

cudaGraphicsUnregisterResource, cudaGraphicsMapResources, cudaGraphicsSubResourceGetMappedArray, cudaGraphicsResourceGetMappedPointer

\_\_host\_\_cudaError\_t cudaGraphicsD3D11RegisterResource (cudaGraphicsResource \*\*resource, ID3D11Resource \*pD3DResource, unsigned int flags)

Register a Direct3D 11 resource for access by CUDA.

### **Parameters**

#### resource

- Pointer to returned resource handle

### pD3DResource

- Direct3D resource to register

### flags

- Parameters for resource registration

### Returns

cudaSuccess, cudaErrorInvalidDevice, cudaErrorInvalidValue, cudaErrorInvalidResourceHandle, cudaErrorUnknown

### Description

Registers the Direct3D 11 resource pD3DResource for access by CUDA.

If this call is successful, then the application will be able to map and unmap this resource until it is unregistered through cudaGraphicsUnregisterResource(). Also on success, this call will increase the internal reference count on pD3DResource. This reference count will be decremented when this resource is unregistered through cudaGraphicsUnregisterResource().

This call potentially has a high-overhead and should not be called every frame in interactive applications.

The type of pD3DResource must be one of the following.

- ▶ ID3D11Buffer: may be accessed via a device pointer
- ▶ ID3D11Texture1D: individual subresources of the texture may be accessed via arrays
- ▶ ID3D11Texture2D: individual subresources of the texture may be accessed via arrays
- ▶ ID3D11Texture3D: individual subresources of the texture may be accessed via arrays

The flags argument may be used to specify additional parameters at register time. The valid values for this parameter are

cudaGraphicsRegisterFlagsNone: Specifies no hints about how this resource will be used.

- cudaGraphicsRegisterFlagsSurfaceLoadStore: Specifies that CUDA will bind this resource to a surface reference.
- cudaGraphicsRegisterFlagsTextureGather: Specifies that CUDA will perform texture gather operations on this resource.

Not all Direct3D resources of the above types may be used for interoperability with CUDA. The following are some limitations.

- ▶ The primary rendertarget may not be registered with CUDA.
- Resources allocated as shared may not be registered with CUDA.
- ► Textures which are not of a format which is 1, 2, or 4 channels of 8, 16, or 32-bit integer or floating-point data cannot be shared.
- Surfaces of depth or stencil formats cannot be shared.

A complete list of supported DXGI formats is as follows. For compactness the notation A\_{B,C,D} represents A\_B, A\_C, and A\_D.

- DXGI\_FORMAT\_A8\_UNORM
- DXGI\_FORMAT\_B8G8R8A8\_UNORM
- DXGI FORMAT B8G8R8X8 UNORM
- DXGI\_FORMAT\_R16\_FLOAT
- ▶ DXGI FORMAT R16G16B16A16 {FLOAT,SINT,SNORM,UINT,UNORM}
- DXGI\_FORMAT\_R16G16\_{FLOAT,SINT,SNORM,UINT,UNORM}
- DXGI\_FORMAT\_R16\_{SINT,SNORM,UINT,UNORM}
- DXGI\_FORMAT\_R32\_FLOAT
- DXGI\_FORMAT\_R32G32B32A32\_{FLOAT,SINT,UINT}
- DXGI\_FORMAT\_R32G32\_{FLOAT,SINT,UINT}
- DXGI\_FORMAT\_R32\_{SINT,UINT}
- DXGI\_FORMAT\_R8G8B8A8\_{SINT,SNORM,UINT,UNORM,UNORM\_SRGB}
- DXGI\_FORMAT\_R8G8\_{SINT,SNORM,UINT,UNORM}
- DXGI\_FORMAT\_R8\_{SINT,SNORM,UINT,UNORM}

If pD3DResource is of incorrect type or is already registered, then cudaErrorInvalidResourceHandle is returned. If pD3DResource cannot be registered, then cudaErrorUnknown is returned.



Note that this function may also return error codes from previous, asynchronous launches.

### See also:

cudaGraphicsUnregisterResource, cudaGraphicsMapResources, cudaGraphicsSubResourceGetMappedArray, cudaGraphicsResourceGetMappedPointer

### 4.19. Direct3D 11 Interoperability [DEPRECATED]

This section describes deprecated Direct3D 11 interoperability functions.

## \_\_host\_\_cudaError\_t cudaD3D11GetDirect3DDevice (ID3D11Device \*\*ppD3D11Device)

Gets the Direct3D device against which the current CUDA context was created.

### **Parameters**

### ppD3D11Device

- Returns the Direct3D device for this thread

### **Returns**

cudaSuccess, cudaErrorUnknown

### Description

Deprecated This function is deprecated as of CUDA 5.0.

This function is deprecated and should no longer be used. It is no longer necessary to associate a CUDA device with a D3D11 device in order to achieve maximum interoperability performance.



Note that this function may also return error codes from previous, asynchronous launches.

### See also:

cudaD3D11SetDirect3DDevice

## \_\_host\_\_cudaError\_t cudaD3D11SetDirect3DDevice (ID3D11Device \*pD3D11Device, int device)

Sets the Direct3D 11 device to use for interoperability with a CUDA device.

### **Parameters**

### pD3D11Device

- Direct3D device to use for interoperability

### device

- The CUDA device to use. This device must be among the devices returned when querying cudaD3D11DeviceListAll from cudaD3D11GetDevices, may be set to -1 to automatically select an appropriate CUDA device.

### **Returns**

cudaSuccess, cudaErrorInitializationError, cudaErrorInvalidValue, cudaErrorSetOnActiveProcess

### Description

Deprecated This function is deprecated as of CUDA 5.0.

This function is deprecated and should no longer be used. It is no longer necessary to associate a CUDA device with a D3D11 device in order to achieve maximum interoperability performance.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaD3D11GetDevice, cudaGraphicsD3D11RegisterResource, cudaDeviceReset

### 4.20. VDPAU Interoperability

This section describes the VDPAU interoperability functions of the CUDA runtime application programming interface.

\_\_host\_\_cudaError\_t cudaGraphicsVDPAURegisterOutputSurface (cudaGraphicsResource \*\*resource, VdpOutputSurface vdpSurface, unsigned int flags)

Register a VdpOutputSurface object.

### **Parameters**

### resource

- Pointer to the returned object handle

### vdpSurface

VDPAU object to be registered

### flags

- Map flags

### Returns

cudaSuccess, cudaErrorInvalidDevice, cudaErrorInvalidValue, cudaErrorInvalidResourceHandle, cudaErrorUnknown

### Description

Registers the VdpOutputSurface specified by vdpSurface for access by CUDA. A handle to the registered object is returned as resource. The surface's intended usage is specified using flags, as follows:

- cudaGraphicsMapFlagsNone: Specifies no hints about how this resource will be used. It is therefore assumed that this resource will be read from and written to by CUDA. This is the default value.
- cudaGraphicsMapFlagsReadOnly: Specifies that CUDA will not write to this resource.
- cudaGraphicsMapFlagsWriteDiscard: Specifies that CUDA will not read from this resource and will write over the entire contents of the resource, so none of the data previously stored in the resource will be preserved.



Note that this function may also return error codes from previous, asynchronous launches.

### See also:

cuda VDPAUS et VDPAUDe vice, cuda Graphics Unregister Resource, cuda Graphics SubResource Get Mapped Array

\_\_host\_\_cudaError\_t cudaGraphicsVDPAURegisterVideoSurface (cudaGraphicsResource \*\*resource, VdpVideoSurface vdpSurface, unsigned int flags)

Register a VdpVideoSurface object.

### **Parameters**

#### resource

- Pointer to the returned object handle

### vdpSurface

- VDPAU object to be registered

### flags

- Map flags

### Returns

cudaSuccess, cudaErrorInvalidDevice, cudaErrorInvalidValue, cudaErrorInvalidResourceHandle, cudaErrorUnknown

### Description

Registers the VdpVideoSurface specified by vdpSurface for access by CUDA. A handle to the registered object is returned as resource. The surface's intended usage is specified using flags, as follows:

- cudaGraphicsMapFlagsNone: Specifies no hints about how this resource will be used. It is therefore assumed that this resource will be read from and written to by CUDA. This is the default value.
- cudaGraphicsMapFlagsReadOnly: Specifies that CUDA will not write to this resource.
- cudaGraphicsMapFlagsWriteDiscard: Specifies that CUDA will not read from this resource and will write over the entire contents of the resource, so none of the data previously stored in the resource will be preserved.



Note that this function may also return error codes from previous, asynchronous launches.

### See also:

cuda VDPAUS et VDPAUDe vice, cuda Graphics Unregister Resource, cuda Graphics SubResource Get Mapped Array

\_\_host\_\_cudaError\_t cudaVDPAUGetDevice (int
\*device, VdpDevice vdpDevice, VdpGetProcAddress
\*vdpGetProcAddress)

Gets the CUDA device associated with a VdpDevice.

### **Parameters**

### device

- Returns the device associated with vdpDevice, or -1 if the device associated with vdpDevice is not a compute device.

### vdpDevice

- A VdpDevice handle

### vdpGetProcAddress

- VDPAU's VdpGetProcAddress function pointer

### Returns

cudaSuccess

### Description

Returns the CUDA device associated with a VdpDevice, if applicable.



Note that this function may also return error codes from previous, asynchronous launches.

### See also:

cudaVDPAUSetVDPAUDevice

### \_\_host\_\_cudaError\_t cudaVDPAUSetVDPAUDevice (int device, VdpDevice vdpDevice, VdpGetProcAddress \*vdpGetProcAddress)

Sets a CUDA device to use VDPAU interoperability.

### **Parameters**

### device

- Device to use for VDPAU interoperability

### vdpDevice

- The VdpDevice to interoperate with

### vdpGetProcAddress

- VDPAU's VdpGetProcAddress function pointer

### **Returns**

cudaSuccess, cudaErrorInvalidDevice, cudaErrorSetOnActiveProcess

### Description

Records vdpDevice as the VdpDevice for VDPAU interoperability with the CUDA device device and sets device as the current device for the calling host thread.

If device has already been initialized then this call will fail with the error cudaErrorSetOnActiveProcess. In this case it is necessary to reset device using cudaDeviceReset() before VDPAU interoperability on device may be enabled.



Note that this function may also return error codes from previous, asynchronous launches.

### See also:

cudaGraphicsVDPAURegisterVideoSurface, cudaGraphicsVDPAURegisterOutputSurface, cudaDeviceReset

### 4.21. EGL Interoperability

This section describes the EGL interoperability functions of the CUDA runtime application programming interface. Note that mapping of EGL resources is performed with the graphics API agnostic, resource mapping interface described in Graphics Interopability.

\_\_host\_\_cudaError\_t cudaEGLStreamConsumerAcquireFrame (cudaEglStreamConnection \*conn, cudaGraphicsResource\_t \*pCudaResource, cudaStream\_t \*pStream, unsigned int timeout)

Acquire an image frame from the EGLStream with CUDA as a consumer.

#### **Parameters**

### conn

- Connection on which to acquire

### pCudaResource

- CUDA resource on which the EGLStream frame will be mapped for use.

### pStream

- CUDA stream for synchronization and any data migrations implied by cudaEglResourceLocationFlags.

### timeout

- Desired timeout in usec.

### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorUnknown

### Description

Acquire an image frame from EGLStreamKHR. cudaGraphicsResourceGetMappedEglFrame can be called on pCudaResource to get cudaEglFrame.

### See also:

cudaEGLStreamConsumerConnect, cudaEGLStreamConsumerDisconnect, cudaEGLStreamConsumerReleaseFrame

# \_\_host\_\_cudaError\_t cudaEGLStreamConsumerConnect (cudaEglStreamConnection \*conn, EGLStreamKHR eglStream)

Connect CUDA to EGLStream as a consumer.

### **Parameters**

#### conn

- Pointer to the returned connection handle

### eglStream

- EGLStreamKHR handle

### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorUnknown

### Description

Connect CUDA as a consumer to EGLStreamKHR specified by eglStream.

The EGLStreamKHR is an EGL object that transfers a sequence of image frames from one API to another.

### See also:

cudaEGLStreamConsumerDisconnect, cudaEGLStreamConsumerAcquireFrame, cudaEGLStreamConsumerReleaseFrame

\_\_host\_\_cudaError\_t
cudaEGLStreamConsumerConnectWithFlags

## (cudaEglStreamConnection \*conn, EGLStreamKHR eglStream, unsigned int flags)

Connect CUDA to EGLStream as a consumer with given flags.

### **Parameters**

#### conn

- Pointer to the returned connection handle

### eglStream

- EGLStreamKHR handle

### flags

- Flags denote intended location - system or video.

### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorUnknown

### Description

Connect CUDA as a consumer to EGLStreamKHR specified by stream with specified flags defined by cudaEglResourceLocationFlags.

The flags specify whether the consumer wants to access frames from system memory or video memory. Default is cudaEglResourceLocationVidmem.

### See also:

cudaEGLStreamConsumerDisconnect, cudaEGLStreamConsumerAcquireFrame, cudaEGLStreamConsumerReleaseFrame

\_\_host\_\_cudaError\_t cudaEGLStreamConsumerReleaseFrame (cudaEglStreamConnection \*conn, cudaGraphicsResource\_t pCudaResource, cudaStream\_t \*pStream)

Releases the last frame acquired from the EGLStream.

### **Parameters**

### conn

- Connection on which to release

### pCudaResource

- CUDA resource whose corresponding frame is to be released

### pStream

- CUDA stream on which release will be done.

### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorUnknown

### Description

Release the acquired image frame specified by pCudaResource to EGLStreamKHR.

### See also:

 $cuda EGLS tream Consumer Connect, \ cuda EGLS tream Consumer Disconnect, \ cuda EGLS tream Consumer Acquire Frame,$ 

### \_\_host\_\_cudaError\_t cudaEGLStreamProducerConnect (cudaEglStreamConnection \*conn, EGLStreamKHR eglStream, EGLint width, EGLint height)

Connect CUDA to EGLStream as a producer.

### **Parameters**

### conn

- Pointer to the returned connection handle

### eglStream

- EGLStreamKHR handle

### width

- width of the image to be submitted to the stream

### height

- height of the image to be submitted to the stream

### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorUnknown

### Description

Connect CUDA as a producer to EGLStreamKHR specified by stream.

The EGLStreamKHR is an EGL object that transfers a sequence of image frames from one API to another.

### See also:

 $cuda EGLS tream Producer Disconnect, cuda EGLS tream Producer Present Frame, \\ cuda EGLS tream Producer Return Frame$ 

# \_\_host\_\_cudaError\_t cudaEGLStreamProducerDisconnect (cudaEglStreamConnection \*conn)

Disconnect CUDA as a producer to EGLStream.

### **Parameters**

#### conn

- Conection to disconnect.

### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorUnknown

### Description

Disconnect CUDA as a producer to EGLStreamKHR.

### See also:

cuda EGLS tream Producer Connect, cuda EGLS tream Producer Present Frame, cuda EGLS tream Producer Return Frame

### \_\_host\_\_cudaError\_t cudaEGLStreamProducerPresentFrame (cudaEglStreamConnection \*conn, cudaEglFrame eglframe, cudaStream\_t \*pStream)

Present a CUDA eglFrame to the EGLStream with CUDA as a producer.

### **Parameters**

### conn

- Connection on which to present the CUDA array

### eglframe

- CUDA Eglstream Proucer Frame handle to be sent to the consumer over EglStream.

  Stream
  - CUDA stream on which to present the frame.

### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorUnknown

### Description

The cudaEglFrame is defined as:

### See also:

 $cuda EGLS tream Producer Connect, cuda EGLS tream Producer Disconnect, \\ cuda EGLS tream Producer Return Frame$ 

```
__host__cudaError_t
cudaEGLStreamProducerReturnFrame
(cudaEglStreamConnection *conn, cudaEglFrame
*eglframe, cudaStream_t *pStream)
```

Return the CUDA eglFrame to the EGLStream last released by the consumer.

### **Parameters**

### conn

- Connection on which to present the CUDA array

### eglframe

- CUDA Eglstream Proucer Frame handle returned from the consumer over EglStream.

### pStream

- CUDA stream on which to return the frame.

### Returns

cudaSuccess, cudaErrorLaunchTimeout, cudaErrorInvalidValue, cudaErrorUnknown

### Description

This API can potentially return cudaErrorLaunchTimeout if the consumer has not returned a frame to EGL stream. If timeout is returned the application can retry.

### See also:

cudaEGLStreamProducerConnect, cudaEGLStreamProducerDisconnect, cudaEGLStreamProducerPresentFrame,

# \_\_host\_\_cudaError\_t cudaGraphicsEGLRegisterImage (cudaGraphicsResource \*\*pCudaResource, EGLImageKHR image, unsigned int flags)

Registers an EGL image.

### **Parameters**

### pCudaResource

- Pointer to the returned object handle

### image

- An EGLImageKHR image which can be used to create target resource.

### flags

- Map flags

### Returns

cuda Success, cuda Error Invalid Resource Handle, cuda Error Invalid Value, cuda Error Unknown

### Description

Registers the EGLImageKHR specified by image for access by CUDA. A handle to the registered object is returned as pCudaResource. Additional Mapping/Unmapping is not required for the registered resource and cudaGraphicsResourceGetMappedEglFrame can be directly called on the pCudaResource.

The application will be responsible for synchronizing access to shared objects. The application must ensure that any pending operation which access the objects have completed before passing control to CUDA. This may be accomplished by issuing and waiting for glFinish command on all GLcontexts (for OpenGL and likewise for other APIs). The application will be also responsible for ensuring that any pending operation on the registered CUDA resource has completed prior to executing subsequent commands in other APIs accessing the same memory objects. This can be accomplished by calling cuCtxSynchronize or cuEventSynchronize (preferably).

The surface's intended usage is specified using flags, as follows:

- cudaGraphicsRegisterFlagsNone: Specifies no hints about how this resource will be used. It is therefore assumed that this resource will be read from and written to by CUDA. This is the default value.
- cudaGraphicsRegisterFlagsReadOnly: Specifies that CUDA will not write to this resource.

cudaGraphicsRegisterFlagsWriteDiscard: Specifies that CUDA will not read from this resource and will write over the entire contents of the resource, so none of the data previously stored in the resource will be preserved.

The EGLImageKHR is an object which can be used to create EGLImage target resource. It is defined as a void pointer. typedef void\* EGLImageKHR

### See also:

cuda Graphics Unregister Resource, cuda Graphics Resource Get Mapped Egl Frame

\_\_host\_\_cudaError\_t cudaGraphicsResourceGetMappedEglFrame (cudaEglFrame \*eglFrame, cudaGraphicsResource\_t resource, unsigned int index, unsigned int mipLevel)

Get an eglFrame through which to access a registered EGL graphics resource.

### **Parameters**

### eglFrame

- Returned eglFrame.

### resource

- Registered resource to access.

### index

- Index for cubemap surfaces.

### mipLevel

- Mipmap level for the subresource to access.

### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorUnknown

### Description

Returns in \*eglFrame an eglFrame pointer through which the registered graphics resource resource may be accessed. This API can only be called for EGL graphics resources.

### The cudaEglFrame is defined as

### See also:

cuda Graphics Sub Resource Get Mapped Array, cuda Graphics Resource Get Mapped Pointer Get Mapped Pointer

### 4.22. Graphics Interoperability

This section describes the graphics interoperability functions of the CUDA runtime application programming interface.

# \_\_host\_\_cudaError\_t cudaGraphicsMapResources (int count, cudaGraphicsResource\_t \*resources, cudaStream\_t stream)

Map graphics resources for access by CUDA.

### **Parameters**

### count

- Number of resources to map

### resources

- Resources to map for CUDA

#### stream

- Stream for synchronization

### Returns

cudaSuccess, cudaErrorInvalidResourceHandle, cudaErrorUnknown

### Description

Maps the count graphics resources in resources for access by CUDA.

The resources in resources may be accessed by CUDA until they are unmapped. The graphics API from which resources were registered should not access any resources while they are mapped by CUDA. If an application does so, the results are undefined.

This function provides the synchronization guarantee that any graphics calls issued before cudaGraphicsMapResources() will complete before any subsequent CUDA work issued in stream begins.

If resources contains any duplicate entries then cudaErrorInvalidResourceHandle is returned. If any of resources are presently mapped for access by CUDA then cudaErrorUnknown is returned.



- This function uses standard default stream semantics.
- Note that this function may also return error codes from previous, asynchronous launches.

### See also:

cuda Graphics Resource Get Mapped Pointer, cuda Graphics Sub Resource Get Mapped Array, cuda Graphics Unmap Resources

### \_\_host\_\_cudaError\_t cudaGraphicsResourceGetMappedMipmappedArray (cudaMipmappedArray\_t \*mipmappedArray, cudaGraphicsResource\_t resource)

Get a mipmapped array through which to access a mapped graphics resource.

### **Parameters**

### mipmappedArray

- Returned mipmapped array through which resource may be accessed
- Mapped resource to access

### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidResourceHandle, cudaErrorUnknown

### Description

Returns in \*mipmappedArray a mipmapped array through which the mapped graphics resource resource may be accessed. The value set in mipmappedArray may change every time that resource is mapped.

If resource is not a texture then it cannot be accessed via an array and cudaErrorUnknown is returned. If resource is not mapped then cudaErrorUnknown is returned.



Note that this function may also return error codes from previous, asynchronous launches.

### See also:

cuda Graphics Resource Get Mapped Pointer

### \_\_host\_\_cudaError\_t cudaGraphicsResourceGetMappedPointer (void \*\*devPtr, size\_t \*size, cudaGraphicsResource\_t resource)

Get an device pointer through which to access a mapped graphics resource.

### **Parameters**

### devPtr

- Returned pointer through which resource may be accessed size
  - Returned size of the buffer accessible starting at \*devPtr

#### resource

- Mapped resource to access

### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidResourceHandle, cudaErrorUnknown

### Description

Returns in \*devPtr a pointer through which the mapped graphics resource resource may be accessed. Returns in \*size the size of the memory in bytes which may be accessed from that pointer. The value set in devPtr may change every time that resource is mapped.

If resource is not a buffer then it cannot be accessed via a pointer and cudaErrorUnknown is returned. If resource is not mapped then cudaErrorUnknown is returned. \*



Note that this function may also return error codes from previous, asynchronous launches.

### See also:

cudaGraphicsMapResources, cudaGraphicsSubResourceGetMappedArray

## \_\_host\_\_cudaError\_t cudaGraphicsResourceSetMapFlags (cudaGraphicsResource\_t resource, unsigned int flags)

Set usage flags for mapping a graphics resource.

### **Parameters**

#### resource

- Registered resource to set flags for

### flags

- Parameters for resource mapping

### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidResourceHandle, cudaErrorUnknown,

### Description

Set flags for mapping the graphics resource resource.

Changes to flags will take effect the next time resource is mapped. The flags argument may be any of the following:

- cudaGraphicsMapFlagsNone: Specifies no hints about how resource will be used. It is therefore assumed that CUDA may read from or write to resource.
- cudaGraphicsMapFlagsReadOnly: Specifies that CUDA will not write to resource.
- cudaGraphicsMapFlagsWriteDiscard: Specifies CUDA will not read from resource and will write over the entire contents of resource, so none of the data previously stored in resource will be preserved.

If resource is presently mapped for access by CUDA then cudaErrorUnknown is returned. If flags is not one of the above values then cudaErrorInvalidValue is returned.



Note that this function may also return error codes from previous, asynchronous launches.

### See also:

cudaGraphicsMapResources

### \_\_host\_\_cudaError\_t cudaGraphicsSubResourceGetMappedArray (cudaArray\_t \*array, cudaGraphicsResource\_t resource, unsigned int arrayIndex, unsigned int mipLevel)

Get an array through which to access a subresource of a mapped graphics resource.

### **Parameters**

### array

- Returned array through which a subresource of resource may be accessed
  - Mapped resource to access

### arrayIndex

- Array index for array textures or cubemap face index as defined by cudaGraphicsCubeFace for cubemap textures for the subresource to access

### mipLevel

- Mipmap level for the subresource to access

### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidResourceHandle, cudaErrorUnknown

### Description

Returns in \*array an array through which the subresource of the mapped graphics resource resource which corresponds to array index arrayIndex and mipmap level mipLevel may be accessed. The value set in array may change every time that resource is mapped.

If resource is not a texture then it cannot be accessed via an array and cudaErrorUnknown is returned. If arrayIndex is not a valid array index for resource then cudaErrorInvalidValue is returned. If mipLevel is not a valid mipmap level for resource then cudaErrorInvalidValue is returned. If resource is not mapped then cudaErrorUnknown is returned.



Note that this function may also return error codes from previous, asynchronous launches.

### See also:

cudaGraphicsResourceGetMappedPointer

# \_\_host\_\_cudaError\_t cudaGraphicsUnmapResources (int count, cudaGraphicsResource\_t \*resources, cudaStream\_t stream)

Unmap graphics resources.

### **Parameters**

#### count

- Number of resources to unmap

### resources

- Resources to unmap

#### stream

- Stream for synchronization

### **Returns**

cudaSuccess, cudaErrorInvalidResourceHandle, cudaErrorUnknown

### Description

Unmaps the count graphics resources in resources.

Once unmapped, the resources in resources may not be accessed by CUDA until they are mapped again.

This function provides the synchronization guarantee that any CUDA work issued in stream before cudaGraphicsUnmapResources() will complete before any subsequently issued graphics work begins.

If resources contains any duplicate entries then cudaErrorInvalidResourceHandle is returned. If any of resources are not presently mapped for access by CUDA then cudaErrorUnknown is returned.



- This function uses standard default stream semantics.
- Note that this function may also return error codes from previous, asynchronous launches.

### See also:

cudaGraphicsMapResources

## \_\_host\_\_cudaError\_t cudaGraphicsUnregisterResource (cudaGraphicsResource\_t resource)

Unregisters a graphics resource for access by CUDA.

### **Parameters**

### resource

- Resource to unregister

### Returns

cudaSuccess, cudaErrorInvalidResourceHandle, cudaErrorUnknown

### Description

Unregisters the graphics resource resource so it is not accessible by CUDA unless registered again.

If resource is invalid then cudaErrorInvalidResourceHandle is returned.



Note that this function may also return error codes from previous, asynchronous launches.

### See also:

cudaGraphicsD3D9RegisterResource, cudaGraphicsD3D10RegisterResource, cudaGraphicsD3D11RegisterResource, cudaGraphicsGLRegisterBuffer, cudaGraphicsGLRegisterImage

### 4.23. Texture Reference Management

This section describes the low level texture reference management functions of the CUDA runtime application programming interface.

Some functions have overloaded C++ API template versions documented separately in the C++ API Routines module.

\_\_host\_\_cudaError\_t cudaBindTexture (size\_t \*offset, const textureReference \*texref, const void \*devPtr, const cudaChannelFormatDesc \*desc, size\_t size)

Binds a memory area to a texture.

### **Parameters**

### offset

- Offset in bytes

### texref

- Texture to bind

### devPtr

- Memory area on device

### desc

- Channel format

### size

- Size of the memory area pointed to by devPtr

### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevicePointer, cudaErrorInvalidTexture

### Description

Binds size bytes of the memory area pointed to by devPtr to the texture reference texref. desc describes how the memory is interpreted when fetching values from the texture. Any memory previously bound to texref is unbound.

Since the hardware enforces an alignment requirement on texture base addresses, cudaBindTexture() returns in \*offset a byte offset that must be applied to texture fetches in order to read from the desired memory. This offset must be divided by the texel size and passed to kernels that read from the texture so they can be applied to the tex1Dfetch() function. If the device memory pointer was returned from cudaMalloc(), the offset is guaranteed to be 0 and NULL may be passed as the offset parameter.

The total number of elements (or texels) in the linear address range cannot exceed cudaDeviceProp::maxTexture1DLinear[0]. The number of elements is computed as (size / elementSize), where elementSize is determined from desc.



Note that this function may also return error codes from previous, asynchronous launches.

### See also:

cudaCreateChannelDesc ( C API), cudaGetChannelDesc, cudaGetTextureReference, cudaBindTexture ( C++ API), cudaBindTexture2D ( C API), cudaBindTextureToArray ( C API), cudaUnbindTexture ( C API), cudaGetTextureAlignmentOffset ( C API)

\_\_host\_\_cudaError\_t cudaBindTexture2D (size\_t \*offset, const textureReference \*texref, const void \*devPtr, const cudaChannelFormatDesc \*desc, size\_t width, size\_t height, size\_t pitch)

Binds a 2D memory area to a texture.

### **Parameters**

### offset

- Offset in bytes

### texref

- Texture reference to bind

### devPtr

- 2D memory area on device

#### desc

- Channel format

### width

- Width in texel units

### height

- Height in texel units

### pitch

- Pitch in bytes

### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevicePointer, cudaErrorInvalidTexture

### **Description**

Binds the 2D memory area pointed to by devPtr to the texture reference texref. The size of the area is constrained by width in texel units, height in texel units, and pitch in byte units. desc describes how the memory is interpreted when fetching values from the texture. Any memory previously bound to texref is unbound.

Since the hardware enforces an alignment requirement on texture base addresses, cudaBindTexture2D() returns in \*offset a byte offset that must be applied to texture fetches in order to read from the desired memory. This offset must be divided by the text size and passed to kernels that read from the texture so they can be applied to the

tex2D() function. If the device memory pointer was returned from cudaMalloc(), the offset is guaranteed to be 0 and NULL may be passed as the offset parameter.

width and height, which are specified in elements (or texels), cannot exceed cudaDeviceProp::maxTexture2DLinear[0] and cudaDeviceProp::maxTexture2DLinear[1] respectively. pitch, which is specified in bytes, cannot exceed cudaDeviceProp::maxTexture2DLinear[2].

The driver returns cudaErrorInvalidValue if pitch is not a multiple of cudaDeviceProp::texturePitchAlignment.



Note that this function may also return error codes from previous, asynchronous launches.

### See also:

cudaCreateChannelDesc ( C API), cudaGetChannelDesc, cudaGetTextureReference, cudaBindTexture ( C API), cudaBindTexture2D ( C++ API), cudaBindTexture2D ( C++ API, inherited channel descriptor), cudaBindTextureToArray ( C API), cudaBindTextureToArray ( C API)

\_\_host\_\_cudaError\_t cudaBindTextureToArray (const textureReference \*texref, cudaArray\_const\_t array, const cudaChannelFormatDesc \*desc)

Binds an array to a texture.

### **Parameters**

### texref

- Texture to bind

### array

- Memory array on device

#### desc

- Channel format

### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevicePointer, cudaErrorInvalidTexture

### Description

Binds the CUDA array array to the texture reference texref. desc describes how the memory is interpreted when fetching values from the texture. Any CUDA array previously bound to texref is unbound.



Note that this function may also return error codes from previous, asynchronous launches.

### See also:

cudaCreateChannelDesc ( C API), cudaGetChannelDesc, cudaGetTextureReference, cudaBindTexture ( C API), cudaBindTexture2D ( C API), cudaBindTextureToArray ( C++ API), cudaUnbindTexture ( C API), cudaGetTextureAlignmentOffset ( C API)

\_\_host\_\_cudaError\_t cudaBindTextureToMipmappedArray (const textureReference \*texref, cudaMipmappedArray\_const\_t mipmappedArray, const cudaChannelFormatDesc \*desc) Binds a mipmapped array to a texture.

### **Parameters**

### texref

- Texture to bind

### mipmappedArray

- Memory mipmapped array on device

### desc

- Channel format

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevicePointer, cudaErrorInvalidTexture

### Description

Binds the CUDA mipmapped array mipmappedArray to the texture reference texref. desc describes how the memory is interpreted when fetching values from the texture. Any CUDA mipmapped array previously bound to texref is unbound.



Note that this function may also return error codes from previous, asynchronous launches.

### See also:

cudaCreateChannelDesc ( C API), cudaGetChannelDesc, cudaGetTextureReference, cudaBindTexture ( C API), cudaBindTexture2D ( C API), cudaBindTextureToArray ( C++ API), cudaUnbindTexture ( C API), cudaGetTextureAlignmentOffset ( C API)

## \_\_host\_\_cudaCreateChannelDesc (int x, int y, int z, int w, cudaChannelFormatKind f)

Returns a channel descriptor using the specified format.

### **Parameters**

X

- X component

y

- Y component

7.

- Z component

w

- W component

f

- Channel format

### Returns

Channel descriptor with format f

### Description

Returns a channel descriptor with format f and number of bits of each component x, y, z, and w. The cudaChannelFormatDesc is defined as:

where cudaChannelFormatKind is one of cudaChannelFormatKindSigned, cudaChannelFormatKindUnsigned, or cudaChannelFormatKindFloat.

### See also:

cudaCreateChannelDesc ( C++ API), cudaGetChannelDesc, cudaGetTextureReference, cudaBindTexture ( C API), cudaBindTexture2D ( C API), cudaBindTextureToArray ( C API), cudaUnbindTexture ( C API), cudaGetTextureAlignmentOffset ( C API)

# \_\_host\_\_cudaError\_t cudaGetChannelDesc (cudaChannelFormatDesc \*desc, cudaArray\_const\_t array)

Get the channel descriptor of an array.

### **Parameters**

### desc

- Channel format

### array

- Memory array on device

### **Returns**

cudaSuccess, cudaErrorInvalidValue

### Description

Returns in \*desc the channel descriptor of the CUDA array array.



Note that this function may also return error codes from previous, asynchronous launches.

### See also:

cudaCreateChannelDesc ( C API), cudaGetTextureReference, cudaBindTexture ( C API), cudaBindTexture2D ( C API), cudaBindTextureToArray ( C API), cudaUnbindTexture ( C API), cudaGetTextureAlignmentOffset ( C API)

\_\_host\_\_cudaError\_t cudaGetTextureAlignmentOffset
(size\_t \*offset, const textureReference \*texref)

Get the alignment offset of a texture.

### **Parameters**

### offset

- Offset of texture reference in bytes

### texref

- Texture to get offset of

### **Returns**

cudaSuccess, cudaErrorInvalidTexture, cudaErrorInvalidTextureBinding

### Description

Returns in \*offset the offset that was returned when texture reference texref was bound.



Note that this function may also return error codes from previous, asynchronous launches.

### See also:

cudaCreateChannelDesc ( C API), cudaGetChannelDesc, cudaGetTextureReference, cudaBindTexture ( C API), cudaBindTexture2D ( C API), cudaBindTextureToArray ( C API), cudaUnbindTexture ( C API), cudaGetTextureAlignmentOffset ( C++ API)

### \_\_host\_\_cudaError\_t cudaGetTextureReference (const textureReference \*\*texref, const void \*symbol)

Get the texture reference associated with a symbol.

### **Parameters**

### texref

- Texture reference associated with symbol symbol
  - Texture to get reference for

### Returns

cudaSuccess, cudaErrorInvalidTexture

### Description

Returns in \*texref the structure associated to the texture reference defined by symbol symbol.



- Note that this function may also return error codes from previous, asynchronous launches.
- Use of a string naming a variable as the symbol paramater was removed in CUDA 5.0.

### See also:

cudaCreateChannelDesc ( C API), cudaGetChannelDesc, cudaGetTextureAlignmentOffset ( C API), cudaBindTexture ( C API), cudaBindTexture2D ( C API), cudaBindTextureToArray ( C API), cudaUnbindTexture ( C API)

### \_\_host\_\_cudaError\_t cudaUnbindTexture (const textureReference \*texref)

Unbinds a texture.

### **Parameters**

### texref

- Texture to unbind

#### Returns

cudaSuccess

### Description

Unbinds the texture bound to texref.



Note that this function may also return error codes from previous, asynchronous launches.

### See also:

cudaCreateChannelDesc ( C API), cudaGetChannelDesc, cudaGetTextureReference, cudaBindTexture ( C API), cudaBindTexture2D ( C API), cudaBindTextureToArray ( C API), cudaUnbindTexture ( C++ API), cudaGetTextureAlignmentOffset ( C API)

### 4.24. Surface Reference Management

This section describes the low level surface reference management functions of the CUDA runtime application programming interface.

Some functions have overloaded C++ API template versions documented separately in the C++ API Routines module.

# \_\_host\_\_cudaError\_t cudaBindSurfaceToArray (const surfaceReference \*surfref, cudaArray\_const\_t array, const cudaChannelFormatDesc \*desc)

Binds an array to a surface.

### **Parameters**

### surfref

- Surface to bind

### array

- Memory array on device

### desc

- Channel format

### **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidSurface

### Description

Binds the CUDA array array to the surface reference surfref. desc describes how the memory is interpreted when fetching values from the surface. Any CUDA array previously bound to surfref is unbound.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaBindSurfaceToArray (C++ API), cudaBindSurfaceToArray (C++ API, inherited channel descriptor), cudaGetSurfaceReference

### \_\_host\_\_cudaError\_t cudaGetSurfaceReference (const surfaceReference \*\*surfref, const void \*symbol)

Get the surface reference associated with a symbol.

### **Parameters**

### surfref

- Surface reference associated with symbol

### symbol

- Surface to get reference for

### **Returns**

cudaSuccess, cudaErrorInvalidSurface

### Description

Returns in \*surfref the structure associated to the surface reference defined by symbol symbol.



- Note that this function may also return error codes from previous, asynchronous launches.
- Use of a string naming a variable as the symbol paramater was removed in CUDA 5.0.

### See also:

cudaBindSurfaceToArray (CAPI)

### 4.25. Texture Object Management

This section describes the low level texture object management functions of the CUDA runtime application programming interface. The texture object API is only supported on devices of compute capability 3.0 or higher.

\_\_host\_\_cudaError\_t cudaCreateTextureObject (cudaTextureObject\_t \*pTexObject, const cudaResourceDesc \*pResDesc, const cudaTextureDesc \*pTexDesc, const cudaResourceViewDesc \*pResViewDesc)

Creates a texture object.

### **Parameters**

### pTexObject

- Texture object to create

### pResDesc

- Resource descriptor

### pTexDesc

- Texture descriptor

### pResViewDesc

- Resource view descriptor

### Returns

cudaSuccess, cudaErrorInvalidValue

### Description

Creates a texture object and returns it in pTexObject. pResDesc describes the data to texture from. pTexDesc describes how the data should be sampled. pResViewDesc is an optional argument that specifies an alternate format for the data described by pResDesc, and also describes the subresource region to restrict access to when texturing. pResViewDesc can only be specified if the type of resource is a CUDA array or a CUDA mipmapped array.

Texture objects are only supported on devices of compute capability 3.0 or higher. Additionally, a texture object is an opaque value, and, as such, should only be accessed through CUDA API calls.

The cudaResourceDesc structure is defined as:

```
struct cudaResourceDesc {
         enum cudaResourceType
         resType;
         union {
           struct {
               cudaArray t
         array;
            } array;
            struct {
                cudaMipmappedArray t
         mipmap;
            } mipmap;
            struct {
                 void *devPtr;
                struct cudaChannelFormatDesc
         desc;
                size t sizeInBytes;
             } linear;
             struct {
                void *devPtr;
                struct cudaChannelFormatDesc
         desc:
                size_t width;
                 size_t height;
                 size t pitchInBytes;
            } pitch2\overline{D};
         } res;
```

where:

cudaResourceDesc::resType specifies the type of resource to texture from.CUresourceType is defined as:

If cudaResourceDesc::resType is set to cudaResourceTypeArray, cudaResourceDesc::res::array::array must be set to a valid CUDA array handle.

If cudaResourceDesc::resType is set to cudaResourceTypeMipmappedArray, cudaResourceDesc::res::mipmap::mipmap must be set to a valid CUDA mipmapped array handle and cudaTextureDesc::normalizedCoords must be set to true.

If cudaResourceDesc::resType is set to cudaResourceTypeLinear, cudaResourceDesc::res::linear::devPtr must be set to a valid device pointer, that is aligned to cudaDeviceProp::textureAlignment. cudaResourceDesc::res::linear::desc describes the format and the number of components per array element. cudaResourceDesc::res::linear::sizeInBytes specifies the size of the array in bytes. The total number of elements in the linear address range cannot exceed cudaDeviceProp::maxTexture1DLinear. The number of elements is computed as (sizeInBytes / sizeof(desc)).

If cudaResourceDesc::resType is set to cudaResourceTypePitch2D, cudaResourceDesc::res::pitch2D::devPtr must be set to a valid device pointer, that is aligned to cudaDeviceProp::textureAlignment. cudaResourceDesc::res::pitch2D::desc describes the format and the number of components per array element. cudaResourceDesc::res::pitch2D::width and cudaResourceDesc::res::pitch2D::height specify the width and height of the array in elements, and cannot exceed cudaDeviceProp::maxTexture2DLinear[0] and cudaDeviceProp::maxTexture2DLinear[1] respectively. cudaResourceDesc::res::pitch2D::pitchInBytes specifies the pitch between two rows in bytes and has to be aligned to cudaDeviceProp::texturePitchAlignment. Pitch cannot exceed cudaDeviceProp::maxTexture2DLinear[2].

The cudaTextureDesc struct is defined as

```
struct cudaTextureDesc {
        enum cudaTextureAddressMode
        addressMode[3];
        enum cudaTextureFilterMode
        filterMode;
        enum cudaTextureReadMode
        readMode;
        int
                                   borderColor[4];
        float
                        normalizedCoords;
        int
        unsigned int
        enum cudaTextureFilterMode
        mipmapFilterMode;
        float
                                   mipmapLevelBias;
                                   minMipmapLevelClamp;
        float
        float
                                    maxMipmapLevelClamp;
```

where

cudaTextureDesc::addressMode specifies the addressing mode for each dimension of the texture data. cudaTextureAddressMode is defined as:

This is ignored if cudaResourceDesc::resType is cudaResourceTypeLinear. Also, if cudaTextureDesc::normalizedCoords is set to zero, cudaAddressModeWrap and cudaAddressModeMirror won't be supported and will be switched to cudaAddressModeClamp.

cudaTextureDesc::filterMode specifies the filtering mode to be used when fetching from the texture. cudaTextureFilterMode is defined as:

This is ignored if cudaResourceDesc::resType is cudaResourceTypeLinear.

 cudaTextureDesc::readMode specifies whether integer data should be converted to floating point or not. cudaTextureReadMode is defined as:

Note that this applies only to 8-bit and 16-bit integer formats. 32-bit integer format would not be promoted, regardless of whether or not this cudaTextureDesc::readMode is set cudaReadModeNormalizedFloat is specified.

- cudaTextureDesc::sRGB specifies whether sRGB to linear conversion should be performed during texture fetch.
- cudaTextureDesc::borderColor specifies the float values of color. where: cudaTextureDesc::borderColor[0] contains value of 'R', cudaTextureDesc::borderColor[1] contains value of 'G', cudaTextureDesc::borderColor[2] contains value of 'B', cudaTextureDesc::borderColor[3] contains value of 'A' Note that application using integer border color values will need to <reinterpret\_cast> these values to float. The values are set only when the addressing mode specified by cudaTextureDesc::addressMode is cudaAddressModeBorder.
- cudaTextureDesc::normalizedCoords specifies whether the texture coordinates will be normalized or not.
- cudaTextureDesc::maxAnisotropy specifies the maximum anistropy ratio to be used when doing anisotropic filtering. This value will be clamped to the range [1,16].

- cudaTextureDesc::mipmapFilterMode specifies the filter mode when the calculated mipmap level lies between two defined mipmap levels.
- cudaTextureDesc::mipmapLevelBias specifies the offset to be applied to the calculated mipmap level.
- cudaTextureDesc::minMipmapLevelClamp specifies the lower end of the mipmap level range to clamp access to.
- cudaTextureDesc::maxMipmapLevelClamp specifies the upper end of the mipmap level range to clamp access to.

The cudaResourceViewDesc struct is defined as

## where:

- ▶ cudaResourceViewDesc::format specifies how the data contained in the CUDA array or CUDA mipmapped array should be interpreted. Note that this can incur a change in size of the texture data. If the resource view format is a block compressed format, then the underlying CUDA array or CUDA mipmapped array has to have a 32-bit unsigned integer format with 2 or 4 channels, depending on the block compressed format. For ex., BC1 and BC4 require the underlying CUDA array to have a 32-bit unsigned int with 2 channels. The other BC formats require the underlying resource to have the same 32-bit unsigned int format but with 4 channels.
- cudaResourceViewDesc::width specifies the new width of the texture data. If the resource view format is a block compressed format, this value has to be 4 times the original width of the resource. For non block compressed formats, this value has to be equal to that of the original resource.
- cudaResourceViewDesc::height specifies the new height of the texture data. If the resource view format is a block compressed format, this value has to be 4 times the original height of the resource. For non block compressed formats, this value has to be equal to that of the original resource.
- cudaResourceViewDesc::depth specifies the new depth of the texture data. This value has to be equal to that of the original resource.
- cudaResourceViewDesc::firstMipmapLevel specifies the most detailed mipmap level. This will be the new mipmap level zero. For non-mipmapped resources, this value has to be zero.cudaTextureDesc::minMipmapLevelClamp and

cudaTextureDesc::maxMipmapLevelClamp will be relative to this value. For ex., if the firstMipmapLevel is set to 2, and a minMipmapLevelClamp of 1.2 is specified, then the actual minimum mipmap level clamp will be 3.2.

- cudaResourceViewDesc::lastMipmapLevel specifies the least detailed mipmap level.
   For non-mipmapped resources, this value has to be zero.
- cudaResourceViewDesc::firstLayer specifies the first layer index for layered textures. This will be the new layer zero. For non-layered resources, this value has to be zero.
- cudaResourceViewDesc::lastLayer specifies the last layer index for layered textures. For non-layered resources, this value has to be zero.

## See also:

cudaDestroyTextureObject

## \_\_host\_\_cudaError\_t cudaDestroyTextureObject (cudaTextureObject\_t texObject)

Destroys a texture object.

## **Parameters**

## texObject

- Texture object to destroy

## Returns

cudaSuccess, cudaErrorInvalidValue

## Description

Destroys the texture object specified by texObject.

## See also:

cudaCreateTextureObject

## \_\_host\_\_cudaError\_t cudaGetTextureObjectResourceDesc (cudaResourceDesc \*pResDesc, cudaTextureObject\_t texObject)

Returns a texture object's resource descriptor.

## **Parameters**

## pResDesc

- Resource descriptor

## texObject

- Texture object

## **Returns**

cudaSuccess, cudaErrorInvalidValue

## Description

Returns the resource descriptor for the texture object specified by texObject.

## See also:

cudaCreateTextureObject

\_\_host\_\_cudaError\_t
cudaGetTextureObjectResourceViewDesc
(cudaResourceViewDesc \*pResViewDesc,
cudaTextureObject\_t texObject)

Returns a texture object's resource view descriptor.

## **Parameters**

## pResViewDesc

- Resource view descriptor

## texObject

- Texture object

## Returns

cudaSuccess, cudaErrorInvalidValue

## Description

Returns the resource view descriptor for the texture object specified by texobject. If no resource view was specified, cudaErrorInvalidValue is returned.

## See also:

cudaCreateTextureObject

## \_\_host\_\_cudaError\_t cudaGetTextureObjectTextureDesc (cudaTextureDesc \*pTexDesc, cudaTextureObject\_t texObject)

Returns a texture object's texture descriptor.

## **Parameters**

## pTexDesc

- Texture descriptor

## texObject

- Texture object

## **Returns**

cudaSuccess, cudaErrorInvalidValue

## Description

Returns the texture descriptor for the texture object specified by texObject.

## See also:

cudaCreateTextureObject

## 4.26. Surface Object Management

This section describes the low level texture object management functions of the CUDA runtime application programming interface. The surface object API is only supported on devices of compute capability 3.0 or higher.

## \_\_host\_\_cudaError\_t cudaCreateSurfaceObject (cudaSurfaceObject\_t \*pSurfObject, const cudaResourceDesc \*pResDesc)

Creates a surface object.

## **Parameters**

## pSurfObject

- Surface object to create

## pResDesc

- Resource descriptor

## **Returns**

cudaSuccess, cudaErrorInvalidValue

## Description

Creates a surface object and returns it in pSurfObject. pResDesc describes the data to perform surface load/stores on. cudaResourceDesc::resType must be cudaResourceTypeArray and cudaResourceDesc::res::array::array must be set to a valid CUDA array handle.

Surface objects are only supported on devices of compute capability 3.0 or higher. Additionally, a surface object is an opaque value, and, as such, should only be accessed through CUDA API calls.

## See also:

cudaDestroySurfaceObject

## \_\_host\_\_cudaError\_t cudaDestroySurfaceObject (cudaSurfaceObject\_t surfObject)

Destroys a surface object.

## **Parameters**

## surfObject

- Surface object to destroy

## Returns

cudaSuccess, cudaErrorInvalidValue

## Description

Destroys the surface object specified by surfObject.

## See also:

cudaCreateSurfaceObject

## \_\_host\_\_cudaError\_t cudaGetSurfaceObjectResourceDesc (cudaResourceDesc \*pResDesc, cudaSurfaceObject\_t surfObject)

Returns a surface object's resource descriptor Returns the resource descriptor for the surface object specified by surfObject.

## **Parameters**

## pResDesc

- Resource descriptor

## surfObject

- Surface object

## **Returns**

cudaSuccess, cudaErrorInvalidValue

## Description

## See also:

cudaCreateSurfaceObject

## 4.27. Version Management

## \_\_host\_\_cudaError\_t cudaDriverGetVersion (int \*driverVersion)

Returns the CUDA driver version.

## **Parameters**

## driverVersion

- Returns the CUDA driver version.

## Returns

cudaSuccess, cudaErrorInvalidValue

## Description

Returns in \*driverVersion the version number of the installed CUDA driver. If no driver is installed, then 0 is returned as the driver version (via driverVersion). This function automatically returns cudaErrorInvalidValue if the driverVersion argument is NULL.



Note that this function may also return error codes from previous, asynchronous launches.

## See also:

cudaRuntimeGetVersion

\_\_host\_\_\_\_device\_\_cudaError\_t cudaRuntimeGetVersion (int \*runtimeVersion)

Returns the CUDA Runtime version.

## **Parameters**

## runtimeVersion

- Returns the CUDA Runtime version.

## **Returns**

cudaSuccess, cudaErrorInvalidValue

## Description

Returns in \*runtimeVersion the version number of the installed CUDA Runtime. This function automatically returns cudaErrorInvalidValue if the runtimeVersion argument is NULL.

## See also:

cudaDriverGetVersion

## 4.28. C++ API Routines

C++-style interface built on top of CUDA runtime API.

This section describes the C++ high level API functions of the CUDA runtime application programming interface. To use these functions, your application needs to be compiled with the nvcc compiler.

## \_\_cudaOccupancyB2DHelper

cppClassifierVisibility: visibility=public

template < class T, int dim > \_\_host\_\_cudaError\_t
cudaBindSurfaceToArray (const surfaceTdim surf,
cudaArray\_const\_t array)

[C++ API] Binds an array to a surface

## **Parameters**

surf

- Surface to bind

## array

- Memory array on device

## **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidSurface

## Description

Binds the CUDA array array to the surface reference surf. The channel descriptor is inherited from the CUDA array. Any CUDA array previously bound to surf is unbound.



Note that this function may also return error codes from previous, asynchronous launches.

## See also:

cudaBindSurfaceToArray ( C API), cudaBindSurfaceToArray ( C++ API)

template < class T, int dim > \_\_host\_\_cudaError\_t
cudaBindSurfaceToArray (const surfaceTdim surf,
cudaArray\_const\_t array, const cudaChannelFormatDesc
desc)

[C++ API] Binds an array to a surface

## **Parameters**

## surf

- Surface to bind

## array

- Memory array on device

## desc

- Channel format

## **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidSurface

## Description

Binds the CUDA array array to the surface reference surf. desc describes how the memory is interpreted when dealing with the surface. Any CUDA array previously bound to surf is unbound.



Note that this function may also return error codes from previous, asynchronous launches.

## See also:

cudaBindSurfaceToArray ( C API), cudaBindSurfaceToArray ( C++ API, inherited channel descriptor)

template < class T, int dim, enum cudaTextureReadMode
readMode > \_\_host\_\_cudaError\_t cudaBindTexture

## (size\_t \*offset, const textureTdimreadMode tex, const void \*devPtr, size\_t size)

[C++ API] Binds a memory area to a texture

## **Parameters**

## offset

- Offset in bytes

## tex

- Texture to bind

## devPtr

- Memory area on device

## size

- Size of the memory area pointed to by devPtr

## **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevicePointer, cudaErrorInvalidTexture

## Description

Binds size bytes of the memory area pointed to by devPtr to texture reference tex. The channel descriptor is inherited from the texture reference type. The offset parameter is an optional byte offset as with the low-level cudaBindTexture( size\_t\*, const struct textureReference\*, const void\*, const struct cudaChannelFormatDesc\*, size\_t) function. Any memory previously bound to tex is unbound.



Note that this function may also return error codes from previous, asynchronous launches.

## See also:

cudaCreateChannelDesc ( C++ API), cudaGetChannelDesc, cudaGetTextureReference, cudaBindTexture ( C API), cudaBindTexture ( C++ API), cudaBindTexture2D ( C++ API), cudaBindTexture2D ( C++ API, inherited channel descriptor), cudaBindTextureToArray ( C++ API), cudaBindTextureToArray ( C++ API, inherited channel descriptor), cudaUnbindTexture ( C++ API), cudaGetTextureAlignmentOffset ( C++ API)

template < class T, int dim, enum cudaTextureReadMode
readMode > \_\_host\_\_cudaError\_t cudaBindTexture
(size\_t \*offset, const textureTdimreadMode tex, const

## void \*devPtr, const cudaChannelFormatDesc desc, size\_t size)

[C++ API] Binds a memory area to a texture

## **Parameters**

## offset

- Offset in bytes

## tex

- Texture to bind

## devPtr

- Memory area on device

## desc

- Channel format

## size

- Size of the memory area pointed to by devPtr

## **Returns**

cuda Success, cuda Error Invalid Value, cuda Error Invalid Device Pointer, cuda Error Invalid Texture

## Description

Binds size bytes of the memory area pointed to by devPtr to texture reference tex. desc describes how the memory is interpreted when fetching values from the texture. The offset parameter is an optional byte offset as with the low-level cudaBindTexture() function. Any memory previously bound to tex is unbound.



Note that this function may also return error codes from previous, asynchronous launches.

## See also:

cudaCreateChannelDesc ( C++ API), cudaGetChannelDesc, cudaGetTextureReference, cudaBindTexture ( C API), cudaBindTexture ( C++ API, inherited channel descriptor), cudaBindTexture2D ( C++ API), cudaBindTexture2D ( C++ API, inherited channel descriptor), cudaBindTextureToArray ( C++ API), cudaBindTextureToArray ( C++ API, inherited channel descriptor), cudaUnbindTexture ( C++ API), cudaGetTextureAlignmentOffset ( C++ API)

template < class T, int dim, enum cudaTextureReadMode
readMode > \_\_host \_\_cudaError\_t cudaBindTexture2D

## (size\_t \*offset, const textureTdimreadMode tex, const void \*devPtr, size\_t width, size\_t height, size\_t pitch)

[C++ API] Binds a 2D memory area to a texture

## **Parameters**

## offset

- Offset in bytes

## tex

- Texture reference to bind

## devPtr

- 2D memory area on device

## width

- Width in texel units

## height

- Height in texel units

## pitch

- Pitch in bytes

## **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevicePointer, cudaErrorInvalidTexture

## Description

Binds the 2D memory area pointed to by devPtr to the texture reference tex. The size of the area is constrained by width in texel units, height in texel units, and pitch in byte units. The channel descriptor is inherited from the texture reference type. Any memory previously bound to tex is unbound.

Since the hardware enforces an alignment requirement on texture base addresses, cudaBindTexture2D() returns in \*offset a byte offset that must be applied to texture fetches in order to read from the desired memory. This offset must be divided by the texel size and passed to kernels that read from the texture so they can be applied to the tex2D() function. If the device memory pointer was returned from cudaMalloc(), the offset is guaranteed to be 0 and NULL may be passed as the offset parameter.



Note that this function may also return error codes from previous, asynchronous launches.

## See also:

cudaCreateChannelDesc (C++ API), cudaGetChannelDesc, cudaGetTextureReference, cudaBindTexture (C++ API), cudaBindTexture (C++ API, inherited channel descriptor), cudaBindTexture2D (CAPI), cudaBindTexture2D (C++ API), cudaBindTextureToArray (C++ API), cudaBindTextureToArray (C++ API, inherited channel descriptor), cudaUnbindTexture (C++ API), cudaGetTextureAlignmentOffset (C++ API)

template < class T, int dim, enum cudaTextureReadMode
readMode > \_\_host\_\_cudaError\_t cudaBindTexture2D
(size\_t \*offset, const textureTdimreadMode tex, const
void \*devPtr, const cudaChannelFormatDesc desc, size\_t
width, size\_t height, size\_t pitch)

[C++ API] Binds a 2D memory area to a texture

## **Parameters**

## offset

- Offset in bytes

## tex

- Texture reference to bind

## devPtr

- 2D memory area on device

## desc

- Channel format

## width

- Width in texel units

## height

- Height in texel units

## pitch

- Pitch in bytes

## Returns

cuda Success, cuda Error Invalid Value, cuda Error Invalid Device Pointer, cuda Error Invalid Texture

## Description

Binds the 2D memory area pointed to by devPtr to the texture reference tex. The size of the area is constrained by width in texel units, height in texel units, and pitch in byte units. desc describes how the memory is interpreted when fetching values from the texture. Any memory previously bound to tex is unbound.

Since the hardware enforces an alignment requirement on texture base addresses, cudaBindTexture2D() returns in \*offset a byte offset that must be applied to texture

fetches in order to read from the desired memory. This offset must be divided by the texel size and passed to kernels that read from the texture so they can be applied to the tex2D() function. If the device memory pointer was returned from cudaMalloc(), the offset is guaranteed to be 0 and NULL may be passed as the offset parameter.



Note that this function may also return error codes from previous, asynchronous launches.

## See also:

cudaCreateChannelDesc ( C++ API), cudaGetChannelDesc, cudaGetTextureReference, cudaBindTexture ( C++ API), cudaBindTexture ( C++ API, inherited channel descriptor), cudaBindTexture2D ( C API), cudaBindTexture2D ( C++ API, inherited channel descriptor), cudaBindTextureToArray ( C++ API), cudaBindTextureToArray ( C++ API, inherited channel descriptor), cudaUnbindTexture ( C++ API), cudaGetTextureAlignmentOffset ( C++ API)

template < class T, int dim, enum
cudaTextureReadMode readMode > \_\_host\_\_cudaError\_t
cudaBindTextureToArray (const textureTdimreadMode
tex, cudaArray\_const\_t array)

[C++ API] Binds an array to a texture

## **Parameters**

tex

- Texture to bind

## array

- Memory array on device

### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevicePointer, cudaErrorInvalidTexture

## Description

Binds the CUDA array array to the texture reference tex. The channel descriptor is inherited from the CUDA array. Any CUDA array previously bound to tex is unbound.



Note that this function may also return error codes from previous, asynchronous launches.

## See also:

cudaCreateChannelDesc (C++ API), cudaGetChannelDesc, cudaGetTextureReference, cudaBindTexture (C++ API), cudaBindTexture (C++ API, inherited channel descriptor), cudaBindTexture2D (C++ API), cudaBindTexture2D (C++ API, inherited channel descriptor), cudaBindTextureToArray (C API), cudaBindTextureToArray (C++ API), cudaUnbindTexture (C++ API), cudaGetTextureAlignmentOffset (C++ API)

template < class T, int dim, enum
cudaTextureReadMode readMode > \_\_host\_\_cudaError\_t
cudaBindTextureToArray (const textureTdimreadMode
tex, cudaArray\_const\_t array, const
cudaChannelFormatDesc desc)

[C++ API] Binds an array to a texture

## **Parameters**

## tex

- Texture to bind

### array

- Memory array on device

## desc

- Channel format

## Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevicePointer, cudaErrorInvalidTexture

## Description

Binds the CUDA array array to the texture reference tex. desc describes how the memory is interpreted when fetching values from the texture. Any CUDA array previously bound to tex is unbound.



Note that this function may also return error codes from previous, asynchronous launches.

## See also:

cudaCreateChannelDesc (C++ API), cudaGetChannelDesc, cudaGetTextureReference, cudaBindTexture (C++ API), cudaBindTexture (C++ API, inherited channel descriptor), cudaBindTexture2D (C++ API), cudaBindTexture2D (C++ API, inherited channel descriptor), cudaBindTextureToArray (C++ API, inherited channel descriptor), cudaUnbindTexture (C++ API), cudaGetTextureAlignmentOffset (C++ API)

template < class T, int dim, enum
cudaTextureReadMode readMode > \_\_host\_\_cudaError\_t
cudaBindTextureToMipmappedArray
(const textureTdimreadMode tex,
cudaMipmappedArray\_const\_t mipmappedArray)

[C++ API] Binds a mipmapped array to a texture

## **Parameters**

tex

- Texture to bind

## mipmappedArray

- Memory mipmapped array on device

## Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevicePointer, cudaErrorInvalidTexture

## Description

Binds the CUDA mipmapped array mipmappedArray to the texture reference tex. The channel descriptor is inherited from the CUDA array. Any CUDA mipmapped array previously bound to tex is unbound.



Note that this function may also return error codes from previous, asynchronous launches.

## See also:

cudaCreateChannelDesc (C++ API), cudaGetChannelDesc, cudaGetTextureReference, cudaBindTexture (C++ API), cudaBindTexture (C++ API, inherited channel descriptor), cudaBindTexture2D (C++ API), cudaBindTexture2D (C++ API, inherited channel

descriptor), cudaBindTextureToArray ( C API), cudaBindTextureToArray ( C++ API), cudaUnbindTexture ( C++ API), cudaGetTextureAlignmentOffset ( C++ API)

template < class T, int dim, enum cudaTextureReadMode readMode > \_\_host\_\_cudaError\_t cudaBindTextureToMipmappedArray (const textureTdimreadMode tex, cudaMipmappedArray\_const\_t mipmappedArray, const cudaChannelFormatDesc desc)

[C++ API] Binds a mipmapped array to a texture

## **Parameters**

tex

- Texture to bind

## mipmappedArray

- Memory mipmapped array on device

## desc

- Channel format

## **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidDevicePointer, cudaErrorInvalidTexture

## Description

Binds the CUDA mipmapped array mipmappedArray to the texture reference tex. desc describes how the memory is interpreted when fetching values from the texture. Any CUDA mipmapped array previously bound to tex is unbound.



Note that this function may also return error codes from previous, asynchronous launches.

## See also:

cudaCreateChannelDesc ( C++ API), cudaGetChannelDesc, cudaGetTextureReference, cudaBindTexture ( C++ API), cudaBindTexture ( C++ API, inherited channel descriptor), cudaBindTexture2D ( C++ API), cudaBindTexture2D ( C++ API, inherited channel descriptor), cudaBindTextureToArray ( C API), cudaBindTextureToArray ( C++ API, inherited channel descriptor), cudaUnbindTexture ( C++ API), cudaGetTextureAlignmentOffset ( C++ API)

## template < class T > \_\_host\_\_cudaCreateChannelDesc (void)

[C++ API] Returns a channel descriptor using the specified format

## **Returns**

Channel descriptor with format f

## Description

Returns a channel descriptor with format f and number of bits of each component x, y, z, and w. The cudaChannelFormatDesc is defined as:

where cudaChannelFormatKind is one of cudaChannelFormatKindSigned, cudaChannelFormatKindUnsigned, or cudaChannelFormatKindFloat.

## See also:

cudaCreateChannelDesc (Low level), cudaGetChannelDesc, cudaGetTextureReference, cudaBindTexture (High level), cudaBindTexture (High level, inherited channel descriptor), cudaBindTexture2D (High level), cudaBindTextureToArray (High level), cudaBindTextureToArray (High level, inherited channel descriptor), cudaUnbindTexture (High level), cudaGetTextureAlignmentOffset (High level)

## \_\_host\_\_cudaError\_t cudaEventCreate (cudaEvent\_t \*event, unsigned int flags)

[C++ API] Creates an event object with the specified flags

## **Parameters**

## event

- Newly created event

## flags

- Flags for new event

## Returns

cudaSuccess, cudaErrorInitializationError, cudaErrorInvalidValue, cudaErrorLaunchFailure, cudaErrorMemoryAllocation

## Description

Creates an event object with the specified flags. Valid flags include:

- cudaEventDefault: Default event creation flag.
- cudaEventBlockingSync: Specifies that event should use blocking synchronization. A host thread that uses cudaEventSynchronize() to wait on an event created with this flag will block until the event actually completes.
- cudaEventDisableTiming: Specifies that the created event does not need to record timing data. Events created with this flag specified and the cudaEventBlockingSync flag not specified will provide the best performance when used with cudaStreamWaitEvent() and cudaEventQuery().



Note that this function may also return error codes from previous, asynchronous launches.

## See also:

cudaEventCreate ( C API), cudaEventCreateWithFlags, cudaEventRecord, cudaEventQuery, cudaEventSynchronize, cudaEventDestroy, cudaEventElapsedTime, cudaStreamWaitEvent

## template < class T > \_\_host\_\_cudaError\_t cudaFuncGetAttributes (cudaFuncAttributes \*attr, T \*entry)

[C++ API] Find out attributes for a given function

## **Parameters**

attr

- Return pointer to function's attributes

## entry

- Function to get attributes of

## Returns

cudaSuccess, cudaErrorInitializationError, cudaErrorInvalidDeviceFunction

## Description

This function obtains the attributes of a function specified via entry. The parameter entry must be a pointer to a function that executes on the device. The parameter specified by entry must be declared as a \_\_global\_\_function. The

fetched attributes are placed in attr. If the specified function does not exist, then cudaErrorInvalidDeviceFunction is returned.

Note that some function attributes such as maxThreadsPerBlock may vary based on the device that is currently being used.



Note that this function may also return error codes from previous, asynchronous launches.

cudaLaunchKernel ( C++ API), cudaFuncSetCacheConfig ( C++ API), cudaFuncGetAttributes ( C API), cudaSetDoubleForDevice, cudaSetDoubleForHost, cudaSetupArgument ( C++ API)

## template < class T > \_\_host\_\_cudaError\_t cudaFuncSetCacheConfig (T \*func, cudaFuncCache cacheConfig)

[C++ API] Sets the preferred cache configuration for a device function

## **Parameters**

## func

- device function pointer

## cacheConfig

- Requested cache configuration

### Returns

cudaSuccess, cudaErrorInitializationError, cudaErrorInvalidDeviceFunction

## Description

On devices where the L1 cache and shared memory use the same hardware resources, this sets through cacheConfig the preferred cache configuration for the function specified via func. This is only a preference. The runtime will use the requested configuration if possible, but it is free to choose a different configuration if required to execute func.

func must be a pointer to a function that executes on the device. The parameter specified by func must be declared as a \_\_global\_\_ function. If the specified function does not exist, then cudaErrorInvalidDeviceFunction is returned.

This setting does nothing on devices where the size of the L1 cache and shared memory are fixed.

Launching a kernel with a different preference than the most recent preference setting may insert a device-side synchronization point.

The supported cache configurations are:

- cudaFuncCachePreferNone: no preference for shared memory or L1 (default)
- cudaFuncCachePreferShared: prefer larger shared memory and smaller L1 cache
- cudaFuncCachePreferL1: prefer larger L1 cache and smaller shared memory



Note that this function may also return error codes from previous, asynchronous launches.

cudaLaunchKernel (C++ API), cudaFuncSetCacheConfig (C API), cudaFuncGetAttributes (C++ API), cudaSetDoubleForDevice, cudaSetDoubleForHost, cudaSetupArgument (C++ API), cudaThreadGetCacheConfig, cudaThreadSetCacheConfig

## template < class T > \_\_host\_\_cudaError\_t cudaGetSymbolAddress (void \*\*devPtr, const T symbol)

[C++ API] Finds the address associated with a CUDA symbol

## **Parameters**

## devPtr

- Return device pointer associated with symbol

## symbol

- Device symbol reference

## Returns

cudaSuccess, cudaErrorInvalidSymbol

## Description

Returns in \*devPtr the address of symbol symbol on the device. symbol can either be a variable that resides in global or constant memory space. If symbol cannot be found, or if symbol is not declared in the global or constant memory space, \*devPtr is unchanged and the error cudaErrorInvalidSymbol is returned.



Note that this function may also return error codes from previous, asynchronous launches.

## See also:

cudaGetSymbolAddress (CAPI), cudaGetSymbolSize (C++API)

## template < class T > \_\_host\_\_cudaError\_t cudaGetSymbolSize (size\_t \*size, const T symbol)

[C++ API] Finds the size of the object associated with a CUDA symbol

## **Parameters**

## size

- Size of object associated with symbol

## symbol

- Device symbol reference

## Returns

cudaSuccess, cudaErrorInvalidSymbol

## Description

Returns in \*size the size of symbol symbol symbol must be a variable that resides in global or constant memory space. If symbol cannot be found, or if symbol is not declared in global or constant memory space, \*size is unchanged and the error cudaErrorInvalidSymbol is returned.



Note that this function may also return error codes from previous, asynchronous launches.

## See also:

cudaGetSymbolAddress (C++ API), cudaGetSymbolSize (C API)

template < class T, int dim, enum
cudaTextureReadMode readMode > \_\_host\_\_cudaError\_t
cudaGetTextureAlignmentOffset (size\_t \*offset, const
textureTdimreadMode tex)

[C++ API] Get the alignment offset of a texture

## **Parameters**

## offset

- Offset of texture reference in bytes

## tex

- Texture to get offset of

## **Returns**

cudaSuccess, cudaErrorInvalidTexture, cudaErrorInvalidTextureBinding

## Description

Returns in \*offset the offset that was returned when texture reference tex was bound.



Note that this function may also return error codes from previous, asynchronous launches.

## See also:

cudaCreateChannelDesc ( C++ API), cudaGetChannelDesc, cudaGetTextureReference, cudaBindTexture ( C++ API), cudaBindTexture ( C++ API, inherited channel descriptor), cudaBindTexture2D ( C++ API), cudaBindTexture2D ( C++ API, inherited channel descriptor), cudaBindTextureToArray ( C++ API), cudaBindTextureToArray ( C++ API, inherited channel descriptor), cudaUnbindTexture ( C++ API), cudaGetTextureAlignmentOffset ( C API)

## template < class T > \_\_host\_\_cudaError\_t cudaLaunch (T \*func)

[C++ API] Launches a device function

## **Parameters**

## func

- Device function pointer to execute

## Returns

cudaSuccess, cudaErrorInvalidDeviceFunction, cudaErrorInvalidConfiguration, cudaErrorLaunchFailure, cudaErrorLaunchTimeout, cudaErrorLaunchOutOfResources, cudaErrorSharedObjectSymbolNotFound, cudaErrorSharedObjectInitFailed

## Description

Deprecated This function is deprecated as of CUDA 7.0

Launches the function func on the device. The parameter func must be a function that executes on the device. The parameter specified by func must be declared as a \_\_global\_\_ function. cudaLaunch() must be preceded by a call to cudaConfigureCall() since it pops the data that was pushed by cudaConfigureCall() from the execution stack.



Note that this function may also return error codes from previous, asynchronous launches.

cudaLaunchKernel (C++ API), cudaFuncSetCacheConfig (C++ API), cudaFuncGetAttributes (C++ API), cudaLaunch (CAPI), cudaSetDoubleForDevice, cudaSetDoubleForHost, cudaSetupArgument (C++ API), cudaThreadGetCacheConfig, cudaThreadSetCacheConfig

template < class T > \_\_host\_\_cudaError\_t
cudaLaunchKernel (const T \*func, dim3 gridDim, dim3
blockDim, void \*\*args, size\_t sharedMem, cudaStream\_t
stream)

Launches a device function.

## **Parameters**

## func

- Device function symbol

## gridDim

- Grid dimentions

## blockDim

- Block dimentions

## args

- Arguments

## sharedMem

- Shared memory (defaults to 0)

## stream

- Stream identifier (defaults to NULL)

## Returns

cuda Success, cuda Error Invalid Device Function, cuda Error Invalid Configuration, cuda Error Launch Failure, cuda Error Launch Timeout, cuda Error Launch Out Of Resources, cuda Error Shared Object Init Failed

## Description

The function invokes kernel func on gridDim (gridDim.x × gridDim.y × gridDim.z) grid of blocks. Each block contains blockDim (blockDim.x × blockDim.y × blockDim.z) threads.

If the kernel has N parameters the args should point to array of N pointers. Each pointer, from args[0] to args[N - 1], point to the region of memory from which the actual parameter will be copied.

sharedMem sets the amount of dynamic shared memory that will be available to each thread block.

stream specifies a stream the invocation is associated to.



- Note that this function may also return error codes from previous, asynchronous launches.
- This function exhibits asynchronous behavior for most use cases.
- This function uses standard default stream semantics.

cudaLaunchKernel (CAPI)

## \_\_host\_\_cudaError\_t cudaMallocHost (void \*\*ptr, size\_t size, unsigned int flags)

[C++ API] Allocates page-locked memory on the host

## **Parameters**

## ptr

- Device pointer to allocated memory

## size

- Requested allocation size in bytes

## flags

- Requested properties of allocated memory

## **Returns**

cudaSuccess, cudaErrorMemoryAllocation

## Description

Allocates size bytes of host memory that is page-locked and accessible to the device. The driver tracks the virtual memory ranges allocated with this function and automatically accelerates calls to functions such as cudaMemcpy(). Since the memory can be accessed directly by the device, it can be read or written with much higher bandwidth than pageable memory obtained with functions such as malloc(). Allocating excessive amounts of pinned memory may degrade system performance, since it reduces the amount of memory available to the system for paging. As a result, this function is best used sparingly to allocate staging areas for data exchange between host and device.

The flags parameter enables different options to be specified that affect the allocation, as follows.

- cudaHostAllocDefault: This flag's value is defined to be 0.
- cudaHostAllocPortable: The memory returned by this call will be considered as pinned memory by all CUDA contexts, not just the one that performed the allocation.
- cudaHostAllocMapped: Maps the allocation into the CUDA address space. The device pointer to the memory may be obtained by calling cudaHostGetDevicePointer().
- cudaHostAllocWriteCombined: Allocates the memory as write-combined (WC). WC memory can be transferred across the PCI Express bus more quickly on some system configurations, but cannot be read efficiently by most CPUs. WC memory is a good option for buffers that will be written by the CPU and read by the device via mapped pinned memory or host->device transfers.

All of these flags are orthogonal to one another: a developer may allocate memory that is portable, mapped and/or write-combined with no restrictions.

cudaSetDeviceFlags() must have been called with the cudaDeviceMapHost flag in order for the cudaHostAllocMapped flag to have any effect.

The cudaHostAllocMapped flag may be specified on CUDA contexts for devices that do not support mapped pinned memory. The failure is deferred to cudaHostGetDevicePointer() because the memory may be mapped into other CUDA contexts via the cudaHostAllocPortable flag.

Memory allocated by this function must be freed with cudaFreeHost().



Note that this function may also return error codes from previous, asynchronous launches.

## See also:

cudaSetDeviceFlags, cudaMallocHost ( C API), cudaFreeHost, cudaHostAlloc

## template < class T > \_\_host\_\_cudaError\_t cudaMallocManaged (T \*\*devPtr, size\_t size, unsigned int flags)

Allocates memory that will be automatically managed by the Unified Memory system.

## **Parameters**

## devPtr

- Pointer to allocated device memory

## size

- Requested allocation size in bytes

## flags

- Must be either cudaMemAttachGlobal or cudaMemAttachHost (defaults to cudaMemAttachGlobal)

## Returns

cudaSuccess, cudaErrorMemoryAllocation cudaErrorNotSupported cudaErrorInvalidValue

## Description

Allocates size bytes of managed memory on the device and returns in \*devPtr a pointer to the allocated memory. If the device doesn't support allocating managed memory, cudaErrorNotSupported is returned. Support for managed memory can be queried using the device attribute cudaDevAttrManagedMemory. The allocated memory is suitably aligned for any kind of variable. The memory is not cleared. If size is 0, cudaMallocManaged returns cudaErrorInvalidValue. The pointer is valid on the CPU and on all GPUs in the system that support managed memory. All accesses to this pointer must obey the Unified Memory programming model.

flags specifies the default stream association for this allocation. flags must be one of cudaMemAttachGlobal or cudaMemAttachHost. The default value for flags is cudaMemAttachGlobal. If cudaMemAttachGlobal is specified, then this memory is accessible from any stream on any device. If cudaMemAttachHost is specified, then the allocation should not be accessed from devices that have a zero value for the device attribute cudaDevAttrConcurrentManagedAccess; an explicit call to cudaStreamAttachMemAsync will be required to enable access on such devices.

If the association is later changed via cudaStreamAttachMemAsync to a single stream, the default association, as specifed during cudaMallocManaged, is restored when that stream is destroyed. For \_\_managed\_\_ variables, the default association is always cudaMemAttachGlobal. Note that destroying a stream is an asynchronous operation,

and as a result, the change to default association won't happen until all work in the stream has completed.

Memory allocated with cudaMallocManaged should be released with cudaFree.

Device memory oversubscription is possible for GPUs that have a non-zero value for the device attribute cudaDevAttrConcurrentManagedAccess. Managed memory on such GPUs may be evicted from device memory to host memory at any time by the Unified Memory driver in order to make room for other allocations.

In a multi-GPU system where all GPUs have a non-zero value for the device attribute cudaDevAttrConcurrentManagedAccess, managed memory may not be populated when this API returns and instead may be populated on access. In such systems, managed memory can migrate to any processor's memory at any time. The Unified Memory driver will employ heuristics to maintain data locality and prevent excessive page faults to the extent possible. The application can also guide the driver about memory usage patterns via cudaMemAdvise. The application can also explicitly migrate memory to a desired processor's memory via cudaMemPrefetchAsync.

In a multi-GPU system where all of the GPUs have a zero value for the device attribute cudaDevAttrConcurrentManagedAccess and all the GPUs have peer-to-peer support with each other, the physical storage for managed memory is created on the GPU which is active at the time cudaMallocManaged is called. All other GPUs will reference the data at reduced bandwidth via peer mappings over the PCIe bus. The Unified Memory driver does not migrate memory among such GPUs.

In a multi-GPU system where not all GPUs have peer-to-peer support with each other and where the value of the device attribute cudaDevAttrConcurrentManagedAccess is zero for at least one of those GPUs, the location chosen for physical storage of managed memory is system-dependent.

- On Linux, the location chosen will be device memory as long as the current set of active contexts are on devices that either have peer-to-peer support with each other or have a non-zero value for the device attribute cudaDevAttrConcurrentManagedAccess. If there is an active context on a GPU that does not have a non-zero value for that device attribute and it does not have peer-to-peer support with the other devices that have active contexts on them, then the location for physical storage will be 'zero-copy' or host memory. Note that this means that managed memory that is located in device memory is migrated to host memory if a new context is created on a GPU that doesn't have a non-zero value for the device attribute and does not support peer-to-peer with at least one of the other devices that has an active context. This in turn implies that context creation may fail if there is insufficient host memory to migrate all managed allocations.
- On Windows, the physical storage is always created in 'zero-copy' or host memory. All GPUs will reference the data at reduced bandwidth over the PCIe bus. In these circumstances, use of the environment variable CUDA\_VISIBLE\_DEVICES is recommended to restrict CUDA to only use

those GPUs that have peer-to-peer support. Alternatively, users can also set CUDA\_MANAGED\_FORCE\_DEVICE\_ALLOC to a non-zero value to force the driver to always use device memory for physical storage. When this environment variable is set to a non-zero value, all devices used in that process that support managed memory have to be peer-to-peer compatible with each other. The error cudaErrorInvalidDevice will be returned if a device that supports managed memory is used and it is not peer-to-peer compatible with any of the other managed memory supporting devices that were previously used in that process, even if cudaDeviceReset has been called on those devices. These environment variables are described in the CUDA programming guide under the "CUDA environment variables" section.

## See also:

cudaMallocPitch, cudaFree, cudaMallocArray, cudaFreeArray, cudaMalloc3D, cudaMalloc3DArray, cudaMallocHost ( C API), cudaFreeHost, cudaHostAlloc, cudaDeviceGetAttribute, cudaStreamAttachMemAsync

template < class T > \_\_host\_\_cudaError\_t
cudaMemcpyFromSymbol (void \*dst, const T symbol,
size\_t count, size\_t offset, cudaMemcpyKind kind)
[C++ API] Copies data from the given symbol on the device

## **Parameters**

## dst

- Destination memory address

## symbol

- Device symbol reference

## count

- Size in bytes to copy

## offset

- Offset from start of symbol in bytes

## kind

- Type of transfer

## Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidSymbol, cudaErrorInvalidDevicePointer, cudaErrorInvalidMemcpyDirection

## Description

Copies count bytes from the memory area offset bytes from the start of symbol symbol to the memory area pointed to by dst. The memory areas may not overlap. symbol is a variable that resides in global or constant memory space. kind can be either cudaMemcpyDeviceToHost or cudaMemcpyDeviceToDevice.



- Note that this function may also return error codes from previous, asynchronous launches.
- ► This function exhibits synchronous behavior for most use cases.
- ▶ Use of a string naming a variable as the symbol paramater was deprecated in CUDA 4.1 and removed in CUDA 5.0.

## See also:

cudaMemcpy, cudaMemcpy2D, cudaMemcpyToArray, cudaMemcpy2DToArray, cudaMemcpyFromArray, cudaMemcpy2DFromArray, cudaMemcpyArrayToArray, cudaMemcpy2DArrayToArray, cudaMemcpyToSymbol, cudaMemcpyAsync, cudaMemcpy2DAsync, cudaMemcpyToArrayAsync, cudaMemcpy2DToArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpy2DFromArrayAsync, cudaMemcpyToSymbolAsync, cudaMemcpyFromSymbolAsync

template < class T > \_\_host\_\_cudaError\_t
cudaMemcpyFromSymbolAsync (void \*dst, const T
symbol, size\_t count, size\_t offset, cudaMemcpyKind
kind, cudaStream\_t stream)

[C++ API] Copies data from the given symbol on the device

## **Parameters**

## dst

- Destination memory address

## symbol

- Device symbol reference

### count

- Size in bytes to copy

## offset

- Offset from start of symbol in bytes

## kind

- Type of transfer

## stream

- Stream identifier

## **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidSymbol, cudaErrorInvalidDevicePointer, cudaErrorInvalidMemcpyDirection

## Description

Copies count bytes from the memory area offset bytes from the start of symbol symbol to the memory area pointed to by dst. The memory areas may not overlap. symbol is a variable that resides in global or constant memory space. kind can be either cudaMemcpyDeviceToHost or cudaMemcpyDeviceToDevice.

cudaMemcpyFromSymbolAsync() is asynchronous with respect to the host, so the call may return before the copy is complete. The copy can optionally be associated to a stream by passing a non-zero stream argument. If kind is cudaMemcpyDeviceToHost and stream is non-zero, the copy may overlap with operations in other streams.



- Note that this function may also return error codes from previous, asynchronous launches.
- ▶ This function exhibits asynchronous behavior for most use cases.
- ▶ Use of a string naming a variable as the symbol paramater was deprecated in CUDA 4.1 and removed in CUDA 5.0.

## See also:

cudaMemcpy, cudaMemcpy2D, cudaMemcpyToArray, cudaMemcpy2DToArray, cudaMemcpyFromArray, cudaMemcpy2DFromArray, cudaMemcpy4ToArrayToArray, cudaMemcpy2DArrayToArray, cudaMemcpyToSymbol, cudaMemcpyFromSymbol, cudaMemcpyAsync, cudaMemcpy2DAsync, cudaMemcpyToArrayAsync, cudaMemcpy2DToArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpy2DFromArrayAsync, cudaMemcpyToSymbolAsync

template < class T > \_\_host\_\_cudaError\_t
cudaMemcpyToSymbol (const T symbol, const void \*src,
size\_t count, size\_t offset, cudaMemcpyKind kind)

[C++ API] Copies data to the given symbol on the device

## **Parameters**

## symbol

- Device symbol reference

## src

- Source memory address

## count

- Size in bytes to copy

## offset

- Offset from start of symbol in bytes

## kind

- Type of transfer

## **Returns**

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidSymbol, cudaErrorInvalidDevicePointer, cudaErrorInvalidMemcpyDirection

## Description

Copies count bytes from the memory area pointed to by src to the memory area offset bytes from the start of symbol. The memory areas may not overlap. symbol is a variable that resides in global or constant memory space. kind can be either cudaMemcpyHostToDevice or cudaMemcpyDeviceToDevice.



- Note that this function may also return error codes from previous, asynchronous launches.
- ► This function exhibits synchronous behavior for most use cases.
- ▶ Use of a string naming a variable as the symbol paramater was deprecated in CUDA 4.1 and removed in CUDA 5.0.

## See also:

cudaMemcpy, cudaMemcpy2D, cudaMemcpyToArray, cudaMemcpy2DToArray, cudaMemcpyFromArray, cudaMemcpy2DFromArray, cudaMemcpyArrayToArray, cudaMemcpy2DArrayToArray, cudaMemcpyFromSymbol, cudaMemcpyAsync, cudaMemcpy2DAsync, cudaMemcpyToArrayAsync, cudaMemcpy2DToArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpyToSymbolAsync, cudaMemcpyFromSymbolAsync, cudaMemcpyToSymbolAsync, cudaMemcpyFromSymbolAsync

template < class T > \_\_host\_\_cudaError\_t
cudaMemcpyToSymbolAsync (const T symbol, const void

## \*src, size\_t count, size\_t offset, cudaMemcpyKind kind, cudaStream\_t stream)

[C++ API] Copies data to the given symbol on the device

## **Parameters**

## symbol

- Device symbol reference

## src

- Source memory address

## count

- Size in bytes to copy

## offset

- Offset from start of symbol in bytes

## kind

- Type of transfer

### stream

- Stream identifier

## Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorInvalidSymbol, cudaErrorInvalidDevicePointer, cudaErrorInvalidMemcpyDirection

## Description

Copies count bytes from the memory area pointed to by src to the memory area offset bytes from the start of symbol. The memory areas may not overlap. symbol is a variable that resides in global or constant memory space. kind can be either cudaMemcpyHostToDevice or cudaMemcpyDeviceToDevice.

cudaMemcpyToSymbolAsync() is asynchronous with respect to the host, so the call may return before the copy is complete. The copy can optionally be associated to a stream by passing a non-zero stream argument. If kind is cudaMemcpyHostToDevice and stream is non-zero, the copy may overlap with operations in other streams.



- Note that this function may also return error codes from previous, asynchronous launches.
- ► This function exhibits asynchronous behavior for most use cases.
- ▶ Use of a string naming a variable as the symbol paramater was deprecated in CUDA 4.1 and removed in CUDA 5.0.

## See also:

cudaMemcpy, cudaMemcpy2D, cudaMemcpyToArray, cudaMemcpy2DToArray, cudaMemcpyFromArray, cudaMemcpy2DFromArray, cudaMemcpyArrayToArray, cudaMemcpy2DArrayToArray, cudaMemcpyToSymbol, cudaMemcpyFromSymbol, cudaMemcpyAsync, cudaMemcpy2DAsync, cudaMemcpyToArrayAsync, cudaMemcpy2DToArrayAsync, cudaMemcpyFromArrayAsync, cudaMemcpy2DFromArrayAsync, cudaMemcpyFromSymbolAsync

# template < class T > \_\_host\_\_cudaError\_t cudaOccupancyMaxActiveBlocksPerMultiprocessor (int \*numBlocks, T func, int blockSize, size\_t dynamicSMemSize)

Returns occupancy for a device function.

## **Parameters**

## numBlocks

- Returned occupancy

## func

- Kernel function for which occupancy is calulated

## blockSize

- Block size the kernel is intended to be launched with

## dynamicSMemSize

- Per-block dynamic shared memory usage intended, in bytes

## **Returns**

cudaSuccess, cudaErrorCudartUnloading, cudaErrorInitializationError, cudaErrorInvalidDevice, cudaErrorInvalidDeviceFunction, cudaErrorInvalidValue, cudaErrorUnknown,

## Description

Returns in \*numBlocks the maximum number of active blocks per streaming multiprocessor for the device function.



Note that this function may also return error codes from previous, asynchronous launches.

## See also:

 $cuda Occupancy Max Active Blocks Per Multiprocessor With Flags \\ cuda Occupancy Max Potential Block Size$ 

 $cuda Occupancy Max Potential Block Size With Flags \\ cuda Occupancy Max Potential Block Size Variable SMem \\ cuda Occupancy Max Potential Block Size Variable SMem With Flags \\$ 

template < class T > \_\_host\_\_cudaError\_t
cudaOccupancyMaxActiveBlocksPerMultiprocessorWithFlags
(int \*numBlocks, T func, int blockSize, size\_t
dynamicSMemSize, unsigned int flags)

Returns occupancy for a device function with the specified flags.

## **Parameters**

## numBlocks

Returned occupancy

## func

- Kernel function for which occupancy is calulated

## blockSize

- Block size the kernel is intended to be launched with

## dynamicSMemSize

- Per-block dynamic shared memory usage intended, in bytes

## flags

- Requested behavior for the occupancy calculator

## Returns

cudaSuccess, cudaErrorCudartUnloading, cudaErrorInitializationError, cudaErrorInvalidDevice, cudaErrorInvalidDeviceFunction, cudaErrorInvalidValue, cudaErrorUnknown,

## Description

Returns in \*numBlocks the maximum number of active blocks per streaming multiprocessor for the device function.

The flags parameter controls how special cases are handled. Valid flags include:

- cudaOccupancyDefault: keeps the default behavior as cudaOccupancyMaxActiveBlocksPerMultiprocessor
- cudaOccupancyDisableCachingOverride: suppresses the default behavior on platform where global caching affects occupancy. On such platforms, if caching is enabled, but per-block SM resource usage would result in zero occupancy, the occupancy calculator will calculate the occupancy as if caching is disabled. Setting this flag makes the occupancy calculator to return 0 in such cases. More information

can be found about this feature in the "Unified L1/Texture Cache" section of the Maxwell tuning guide.



Note that this function may also return error codes from previous, asynchronous launches.

## See also:

cudaOccupancyMaxActiveBlocksPerMultiprocessor cudaOccupancyMaxPotentialBlockSize cudaOccupancyMaxPotentialBlockSizeWithFlags cudaOccupancyMaxPotentialBlockSizeVariableSMem cudaOccupancyMaxPotentialBlockSizeVariableSMemWithFlags

# template < class T > \_\_host\_\_cudaError\_t cudaOccupancyMaxPotentialBlockSize (int \*minGridSize, int \*blockSize, T func, size\_t dynamicSMemSize, int blockSizeLimit)

Returns grid and block size that achieves maximum potential occupancy for a device function.

## **Parameters**

## minGridSize

- Returned minimum grid size needed to achieve the best potential occupancy **blockSize**
- Returned block size

## func

- Device function symbol

## dynamicSMemSize

- Per-block dynamic shared memory usage intended, in bytes

## blockSizeLimit

- The maximum block size func is designed to work with. 0 means no limit.

## Returns

cudaSuccess, cudaErrorCudartUnloading, cudaErrorInitializationError, cudaErrorInvalidDevice, cudaErrorInvalidDeviceFunction, cudaErrorInvalidValue, cudaErrorUnknown,

# Description

Returns in \*minGridSize and \*blocksize a suggested grid / block size pair that achieves the best potential occupancy (i.e. the maximum number of active warps with the smallest number of blocks).

Use

#### See also:

cudaOccupancyMaxPotentialBlockSizeVariableSMem if the amount of per-block dynamic shared memory changes with different block sizes.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaOccupancyMaxActiveBlocksPerMultiprocessor cudaOccupancyMaxActiveBlocksPerMultiprocessorWithFlags cudaOccupancyMaxActiveBlocksPerMultiprocessorWithFlags cudaOccupancyMaxPotentialBlockSizeVariableSMem cudaOccupancyMaxPotentialBlockSizeVariableSMemWithFlags

template < typename UnaryFunction, class T >
 \_\_host\_\_cudaError\_t
cudaOccupancyMaxPotentialBlockSizeVariableSMem (int
\*minGridSize, int \*blockSize, T func, UnaryFunction
blockSizeToDynamicSMemSize, int blockSizeLimit)

Returns grid and block size that achieves maximum potential occupancy for a device function.

# **Parameters**

#### minGridSize

- Returned minimum grid size needed to achieve the best potential occupancy **blockSize** 
  - Returned block size

#### func

- Device function symbol

# blockSizeToDynamicSMemSize

- A unary function / functor that takes block size, and returns the size, in bytes, of dynamic shared memory needed for a block

#### blockSizeLimit

- The maximum block size func is designed to work with. 0 means no limit.

#### Returns

cudaSuccess, cudaErrorCudartUnloading, cudaErrorInitializationError, cudaErrorInvalidDevice, cudaErrorInvalidDeviceFunction, cudaErrorInvalidValue, cudaErrorUnknown,

# Description

Returns in \*minGridSize and \*blocksize a suggested grid / block size pair that achieves the best potential occupancy (i.e. the maximum number of active warps with the smallest number of blocks).



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaOccupancyMaxPotentialBlockSizeVariableSMemWithFlags cudaOccupancyMaxActiveBlocksPerMultiprocessor cudaOccupancyMaxActiveBlocksPerMultiprocessorWithFlags cudaOccupancyMaxPotentialBlockSize cudaOccupancyMaxPotentialBlockSizeWithFlags

template < typename UnaryFunction, class T >
\_\_host\_\_cudaError\_t
cudaOccupancyMaxPotentialBlockSizeVariableSMemWithFlags
(int \*minGridSize, int \*blockSize, T func, UnaryFunction)

# blockSizeToDynamicSMemSize, int blockSizeLimit, unsigned int flags)

Returns grid and block size that achieves maximum potential occupancy for a device function.

#### **Parameters**

#### minGridSize

- Returned minimum grid size needed to achieve the best potential occupancy

#### blockSize

- Returned block size

#### func

- Device function symbol

# blockSizeToDynamicSMemSize

- A unary function / functor that takes block size, and returns the size, in bytes, of dynamic shared memory needed for a block

#### blockSizeLimit

- The maximum block size func is designed to work with. 0 means no limit.

#### flags

- Requested behavior for the occupancy calculator

#### **Returns**

cudaSuccess, cudaErrorCudartUnloading, cudaErrorInitializationError, cudaErrorInvalidDevice, cudaErrorInvalidDeviceFunction, cudaErrorInvalidValue, cudaErrorUnknown,

## Description

Returns in \*minGridSize and \*blocksize a suggested grid / block size pair that achieves the best potential occupancy (i.e. the maximum number of active warps with the smallest number of blocks).

The flags parameter controls how special cases are handled. Valid flags include:

- cudaOccupancyDefault: keeps the default behavior as cudaOccupancyMaxPotentialBlockSizeVariableSMemWithFlags
- cudaOccupancyDisableCachingOverride: This flag suppresses the default behavior on platform where global caching affects occupancy. On such platforms, if caching is enabled, but per-block SM resource usage would result in zero occupancy, the occupancy calculator will calculate the occupancy as if caching is disabled. Setting this flag makes the occupancy calculator to return 0 in such cases. More information can be found about this feature in the "Unified L1/Texture Cache" section of the Maxwell tuning guide.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaOccupancyMaxPotentialBlockSizeVariableSMem cudaOccupancyMaxActiveBlocksPerMultiprocessor cudaOccupancyMaxActiveBlocksPerMultiprocessorWithFlags cudaOccupancyMaxPotentialBlockSize cudaOccupancyMaxPotentialBlockSizeWithFlags

template < class T > \_\_host\_\_cudaError\_t
cudaOccupancyMaxPotentialBlockSizeWithFlags
(int \*minGridSize, int \*blockSize, T func, size\_t
dynamicSMemSize, int blockSizeLimit, unsigned int
flags)

Returns grid and block size that achived maximum potential occupancy for a device function with the specified flags.

#### **Parameters**

## minGridSize

- Returned minimum grid size needed to achieve the best potential occupancy **blockSize** 
  - Returned block size

#### func

- Device function symbol

# dynamicSMemSize

- Per-block dynamic shared memory usage intended, in bytes

#### blockSizeLimit

- The maximum block size func is designed to work with. 0 means no limit.

# flags

- Requested behavior for the occupancy calculator

## Returns

cudaSuccess, cudaErrorCudartUnloading, cudaErrorInitializationError, cudaErrorInvalidDevice, cudaErrorInvalidDeviceFunction, cudaErrorInvalidValue, cudaErrorUnknown,

# Description

Returns in \*minGridSize and \*blocksize a suggested grid / block size pair that achieves the best potential occupancy (i.e. the maximum number of active warps with the smallest number of blocks).

The flags parameter controls how special cases are handle. Valid flags include:

- cudaOccupancyDefault: keeps the default behavior as cudaOccupancyMaxPotentialBlockSize
- cudaOccupancyDisableCachingOverride: This flag suppresses the default behavior on platform where global caching affects occupancy. On such platforms, if caching is enabled, but per-block SM resource usage would result in zero occupancy, the occupancy calculator will calculate the occupancy as if caching is disabled. Setting this flag makes the occupancy calculator to return 0 in such cases. More information can be found about this feature in the "Unified L1/Texture Cache" section of the Maxwell tuning guide.

Use

#### See also:

cudaOccupancyMaxPotentialBlockSizeVariableSMem if the amount of per-block dynamic shared memory changes with different block sizes.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaOccupancyMaxActiveBlocksPerMultiprocessor cudaOccupancyMaxActiveBlocksPerMultiprocessorWithFlags cudaOccupancyMaxPotentialBlockSizeVariableSMem cudaOccupancyMaxPotentialBlockSizeVariableSMemWithFlags

# template < class T > \_\_host\_\_cudaError\_t cudaSetupArgument (T arg, size\_t offset)

[C++ API] Configure a device launch

#### **Parameters**

#### arg

- Argument to push for a kernel launch

#### offset

- Offset in argument stack to push new arg

#### Returns

cudaSuccess

# Description

Deprecated This function is deprecated as of CUDA 7.0

Pushes size bytes of the argument pointed to by arg at offset bytes from the start of the parameter passing area, which starts at offset 0. The arguments are stored in the top of the execution stack. cudaSetupArgument() must be preceded by a call to cudaConfigureCall().



Note that this function may also return error codes from previous, asynchronous launches.

cudaLaunchKernel (C++ API), cudaFuncGetAttributes (C++ API), cudaLaunch (C++ API), cudaSetDoubleForDevice, cudaSetDoubleForHost, cudaSetupArgument (CAPI)

template < class T > \_\_host\_\_cudaError\_t
cudaStreamAttachMemAsync (cudaStream\_t stream, T
\*devPtr, size\_t length, unsigned int flags)

Attach memory to a stream asynchronously.

# **Parameters**

#### stream

- Stream in which to enqueue the attach operation

# devPtr

- Pointer to memory (must be a pointer to managed memory)

## length

- Length of memory (must be zero, defaults to zero)

# flags

- Must be one of cudaMemAttachGlobal, cudaMemAttachHost or cudaMemAttachSingle (defaults to cudaMemAttachSingle)

#### Returns

cudaSuccess, cudaErrorNotReady, cudaErrorInvalidValue cudaErrorInvalidResourceHandle

# Description

Enqueues an operation in stream to specify stream association of length bytes of memory starting from devPtr. This function is a stream-ordered operation, meaning that it is dependent on, and will only take effect when, previous work in stream has completed. Any previous association is automatically replaced.

devPtr must point to an address within managed memory space declared using the \_\_managed\_\_ keyword or allocated with cudaMallocManaged.

length must be zero, to indicate that the entire allocation's stream association is being changed. Currently, it's not possible to change stream association for a portion of an allocation. The default value for length is zero.

The stream association is specified using flags which must be one of cudaMemAttachGlobal, cudaMemAttachHost or cudaMemAttachSingle. The default value for flags is cudaMemAttachSingle If the cudaMemAttachGlobal flag is specified, the memory can be accessed by any stream on any device. If the cudaMemAttachHost flag is specified, the program makes a guarantee that it won't access the memory on the device from any stream on a device that has a zero value for the device attribute cudaDevAttrConcurrentManagedAccess. If the cudaMemAttachSingle flag is specified and stream is associated with a device that has a zero value for the device attribute cudaDevAttrConcurrentManagedAccess, the program makes a guarantee that it will only access the memory on the device from stream. It is illegal to attach singly to the NULL stream, because the NULL stream is a virtual global stream and not a specific stream. An error will be returned in this case.

When memory is associated with a single stream, the Unified Memory system will allow CPU access to this memory region so long as all operations in stream have completed, regardless of whether other streams are active. In effect, this constrains exclusive ownership of the managed memory region by an active GPU to per-stream activity instead of whole-GPU activity.

Accessing memory on the device from streams that are not associated with it will produce undefined results. No error checking is performed by the Unified Memory system to ensure that kernels launched into other streams do not access this region.

It is a program's responsibility to order calls to cudaStreamAttachMemAsync via events, synchronization or other means to ensure legal access to memory at all times. Data

visibility and coherency will be changed appropriately for all kernels which follow a stream-association change.

If stream is destroyed while data is associated with it, the association is removed and the association reverts to the default visibility of the allocation as specified at cudaMallocManaged. For \_\_managed\_\_ variables, the default association is always cudaMemAttachGlobal. Note that destroying a stream is an asynchronous operation, and as a result, the change to default association won't happen until all work in the stream has completed.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaStreamCreate, cudaStreamCreateWithFlags, cudaStreamWaitEvent, cudaStreamSynchronize, cudaStreamAddCallback, cudaStreamDestroy, cudaMallocManaged

template < class T, int dim, enum cudaTextureReadMode
readMode > \_\_host\_\_cudaError\_t cudaUnbindTexture
(const textureTdimreadMode tex)

[C++ API] Unbinds a texture

#### **Parameters**

tex

- Texture to unbind

#### Returns

cudaSuccess

## Description

Unbinds the texture bound to tex.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaCreateChannelDesc (C++ API), cudaGetChannelDesc, cudaGetTextureReference, cudaBindTexture (C++ API), cudaBindTexture (C++ API, inherited channel descriptor), cudaBindTexture2D (C++ API), cudaBindTexture2D (C++ API, inherited channel descriptor), cudaBindTextureToArray (C++ API), cudaBindTextureToArray (C++ API, inherited channel descriptor), cudaUnbindTexture (CAPI), cudaGetTextureAlignmentOffset (C++ API)

# 4.29. Interactions with the CUDA Driver API

This section describes the interactions between the CUDA Driver API and the CUDA Runtime API

# **Primary Contexts**

There exists a one to one relationship between CUDA devices in the CUDA Runtime API and CUcontext s in the CUDA Driver API within a process. The specific context which the CUDA Runtime API uses for a device is called the device's primary context. From the perspective of the CUDA Runtime API, a device and its primary context are synonymous.

## Initialization and Tear-Down

CUDA Runtime API calls operate on the CUDA Driver API CUcontext which is current to to the calling host thread.

The function cudaSetDevice() makes the primary context for the specified device current to the calling thread by calling cuCtxSetCurrent().

The CUDA Runtime API will automatically initialize the primary context for a device at the first CUDA Runtime API call which requires an active context. If no CUcontext is current to the calling thread when a CUDA Runtime API call which requires an active context is made, then the primary context for a device will be selected, made current to the calling thread, and initialized.

The context which the CUDA Runtime API initializes will be initialized using the parameters specified by the CUDA Runtime API functions cudaSetDeviceFlags(), cudaD3D9SetDirect3DDevice(), cudaD3D10SetDirect3DDevice(), cudaD3D11SetDirect3DDevice(), cudaGLSetGLDevice(), and cudaVDPAUSetVDPAUDevice(). Note that these functions will fail with cudaErrorSetOnActiveProcess if they are called when the primary context for the specified device has already been initialized. (or if the current device has already been initialized, in the case of cudaSetDeviceFlags()).

Primary contexts will remain active until they are explicitly deinitialized using cudaDeviceReset(). The function cudaDeviceReset() will deinitialize the primary context for the calling thread's current device immediately. The context will remain current to

all of the threads that it was current to. The next CUDA Runtime API call on any thread which requires an active context will trigger the reinitialization of that device's primary context.

Note that there is no reference counting of the primary context's lifetime. It is recommended that the primary context not be deinitialized except just before exit or to recover from an unspecified launch failure.

# **Context Interoperability**

Note that the use of multiple CUcontext s per device within a single process will substantially degrade performance and is strongly discouraged. Instead, it is highly recommended that the implicit one-to-one device-to-context mapping for the process provided by the CUDA Runtime API be used.

If a non-primary CUcontext created by the CUDA Driver API is current to a thread then the CUDA Runtime API calls to that thread will operate on that CUcontext, with some exceptions listed below. Interoperability between data types is discussed in the following sections.

The function cudaPointerGetAttributes() will return the error cudaErrorIncompatibleDriverContext if the pointer being queried was allocated by a non-primary context. The function cudaDeviceEnablePeerAccess() and the rest of the peer access API may not be called when a non-primary CUcontext is current. To use the pointer query and peer access APIs with a context created using the CUDA Driver API, it is necessary that the CUDA Driver API be used to access these features.

All CUDA Runtime API state (e.g, global variables' addresses and values) travels with its underlying CUcontext. In particular, if a CUcontext is moved from one thread to another then all CUDA Runtime API state will move to that thread as well.

Please note that attaching to legacy contexts (those with a version of 3010 as returned by cuCtxGetApiVersion()) is not possible. The CUDA Runtime will return cudaErrorIncompatibleDriverContext in such cases.

#### Interactions between CUstream and cudaStream\_t

The types CUstream and cudaStream\_t are identical and may be used interchangeably.

## Interactions between CUevent and cudaEvent\_t

The types CUevent and cudaEvent\_t are identical and may be used interchangeably.

## Interactions between CUarray and cudaArray\_t

The types CUarray and struct cudaArray \* represent the same data type and may be used interchangeably by casting the two types between each other.

In order to use a CUarray in a CUDA Runtime API function which takes a struct cudaArray \*, it is necessary to explicitly cast the CUarray to a struct cudaArray \*.

In order to use a struct cudaArray \* in a CUDA Driver API function which takes a CUarray, it is necessary to explicitly cast the struct cudaArray \* to a CUarray .

# Interactions between CUgraphicsResource and cudaGraphicsResource\_t

The types CUgraphicsResource and cudaGraphicsResource\_t represent the same data type and may be used interchangeably by casting the two types between each other.

In order to use a CUgraphicsResource in a CUDA Runtime API function which takes a cudaGraphicsResource\_t, it is necessary to explicitly cast the CUgraphicsResource to a cudaGraphicsResource\_t.

In order to use a cudaGraphicsResource\_t in a CUDA Driver API function which takes a CUgraphicsResource, it is necessary to explicitly cast the cudaGraphicsResource\_t to a CUgraphicsResource.

# 4.30. Profiler Control

This section describes the profiler control functions of the CUDA runtime application programming interface.

\_\_host\_\_cudaError\_t cudaProfilerInitialize (const char
\*configFile, const char \*outputFile, cudaOutputMode\_t
outputMode)

Initialize the CUDA profiler.

#### **Parameters**

# configFile

- Name of the config file that lists the counters/options for profiling. **outputFile**
- Name of the outputFile where the profiling results will be stored.
   outputMode
  - outputMode, can be cudaKeyValuePair OR cudaCSV.

#### Returns

cudaSuccess, cudaErrorInvalidValue, cudaErrorProfilerDisabled

#### Description

Using this API user can initialize the CUDA profiler by specifying the configuration file, output file and output file format. This API is generally used to profile different set of counters by looping the kernel launch. The configFile parameter can be used to select profiling options including profiler counters. Refer to the "Compute Command Line Profiler User Guide" for supported profiler options and counters.

Limitation: The CUDA profiler cannot be initialized with this API if another profiling tool is already active, as indicated by the cudaErrorProfilerDisabled return code.

Typical usage of the profiling APIs is as follows:

for each set of counters/options { cudaProfilerInitialize(); //Initialize profiling,set the counters/options in the config file ... cudaProfilerStart(); // code to be profiled cudaProfilerStop(); ... cudaProfilerStart(); // code to be profiled cudaProfilerStop(); ... }



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaProfilerStart, cudaProfilerStop

\_\_host\_\_cudaError\_t cudaProfilerStart (void)

Enable profiling.

# Returns

cudaSuccess

#### Description

Enables profile collection by the active profiling tool for the current context. If profiling is already enabled, then cudaProfilerStart() has no effect.

cudaProfilerStart and cudaProfilerStop APIs are used to programmatically control the profiling granularity by allowing profiling to be done only on selective pieces of code.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaProfilerInitialize, cudaProfilerStop

\_\_host\_\_cudaError\_t cudaProfilerStop (void)

Disable profiling.

#### Returns

cudaSuccess

# **Description**

Disables profile collection by the active profiling tool for the current context. If profiling is already disabled, then cudaProfilerStop() has no effect.

cudaProfilerStart and cudaProfilerStop APIs are used to programmatically control the profiling granularity by allowing profiling to be done only on selective pieces of code.



Note that this function may also return error codes from previous, asynchronous launches.

#### See also:

cudaProfilerInitialize, cudaProfilerStart

# 4.31. Data types used by CUDA Runtime

struct cudaChannelFormatDesc

struct cudaDeviceProp

struct cudaEglFrame

struct cudaEglPlaneDesc

struct cudaExtent

struct cudaFuncAttributes

struct cudalpcEventHandle\_t

struct cudalpcMemHandle\_t

struct cudaMemcpy3DParms

struct cudaMemcpy3DPeerParms

struct cudaPitchedPtr

struct cudaPointerAttributes

struct cudaPos

struct cudaResourceDesc

struct cudaResourceViewDesc

struct cudaTextureDesc

struct surfaceReference

struct textureReference

# enum cudaChannelFormatKind

Channel format kind

#### **Values**

cudaChannelFormatKindSigned = 0

Signed channel format

cudaChannelFormatKindUnsigned = 1

Unsigned channel format

cudaChannelFormatKindFloat = 2

Float channel format

cudaChannelFormatKindNone = 3

No channel format

# enum cudaComputeMode

CUDA device compute modes

#### **Values**

# cudaComputeModeDefault = 0

Default compute mode (Multiple threads can use cudaSetDevice() with this device)

# cudaComputeModeExclusive = 1

Compute-exclusive-thread mode (Only one thread in one process will be able to use cudaSetDevice() with this device)

#### cudaComputeModeProhibited = 2

Compute-prohibited mode (No threads can use cudaSetDevice() with this device)

# cudaComputeModeExclusiveProcess = 3

Compute-exclusive-process mode (Many threads in one process will be able to use cudaSetDevice() with this device)

# enum cudaDeviceAttr

CUDA device attributes

#### **Values**

#### cudaDevAttrMaxThreadsPerBlock = 1

Maximum number of threads per block

#### cudaDevAttrMaxBlockDimX = 2

Maximum block dimension X

#### cudaDevAttrMaxBlockDimY = 3

Maximum block dimension Y

cudaDevAttrMaxBlockDimZ = 4

Maximum block dimension Z

# cudaDevAttrMaxGridDimX = 5

Maximum grid dimension X

#### cudaDevAttrMaxGridDimY = 6

Maximum grid dimension Y

# cudaDevAttrMaxGridDimZ = 7

Maximum grid dimension Z

# cudaDevAttrMaxSharedMemoryPerBlock = 8

Maximum shared memory available per block in bytes

# cudaDevAttrTotalConstantMemory = 9

Memory available on device for \_\_constant\_\_ variables in a CUDA C kernel in bytes

# cudaDevAttrWarpSize = 10

Warp size in threads

#### cudaDevAttrMaxPitch = 11

Maximum pitch in bytes allowed by memory copies

# cudaDevAttrMaxRegistersPerBlock = 12

Maximum number of 32-bit registers available per block

# cudaDevAttrClockRate = 13

Peak clock frequency in kilohertz

# cudaDevAttrTextureAlignment = 14

Alignment requirement for textures

# cudaDevAttrGpuOverlap = 15

Device can possibly copy memory and execute a kernel concurrently

# cudaDevAttrMultiProcessorCount = 16

Number of multiprocessors on device

#### cudaDevAttrKernelExecTimeout = 17

Specifies whether there is a run time limit on kernels

#### cudaDevAttrIntegrated = 18

Device is integrated with host memory

# cudaDevAttrCanMapHostMemory = 19

Device can map host memory into CUDA address space

#### cudaDevAttrComputeMode = 20

Compute mode (See cudaComputeMode for details)

#### cudaDevAttrMaxTexture1DWidth = 21

Maximum 1D texture width

#### cudaDevAttrMaxTexture2DWidth = 22

Maximum 2D texture width

## cudaDevAttrMaxTexture2DHeight = 23

Maximum 2D texture height

#### cudaDevAttrMaxTexture3DWidth = 24

Maximum 3D texture width

## cudaDevAttrMaxTexture3DHeight = 25

Maximum 3D texture height

# cudaDevAttrMaxTexture3DDepth = 26

Maximum 3D texture depth

# cudaDevAttrMaxTexture2DLayeredWidth = 27

Maximum 2D layered texture width

# cudaDevAttrMaxTexture2DLayeredHeight = 28

Maximum 2D layered texture height

# cudaDevAttrMaxTexture2DLayeredLayers = 29

Maximum layers in a 2D layered texture

## cudaDevAttrSurfaceAlignment = 30

Alignment requirement for surfaces

#### cudaDevAttrConcurrentKernels = 31

Device can possibly execute multiple kernels concurrently

#### cudaDevAttrEccEnabled = 32

Device has ECC support enabled

#### cudaDevAttrPciBusId = 33

PCI bus ID of the device

#### cudaDevAttrPciDeviceId = 34

PCI device ID of the device

#### cudaDevAttrTccDriver = 35

Device is using TCC driver model

# cudaDevAttrMemoryClockRate = 36

Peak memory clock frequency in kilohertz

## cudaDevAttrGlobalMemoryBusWidth = 37

Global memory bus width in bits

# cudaDevAttrL2CacheSize = 38

Size of L2 cache in bytes

## cudaDevAttrMaxThreadsPerMultiProcessor = 39

Maximum resident threads per multiprocessor

## cudaDevAttrAsyncEngineCount = 40

Number of asynchronous engines

## cudaDevAttrUnifiedAddressing = 41

Device shares a unified address space with the host

# cudaDevAttrMaxTexture1DLayeredWidth = 42

Maximum 1D layered texture width

# cudaDevAttrMaxTexture1DLayeredLayers = 43

Maximum layers in a 1D layered texture

# cudaDevAttrMaxTexture2DGatherWidth = 45

Maximum 2D texture width if cudaArrayTextureGather is set

# cudaDevAttrMaxTexture2DGatherHeight = 46

Maximum 2D texture height if cudaArrayTextureGather is set

#### cudaDevAttrMaxTexture3DWidthAlt = 47

Alternate maximum 3D texture width

# cudaDevAttrMaxTexture3DHeightAlt = 48

Alternate maximum 3D texture height
cudaDevAttrMaxTexture3DDepthAlt = 49
Alternate maximum 3D texture depth
cudaDevAttrPciDomainId = 50
PCI domain ID of the device
cudaDevAttrTexturePitchAlignment = 51
Pitch alignment requirement for textures
cudaDevAttrMaxTextureCubemapWidth = 52
Maximum cubemap texture width/height
cudaDevAttrMaxTextureCubemapLayeredWidth = 53
Maximum cubemap layered texture width/height
cudaDevAttrMaxTextureCubemapLayeredLayers = 54
Maximum layers in a cubemap layered texture
cudaDevAttrMaxSurface1DWidth = 55
Maximum 1D surface width
cudaDevAttrMaxSurface2DWidth = 56
Maximum 2D surface width
cudaDevAttrMaxSurface2DHeight = 57
Maximum 2D surface height
cudaDevAttrMaxSurface3DWidth = 58
Maximum 3D surface width
cudaDevAttrMaxSurface3DHeight = 59
Maximum 3D surface height
cudaDevAttrMaxSurface3DDepth = 60
Maximum 3D surface depth
cudaDevAttrMaxSurface1DLayeredWidth = 61
Maximum 1D layered surface width
cudaDevAttrMaxSurface1DLayeredLayers = 62
Maximum layers in a 1D layered surface
cudaDevAttrMaxSurface2DLayeredWidth = 63
Maximum 2D layered surface width
cudaDevAttrMaxSurface2DLayeredHeight = 64
Maximum 2D layered surface height
cudaDevAttrMaxSurface2DLayeredLayers = 65
Maximum layers in a 2D layered surface

# cudaDevAttrMaxSurfaceCubemapLayeredWidth = 67 Maximum cubemap layered surface width cudaDevAttrMaxSurfaceCubemapLayeredLayers = 68

Maximum layers in a cubemap layered surface

# cuda Dev Attr Max Texture 1 DLinear Width = 69

cudaDevAttrMaxSurfaceCubemapWidth = 66

Maximum 1D linear texture width

Maximum cubemap surface width

# cudaDevAttrMaxTexture2DLinearWidth = 70

Maximum 2D linear texture width

# cudaDevAttrMaxTexture2DLinearHeight = 71

Maximum 2D linear texture height

# cudaDevAttrMaxTexture2DLinearPitch = 72

Maximum 2D linear texture pitch in bytes

# cudaDevAttrMaxTexture2DMipmappedWidth = 73

Maximum mipmapped 2D texture width

# cudaDevAttrMaxTexture2DMipmappedHeight = 74

Maximum mipmapped 2D texture height

# cudaDevAttrComputeCapabilityMajor = 75

Major compute capability version number

# cudaDevAttrComputeCapabilityMinor = 76

Minor compute capability version number

# cudaDevAttrMaxTexture1DMipmappedWidth = 77

Maximum mipmapped 1D texture width

# cudaDevAttrStreamPrioritiesSupported = 78

Device supports stream priorities

# cudaDevAttrGlobalL1CacheSupported = 79

Device supports caching globals in L1

# cudaDevAttrLocalL1CacheSupported = 80

Device supports caching locals in L1

# cudaDevAttrMaxSharedMemoryPerMultiprocessor = 81

Maximum shared memory available per multiprocessor in bytes

# cudaDevAttrMaxRegistersPerMultiprocessor = 82

Maximum number of 32-bit registers available per multiprocessor

# cudaDevAttrManagedMemory = 83

Device can allocate managed memory on this system

## cudaDevAttrIsMultiGpuBoard = 84

Device is on a multi-GPU board

#### cudaDevAttrMultiGpuBoardGroupID = 85

Unique identifier for a group of devices on the same multi-GPU board

#### cudaDevAttrHostNativeAtomicSupported = 86

Link between the device and the host supports native atomic operations

# cudaDevAttrSingleToDoublePrecisionPerfRatio = 87

Ratio of single precision performance (in floating-point operations per second) to double precision performance

#### cudaDevAttrPageableMemoryAccess = 88

Device supports coherently accessing pageable memory without calling cudaHostRegister on it

#### cudaDevAttrConcurrentManagedAccess = 89

Device can coherently access managed memory concurrently with the CPU

# cudaDevAttrComputePreemptionSupported = 90

**Device supports Compute Preemption** 

# cudaDevAttrCanUseHostPointerForRegisteredMem = 91

Device can access host registered memory at the same virtual address as the CPU

# enum cudaDeviceP2PAttr

CUDA device P2P attributes

#### **Values**

#### cudaDevP2PAttrPerformanceRank = 1

A relative value indicating the performance of the link between two devices

# cudaDevP2PAttrAccessSupported = 2

Peer access is enabled

# cudaDevP2PAttrNativeAtomicSupported = 3

Native atomic operation over the link supported

# enum cudaEglColorFormat

CUDA EGL Color Format - The different planar and multiplanar formats currently supported for CUDA\_EGL interops.

#### **Values**

# cudaEglColorFormatYUV420Planar = 0

Y, U, V in three surfaces, each in a separate surface, U/V width = 1/2 Y width, U/V height = 1/2 Y height.

#### cudaEglColorFormatYUV420SemiPlanar = 1

Y, UV in two surfaces (UV as one surface), width, height ratio same as YUV420Planar.

# cudaEglColorFormatYUV422Planar = 2

Y, U, V each in a separate surface, U/V width = 1/2 Y width, U/V height = Y height.

## cudaEglColorFormatYUV422SemiPlanar = 3

Y, UV in two surfaces, width, height ratio same as YUV422Planar.

# cudaEglColorFormatRGB = 4

R/G/B three channels in one surface with RGB byte ordering.

#### cudaEglColorFormatBGR = 5

R/G/B three channels in one surface with BGR byte ordering.

## cudaEglColorFormatARGB = 6

R/G/B/A four channels in one surface with ARGB byte ordering.

#### cudaEglColorFormatRGBA = 7

R/G/B/A four channels in one surface with RGBA byte ordering.

# cudaEglColorFormatL = 8

single luminance channel in one surface.

## cudaEglColorFormatR = 9

single color channel in one surface.

# enum cudaEglFrameType

CUDA EglFrame type - array or pointer

#### **Values**

cudaEglFrameTypeArray = 0
 Frame type CUDA array
cudaEglFrameTypePitch = 1
 Frame type CUDA pointer

# enum cudaEglResourceLocationFlags

Resource location flags- sysmem or vidmem

For CUDA context on iGPU, since video and system memory are equivalent - these flags will not have an effect on the execution.

For CUDA context on dGPU, applications can use the flag cudaEglResourceLocationFlags to give a hint about the desired location.

cudaEglResourceLocationSysmem - the frame data is made resident on the system memory to be accessed by CUDA.

cudaEglResourceLocationVidmem - the frame data is made resident on the dedicated video memory to be accessed by CUDA.

There may be an additional latency due to new allocation and data migration, if the frame is produced on a different memory.

#### **Values**

cudaEglResourceLocationSysmem = 0x00
 Resource location sysmem
cudaEglResourceLocationVidmem = 0x01
 Resource location vidmem

# enum cudaError

CUDA error types

# **Values**

#### cudaSuccess = 0

The API call returned with no errors. In the case of query calls, this can also mean that the operation being queried is complete (see cudaEventQuery() and cudaStreamQuery()).

cudaErrorMissingConfiguration = 1

The device function being invoked (usually via cudaLaunchKernel()) was not previously configured via the cudaConfigureCall() function.

# cudaErrorMemoryAllocation = 2

The API call failed because it was unable to allocate enough memory to perform the requested operation.

#### cudaErrorInitializationError = 3

The API call failed because the CUDA driver and runtime could not be initialized.

#### cudaErrorLaunchFailure = 4

An exception occurred on the device while executing a kernel. Common causes include dereferencing an invalid device pointer and accessing out of bounds shared memory. The device cannot be used until cudaThreadExit() is called. All existing device memory allocations are invalid and must be reconstructed if the program is to continue using CUDA.

#### cudaErrorPriorLaunchFailure = 5

This indicated that a previous kernel launch failed. This was previously used for device emulation of kernel launches. Deprecated This error return is deprecated as of CUDA 3.1. Device emulation mode was removed with the CUDA 3.1 release.

#### cudaErrorLaunchTimeout = 6

This indicates that the device kernel took too long to execute. This can only occur if timeouts are enabled - see the device property kernelExecTimeoutEnabled for more information. This leaves the process in an inconsistent state and any further CUDA work will return the same error. To continue using CUDA, the process must be terminated and relaunched.

## cudaErrorLaunchOutOfResources = 7

This indicates that a launch did not occur because it did not have appropriate resources. Although this error is similar to cudaErrorInvalidConfiguration, this error usually indicates that the user has attempted to pass too many arguments to the device kernel, or the kernel launch specifies too many threads for the kernel's register count.

# cudaErrorInvalidDeviceFunction = 8

The requested device function does not exist or is not compiled for the proper device architecture.

#### cudaErrorInvalidConfiguration = 9

This indicates that a kernel launch is requesting resources that can never be satisfied by the current device. Requesting more shared memory per block than the device supports will trigger this error, as will requesting too many threads or blocks. See cudaDeviceProp for more device limitations.

# cudaErrorInvalidDevice = 10

This indicates that the device ordinal supplied by the user does not correspond to a valid CUDA device.

#### cudaErrorInvalidValue = 11

This indicates that one or more of the parameters passed to the API call is not within an acceptable range of values.

#### cudaErrorInvalidPitchValue = 12

This indicates that one or more of the pitch-related parameters passed to the API call is not within the acceptable range for pitch.

# cudaErrorInvalidSymbol = 13

This indicates that the symbol name/identifier passed to the API call is not a valid name or identifier.

# cudaErrorMapBufferObjectFailed = 14

This indicates that the buffer object could not be mapped.

# cudaErrorUnmapBufferObjectFailed = 15

This indicates that the buffer object could not be unmapped.

## cudaErrorInvalidHostPointer = 16

This indicates that at least one host pointer passed to the API call is not a valid host pointer.

#### cudaErrorInvalidDevicePointer = 17

This indicates that at least one device pointer passed to the API call is not a valid device pointer.

#### cudaErrorInvalidTexture = 18

This indicates that the texture passed to the API call is not a valid texture.

# cudaErrorInvalidTextureBinding = 19

This indicates that the texture binding is not valid. This occurs if you call cudaGetTextureAlignmentOffset() with an unbound texture.

# cudaErrorInvalidChannelDescriptor = 20

This indicates that the channel descriptor passed to the API call is not valid. This occurs if the format is not one of the formats specified by cudaChannelFormatKind, or if one of the dimensions is invalid.

# cudaErrorInvalidMemcpyDirection = 21

This indicates that the direction of the memcpy passed to the API call is not one of the types specified by cudaMemcpyKind.

## cudaErrorAddressOfConstant = 22

This indicated that the user has taken the address of a constant variable, which was forbidden up until the CUDA 3.1 release. Deprecated This error return is deprecated as of CUDA 3.1. Variables in constant memory may now have their address taken by the runtime via cudaGetSymbolAddress().

## cudaErrorTextureFetchFailed = 23

This indicated that a texture fetch was not able to be performed. This was previously used for device emulation of texture operations. Deprecated This error return is deprecated as of CUDA 3.1. Device emulation mode was removed with the CUDA 3.1 release.

#### cudaErrorTextureNotBound = 24

This indicated that a texture was not bound for access. This was previously used for device emulation of texture operations. Deprecated This error return is deprecated as of CUDA 3.1. Device emulation mode was removed with the CUDA 3.1 release.

# cudaErrorSynchronizationError = 25

This indicated that a synchronization operation had failed. This was previously used for some device emulation functions. Deprecated This error return is deprecated as of CUDA 3.1. Device emulation mode was removed with the CUDA 3.1 release.

# cudaErrorInvalidFilterSetting = 26

This indicates that a non-float texture was being accessed with linear filtering. This is not supported by CUDA.

# cudaErrorInvalidNormSetting = 27

This indicates that an attempt was made to read a non-float texture as a normalized float. This is not supported by CUDA.

#### cudaErrorMixedDeviceExecution = 28

Mixing of device and device emulation code was not allowed. Deprecated This error return is deprecated as of CUDA 3.1. Device emulation mode was removed with the CUDA 3.1 release.

# cudaErrorCudartUnloading = 29

This indicates that a CUDA Runtime API call cannot be executed because it is being called during process shut down, at a point in time after CUDA driver has been unloaded.

#### cudaErrorUnknown = 30

This indicates that an unknown internal error has occurred.

# cudaErrorNotYetImplemented = 31

This indicates that the API call is not yet implemented. Production releases of CUDA will never return this error. Deprecated This error return is deprecated as of CUDA 4.1.

## cudaErrorMemoryValueTooLarge = 32

This indicated that an emulated device pointer exceeded the 32-bit address range. Deprecated This error return is deprecated as of CUDA 3.1. Device emulation mode was removed with the CUDA 3.1 release.

#### cudaErrorInvalidResourceHandle = 33

This indicates that a resource handle passed to the API call was not valid. Resource handles are opaque types like cudaStream\_t and cudaEvent\_t.

#### cudaErrorNotReady = 34

This indicates that asynchronous operations issued previously have not completed yet. This result is not actually an error, but must be indicated differently than cudaSuccess (which indicates completion). Calls that may return this value include cudaEventQuery() and cudaStreamQuery().

#### cudaErrorInsufficientDriver = 35

This indicates that the installed NVIDIA CUDA driver is older than the CUDA runtime library. This is not a supported configuration. Users should install an updated NVIDIA display driver to allow the application to run.

#### cudaErrorSetOnActiveProcess = 36

This indicates that the user has called cudaSetValidDevices(), cudaSetDeviceFlags(), cudaD3D9SetDirect3DDevice(), cudaD3D10SetDirect3DDevice, cudaD3D11SetDirect3DDevice(), or cudaVDPAUSetVDPAUDevice() after initializing

the CUDA runtime by calling non-device management operations (allocating memory and launching kernels are examples of non-device management operations). This error can also be returned if using runtime/driver interoperability and there is an existing CUcontext active on the host thread.

# cudaErrorInvalidSurface = 37

This indicates that the surface passed to the API call is not a valid surface.

#### cudaErrorNoDevice = 38

This indicates that no CUDA-capable devices were detected by the installed CUDA driver.

#### cudaErrorECCUncorrectable = 39

This indicates that an uncorrectable ECC error was detected during execution.

# cudaErrorSharedObjectSymbolNotFound = 40

This indicates that a link to a shared object failed to resolve.

# cudaErrorSharedObjectInitFailed = 41

This indicates that initialization of a shared object failed.

# cudaErrorUnsupportedLimit = 42

This indicates that the cudaLimit passed to the API call is not supported by the active device.

# cudaErrorDuplicateVariableName = 43

This indicates that multiple global or constant variables (across separate CUDA source files in the application) share the same string name.

# cudaErrorDuplicateTextureName = 44

This indicates that multiple textures (across separate CUDA source files in the application) share the same string name.

#### cudaErrorDuplicateSurfaceName = 45

This indicates that multiple surfaces (across separate CUDA source files in the application) share the same string name.

#### cudaErrorDevicesUnavailable = 46

This indicates that all CUDA devices are busy or unavailable at the current time. Devices are often busy/unavailable due to use of cudaComputeModeExclusive, cudaComputeModeProhibited or when long running CUDA kernels have filled up the GPU and are blocking new work from starting. They can also be unavailable due to memory constraints on a device that already has active CUDA work being performed.

# cudaErrorInvalidKernelImage = 47

This indicates that the device kernel image is invalid.

# cudaErrorNoKernelImageForDevice = 48

This indicates that there is no kernel image available that is suitable for the device. This can occur when a user specifies code generation options for a particular CUDA source file that do not include the corresponding device configuration.

#### cudaErrorIncompatibleDriverContext = 49

This indicates that the current context is not compatible with this the CUDA Runtime. This can only occur if you are using CUDA Runtime/Driver interoperability and have

created an existing Driver context using the driver API. The Driver context may be incompatible either because the Driver context was created using an older version of the API, because the Runtime API call expects a primary driver context and the Driver context is not primary, or because the Driver context has been destroyed. Please see Interactions with the CUDA Driver API" for more information.

#### cudaErrorPeerAccessAlreadyEnabled = 50

This error indicates that a call to cudaDeviceEnablePeerAccess() is trying to re-enable peer addressing on from a context which has already had peer addressing enabled.

#### cudaErrorPeerAccessNotEnabled = 51

This error indicates that cudaDeviceDisablePeerAccess() is trying to disable peer addressing which has not been enabled yet via cudaDeviceEnablePeerAccess().

# cudaErrorDeviceAlreadyInUse = 54

This indicates that a call tried to access an exclusive-thread device that is already in use by a different thread.

## cudaErrorProfilerDisabled = 55

This indicates profiler is not initialized for this run. This can happen when the application is running with external profiling tools like visual profiler.

# cudaErrorProfilerNotInitialized = 56

Deprecated This error return is deprecated as of CUDA 5.0. It is no longer an error to attempt to enable/disable the profiling via cudaProfilerStart or cudaProfilerStop without initialization.

# cudaErrorProfilerAlreadyStarted = 57

Deprecated This error return is deprecated as of CUDA 5.0. It is no longer an error to call cudaProfilerStart() when profiling is already enabled.

#### cudaErrorProfilerAlreadyStopped = 58

Deprecated This error return is deprecated as of CUDA 5.0. It is no longer an error to call cudaProfilerStop() when profiling is already disabled.

#### cudaErrorAssert = 59

An assert triggered in device code during kernel execution. The device cannot be used again until cudaThreadExit() is called. All existing allocations are invalid and must be reconstructed if the program is to continue using CUDA.

#### cudaErrorTooManyPeers = 60

This error indicates that the hardware resources required to enable peer access have been exhausted for one or more of the devices passed to cudaEnablePeerAccess().

# cudaErrorHostMemoryAlreadyRegistered = 61

This error indicates that the memory range passed to cudaHostRegister() has already been registered.

## cudaErrorHostMemoryNotRegistered = 62

This error indicates that the pointer passed to cudaHostUnregister() does not correspond to any currently registered memory region.

#### cudaErrorOperatingSystem = 63

This error indicates that an OS call failed.

# cudaErrorPeerAccessUnsupported = 64

This error indicates that P2P access is not supported across the given devices.

# cudaErrorLaunchMaxDepthExceeded = 65

This error indicates that a device runtime grid launch did not occur because the depth of the child grid would exceed the maximum supported number of nested grid launches.

# cudaErrorLaunchFileScopedTex = 66

This error indicates that a grid launch did not occur because the kernel uses file-scoped textures which are unsupported by the device runtime. Kernels launched via the device runtime only support textures created with the Texture Object API's.

# cudaErrorLaunchFileScopedSurf = 67

This error indicates that a grid launch did not occur because the kernel uses file-scoped surfaces which are unsupported by the device runtime. Kernels launched via the device runtime only support surfaces created with the Surface Object API's.

# cudaErrorSyncDepthExceeded = 68

This error indicates that a call to cudaDeviceSynchronize made from the device runtime failed because the call was made at grid depth greater than than either the default (2 levels of grids) or user specified device limit cudaLimitDevRuntimeSyncDepth. To be able to synchronize on launched grids at a greater depth successfully, the maximum nested depth at which cudaDeviceSynchronize will be called must be specified with the cudaLimitDevRuntimeSyncDepth limit to the cudaDeviceSetLimit api before the host-side launch of a kernel using the device runtime. Keep in mind that additional levels of sync depth require the runtime to reserve large amounts of device memory that cannot be used for user allocations.

#### cudaErrorLaunchPendingCountExceeded = 69

This error indicates that a device runtime grid launch failed because the launch would exceed the limit cudaLimitDevRuntimePendingLaunchCount. For this launch to proceed successfully, cudaDeviceSetLimit must be called to set the cudaLimitDevRuntimePendingLaunchCount to be higher than the upper bound of outstanding launches that can be issued to the device runtime. Keep in mind that raising the limit of pending device runtime launches will require the runtime to reserve device memory that cannot be used for user allocations.

## cudaErrorNotPermitted = 70

This error indicates the attempted operation is not permitted.

# cudaErrorNotSupported = 71

This error indicates the attempted operation is not supported on the current system or device.

# cudaErrorHardwareStackError = 72

Device encountered an error in the call stack during kernel execution, possibly due to stack corruption or exceeding the stack size limit. This leaves the process in an inconsistent state and any further CUDA work will return the same error. To continue using CUDA, the process must be terminated and relaunched.

# cudaErrorIllegalInstruction = 73

The device encountered an illegal instruction during kernel execution This leaves the process in an inconsistent state and any further CUDA work will return the same error. To continue using CUDA, the process must be terminated and relaunched.

# cudaErrorMisalignedAddress = 74

The device encountered a load or store instruction on a memory address which is not aligned. This leaves the process in an inconsistent state and any further CUDA work will return the same error. To continue using CUDA, the process must be terminated and relaunched.

# cudaErrorInvalidAddressSpace = 75

While executing a kernel, the device encountered an instruction which can only operate on memory locations in certain address spaces (global, shared, or local), but was supplied a memory address not belonging to an allowed address space. This leaves the process in an inconsistent state and any further CUDA work will return the same error. To continue using CUDA, the process must be terminated and relaunched.

#### cudaErrorInvalidPc = 76

The device encountered an invalid program counter. This leaves the process in an inconsistent state and any further CUDA work will return the same error. To continue using CUDA, the process must be terminated and relaunched.

# cudaErrorIllegalAddress = 77

The device encountered a load or store instruction on an invalid memory address. This leaves the process in an inconsistent state and any further CUDA work will return the same error. To continue using CUDA, the process must be terminated and relaunched.

# cudaErrorInvalidPtx = 78

A PTX compilation failed. The runtime may fall back to compiling PTX if an application does not contain a suitable binary for the current device.

#### cudaErrorInvalidGraphicsContext = 79

This indicates an error with the OpenGL or DirectX context.

#### cudaErrorNvlinkUncorrectable = 80

This indicates that an uncorrectable NVLink error was detected during the execution.

#### cudaErrorStartupFailure = 0x7f

This indicates an internal startup failure in the CUDA runtime.

## cudaErrorApiFailureBase = 10000

Any unhandled CUDA driver error is added to this value and returned via the runtime. Production releases of CUDA should not return such errors. Deprecated This error return is deprecated as of CUDA 4.1.

# enum cudaFuncCache

CUDA function cache configurations

#### **Values**

# cudaFuncCachePreferNone = 0

Default function cache configuration, no preference

#### cudaFuncCachePreferShared = 1

Prefer larger shared memory and smaller L1 cache

# cudaFuncCachePreferL1 = 2

Prefer larger L1 cache and smaller shared memory

# cudaFuncCachePreferEqual = 3

Prefer equal size L1 cache and shared memory

# enum cudaGraphicsCubeFace

CUDA graphics interop array indices for cube maps

#### **Values**

# cudaGraphicsCubeFacePositiveX = 0x00

Positive X face of cubemap

# cudaGraphicsCubeFaceNegativeX = 0x01

Negative X face of cubemap

# cudaGraphicsCubeFacePositiveY = 0x02

Positive Y face of cubemap

# cudaGraphicsCubeFaceNegativeY = 0x03

Negative Y face of cubemap

#### cudaGraphicsCubeFacePositiveZ = 0x04

Positive Z face of cubemap

## cudaGraphicsCubeFaceNegativeZ = 0x05

Negative Z face of cubemap

# enum cudaGraphicsMapFlags

CUDA graphics interop map flags

#### **Values**

# cudaGraphicsMapFlagsNone = 0

Default; Assume resource can be read/written

# cudaGraphicsMapFlagsReadOnly = 1

CUDA will not write to this resource

## cudaGraphicsMapFlagsWriteDiscard = 2

CUDA will only write to and will not read from this resource

# enum cudaGraphicsRegisterFlags

CUDA graphics interop register flags

## **Values**

cudaGraphicsRegisterFlagsNone = 0

Default

cudaGraphicsRegisterFlagsReadOnly = 1

CUDA will not write to this resource

cudaGraphicsRegisterFlagsWriteDiscard = 2

CUDA will only write to and will not read from this resource

cudaGraphicsRegisterFlagsSurfaceLoadStore = 4

CUDA will bind this resource to a surface reference

cudaGraphicsRegisterFlagsTextureGather = 8

CUDA will perform texture gather operations on this resource

# enum cudaLimit

**CUDA Limits** 

#### **Values**

cudaLimitStackSize = 0x00

GPU thread stack size

cudaLimitPrintfFifoSize = 0x01

GPU printf/fprintf FIFO size

cudaLimitMallocHeapSize = 0x02

GPU malloc heap size

cudaLimitDevRuntimeSyncDepth = 0x03

GPU device runtime synchronize depth

cudaLimitDevRuntimePendingLaunchCount = 0x04

GPU device runtime pending launch count

# enum cudaMemcpyKind

CUDA memory copy types

# **Values**

cudaMemcpyHostToHost = 0

Host -> Host

cudaMemcpyHostToDevice = 1

Host -> Device

cudaMemcpyDeviceToHost = 2

Device -> Host

cudaMemcpyDeviceToDevice = 3

Device -> Device

cudaMemcpyDefault = 4

Direction of the transfer is inferred from the pointer values. Requires unified virtual addressing

# enum cudaMemoryAdvise

**CUDA Memory Advise values** 

#### **Values**

# cudaMemAdviseSetReadMostly = 1

Data will mostly be read and only occassionally be written to

# cudaMemAdviseUnsetReadMostly = 2

Undo the effect of cudaMemAdviseSetReadMostly

# cudaMemAdviseSetPreferredLocation = 3

Set the preferred location for the data as the specified device

#### cudaMemAdviseUnsetPreferredLocation = 4

Clear the preferred location for the data

# cudaMemAdviseSetAccessedBy = 5

Data will be accessed by the specified device, so prevent page faults as much as possible

# cudaMemAdviseUnsetAccessedBy = 6

Let the Unified Memory subsystem decide on the page faulting policy for the specified device

# enum cudaMemoryType

CUDA memory types

#### **Values**

cudaMemoryTypeHost = 1

Host memory

cudaMemoryTypeDevice = 2

Device memory

# enum cudaMemRangeAttribute

CUDA range attributes

#### **Values**

# cudaMemRangeAttributeReadMostly = 1

Whether the range will mostly be read and only occassionally be written to

#### cudaMemRangeAttributePreferredLocation = 2

The preferred location of the range

cudaMemRangeAttributeAccessedBy = 3

Memory range has cudaMemAdviseSetAccessedBy set for specified device cudaMemRangeAttributeLastPrefetchLocation = 4

The last location to which the range was prefetched

# enum cudaOutputMode

**CUDA** Profiler Output modes

#### **Values**

cudaKeyValuePair = 0x00

Output mode Key-Value pair format.

cudaCSV = 0x01

Output mode Comma separated values format.

# enum cudaResourceType

CUDA resource types

## **Values**

cudaResourceTypeArray = 0x00

Array resource

cudaResourceTypeMipmappedArray = 0x01

Mipmapped array resource

cudaResourceTypeLinear = 0x02

Linear resource

cudaResourceTypePitch2D = 0x03

Pitch 2D resource

# enum cudaResourceViewFormat

CUDA texture resource view formats

## **Values**

cudaResViewFormatNone = 0x00

No resource view format (use underlying resource format)

cudaResViewFormatUnsignedChar1 = 0x01

1 channel unsigned 8-bit integers

cudaResViewFormatUnsignedChar2 = 0x02

2 channel unsigned 8-bit integers

cudaResViewFormatUnsignedChar4 = 0x03

4 channel unsigned 8-bit integers

cudaResViewFormatSignedChar1 = 0x04

1 channel signed 8-bit integers

# cudaResViewFormatSignedChar2 = 0x05 2 channel signed 8-bit integers cudaResViewFormatSignedChar4 = 0x06 4 channel signed 8-bit integers cudaResViewFormatUnsignedShort1 = 0x07 1 channel unsigned 16-bit integers cudaResViewFormatUnsignedShort2 = 0x08 2 channel unsigned 16-bit integers cudaResViewFormatUnsignedShort4 = 0x09 4 channel unsigned 16-bit integers cudaResViewFormatSignedShort1 = 0x0a 1 channel signed 16-bit integers cudaResViewFormatSignedShort2 = 0x0b 2 channel signed 16-bit integers cudaResViewFormatSignedShort4 = 0x0c 4 channel signed 16-bit integers cudaResViewFormatUnsignedInt1 = 0x0d 1 channel unsigned 32-bit integers cudaResViewFormatUnsignedInt2 = 0x0e 2 channel unsigned 32-bit integers cudaResViewFormatUnsignedInt4 = 0x0f 4 channel unsigned 32-bit integers cudaResViewFormatSignedInt1 = 0x10 1 channel signed 32-bit integers cudaResViewFormatSignedInt2 = 0x11 2 channel signed 32-bit integers cudaResViewFormatSignedInt4 = 0x12 4 channel signed 32-bit integers cudaResViewFormatHalf1 = 0x131 channel 16-bit floating point cudaResViewFormatHalf2 = 0x142 channel 16-bit floating point cudaResViewFormatHalf4 = 0x154 channel 16-bit floating point cudaResViewFormatFloat1 = 0x16 1 channel 32-bit floating point cudaResViewFormatFloat2 = 0x172 channel 32-bit floating point cudaResViewFormatFloat4 = 0x18 4 channel 32-bit floating point

cudaResViewFormatUnsignedBlockCompressed1 = 0x19

cudaResViewFormatUnsignedBlockCompressed2 = 0x1a

Block compressed 1

Block compressed 2

# cudaRes View Format Unsigned Block Compressed 3 = 0x1b

Block compressed 3

# cudaRes ViewFormat Unsigned Block Compressed 4 = 0x1c

Block compressed 4 unsigned

# cudaRes ViewFormat Signed Block Compressed 4 = 0x1d

Block compressed 4 signed

# cudaRes ViewFormat Unsigned Block Compressed 5 = 0x1e

Block compressed 5 unsigned

# cudaResViewFormatSignedBlockCompressed5 = 0x1f

Block compressed 5 signed

# cudaRes ViewFormat Unsigned BlockCompressed 6H = 0x20

Block compressed 6 unsigned half-float

# cudaResViewFormatSignedBlockCompressed6H = 0x21

Block compressed 6 signed half-float

# cudaResViewFormatUnsignedBlockCompressed7 = 0x22

Block compressed 7

# enum cudaSharedMemConfig

CUDA shared memory configuration

#### **Values**

cudaSharedMemBankSizeDefault = 0

cudaSharedMemBankSizeFourByte = 1

cudaSharedMemBankSizeEightByte = 2

# enum cudaSurfaceBoundaryMode

CUDA Surface boundary modes

#### **Values**

cudaBoundaryModeZero = 0

Zero boundary mode

## cudaBoundaryModeClamp = 1

Clamp boundary mode

# cudaBoundaryModeTrap = 2

Trap boundary mode

# enum cudaSurfaceFormatMode

**CUDA** Surface format modes

#### **Values**

cudaFormatModeForced = 0

Forced format mode

cudaFormatModeAuto = 1

Auto format mode

# enum cudaTextureAddressMode

CUDA texture address modes

#### **Values**

cudaAddressModeWrap = 0

Wrapping address mode

cudaAddressModeClamp = 1

Clamp to edge address mode

cudaAddressModeMirror = 2

Mirror address mode

cudaAddressModeBorder = 3

Border address mode

# enum cudaTextureFilterMode

CUDA texture filter modes

# **Values**

cudaFilterModePoint = 0

Point filter mode

cudaFilterModeLinear = 1

Linear filter mode

# enum cudaTextureReadMode

CUDA texture read modes

#### **Values**

cudaReadModeElementType = 0

Read texture as specified element type

cudaReadModeNormalizedFloat = 1

Read texture as normalized float

# typedef cudaArray \*cudaArray\_const\_t

CUDA array (as source copy argument)

typedef cudaArray \*cudaArray\_t

CUDA array

typedef struct CUeglStreamConnection\_st
\*cudaEglStreamConnection

**CUDA EGLSream Connection** 

typedef cudaError\_t

**CUDA** Error types

typedef struct CUevent\_st \*cudaEvent\_t

CUDA event types

typedef cudaGraphicsResource \*cudaGraphicsResource\_t

CUDA graphics resource types

typedef cudaMipmappedArray
\*cudaMipmappedArray\_const\_t

CUDA mipmapped array (as source argument)

typedef cudaMipmappedArray \*cudaMipmappedArray\_t

CUDA mipmapped array

typedef cudaOutputMode\_t

CUDA output file modes

typedef struct CUstream\_st \*cudaStream\_t

CUDA stream

typedef unsigned long long cudaSurfaceObject\_t

An opaque value that represents a CUDA Surface object

## typedef unsigned long long cudaTextureObject\_t

An opaque value that represents a CUDA texture object

## typedef struct CUuuid\_stcudaUUID\_t

CUDA UUID types

## #define CUDA EGL MAX PLANES 3

Maximum number of planes per frame

## #define CUDA\_IPC\_HANDLE\_SIZE 64

CUDA IPC Handle Size

## #define cudaArrayCubemap 0x04

Must be set in cudaMalloc3DArray to create a cubemap CUDA array

## #define cudaArrayDefault 0x00

Default CUDA array allocation flag

## #define cudaArrayLayered 0x01

Must be set in cudaMalloc3DArray to create a layered CUDA array

## #define cudaArraySurfaceLoadStore 0x02

Must be set in cudaMallocArray or cudaMalloc3DArray in order to bind surfaces to the CUDA array

## #define cudaArrayTextureGather 0x08

Must be set in cudaMallocArray or cudaMalloc3DArray in order to perform texture gather operations on the CUDA array

## #define cudaCpuDeviceId ((int)-1)

Device id that represents the CPU

## #define cudaDeviceBlockingSync 0x04

Deprecated This flag was deprecated as of CUDA 4.0 and replaced with cudaDeviceScheduleBlockingSync.

Device flag - Use blocking synchronization

## #define cudaDeviceLmemResizeToMax 0x10

Device flag - Keep local memory allocation after launch

## #define cudaDeviceMapHost 0x08

Device flag - Support mapped pinned allocations

## #define cudaDeviceMask 0x1f

Device flags mask

## #define cudaDevicePropDontCare

Empty device properties

## #define cudaDeviceScheduleAuto 0x00

Device flag - Automatic scheduling

## #define cudaDeviceScheduleBlockingSync 0x04

Device flag - Use blocking synchronization

## #define cudaDeviceScheduleMask 0x07

Device schedule flags mask

## #define cudaDeviceScheduleSpin 0x01

Device flag - Spin default scheduling

## #define cudaDeviceScheduleYield 0x02

Device flag - Yield default scheduling

## #define cudaEventBlockingSync 0x01

Event uses blocking synchronization

## #define cudaEventDefault 0x00

Default event flag

## #define cudaEventDisableTiming 0x02

Event will not record timing data

## #define cudaEventInterprocess 0x04

Event is suitable for interprocess use. cudaEventDisableTiming must be set

## #define cudaHostAllocDefault 0x00

Default page-locked allocation flag

## #define cudaHostAllocMapped 0x02

Map allocation into device space

## #define cudaHostAllocPortable 0x01

Pinned memory accessible by all CUDA contexts

## #define cudaHostAllocWriteCombined 0x04

Write-combined memory

## #define cudaHostRegisterDefault 0x00

Default host memory registration flag

## #define cudaHostRegisterIoMemory 0x04

Memory-mapped I/O space

## #define cudaHostRegisterMapped 0x02

Map registered memory into device space

## #define cudaHostRegisterPortable 0x01

Pinned memory accessible by all CUDA contexts

## #define cudaInvalidDeviceId ((int)-2)

Device id that represents an invalid device

## #define cudalpcMemLazyEnablePeerAccess 0x01

Automatically enable peer access between remote devices as needed

## #define cudaMemAttachGlobal 0x01

Memory can be accessed by any stream on any device

## #define cudaMemAttachHost 0x02

Memory cannot be accessed by any stream on any device

## #define cudaMemAttachSingle 0x04

Memory can only be accessed by a single stream on the associated device

## #define cudaOccupancyDefault 0x00

Default behavior

## #define cudaOccupancyDisableCachingOverride 0x01

Assume global caching is enabled and cannot be automatically turned off

## #define cudaPeerAccessDefault 0x00

Default peer addressing enable flag

## #define cudaStreamDefault 0x00

Default stream flag

## #define cudaStreamLegacy ((cudaStream\_t)0x1)

Legacy stream handle

Stream handle that can be passed as a cudaStream\_t to use an implicit stream with legacy synchronization behavior.

See details of the synchronization behavior.

## #define cudaStreamNonBlocking 0x01

Stream does not synchronize with stream 0 (the NULL stream)

## #define cudaStreamPerThread ((cudaStream\_t)0x2)

Per-thread stream handle

Stream handle that can be passed as a cudaStream\_t to use an implicit stream with per-thread synchronization behavior.

See details of the synchronization behavior.

# Chapter 5. DATA STRUCTURES

Here are the data structures with brief descriptions:

\_\_cudaOccupancyB2DHelper cudaChannelFormatDesc cudaDeviceProp cudaEglFrame cudaEglPlaneDesc cudaExtent cudaFuncAttributes cudaIpcEventHandle\_t cudaIpcMemHandle\_t cudaMemcpy3DParms cudaMemcpy3DPeerParms cudaPitchedPtr cudaPointerAttributes cudaPos cudaResourceDesc **cudaResourceViewDesc** cudaTextureDesc surfaceReference textureReference

## 5.1. \_\_cudaOccupancyB2DHelper

C++ API Routines cppClassifierVisibility: visibility=public cppClassifierTemplateModel:

Helper functor for cudaOccupancyMaxPotentialBlockSize

## 5.2. cudaChannelFormatDesc Struct Reference

CUDA Channel format descriptor

## enumcudaChannelFormatKind cudaChannelFormatDesc::f

Channel format kind

int cudaChannelFormatDesc::w

W

int cudaChannelFormatDesc::x

X

int cudaChannelFormatDesc::y

y

int cudaChannelFormatDesc::z

 $\mathbf{Z}$ 

## 5.3. cudaDeviceProp Struct Reference

CUDA device properties

int cudaDeviceProp::asyncEngineCount

Number of asynchronous engines

int cudaDeviceProp::canMapHostMemory

Device can map host memory with cudaHostAlloc/cudaHostGetDevicePointer

int cudaDeviceProp::clockRate

Clock frequency in kilohertz

int cudaDeviceProp::computeMode

Compute mode (See cudaComputeMode)

int cudaDeviceProp::concurrentKernels

Device can possibly execute multiple kernels concurrently

int cudaDeviceProp::concurrentManagedAccess

Device can coherently access managed memory concurrently with the CPU

int cudaDeviceProp::deviceOverlap

Device can concurrently copy memory and execute a kernel. Deprecated. Use instead asyncEngineCount.

int cudaDeviceProp::ECCEnabled

Device has ECC support enabled

int cudaDeviceProp::globalL1CacheSupported

Device supports caching globals in L1

int cudaDeviceProp::hostNativeAtomicSupported

Link between the device and the host supports native atomic operations

int cudaDeviceProp::integrated

Device is integrated as opposed to discrete

int cudaDeviceProp::isMultiGpuBoard

Device is on a multi-GPU board

int cudaDeviceProp::kernelExecTimeoutEnabled

Specified whether there is a run time limit on kernels

int cudaDeviceProp::l2CacheSize

Size of L2 cache in bytes

int cudaDeviceProp::localL1CacheSupported

Device supports caching locals in L1

int cudaDeviceProp::major

Major compute capability

int cudaDeviceProp::managedMemory

Device supports allocating managed memory on this system

int cudaDeviceProp::maxGridSize

Maximum size of each dimension of a grid

int cudaDeviceProp::maxSurface1D

Maximum 1D surface size

int cudaDeviceProp::maxSurface1DLayered

Maximum 1D layered surface dimensions

int cudaDeviceProp::maxSurface2D

Maximum 2D surface dimensions

int cudaDeviceProp::maxSurface2DLayered

Maximum 2D layered surface dimensions

int cudaDeviceProp::maxSurface3D

Maximum 3D surface dimensions

int cudaDeviceProp::maxSurfaceCubemap

Maximum Cubemap surface dimensions

int cudaDeviceProp::maxSurfaceCubemapLayered

Maximum Cubemap layered surface dimensions

int cudaDeviceProp::maxTexture1D

Maximum 1D texture size

int cudaDeviceProp::maxTexture1DLayered

Maximum 1D layered texture dimensions

int cudaDeviceProp::maxTexture1DLinear

Maximum size for 1D textures bound to linear memory

int cudaDeviceProp::maxTexture1DMipmap

Maximum 1D mipmapped texture size

int cudaDeviceProp::maxTexture2D

Maximum 2D texture dimensions

int cudaDeviceProp::maxTexture2DGather

Maximum 2D texture dimensions if texture gather operations have to be performed

int cudaDeviceProp::maxTexture2DLayered

Maximum 2D layered texture dimensions

int cudaDeviceProp::maxTexture2DLinear

Maximum dimensions (width, height, pitch) for 2D textures bound to pitched memory

int cudaDeviceProp::maxTexture2DMipmap

Maximum 2D mipmapped texture dimensions

int cudaDeviceProp::maxTexture3D

Maximum 3D texture dimensions

int cudaDeviceProp::maxTexture3DAlt

Maximum alternate 3D texture dimensions

int cudaDeviceProp::maxTextureCubemap

Maximum Cubemap texture dimensions

int cudaDeviceProp::maxTextureCubemapLayered

Maximum Cubemap layered texture dimensions

int cudaDeviceProp::maxThreadsDim

Maximum size of each dimension of a block

int cudaDeviceProp::maxThreadsPerBlock

Maximum number of threads per block

int cudaDeviceProp::maxThreadsPerMultiProcessor

Maximum resident threads per multiprocessor

int cudaDeviceProp::memoryBusWidth

Global memory bus width in bits

int cudaDeviceProp::memoryClockRate

Peak memory clock frequency in kilohertz

size\_t cudaDeviceProp::memPitch

Maximum pitch in bytes allowed by memory copies

int cudaDeviceProp::minor

Minor compute capability

int cudaDeviceProp::multiGpuBoardGroupID

Unique identifier for a group of devices on the same multi-GPU board

int cudaDeviceProp::multiProcessorCount

Number of multiprocessors on device

char cudaDeviceProp::name

ASCII string identifying device

int cudaDeviceProp::pageableMemoryAccess

Device supports coherently accessing pageable memory without calling cudaHostRegister on it

int cudaDeviceProp::pciBusID

PCI bus ID of the device

int cudaDeviceProp::pciDeviceID

PCI device ID of the device

int cudaDeviceProp::pciDomainID

PCI domain ID of the device

int cudaDeviceProp::regsPerBlock

32-bit registers available per block

int cudaDeviceProp::regsPerMultiprocessor

32-bit registers available per multiprocessor

size\_t cudaDeviceProp::sharedMemPerBlock

Shared memory available per block in bytes

size\_t cudaDeviceProp::sharedMemPerMultiprocessor

Shared memory available per multiprocessor in bytes

int cudaDeviceProp::singleToDoublePrecisionPerfRatio

Ratio of single precision performance (in floating-point operations per second) to double precision performance

int cudaDeviceProp::streamPrioritiesSupported

Device supports stream priorities

size\_t cudaDeviceProp::surfaceAlignment

Alignment requirements for surfaces

int cudaDeviceProp::tccDriver

1 if device is a Tesla device using TCC driver, 0 otherwise

size\_t cudaDeviceProp::textureAlignment

Alignment requirement for textures

size\_t cudaDeviceProp::texturePitchAlignment

Pitch alignment requirement for texture references bound to pitched memory

size\_t cudaDeviceProp::totalConstMem

Constant memory available on device in bytes

size\_t cudaDeviceProp::totalGlobalMem

Global memory available on device in bytes

int cudaDeviceProp::unifiedAddressing

Device shares a unified address space with the host

int cudaDeviceProp::warpSize

Warp size in threads

## 5.4. cudaEglFrame Struct Reference

CUDA EGLFrame Descriptor - structure defining one frame of EGL.

Each frame may contain one or more planes depending on whether the surface is Multiplanar or not. Each plane of EGLFrame is represented by cudaEglPlaneDesc which is defined as:

```
f typedef struct cudaEglPlaneDesc_st {
    unsigned int width;
    unsigned int height;
    unsigned int depth;
    unsigned int pitch;
    unsigned int numChannels;
    struct cudaChannelFormatDesc channelDesc;
    unsigned int reserved[4];
} cudaEglPlaneDesc;
```

## cudaEglColorFormat cudaEglFrame::eglColorFormat

**CUDA EGL Color Format** 

## cudaEglFrameType cudaEglFrame::frameType

Array or Pitch

## cudaArray\_t cudaEglFrame::pArray

Array of CUDA arrays corresponding to each plane

## unsigned int cudaEglFrame::planeCount

Number of planes

## struct cudaEglPlaneDesc cudaEglFrame::planeDesc

CUDA EGL Plane Descriptor cuda Egl Plane Desc

## struct cudaPitchedPtr cudaEglFrame::pPitch

Array of Pointers corresponding to each plane

## 5.5. cudaEglPlaneDesc Struct Reference

CUDA EGL Plane Descriptor - structure defining each plane of a CUDA EGLFrame

## struct cudaChannelFormatDesc cudaEglPlaneDesc::channelDesc

Channel Format Descriptor

unsigned int cudaEglPlaneDesc::depth

Depth of plane

unsigned int cudaEglPlaneDesc::height

Height of plane

unsigned int cudaEglPlaneDesc::numChannels

Number of channels for the plane

unsigned int cudaEglPlaneDesc::pitch

Pitch of plane

unsigned int cudaEglPlaneDesc::reserved

Reserved for future use

unsigned int cudaEglPlaneDesc::width

Width of plane

## 5.6. cudaExtent Struct Reference

**CUDA** extent

See also:

make\_cudaExtent

size\_t cudaExtent::depth

Depth in elements

size\_t cudaExtent::height

Height in elements

size\_t cudaExtent::width

Width in elements when referring to array memory, in bytes when referring to linear memory

## 5.7. cudaFuncAttributes Struct Reference

CUDA function attributes

## int cudaFuncAttributes::binaryVersion

The binary architecture version for which the function was compiled. This value is the major binary version \* 10 + the minor binary version, so a binary version 1.3 function would return the value 13.

## int cudaFuncAttributes::cacheModeCA

The attribute to indicate whether the function has been compiled with user specified option "-Xptxas --dlcm=ca" set.

## size\_t cudaFuncAttributes::constSizeBytes

The size in bytes of user-allocated constant memory required by this function.

## size\_t cudaFuncAttributes::localSizeBytes

The size in bytes of local memory used by each thread of this function.

## int cudaFuncAttributes::maxThreadsPerBlock

The maximum number of threads per block, beyond which a launch of the function would fail. This number depends on both the function and the device on which the function is currently loaded.

## int cudaFuncAttributes::numRegs

The number of registers used by each thread of this function.

## int cudaFuncAttributes::ptxVersion

The PTX virtual architecture version for which the function was compiled. This value is the major PTX version \* 10 + the minor PTX version, so a PTX version 1.3 function would return the value 13.

## size\_t cudaFuncAttributes::sharedSizeBytes

The size in bytes of statically-allocated shared memory per block required by this function. This does not include dynamically-allocated shared memory requested by the user at runtime.

## 5.8. cudalpcEventHandle\_t Struct Reference

CUDA IPC event handle

## 5.9. cudalpcMemHandle\_t Struct Reference

CUDA IPC memory handle

## 5.10. cudaMemcpy3DParms Struct Reference

CUDA 3D memory copying parameters

cudaArray\_t cudaMemcpy3DParms::dstArray

Destination memory address

struct cudaPos cudaMemcpy3DParms::dstPos

Destination position offset

struct cudaPitchedPtr cudaMemcpy3DParms::dstPtr

Pitched destination memory address

struct cudaExtent cudaMemcpy3DParms::extent

Requested memory copy size

enumcudaMemcpyKind cudaMemcpy3DParms::kind

Type of transfer

cudaArray\_t cudaMemcpy3DParms::srcArray

Source memory address

struct cudaPos cudaMemcpy3DParms::srcPos

Source position offset

struct cudaPitchedPtr cudaMemcpy3DParms::srcPtr

Pitched source memory address

## 5.11. cudaMemcpy3DPeerParms Struct Reference

CUDA 3D cross-device memory copying parameters

cudaArray\_t cudaMemcpy3DPeerParms::dstArray

Destination memory address

int cudaMemcpy3DPeerParms::dstDevice

Destination device

struct cudaPos cudaMemcpy3DPeerParms::dstPos

Destination position offset

struct cudaPitchedPtr cudaMemcpy3DPeerParms::dstPtr

Pitched destination memory address

struct cudaExtent cudaMemcpy3DPeerParms::extent

Requested memory copy size

cudaArray\_t cudaMemcpy3DPeerParms::srcArray

Source memory address

int cudaMemcpy3DPeerParms::srcDevice

Source device

struct cudaPos cudaMemcpy3DPeerParms::srcPos

Source position offset

## struct cudaPitchedPtr cudaMemcpy3DPeerParms::srcPtr

Pitched source memory address

## 5.12. cudaPitchedPtr Struct Reference

CUDA Pitched memory pointer

See also:

make\_cudaPitchedPtr

size\_t cudaPitchedPtr::pitch

Pitch of allocated memory in bytes

void \*cudaPitchedPtr::ptr

Pointer to allocated memory

size\_t cudaPitchedPtr::xsize

Logical width of allocation in elements

size\_t cudaPitchedPtr::ysize

Logical height of allocation in elements

## 5.13. cudaPointerAttributes Struct Reference

CUDA pointer attributes

## int cudaPointerAttributes::device

The device against which the memory was allocated or registered. If the memory type is cudaMemoryTypeDevice then this identifies the device on which the memory referred physically resides. If the memory type is cudaMemoryTypeHost then this identifies the device which was current when the memory was allocated or registered (and if that device is deinitialized then this allocation will vanish with that device's state).

## void \*cudaPointerAttributes::devicePointer

The address which may be dereferenced on the current device to access the memory or NULL if no such address exists.

## void \*cudaPointerAttributes::hostPointer

The address which may be dereferenced on the host to access the memory or NULL if no such address exists.

## int cudaPointerAttributes::isManaged

Indicates if this pointer points to managed memory

## enumcudaMemoryType cudaPointerAttributes::memoryType

The physical location of the memory, cudaMemoryTypeHost or cudaMemoryTypeDevice.

## 5.14. cudaPos Struct Reference

CUDA 3D position

See also:

make\_cudaPos

```
size_t cudaPos::x

x

size_t cudaPos::y

y

size_t cudaPos::z
```

 $\mathbf{Z}$ 

## 5.15. cudaResourceDesc Struct Reference

CUDA resource descriptor

cudaArray\_t cudaResourceDesc::array

CUDA array

struct cudaChannelFormatDesc cudaResourceDesc::desc

Channel descriptor

void \*cudaResourceDesc::devPtr

Device pointer

size\_t cudaResourceDesc::height

Height of the array in elements

cudaMipmappedArray\_t cudaResourceDesc::mipmap

CUDA mipmapped array

size\_t cudaResourceDesc::pitchInBytes

Pitch between two rows in bytes

enumcudaResourceType cudaResourceDesc::resType

Resource type

size\_t cudaResourceDesc::sizeInBytes

Size in bytes

size\_t cudaResourceDesc::width

Width of the array in elements

## 5.16. cudaResourceViewDesc Struct Reference

CUDA resource view descriptor

size\_t cudaResourceViewDesc::depth

Depth of the resource view

unsigned int cudaResourceViewDesc::firstLayer

First layer index

unsigned int cudaResourceViewDesc::firstMipmapLevel

First defined mipmap level

enumcudaResourceViewFormat cudaResourceViewDesc::format

Resource view format

size\_t cudaResourceViewDesc::height

Height of the resource view

unsigned int cudaResourceViewDesc::lastLayer

Last layer index

unsigned int cudaResourceViewDesc::lastMipmapLevel

Last defined mipmap level

size\_t cudaResourceViewDesc::width

Width of the resource view

## 5.17. cudaTextureDesc Struct Reference

CUDA texture descriptor

enumcudaTextureAddressMode cudaTextureDesc::addressMode

Texture address mode for up to 3 dimensions

float cudaTextureDesc::borderColor

**Texture Border Color** 

enumcudaTextureFilterMode cudaTextureDesc::filterMode

Texture filter mode

unsigned int cudaTextureDesc::maxAnisotropy

Limit to the anisotropy ratio

float cudaTextureDesc::maxMipmapLevelClamp

Upper end of the mipmap level range to clamp access to

float cudaTextureDesc::minMipmapLevelClamp

Lower end of the mipmap level range to clamp access to

enumcudaTextureFilterMode cudaTextureDesc::mipmapFilterMode

Mipmap filter mode

float cudaTextureDesc::mipmapLevelBias

Offset applied to the supplied mipmap level

int cudaTextureDesc::normalizedCoords

Indicates whether texture reads are normalized or not

enumcudaTextureReadMode cudaTextureDesc::readMode

Texture read mode

int cudaTextureDesc::sRGB

Perform sRGB->linear conversion during texture read

## 5.18. surfaceReference Struct Reference

CUDA Surface reference

struct cudaChannelFormatDesc surfaceReference::channelDesc

Channel descriptor for surface reference

## 5.19. textureReference Struct Reference

CUDA texture reference

enumcudaTextureAddressMode textureReference::addressMode

Texture address mode for up to 3 dimensions

struct cudaChannelFormatDesc textureReference::channelDesc

Channel descriptor for the texture reference

enumcudaTextureFilterMode textureReference::filterMode

Texture filter mode

unsigned int textureReference::maxAnisotropy

Limit to the anisotropy ratio

float textureReference::maxMipmapLevelClamp

Upper end of the mipmap level range to clamp access to

## float textureReference::minMipmapLevelClamp

Lower end of the mipmap level range to clamp access to

enumcudaTextureFilterMode textureReference::mipmapFilterMode

Mipmap filter mode

float textureReference::mipmapLevelBias

Offset applied to the supplied mipmap level

int textureReference::normalized

Indicates whether texture reads are normalized or not

int textureReference::sRGB

Perform sRGB->linear conversion during texture read

# Chapter 6. DATA FIELDS

Here is a list of all documented struct and union fields with links to the struct/union documentation for each field:

```
Α
addressMode
  textureReference
  cudaTextureDesc
  cudaResourceDesc
asyncEngineCount
  cudaDeviceProp
В
binaryVersion
  cudaFuncAttributes
borderColor
  cudaTextureDesc
C
cache Mode CA\\
  cudaFuncAttributes
can Map Host Memory
  cudaDeviceProp
channelDesc
  surfaceReference
  textureReference
  cudaEglPlaneDesc
clockRate
  cudaDeviceProp
```

```
computeMode
  cudaDeviceProp
concurrentKernels
  cudaDeviceProp
concurrent Managed Access\\
  cudaDeviceProp
constSizeBytes
  cudaFuncAttributes
D
depth
  cudaEglPlaneDesc
  cudaExtent
  cudaResourceViewDesc
desc
  cudaResourceDesc
device
  cudaPointerAttributes
deviceOverlap
  cudaDeviceProp
devicePointer
  cudaPointerAttributes
devPtr
  cudaResourceDesc
dstArray
  cudaMemcpy3DParms
  cudaMemcpy3DPeerParms
dstDevice
  cudaMemcpy3DPeerParms
dstPos
  cudaMemcpy3DPeerParms
  cudaMemcpy3DParms
dstPtr
  cudaMemcpy3DParms
  cudaMemcpy3DPeerParms
Ε
ECCEnabled
  cudaDeviceProp
eglColorFormat
  cudaEglFrame
extent
  cudaMemcpy3DParms
```

#### cudaMemcpy3DPeerParms

```
F
f
  cuda Channel Format Desc\\
filterMode
   textureReference
  cudaTextureDesc
firstLayer
  cuda Resource View Desc\\
firstMipmapLevel
   cudaResourceViewDesc
format
   cudaResourceViewDesc
frameType
   cudaEglFrame
G
globalL1CacheSupported
  cudaDeviceProp
Н
height
  cuda Egl Plane Desc\\
   cudaExtent
   cudaResourceViewDesc
  cudaResourceDesc
host Native Atomic Supported \\
   cudaDeviceProp
hostPointer
  cudaPointerAttributes
integrated
   cudaDeviceProp
isManaged
  cuda Pointer Attributes\\
is Multi Gpu Board \\
   cudaDeviceProp
kernelExecTimeoutEnabled
   cudaDeviceProp
```

## kind cudaMemcpy3DParms 12CacheSize cudaDeviceProp lastLayer cudaResourceViewDesc lastMipmapLevel cudaResourceViewDesc localL1CacheSupported cudaDeviceProp localSizeBytes cudaFuncAttributes M major cudaDeviceProp managedMemory cudaDeviceProp maxAnisotropy cudaTextureDesc textureReference maxGridSize cudaDeviceProp maxMipmapLevelClamp textureReference cudaTextureDesc maxSurface1D cudaDeviceProp maxSurface1DLayered cudaDeviceProp maxSurface2D cudaDeviceProp max Surface 2D LayeredcudaDeviceProp maxSurface3D cudaDeviceProp maxSurfaceCubemapcudaDeviceProp

maxSurfaceCubemapLayered

cudaDeviceProp

#### maxTexture1D

cudaDeviceProp

#### max Texture 1DL ayered

cudaDeviceProp

#### maxTexture1DLinear

cudaDeviceProp

#### maxTexture1DMipmap

cudaDeviceProp

#### maxTexture2D

cudaDeviceProp

#### maxTexture2DGather

cudaDeviceProp

#### maxTexture2DLayered

cudaDeviceProp

#### max Texture 2D Linear

cudaDeviceProp

#### maxTexture2DMipmap

cudaDeviceProp

#### maxTexture3D

cudaDeviceProp

#### maxTexture3DAlt

cudaDeviceProp

#### maxTextureCubemap

cudaDeviceProp

#### maxTextureCubemapLayered

cudaDeviceProp

#### maxThreadsDim

cudaDeviceProp

#### maxThreadsPerBlock

cudaFuncAttributes

cudaDeviceProp

#### maxThreadsPerMultiProcessor

cudaDeviceProp

#### memoryBusWidth

cudaDeviceProp

#### memoryClockRate

cudaDeviceProp

#### memoryType

cudaPointerAttributes

#### memPitch

cudaDeviceProp

#### minMipmapLevelClamp

textureReference

```
cudaTextureDesc
minor
  cudaDeviceProp
mipmap
  cudaRe source Desc\\
mipmapFilterMode
  cudaTextureDesc
  textureReference
mipmapLevelBias
  textureReference
  cudaTextureDesc
multiGpuBoardGroupID
  cudaDeviceProp
multiProcessorCount
  cudaDeviceProp
N
name
  cudaDeviceProp
normalized
  textureReference
normalizedCoords
  cudaTextureDesc
numChannels
  cuda Egl Plane Desc\\
numRegs
  cudaFuncAttributes
pageableMemoryAccess
  cudaDeviceProp
pArray
  cudaEglFrame
pciBusID
  cudaDeviceProp
pciDeviceID
  cudaDeviceProp
pciDomainID
  cudaDeviceProp
pitch
  cudaEglPlaneDesc
  cudaPitchedPtr
```

```
pitchInBytes
  cudaRe source Desc\\
planeCount
  cudaEglFrame
planeDesc
  cudaEglFrame
pPitch
  cudaEglFrame
ptr
  cudaPitchedPtr
ptxVersion
  cudaFuncAttributes
R
readMode
  cudaTextureDesc
regsPerBlock
  cudaDeviceProp
regsPerMultiprocessor
  cudaDeviceProp
reserved
  cudaEglPlaneDesc
resType
  cudaResourceDesc
S
shared MemPerBlock\\
  cudaDeviceProp
shared MemPerMultiprocessor\\
  cudaDeviceProp
sharedSizeBytes
  cudaFuncAttributes
singleToDoublePrecisionPerfRatio
  cudaDeviceProp
sizeInBytes
  cudaResourceDesc
srcArray
  cudaMemcpy3DParms
  cudaMemcpy3DPeerParms
srcDevice
  cudaMemcpy3DPeerParms
srcPos
  cudaMemcpy3DParms
```

```
cudaMemcpy3DPeerParms
srcPtr
  cudaMemcpy3DParms
  cudaMemcpy3DPeerParms
sRGB
  textureReference
  cudaTextureDesc
streamPrioritiesSupported
  cudaDeviceProp
surface A lignment\\
  cudaDeviceProp
Т
tccDriver
  cudaDeviceProp
textureAlignment
  cudaDeviceProp
texturePitchAlignment
  cudaDeviceProp
totalConstMem
  cudaDeviceProp
totalGlobalMem
  cudaDeviceProp
U
unifiedAddressing
  cudaDeviceProp
W
  cudaChannelFormatDesc
warpSize
  cudaDeviceProp
width
  cudaResourceDesc
  cudaExtent
  cudaEglPlaneDesc
  cudaResourceViewDesc
Χ
x
  cudaChannelFormatDesc
  cudaPos
```

```
xsize
    cudaPitchedPtr

Y
y
    cudaChannelFormatDesc
    cudaPos
ysize
    cudaPitchedPtr

Z
z
    cudaChannelFormatDesc
    cudaPos
```

# Chapter 7. DEPRECATED LIST

Global cudaThreadExit
Global cudaThreadGetCacheConfig
Global cudaThreadGetLimit
Global cudaThreadSetCacheConfig
Global cudaThreadSetLimit
Global cudaThreadSynchronize
Global cudaSetDoubleForDevice  This function is deprecated as of CUDA 7.5
Global cudaSetDoubleForHost

This function is deprecated as of CUDA 7.5

#### Global cudaConfigureCall

This function is deprecated as of CUDA 7.0

#### Global cudaLaunch

This function is deprecated as of CUDA 7.0

#### Global cudaSetupArgument

This function is deprecated as of CUDA 7.0

#### Global cudaGLMapBufferObject

This function is deprecated as of CUDA 3.0.

#### Global cudaGLMapBufferObjectAsync

This function is deprecated as of CUDA 3.0.

#### Global cudaGLRegisterBufferObject

This function is deprecated as of CUDA 3.0.

#### Global cudaGLSetBufferObjectMapFlags

This function is deprecated as of CUDA 3.0.

#### Global cudaGLSetGLDevice

This function is deprecated as of CUDA 5.0.

#### Global cudaGLUnmapBufferObject

This function is deprecated as of CUDA 3.0.

#### Global cudaGLUnmapBufferObjectAsync

This function is deprecated as of CUDA 3.0.

#### Global cudaGLUnregisterBufferObject

This function is deprecated as of CUDA 3.0.

#### Global cudaD3D9MapResources

This function is deprecated as of CUDA 3.0.

#### Global cudaD3D9RegisterResource

This function is deprecated as of CUDA 3.0.

#### Global cudaD3D9ResourceGetMappedArray

This function is deprecated as of CUDA 3.0.

#### Global cudaD3D9ResourceGetMappedPitch

This function is deprecated as of CUDA 3.0.

#### Global cudaD3D9ResourceGetMappedPointer

This function is deprecated as of CUDA 3.0.

#### Global cudaD3D9ResourceGetMappedSize

This function is deprecated as of CUDA 3.0.

#### Global cudaD3D9ResourceGetSurfaceDimensions

This function is deprecated as of CUDA 3.0.

#### Global cudaD3D9ResourceSetMapFlags

This function is deprecated as of CUDA 3.0.

#### Global cudaD3D9UnmapResources

This function is deprecated as of CUDA 3.0.

#### Global cudaD3D9UnregisterResource

This function is deprecated as of CUDA 3.0.

#### Global cudaD3D10GetDirect3DDevice

This function is deprecated as of CUDA 5.0.

#### Global cudaD3D10MapResources

This function is deprecated as of CUDA 3.0.

#### Global cudaD3D10RegisterResource

This function is deprecated as of CUDA 3.0.

#### Global cudaD3D10ResourceGetMappedArray

This function is deprecated as of CUDA 3.0.

#### Global cudaD3D10ResourceGetMappedPitch

This function is deprecated as of CUDA 3.0.

#### Global cudaD3D10ResourceGetMappedPointer

This function is deprecated as of CUDA 3.0.

#### Global cudaD3D10ResourceGetMappedSize

This function is deprecated as of CUDA 3.0.

#### Global cudaD3D10ResourceGetSurfaceDimensions

This function is deprecated as of CUDA 3.0.

#### Global cudaD3D10ResourceSetMapFlags

This function is deprecated as of CUDA 3.0.

#### Global cudaD3D10SetDirect3DDevice

This function is deprecated as of CUDA 5.0.

#### Global cudaD3D10UnmapResources

This function is deprecated as of CUDA 3.0.

#### Global cudaD3D10UnregisterResource

This function is deprecated as of CUDA 3.0.

#### Global cudaD3D11GetDirect3DDevice

This function is deprecated as of CUDA 5.0.

#### Global cudaD3D11SetDirect3DDevice

This function is deprecated as of CUDA 5.0.

#### Global cudaLaunch

This function is deprecated as of CUDA 7.0

#### Global cudaSetupArgument

This function is deprecated as of CUDA 7.0

#### Global cudaErrorPriorLaunchFailure

This error return is deprecated as of CUDA 3.1. Device emulation mode was removed with the CUDA 3.1 release.

#### Global cudaErrorAddressOfConstant

This error return is deprecated as of CUDA 3.1. Variables in constant memory may now have their address taken by the runtime via cudaGetSymbolAddress().

#### Global cudaErrorTextureFetchFailed

This error return is deprecated as of CUDA 3.1. Device emulation mode was removed with the CUDA 3.1 release.

#### Global cudaErrorTextureNotBound

This error return is deprecated as of CUDA 3.1. Device emulation mode was removed with the CUDA 3.1 release.

#### Global cudaErrorSynchronizationError

This error return is deprecated as of CUDA 3.1. Device emulation mode was removed with the CUDA 3.1 release.

#### Global cudaErrorMixedDeviceExecution

This error return is deprecated as of CUDA 3.1. Device emulation mode was removed with the CUDA 3.1 release.

#### Global cudaErrorNotYetImplemented

This error return is deprecated as of CUDA 4.1.

#### Global cudaErrorMemoryValueTooLarge

This error return is deprecated as of CUDA 3.1. Device emulation mode was removed with the CUDA 3.1 release.

#### Global cudaErrorProfilerNotInitialized

This error return is deprecated as of CUDA 5.0. It is no longer an error to attempt to enable/disable the profiling via cudaProfilerStart or cudaProfilerStop without initialization.

#### Global cudaErrorProfilerAlreadyStarted

This error return is deprecated as of CUDA 5.0. It is no longer an error to call cudaProfilerStart() when profiling is already enabled.

#### Global cudaErrorProfilerAlreadyStopped

This error return is deprecated as of CUDA 5.0. It is no longer an error to call cudaProfilerStop() when profiling is already disabled.

#### Global cudaErrorApiFailureBase

This error return is deprecated as of CUDA 4.1.

## $Global\ cuda Device Blocking Sync$

This flag was deprecated as of CUDA  $4.0\,\mathrm{and}$  replaced with cudaDeviceScheduleBlockingSync.

#### Notice

ALL NVIDIA DESIGN SPECIFICATIONS, REFERENCE BOARDS, FILES, DRAWINGS, DIAGNOSTICS, LISTS, AND OTHER DOCUMENTS (TOGETHER AND SEPARATELY, "MATERIALS") ARE BEING PROVIDED "AS IS." NVIDIA MAKES NO WARRANTIES, EXPRESSED, IMPLIED, STATUTORY, OR OTHERWISE WITH RESPECT TO THE MATERIALS, AND EXPRESSLY DISCLAIMS ALL IMPLIED WARRANTIES OF NONINFRINGEMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE.

Information furnished is believed to be accurate and reliable. However, NVIDIA Corporation assumes no responsibility for the consequences of use of such information or for any infringement of patents or other rights of third parties that may result from its use. No license is granted by implication of otherwise under any patent rights of NVIDIA Corporation. Specifications mentioned in this publication are subject to change without notice. This publication supersedes and replaces all other information previously supplied. NVIDIA Corporation products are not authorized as critical components in life support devices or systems without express written approval of NVIDIA Corporation.

#### **Trademarks**

NVIDIA and the NVIDIA logo are trademarks or registered trademarks of NVIDIA Corporation in the U.S. and other countries. Other company and product names may be trademarks of the respective companies with which they are associated.

#### Copyright

© 2007-2016 NVIDIA Corporation. All rights reserved.

