

- Please put a board under the REFLO to prevent from heat transferring to the table. The bottom of the REFLO is soon hot.
- Please take care not to touch the fire brick for a long time after soldering.
 It could be very hot.

