


电压:



电压定义示意图

电场力
$$\vec{F} = q\vec{E}$$

$$\vec{E} = \vec{E}_c + \vec{E}_i + \vec{E}_e$$

$$\vec{E}_c - \textbf{库仑电场强度;}$$

$$\vec{E}_i - \textbf{感应电场强度;}$$

$$\vec{E}_e - \textbf{局外电场强度.}$$

电场力 \bar{F} 将试探电荷 q 从 a 点沿路线 l 移动到 b 点所做的功为:

$$W = \int_{l} \vec{F} \cdot d\vec{l}$$



$$\begin{split} W &= \int\limits_{l} \vec{F} \cdot d\vec{l} = q \int\limits_{l} \vec{E} \cdot d\vec{l} = q \int\limits_{l} (\vec{E}_c + \vec{E}_i + \vec{E}_e) \cdot d\vec{l} = q u_{ab(l)} \\ u_{ab(l)} &= \int \vec{E} \cdot d\vec{l} = \int (\vec{E}_c + \vec{E}_i + \vec{E}_e) \cdot d\vec{l} \end{split}$$

 $u_{ab(l}$ 是电场力将单位正电荷由a点沿路线l移动到b点所作的功,称为由a点到b点沿路线l的电压。

 $u_{ab} = \int_a^b \vec{E}_c \cdot d\vec{l}$ 单位正电荷在电场力的作用下由a点移动到 b点所做的功为a,b两点之间的电压,即 $u = \frac{\mathrm{d}W}{\mathrm{d}q}$ 电压的单位:伏特(V)





电压的实际方向:由高电位指向低电位

电压参考方向的表示法:

