
top_fnd_counter
CLK
RST
btn[2:0]
SW[7:0]
btn_debouncer
CLK
RST
btn[2:0]
u_btnL_debouncer
u_btnL_debouncer
u_btnL_debouncer
[0]
[1]
[2]
[0]
[1]
[2]
clean_btn[2:0]
1ms_tick_generator
CLK
RST
tick
main_controller
CLK
RST
SW[7:0]
seg_data[7:0]
fnd_controller
CLK
RST
an[3:0]
seg[7:0]
led[15:0]