Cylon Backup Help Guide

Table of Contents

- 1. Introduction
- 2. Getting Started
 - a. System Requirements
 - b. <u>Installation</u>
- 3. Users
 - a. Roles
 - b. Add User
 - c. Delete User
 - d. Edit User
- 4. General Settings
- 5. Email Settings
- 6. Sites
 - a. Importing sites
 - b. Set store number
 - c. Reset read only
- 7. Backup
 - a. Manual backup
 - b. Auto backup
- 8. Restore
 - a. Restore from file
 - b. Restore selected
 - c. Single site restore
- 9. Check out
- 10. Check in
 - a. Operation Check-in
 - b. Engineer Check-in
- 11. <u>Logs</u>

1. Introduction

The Cylon Backup application serves two primary functions:

- a) Backup and Restore of Cylon Files: Allows manual or automatic backups of Cylon sites. The system can identify updated sites and back them up automatically.
- b) **Managing Cylon Sites During Engineering**: Ensures no conflicting changes are made to sites being engineered remotely. The application locks the site on the server until the engineered version is restored.

2. Getting Started

System Requirements

PC with the following minimum specifications

• **Processor**: i3 or higher

• **RAM**: 4GB

Storage: 10GB availableJava Version: Java 17

Cylon Server Access: Can be installed on the Cylon server
Backup Server Access: Can be installed on the backup server

Database: MySQL 8.0 or greater

Installation

- a) Extract the application files to a folder (e.g., C:\CylonBackup).
- b) Run the CylonBackup.bat file.
- c) Open the web interface in a browser: http://localhost:8080 or http://[IP Address]:8080.
- d) Configure the default user and settings as described in the "Users" and "General Settings" sections.

3. Users

The default user is 'Admin' and password is 'Optimised1234'. For security this should be changed during setup

Name: The full name of the user

Username: The name the user uses to log into the application. Note this is case sensitive.

Password: Minimum of 8 characters

Dark Mode: Check this box to set the initial mode to dark mode for the user.

Roles: Users have access based on their roles. At least one user must have the **Administrator** role.

Role	Menu Access
Administrator	Users, General Settings, Email Settings,
	Logs
Supervisor	Sites, Engineers, Backup, Restore, Check
	in
Engineer	Check out

Add User:

- 1. Click the Add User button.
- 2. Fill in the required fields:
 - Name
 - Username (case-sensitive)

- Password (minimum 8 characters)
- Role(s)
- 3. Click Save to add the user.

Delete User:

- 1. Select the user to delete.
- 2. Click the **Delete** button.

Note: You cannot delete yourself.

Edit User:

- 1. Select the user to edit.
- 2. Update the required fields.
- 3. Click Save.

4. General Settings

These settings must be configured before use:

Setting	Description	Default Value
Cylon Path	The path to and including the UnitronUC32	C:\UnitronUC32
	direction	
Backup Path	The path to the backup directory	C:\Backup
Backup time	The time of day when the application will	03:00am
	backup changed sites if auto backup is	
	selected	
Auto backup	Will enable the automatic backup of the	Checked
	sites	
Exclude files	File to exclude when backup up a site.	All unchecked
System files	These files will be backed up to the	All checked
	following directory [Backup	
	path]/System/yyyy-mm—dd. When yyyy id	
	the current year, mm is the current month	
	and dd is the current year. If required these	
	files will have to be manually restored.	
Update site	The time of day when the application will	02:00am
time	update the list of sites from Cylon to its	
	database. This only needs to be done if a	
	site is added or deleted from the Cylon	
	system. Therefore, advisable to run this	
	manually. Note if automatic is required it is	
	recommended that time be set before the	
	backup time.	
Auto update	Will enable the automatic updates of the	Unchecked
sites	site database.	

5. Email Settings

Configure email settings for sending and receiving notifications. If using Gmail, generate an app password (<u>instructions</u>).

Setting	Description
Username	The username for the email server
Password	The password for the email server
Pop3Host	The Pop3 host for sending emails
Pop3Port	The Pop3 port for sending emails
SMTP Host	The SMTP host for receiving emails
SMTP Port	The SMTP port for receiving emails
From	The email address which sent emails will show as from
SMTP Auth	Check this to use SMTP authentication
SMTP StartTls	Check this to enable StartTLS
Enable	
SMTP StartTLS Req	Check this if StartTLS is required

6. Sites

The application stores the site backup information in a database and required that site information be imported from the Cylon system. The Cylon system does not store the store number, there required it will be necessary to add this manually.

Importing Sites

- Manual Import:
 - 1. Select Sites from the menu.
 - 2. Click **Update Sites**.
- Automatic Import:
 - 1. Enable in settings.
 - 2. The application updates the site database at the set time daily.

Set Store Number:

- 1. Select the site.
- 2. Enter the store number in the "Store Number" field.
- 3. Press Save.

Reset Read-Only:

 Administrator Only: If a site is editable within the Cylon system after being checked in, reset it by selecting the site and pressing the Reset Read only button.

7. Backup

Manual Backup

- 1. Select one or more sites.
- 2. Click the Backup button.
 - Existing backups are moved to the "Old Backups" folder.

Auto Backup

• Automatically backs up changed sites if enabled in settings. Older backups are moved to the "Old Backups" folder.

Note Any site that is checked out to an engineer will not be available for backup.

8. Restore

Restore from File

- 1. Click Restore from File.
- 2. Navigate to the backup file location and select it.
- 3. Press Open.
 - o The site will be backed up before restoration.

Restore Selected

- 1. Select sites using the checkboxes.
- 2. Click Restore Selected.
 - Restores sites to the latest version.

Single Site Restore

- 1. Check the **Single Site** box.
- 2. Select the site and desired backup version.
- 3. The site will be backed up before restoration.
- 4. **Note** Any site that is checked out to an engineer will not be available for backup.

9. Checkout

Steps:

- a) Select a site.
- b) Choose an engineer from the drop-down list.
- c) Set a return date (within 2 weeks).
- d) Click Checkout.
 - o The site is emailed to the engineer and locked on the server.

- o If the return date is exceeded, application will send and reminder email to the engineer every other day.
- o If the engineer requires more time to engineer the site, the operator can change the due date to two weeks from the current date.
- This can be done by going to the check-in page and selecting the site and pressing the checkout button.

10. Check-in

Operator Check-In

- a) Select the site.
- b) Click Check-In.
- c) Navigate to the backup file location and select it.
- d) The site is backed up before restoration.

Engineer Check-In

- a) Engineer emails the backup to the application's email address.
- b) The application monitors the inbox and restores the site if valid.

11. Logs

Logs provide detailed records of application operations and should be reviewed regularly for troubleshooting and audit purposes.