
# Real Time Operating System II

# Task Priority Example

```
/*Button Task*/
void vButtonTask(void)
                               /*high priority*/
           while(True)
                      block until user pushes a button
                      respond to the user
/*Level Task*/
void vLevelTask(void)
                              /*low priority*/
           while(True)
                      Read levels of floats in the tank.
                      Calculate average float level.
                       Do some interminable calculations.
                      figure out which tank to do next.
```

# Task Priority Example

RTOS will stop the low-priority vLevelsTask in its track and move it to ready state.




- Runs the high priority vButtonTask task to let it respond to the user.
- ❖ vButtonTask task is finished responding, it blocks and the RTOS gives up back to the vLevelsTask task once again.

#### **RTOS Initialization Code**

```
void main(void)
InitRTOS();
StartTask(vButtonTask, HIGH_PRIORITY);
StartTask(vLevelTask,LOW_PRIORITY);
StartRTOS();
```

#### Task and Data



## Shared Data problem

```
void Task1(void)
              vCountErrors(9);
void Task2(void)
              vCountErrors(11);
Static int cErrors;
void vCountErrors(int cNewErrors)
       cErrors+=cNewErrors;
```

# **Assembly Code**

```
void vCountErrors(int cNewErrors)
{
          Mov R1, cErrors
          Add R1, cNewErrors
          Mov cErrors, R1
          return
}
```

#### Shared Data Problem Contd...

Suppose cErrors=5

Task T1 calls vCountErrors(9)

Mov R1, cErrors ;R1=5

Add R1, cNewErrors ;R1=9+5=14

RTOS switches to Task T2

Task T2 calls vCountErrors(11) ;R1=5

Mov R1, cErrors ;R1=5

Add R1, cNewErrors ;R1=16

Mov cErrors, R1 ;cErrors=16

RTOS switches to task T1

Mov cErrors, R1 ;cErrors = 14

### Reentrancy

Functions that can be called by more than one task and will always work correctly even if the RTOS switches from one task to another in the middle of execution.

or

Function that can be interrupted at any time and resumed at a later time without loss of data.

It either uses local variables or protects data when global variables are used.

It can be used by more than one task without fear of data corruption.

### Reentrancy

3 rules to decide if a function is reentrant:

- ❖ It uses all shared variables in an atomic way, unless they are stored on the stack of the task that called the function or are otherwise the private variables.
- **!** It does not call non-entrant functions.
- ❖ It does not use the hardware in a non-atomic way.

## Reentrancy

Suppose two functions each share the same variable foobar. One of the function contains the following:

```
temp=foobar;
temp+=1;
foobar=temp;
```

The code is reentrant because foobar is used non atomically.

Instead of using the above 3 equations, we use the following:

```
foobar+=1;
```


Assembly code: **mov ax**, [foobar]

inc ax

mov [foobar], ax

Atomic Version: inc[foobar]


- \* RTOS, new tool to deal with shared data problems.
- Terms used in Semaphore:
  - get and give
  - \* take and release
  - pend and post
  - ❖ p and v
  - \* wait and signal
- \* RTOS idea is similar to that of a railroad semaphore.



- ❖ It was invented by Edgser Dijkstra in mid 1960s.
  - Control access to shared resources.
  - ❖ Signal the occurrence of an event.
  - ❖ Allow two tasks to synchronize their activties.
- **\*** Commonly used semaphore is called Binary Semaphore.
- ❖ Three operations can be performed on a semaphore which are Initialize, wait and signal.
- \* Two RTOS functions in Binary Semaphore:
  - **\*** TakeSemaphore
  - \* ReleaseSemaphore
- ❖ If a task calls **TakeSemaphore** to take semaphore and has not called **ReleaseSemaphore** to release it, then any other task that calls **TakeSemaphore** will block until the first task calls **ReleaseSemaphore**.
- Only one task can have a semaphore at a time.

#### **Example of Take and Release Semaphore:**

```
/*Button Task*/
void vButtonTask(void)
                              /*high priority*/
           while(True)
                       block until user pushes a button
                       respond to the user
/*Level Task*/
void vLevelTask(void)
                             /*low priority*/
            while(True)
                       TakeSemaphore();
                       Read levels of floats in the tank.
                       Calculate average float level.
                       ReleaseSemaphore();
                       Do some interminable calculations.
                       figure out which tank to do next.
```



```
Semaphores makes a function reentrant.
void Task1(void)
                vCountErrors(9);
void Task2(void)
                vCountErrors(11);
Static int cErrors;
void vCountErrors(int cNewErrors)
        TakeSemaphore();
        cErrors+=cNewErrors;
       ReleaseSemaphore();
```