Computer Architecture (ENE1004)

Lec - 4: Instructions: Language of the Computer (Chapter 2) - 3

Review: Representing MIPS Instructions

Name	Format	Example				Comments		
add	R	0	18	19	17	0	32	add \$s1,\$s2,\$s3
sub	R	0	18	19	17	0	34	sub \$s1,\$s2,\$s3
addi	I	8	18	17	100			addi \$s1,\$s2,100
lw	I	35	18	17	100			lw \$s1,100(\$s2)
SW	I	43	18	17	100			sw \$s1,100(\$s2)
Field size		6 bits	5 bits	5 bits	5 bits	5 bits	6 bits	All MIPS instructions are 32 bits long
R-format	R	ор	rs	rt	rd	shamt	funct	Arithmetic instruction format
I-format	I	ор	rs	rt	address			Data transfer format

- R-type and I-type
- Each type has different fields with fixed sizes
- Opcode (+funct) is unique for each operation
- Registers as source/destination operands are specified their numbers
- Notice: the order of register fields is different from that in an instruction

Review: Example

- Assume that \$11 has the base address of A and \$s2 corresponds to h
- A[300] = h + A[300]; is compiled to

```
Iw $t0, 1200($t1) # temporary reg $t0 gets A[300]
add $t0, $s2, $t0 # temporary reg $t0 gets h + A[300]
sw $t0, 1200($t1) # store h + A[300] back into A[300]
```

Ор	rs	rt	rd	address/ shamt	funct
35	9	8	1200		
0	18	8	8	0	32
43	9	8	1200		

100011	01001	01000	0000 0100 1011 0000		
000000	10010	01000	01000	00000	100000
101011	01001	01000	0000 0100 1011 0000		000

MIPS Instructions for Logical Operations: Shifts

Logical operations	C operators	Java operators	MIPS instructions
Shift left	<<	<<	s11
Shift right	>>	>>>	srl

- Moving all the bits in a word to the left or right, filling the emptied bits with 0s
 - Shift left (**sll**) and shift right (**srl**)
 - Example of shifting 9 by 4
 - 9 = 0000 0000 0000 0000 0000 0000 1001
 - (To the left) 9 << 4 = 0000 0000 0000 0000 0000 0000 1001 0000 = 144
 - (To the right) $9 >> 4 = 0000\ 0000\ 0000\ 0000\ 0000\ 0000\ 0000\ 0000\ = 0$
- Example: sll \$t2, \$s0, 4 # reg \$t2 = reg \$s0 << 4 bits
 - The original value is in \$s0 and the result of shifting left by 4 goes into \$t2

	ор	rs	rt	rd	shamt	funct
R-type	0	0	16	10	4	0

• (op=0 + funct=0) for **sII**, rd=10 for \$t2, rt=16 for \$s0, and shamt=4 (rs is unused and set to 0)

MIPS Instructions for Logical Operations: AND/OR

Logical operations	C operators	Java operators	MIPS instructions
Bit-by-bit AND	&	&	and, andi
Bit-by-bit OR			or, ori
Bit-by-bit NOT	~	~	nor

Example

- \$t2 = 0000 0000 0000 0000 0000 1101 1100 0000 = 3,520
- $$t1 = 0000\ 0000\ 0000\ 0001\ 1100\ 0000\ 0000 = 15,360$
- AND: sets 1 in the bit only if both the corresponding bits of the operands are 1
 - and \$t0, \$t1, \$t2 # reg \$t0 = reg \$t1 & reg \$t2
 - $$t0 = 0000\ 0000\ 0000\ 0000\ 1100\ 0000\ 0000 = 3,072$
- OR: sets 1 in the bit if either operand bit is a 1
 - or \$t0, \$t1, \$t2 # reg \$t0 = reg \$t1 | reg \$t2
 - $$t0 = 0000\ 0000\ 0000\ 0001\ 1101\ 1100\ 0000 = 15,808$
- Immediate instructions are supported for AND and OR
 - andi (and immediate), ori (or immediate)

MIPS Instructions for Logical Operations: NOR

Logical operations	C operators	Java operators	MIPS instructions
Bit-by-bit AND	&	&	and, andi
Bit-by-bit OR			or, ori
Bit-by-bit NOT	~	~	nor

- NOT: takes one operand and places a 1 in the bit if one operand bit is a 0, and vice versa
 - MIPS designers did their best for keeping with the three-operand format
 - MIPS designers decided to include NOR (NOT OR) instead of NOT
 - A NOR 0 = NOT (A OR 0) = NOT (A)
 - If one operand is zero, NOR is equivalent to NOT
- Example: nor \$t0, \$t1, \$t3 # reg \$t0 = ~ (reg \$t1 | reg \$t3)
 - \$t1 = 0000 0000 0000 0000 0011 1100 0000 0000 = 15,360

 - \$t1 OR \$t3 = 0000 0000 0000 0001 1100 0000 0000
 - ~(\$t1 OR \$t3) = 1111 1111 1111 1111 1100 0011 1111 1111 = NOT \$t1
- Immediate NOR is not supported, since its main use is to invert the bits (NOT)

MIPS Decision-making Instructions

- Computers have an ability to make decisions
 - Based on input data or values created during computation, different instructions are executed
 - Decision making is commonly represented in programming languages using if statements
 - MIPS includes two decision-making instructions
- Branch if equal: beq register1, register2, L1
 - L1 is a label that indicates a statement in the code; recall goto statement in C
 - It jumps to the statement labeled L1 if the value in register1 equals the value in register2
- Branch if not equal: bne register1, register2, L1
 - It jumps to the statement labeled L1 if the value in register1 does not equal the value in register2
- We call the two instructions "conditional branches"
- "Unconditional branch" jump: j L1
 - There is no condition
 - It always jumps to the statement labeled L1


MIPS Decision-making Instructions: if-else

- ·if (i == j) f = g + h; else f = g h;
 - f corresponds to \$s0, g to \$s1, h to \$s2, i to \$s3, j to \$s4
 - is translated into

```
bne $s3, $s4, Else # go to Else if i ≠ j
add $s0, $s1, $s2 # f = g + h (skipped if i ≠ j)
j Exit # go to Exit

Else: # here is the label Else
sub $s0, $s1, $s2 # f = g - h (skipped if i = j)

Exit: # here is the label Exit
```



- Without the unconditional branch (j Exit), both add and sub are executed
- An alternative: beq \$s3, \$s4, Then # go to Then if i = j
 - If you like this, where do you locate the case of where i ≠ j?
 - In general, the code will be more efficient if we test for the opposite condition to branch over the code that performs the subsequent *then* part of the if

MIPS Decision-making Instructions: while

- Decisions are also important for iterating a computation, which are found in loops
- while (save[i] == k) i += 1;
 - i corresponds to \$s3, k to \$s5, the base of the array save is in \$s6
 - is translated into

• Notice: Shift left logical "m" by "n" bits generates m * 2^n

MIPS Decision-making Instructions: for

- •for (i = 0; i < 4; i++) { //do something }</pre>
 - Do you have any idea for handling "i < 4"?
 - It would be useful to see if a variable is less than another variable
- Two useful instructions, which can tell if a variable is less than another variable
 - Set less than: slt reg1, reg2, reg3 # reg1 = 1 if reg2 < reg3
 - It compares two registers (reg2 and reg3), and sets a register (reg1) to 1 if reg2 < reg3
 - Otherwise (if reg2 >= reg3), it sets reg1 to 0
 - Set less than immediate: slti reg1, reg2, const #reg1=1 if reg2<const
 - Immediate version of slt
 - It compares reg2 and constant, and sets a register (reg1) to 1 if reg2 < constant
- •for (i = 0; i < 4; i++) { //do something }</pre>
 - Do you have any idea for initializing a variable "i = 0"?
 - MIPS includes a register, named "\$zero", which always holds a value of 0
 - · add \$s0, \$zero, \$zero # \$s0 will hold a value of 0

register	assembly name	Comment
r0	\$zero	Always 0

MIPS Decision-making Instructions: for

- •for (i = 0; i < 4; i++) { //do something }</pre>
 - i corresponds to \$t0
 - is translated into

```
add $t0, $zero, $zero # i is initialized to 0, $t0 = 0
Loop:
```

do something

```
addi $t0, $t0, 1 # i ++
slti $t1, $t0, 4 # $t1 = 1 if i < 4
bne $t1, $zero, Loop # go to Loop if i < 4
```

MIPS Decision-making Instructions: switch/case

- A straightforward way to implement switch is using a chain of if-then-else statements
 - Would you try to write a switch statement?
- An alternative is to take advantage of jump (address) table
 - We will discuss this later