

ALPHABETICAL INDEX

AI
SECTION

A

A/C COMPRESSOR CONSTRUCTION 07-11-4
A/C CUT-OFF CONTROL
BLOCK DIAGRAM [WL-3] 01-40A-14
A/C CUT-OFF CONTROL
CONDITION [WL-3] 01-40A-14
A/C CUT-OFF CONTROL OUTLINE [WL-3] 01-40A-14
A/C CUT-OFF CONTROL
BLOCK DIAGRAM [WL-C, WE-C] 01-40B-18
A/C CUT-OFF CONTROL
OPERATION [WL-C, WE-C] 01-40B-18
A/C CUT-OFF CONTROL
OUTLINE [WL-C, WE-C] 01-40B-18
ABS CM PART CONSTRUCTION/
OPERATION [REAR ABS] 04-13A-6
ABS CM PART FUNCTION [4W-ABS] 04-13B-5
ABS CM PART FUNCTION [REAR ABS] 04-13A-5
ABS CONTROL OPERATION [REAR ABS] 04-13A-8
ABS CONTROL OPERATION [4W-ABS] 04-13B-6
ABS CONTROL OUTLINE [4W-ABS] 04-13B-5
ABS CONTROL OUTLINE [REAR ABS] 04-13A-7
ABS HU PART CONSTRUCTION/
OPERATION [4W-ABS] 04-13B-3
ABS HU PART CONSTRUCTION/
OPERATION [REAR ABS] 04-13A-3
ABS HU PART FUNCTION [4W-ABS] 04-13B-3
ABS HU PART FUNCTION [REAR ABS] 04-13A-2
ABS HU/CM CONSTRUCTION [4W-ABS] 04-13B-2
ABS OUTLINE [4W-ABS] 04-13B-1
ABS OUTLINE [REAR ABS] 04-13A-1
ABS SPEED SENSOR AND ABS
SENSOR ROTOR CONSTRUCTION/
OPERATION [REAR ABS] 04-13A-9
ABS SPEED SENSOR FUNCTION
[REAR ABS] 04-13A-8
ABS STRUCTURAL VIEW [4W-ABS] 04-13B-1
ABS STRUCTURAL VIEW [REAR ABS] 04-13A-1
ABS SYSTEM WIRING DIAGRAM
[4W-ABS] 04-13B-2
ABS SYSTEM WIRING DIAGRAM
[REAR ABS] 04-13A-2
ABS WHEEL-SPEED SENSOR AND
ABS SENSOR ROTOR FUNCTION
[4W-ABS] 04-13B-6
ABS WHEEL-SPEED SENSOR AND
ABS SENSOR ROTOR
CONSTRUCTION/OPERATION [4W-ABS] 04-13B-6
ACCELERATOR PEDAL COMPONENT
CONSTRUCTION [WL-C, WE-C] 01-13B-6
ACCELERATOR PEDAL COMPONENT
DESCRIPTION [WL-3] 01-13A-5
ACCELERATOR PEDAL POSITION
(APP) SENSOR CONSTRUCTION/
OPERATION [WL-3] 01-40A-18
ACCELERATOR PEDAL POSITION
(APP) SENSOR DESCRIPTION
[WL-C, WE-C] 01-40B-23
ACCELERATOR PEDAL POSITION
(APP) SENSOR FUNCTION [WL-3] 01-40A-18

ACCELERATOR PEDAL POSITION
(APP) SENSOR FUNCTION
[WL-C, WE-C] 01-40B-23
AIM OF DEVELOPMENT 00-00-1
AIR BAG SYSTEM OUTLINE 08-10-1
AIR BAG SYSTEM STRUCTURAL VIEW 08-10-2
AIR BAG SYSTEM WIRING DIAGRAM 08-10-2
AIR CHARGING SYSTEM DIAGRAM
[WL-C, WE-C] 01-13B-4
AIR CHARGING SYSTEM OPERATION
[WL-C, WE-C] 01-13B-4
AIR CHARGING SYSTEM OUTLINE
[WL-C, WE-C] 01-13B-4
AIR CLEANER CONSTRUCTION [WL-3] 01-13A-3
AIR CLEANER CONSTRUCTION
[WL-C, WE-C] 01-13B-3
AUDIO SYSTEM BLOCK DIAGRAM 09-20-2
AUDIO SYSTEM OUTLINE 09-20-1
AUDIO SYSTEM SPECIFICATIONS 09-20-2
AUDIO SYSTEM STRUCTURAL VIEW 09-20-1
AUDIO UNIT CONSTRUCTION 09-20-9
AUDIO UNIT STRUCTURAL VIEW 09-20-9
AUTO LEVEL CONTROL (ALC) FUNCTION 09-20-5
AUTO LEVEL CONTROL (ALC)
OPERATION 09-20-5
AUTO TENSIONER CONSTRUCTION
[WL-C, WE-C] 01-10B-8

B

BASIC SYSTEM LOCATION INDEX 07-11-1
BLOWER MOTOR CONSTRUCTION 07-40-2
BLOWER UNIT CONSTRUCTION/OPERATION 07-11-2
BODY AND ACCESSORIES ABBREVIATIONS 09-00-1
BODY AND ACCESSORIES FEATURES 09-00-1
BODY PANEL OUTLINE 09-10-1
BODY PANEL STRUCTURAL VIEW 09-10-1
BOOST PRESSURE CONTROL
BLOCK DIAGRAM [WL-C, WE-C] 01-40B-12
BOOST PRESSURE CONTROL
OPERATION [WL-C, WE-C] 01-40B-12
BOOST PRESSURE CONTROL
OUTLINE [WL-C, WE-C] 01-40B-12
BOOST SENSOR CONSTRUCTION/
OPERATION [WL-3] 01-40A-17
BOOST SENSOR CONSTRUCTION/
OPERATION [WL-C, WE-C] 01-40B-22
BOOST SENSOR FUNCTION [WL-3] 01-40A-17
BOOST SENSOR FUNCTION [WL-C, WE-C] 01-40B-22
BRAKE ABBREVIATIONS 04-00-1
BRAKE FEATURES 04-00-1
BRAKE SPECIFICATIONS 04-00-2

C

CAMSHAFT CONSTRUCTION [WL-3] 01-10A-9
CAMSHAFT CONSTRUCTION [WL-C, WE-C] 01-10B-8
CAMSHAFT POSITION (CMP) SENSOR
CONSTRUCTION/OPERATION
[WL-C, WE-C] 01-40B-26

AI

ALPHABETICAL INDEX

CAMSHAFT POSITION (CMP) SENSOR
 FUNCTION [WL-C, WE-C] 01-40B-25
 CENTER PANEL UNIT OUTLINE 09-20-3
 CENTER PANEL UNIT CONSTRUCTION 09-20-3
 CHARGE AIR COOLER
 CONSTRUCTION [WL-3] 01-13A-4
 CHARGE AIR COOLER
 CONSTRUCTION [WL-C, WE-C] 01-13B-6
 CHARGING SYSTEM OUTLINE
 [WL-3, WL-C, WE-C] 01-17-1
 CHARGING SYSTEM STRUCTURAL
 VIEW [WL-3, WL-C, WE-C] 01-17-1
 CHECK VALVE (TWO-WAY)
 CONSTRUCTION/OPERATION [WL-3] 01-16A-7
 CHECK VALVE (TWO-WAY)
 FUNCTION [WL-3] 01-16A-7
 CHECK VALVE FUNCTION [WL-C, WE-C] 01-14B-13
 CLIMATE CONTROL UNIT CONSTRUCTION 07-40-4
 CLUTCH COVER OUTLINE
 [S15M-D, S15MX-D] 05-10-2
 CLUTCH MASTER CYLINDER
 CONSTRUCTION 05-10-2
 CLUTCH PEDAL POSITION (CPP)
 SWITCH CONSTRUCTION/
 OPERATION [WL-3] 01-40A-24
 CLUTCH PEDAL POSITION (CPP)
 SWITCH FUNCTION [WL-3] 01-40A-24
 CLUTCH PEDAL POSITION (CPP)
 SWITCH DESCRIPTION [WL-C, WE-C] 01-40B-28
 CLUTCH PEDAL POSITION (CPP)
 SWITCH FUNCTION [WL-C, WE-C] 01-40B-27
 CLUTCH RELEASE CYLINDER construction 05-10-2
 CLUTCH STRUCTURAL VIEW 05-10-1
 COMMON RAIL CONSTRUCTION
 [WL-C, WE-C] 01-14B-10
 COMMON RAIL FUNCTION [WL-C, WE-C] 01-14B-10
 COMMON RAIL INJECTION
 SYSTEM FUNCTION [WL-C, WE-C] 01-14B-4
 COMMUNICATION FUNCTION [WL-3] 01-02A-4
 CONDENSER CONSTRUCTION 07-11-5
 CONNECTING ROD, CONNECTING ROD
 BEARING CONSTRUCTION [WL-3] 01-10A-7
 CONNECTING ROD, CONNECTING ROD
 BEARING CONSTRUCTION [WL-C, WE-C] 01-10B-5
 CONTROL SLEEVE (CS) SENSOR
 CONSTRUCTION/OPERATION [WL-3] 01-40A-21
 CONTROL SLEEVE (CS) SENSOR
 FUNCTION [WL-3] 01-40A-20
 CONTROL SYSTEM LOCATION INDEX 07-40-1
 CONTROL SYSTEM OUTLINE 07-40-1
 CONTROL SYSTEM WIRING DIAGRAM 07-40-2
 CONVENTIONAL BRAKE SYSTEM OUTLINE 04-11-1
 CONVENTIONAL BRAKE
 SYSTEM STRUCTURAL VIEW 04-11-1
 COOLING FAN CONSTRUCTION
 [WL-C, WE-C] 01-12B-4
 COOLING FAN CONSTRUCTION [WL-3] 01-12A-4
 COOLING SYSTEM
 FLOW DIAGRAM [WL-C, WE-C] 01-12B-2
 COOLING SYSTEM OUTLINE [WL-3] 01-12A-1
 COOLING SYSTEM OUTLINE [WL-C, WE-C] 01-12B-1
 COOLING SYSTEM STRUCTURAL
 VIEW [WL-C, WE-C] 01-12B-1
 COOLING SYSTEM FLOW DIAGRAM [WL-3] 01-12A-2

COOLING SYSTEM
 STRUCTURAL VIEW [WL-3] 01-12A-1
 COOLING UNIT
 CONSTRUCTION/OPERATION 07-11-3
 CRANKSHAFT POSITION (CKP)
 SENSOR FUNCTION [WL-3] 01-40A-22
 CRANKSHAFT POSITION (CKP)
 SENSOR CONSTRUCTION/
 OPERATION [WL-3] 01-40A-23
 CRANKSHAFT POSITION (CKP)
 SENSOR CONSTRUCTION/
 OPERATION [WL-C, WE-C] 01-40B-27
 CRANKSHAFT POSITION (CKP)
 SENSOR FUNCTION [WL-C, WE-C] 01-40B-26
 CRANKSHAFT PULLEY
 CONSTRUCTION [WL-C, WE-C] 01-10B-4
 CRANKSHAFT PULLEY, DRIVE BELT
 CONSTRUCTION [WL-3] 01-10A-5
 CRANKSHAFT, MAIN BEARING
 CONSTRUCTION [WL-C, WE-C] 01-10B-3
 CRANKSHAFT, MAIN BEARING, THRUST
 BEARING CONSTRUCTION [WL-3] 01-10A-4
 CYLINDER BLOCK CONSTRUCTION [WL-3] 01-10A-3
 CYLINDER BLOCK
 CONSTRUCTION [WL-C, WE-C] 01-10B-2
 CYLINDER HEAD CONSTRUCTION [WL-3] 01-10A-2
 CYLINDER HEAD CONSTRUCTION
 [WL-C, WE-C] 01-10B-2
 CYLINDER HEAD COVER
 CONSTRUCTION [WL-C, WE-C] 01-10B-1
 CYLINDER HEAD COVER,
 CYLINDER HEAD COVER GASKET
 CONSTRUCTION [WL-3] 01-10A-2
 CYLINDER HEAD GASKET
 CONSTRUCTION [WL-3] 01-10A-3
 CYLINDER HEAD GASKET
 CONSTRUCTION [WL-C, WE-C] 01-10B-2

D

DIAGNOSTIC SYSTEM
 WIRING DIAGRAM [WL-3] 01-02A-2
 DIAGNOSTIC SYSTEM
 WIRING DIAGRAM [WL-C, WE-C] 01-02B-2
 DLC-2 CONSTRUCTION [4W-ABS] 04-02B-5
 DOUBLE CONE SYNCHRONIZER
 MECHANISM CONSTRUCTION/
 OPERATION [S15M-D, S15MX-D] 05-11B-7
 DOUBLE CONE SYNCHRONIZER
 MECHANISM OPERATION [R15M-D] 05-11A-4
 DOUBLE cone SYNCHRONIZER
 MECHANISM OUTLINE
 [S15M-D, S15MX-D] 05-11B-7
 DOUBLE CONE SYNCHRONIZER
 MECHANISM STRUCTURE [R15M-D] 05-11A-3
 DRIVE BELT CONSTRUCTION [WL-C, WE-C] 01-10B-5
 DRIVELINE/AXLE ABBREVIATIONS 03-00-1
 DRIVELINE/AXLE FEATURES 03-00-1
 DRIVELINE/AXLE SPECIFICATIONS 03-00-2
 DRIVER-SIDE AIR BAG MODULE
 CONSTRUCTION/OPERATION 08-10-5
 DRIVER-SIDE AIR BAG MODULE FUNCTION 08-10-4
 DTC DETECTION LOGIC AND
 CONDITIONS [WL-3] 01-02A-6

ALPHABETICAL INDEX

DTC DETECTION LOGIC AND CONDITIONS [WL-C, WE-C]	01-02B-9
DTC TABLE [WL-3]	01-02A-4
DTC TEST MODE [WL-C, WE-C]	01-02B-6
DUAL-MASS FLYWHEEL FUNCTION [S15M-D, S15MX-D]	05-10-3

E

EGR CONTROL BLOCK DIAGRAM [WL-3]	01-40A-13
EGR CONTROL BLOCK DIAGRAM [WL-C, WE-C]	01-40B-17
EGR CONTROL OPERATION [WL-3]	01-40A-13
EGR CONTROL OPERATION [WL-C, WE-C]	01-40B-17
EGR CONTROL OUTLINE [WL-3]	01-40A-13
EGR CONTROL OUTLINE [WL-C, WE-C]	01-40B-17
EGR CONTROL SOLENOID VALVE DESCRIPTION [WL-3]	01-16A-5
EGR CONTROL SOLENOID VALVE DESCRIPTION [WL-C, WE-C]	01-16B-5
EGR CONTROL SOLENOID VALVE FUNCTION [WL-3]	01-16A-5
EGR CONTROL SOLENOID VALVE FUNCTION [WL-C, WE-C]	01-16B-5
EGR COOLER DESCRIPTION [WL-3]	01-16A-6
EGR COOLER DESCRIPTION [WL-C, WE-C]	01-16B-6
EGR COOLER FUNCTION [WL-3]	01-16A-5
EGR COOLER FUNCTION [WL-C, WE-C]	01-16B-5
EGR SORENOID VALVE (VACUUM, VENT) DESCRIPTION [WL-3]	01-16A-5
EGR SORENOID VALVE (VACUUM, VENT) FUNCTION [WL-3]	01-16A-5
EGR SORENOID VALVE DESCRIPTION [WL-C, WE-C]	01-16B-5
EGR SORENOID VALVE FUNCTION [WL-C, WE-C]	01-16B-5
EGR SYSTEM DIAGRAM [WL-3]	01-16A-4
EGR SYSTEM DIAGRAM [WL-C, WE-C]	01-16B-4
EGR SYSTEM FUNCTION [WL-3]	01-16A-4
EGR SYSTEM FUNCTION [WL-C, WE-C]	01-16B-4
EGR SYSTEM OPERATION [WL-3]	01-16A-4
EGR SYSTEM OPERATION [WL-3]	01-16A-5
EGR SYSTEM OPERATION [WL-C, WE-C]	01-16B-4
EGR SYSTEM OPERATION [WL-C, WE-C]	01-16B-5
EGR SYSTEM OUTLINE [WL-3]	01-16A-4
EGR SYSTEM OUTLINE [WL-C, WE-C]	01-16B-4
EGR VALVE POSITION SENSOR FUNCTION [WL-3]	01-40A-23
EGR VALVE POSITION SENSOR FUNCTION [WL-C, WE-C]	01-40B-27
ELECTRONIC GOVERNOR CONSTRUCTION [WL-3]	01-14A-7
ELECTRONIC GOVERNOR FUNCTION [WL-3]	01-14A-6
ELECTRONIC GOVERNOR OPERATION [WL-3]	01-14A-7
EMISSION SYSTEM DIAGRAM [WL-3]	01-16A-3
EMISSION SYSTEM DIAGRAM [WL-C, WE-C]	01-16B-3
EMISSION SYSTEM OUTLINE [WL-3]	01-16A-1
EMISSION SYSTEM OUTLINE [WL-C, WE-C]	01-16B-1
EMISSION SYSTEM STRUCTURAL VIEW [WL-3]	01-16A-2
EMISSION SYSTEM STRUCTURAL VIEW [WL-C, WE-C]	01-16B-2
ENGINE ABBREVIATIONS	01-00-1
ENGINE CONTROL SYSTEM BLOCK DIAGRAM [WL-3]	01-40A-7
ENGINE CONTROL SYSTEM BLOCK DIAGRAM [WL-C, WE-C]	01-40B-9
ENGINE CONTROL SYSTEM DIAGRAM [WL-3]	01-40A-4
ENGINE CONTROL SYSTEM DIAGRAM [WL-C, WE-C]	01-40B-4
ENGINE CONTROL SYSTEM OUTLINE [WL-3]	01-40A-2
ENGINE CONTROL SYSTEM OUTLINE [WL-C, WE-C]	01-40B-2
ENGINE CONTROL SYSTEM RELATION CHART [WL-3]	01-40A-8
ENGINE CONTROL SYSTEM RELATION CHART [WL-C, WE-C]	01-40B-10
ENGINE CONTROL SYSTEM STRUCTURAL VIEW [WL-3]	01-40A-3
ENGINE CONTROL SYSTEM STRUCTURAL VIEW [WL-C, WE-C]	01-40B-3
ENGINE CONTROL SYSTEM WIRING DIAGRAM [WL-3]	01-40A-5
ENGINE CONTROL SYSTEM WIRING DIAGRAM [WL-C, WE-C]	01-40B-5
ENGINE COOLANT TEMPERATURE (ECT) SENSOR CONSTRUCTION/ OPERATION [WL-3]	01-40A-22
ENGINE COOLANT TEMPERATURE (ECT) SENSOR CONSTRUCTION/ OPERATION [WL-C, WE-C]	01-40B-25
ENGINE COOLANT TEMPERATURE (ECT) SENSOR FUNCTION [WL-3]	01-40A-22
ENGINE COOLANT TEMPERATURE (ECT) SENSOR FUNCTION [WL-C, WE-C]	01-40B-25
ENGINE FEATURES [WL-3, WL-C, WE-C]	01-00-2
ENGINE MOUNT STRUCTURAL VIEW [WL-3]	01-10A-10
ENGINE MOUNT STRUCTURAL VIEW [WL-C, WE-C]	01-10B-9
ENGINE SPECIFICATION [WL-3]	01-00-3
ENGINE SPECIFICATION [WL-C, WE-C]	01-00-5
ENGINE STRUCTURAL VIEW [WL-3]	01-10A-1
ENGINE STRUCTURAL VIEW [WL-C, WE-C]	01-10B-1
EVAPORATIVE CHAMBER CONSTRUCTION/OPERATION [WL-3]	01-16A-7
EVAPORATIVE CHAMBER FUNCTION [WL-3]	01-16A-7
EXHAUST SYSTEM OUTLINE [WL-3]	01-15A-1
EXHAUST SYSTEM OUTLINE [WL-C, WE-C]	01-15B-1
EXHAUST SYSTEM STRUCTURAL VIEW [WL-3]	01-15A-1
EXHAUST SYSTEM STRUCTURAL VIEW [WL-C, WE-C]	01-15B-1
EXTERIOR TRIM OUTLINE	09-16-1
EXTERIOR TRIM STRUCTURAL VIEW	09-16-1
FAIL-SAFE FUNCTION [WL-3]	01-02A-4
FAILURE DETECTION FUNCTION [WL-3]	01-02A-4
FAILURE INDICATION FUNCTION [WL-3]	01-02A-4
FRONT AXLE OUTLINE	03-11-1
FRONT AXLE CROSS-SECTIONAL VIEW	03-11-1

F

ALPHABETICAL INDEX

FRONT BRAKE (DISC) CONSTRUCTION04-11-6
 FRONT COMBINATION LIGHT
 CONSTRUCTION.....09-18-3
 FRONT DRIVE SHAFT
 CROSS-SECTIONAL VIEW.....03-13-1
 FRONT DRIVE SHAFT OUTLINE03-13-1
 FRONT LOWER ARM AND TIE ROD
 CONSTRUCTION [4x2 (EXCEPT Hi-Rider)]02-13-3
 FRONT SUSPENSION DESCRIPTION02-13-3
 FRONT SUSPENSION OUTLINE02-13-1
 FRONT SUSPENSION STRUCTURAL VIEW02-13-1
 FRONT WHEEL ALIGNMENT DESCRIPTION02-11-1
 FUEL CUT SOLENOID VALVE
 FUNCTION [WL-3].....01-14A-8
 FUEL CUT SOLENOID VALVE
 OPERATION [WL-3].....01-14A-8
 FUEL FILTER CONSTRUCTION/
 OPERATION [WL-3].....01-14A-4
 FUEL FILTER CONSTRUCTION/
 OPERATION [WL-C, WE-C].....01-14B-5
 FUEL FILTER FUNCTION [WL-3]01-14A-4
 FUEL FILTER FUNCTION [WL-C, WE-C]01-14B-4
 FUEL GAUGE CONTROL OUTLINE09-22-8
 FUEL GAUGE CONTROL
 CONSTRUCTION/OPERATION09-22-8
 FUEL INJECTION AMOUNT CONTROL
 BLOCK DIAGRAM [WL-C, WE-C].....01-40B-13
 FUEL INJECTION AMOUNT
 CONTROL BLOCK DIAGRAM [WL-3]01-40A-10
 FUEL INJECTION AMOUNT CONTROL
 OPERATION [WL-C, WE-C].....01-40B-13
 FUEL INJECTION AMOUNT
 CONTROL OUTLINE [WL-3]01-40A-10
 FUEL INJECTION AMOUNT CONTROL
 OUTLINE [WL-C, WE-C]01-40B-12
 FUEL INJECTION AMOUNT
 CONTROL OPERATION [WL-3]01-40A-11
 FUEL INJECTION PUMP
 CONSTRUCTION [WL-3].....01-14A-5
 FUEL INJECTION PUMP FUNCTION [WL-3] ...01-14A-4
 FUEL INJECTION PUMP OPERATION [WL-3] ...01-14A-5
 FUEL INJECTION TIMING CONTROL
 BLOCK DIAGRAM [WL-C, WE-C]01-40B-14
 FUEL INJECTION TIMING
 CONTROL OPERATION [WL-3]01-40A-12
 FUEL INJECTION TIMING CONTROL
 OPERATION [WL-C, WE-C].....01-40B-14
 FUEL INJECTION TIMING
 CONTROL OUTLINE [WL-3]01-40A-12
 FUEL INJECTION TIMING CONTROL
 OUTLINE [WL-C, WE-C].....01-40B-13
 FUEL INJECTION TIMING CONTROL
 BLOCK DIAGRAM [WL-3]01-40A-12
 FUEL INJECTOR CONSTRUCTION
 [WL-C, WE-C].....01-14B-10
 FUEL INJECTOR FUNCTION [WL-C, WE-C] ...01-14B-10
 FUEL INJECTOR OPERATION [WL-C, WE-C] ..01-14B-12
 FUEL METERING VALVE
 CONSTRUCTION/OPERATION
 [WL-C, WE-C]01-14B-9
 FUEL METERING VALVE
 FUNCTION [WL-C, WE-C].....01-14B-9
 FUEL PRESSURE CONTROL
 BLOCK DIAGRAM [WL-C, WE-C]01-40B-16

FUEL PRESSURE CONTROL
 OPERATION [WL-C, WE-C].....01-40B-16
 FUEL PRESSURE CONTROL
 OUTLINE [WL-C, WE-C].....01-40B-16
 FUEL PRESSURE SENSOR
 CONSTRUCTION/OPERATION
 [WL-C, WE-C]01-40B-25
 FUEL PRESSURE SENSOR
 FUNCTION [WL-C, WE-C]01-40B-24
 FUEL PUMP SPEED SENSOR
 CONSTRUCTION [WL-3]01-40A-20
 FUEL PUMP SPEED SENSOR
 FUNCTION [WL-3]01-40A-19
 FUEL PUMP SPEED SENSOR
 OPERATION [WL-3].....01-40A-20
 FUEL SYSTEM DIAGRAM [WL-3]01-14A-3
 FUEL SYSTEM DIAGRAM [WL-C, WE-C]01-14B-3
 FUEL SYSTEM OUTLINE [WL-3].....01-14A-1
 FUEL SYSTEM OUTLINE [WL-C, WE-C].....01-14B-1
 FUEL SYSTEM STRUCTURAL VIEW [WL-3].....01-14A-2
 FUEL SYSTEM STRUCTURAL VIEW
 [WL-C, WE-C].....01-14B-2
 FUEL TANK CONSTRUCTION [WL-C, WE-C]...01-14B-4
 FUEL TANK CONSTRUCTION [WL-3].....01-14A-4
 FUEL TEMPERATURE SENSOR
 CONSTRUCTION/OPERATION
 [WL-C, WE-C]01-40B-24
 FUEL TEMPERATURE SENSOR
 CONSTRUCTION/OPERATION [WL-3].....01-40A-19
 FUEL TEMPERATURE SENSOR
 FUNCTION [WL-3]01-40A-19
 FUEL TEMPERATURE SENSOR
 FUNCTION [WL-C, WE-C].....01-40B-24

G

G SENSOR CONSTRUCTION/
 OPERATION [4W-ABS]04-13B-7
 G SENSOR FUNCTION [4W-ABS].....04-13B-7
 GENERATOR CONSTRUCTION
 [WL-3, WL-C, WE-C].....01-17-2
 GLOW CONTROL BLOCK DIAGRAM [WL-3] ...01-40A-9
 GLOW CONTROL
 BLOCK DIAGRAM [WL-C, WE-C]01-40B-11
 GLOW CONTROL OPERATION
 [WL-C, WE-C]01-40B-12
 GLOW CONTROL OPERATION [WL-3].....01-40A-9
 GLOW CONTROL OUTLINE [WL-3].....01-40A-9
 GLOW CONTROL OUTLINE [WL-C, WE-C] ...01-40B-11
 GLOW PLUG CONSTRUCTION [WL-3].....01-13A-7
 GLOW PLUG CONSTRUCTION [WL-C, WE-C]..01-13B-7
 GLOW PLUG FUNCTION [WL-3]01-13A-6
 GLOW PLUG FUNCTION [WL-C, WE-C].....01-13B-6
 GLOW PLUG OUTLINE [WL-3]01-13A-6
 GLOW PLUG RELAY OPERATION [WL-3]01-13A-7
 GLOW PLUG RELAY OPERATION
 [WL-C, WE-C]01-13B-7
 GLOW SYSTEM CONSTRUCTION
 [WL-C, WE-C]01-13B-6
 GLOW SYSTEM OPERATION [WL-3]01-13A-5
 GLOW SYSTEM OPERATION [WL-C, WE-C] ...01-13B-6
 GLOW SYSTEM OUTLINE [WL-3].....01-13A-5
 GLOW SYSTEM OUTLINE [WL-C, WE-C].....01-13B-6

ALPHABETICAL INDEX

H

HORN CONSTRUCTION	09-22-9
HVAC ABBREVIATION	07-00-1
HVAC FEATURES	07-00-1
HVAC SPECIFICATIONS	07-00-1

I

IDLE SPEED CONTROL BLOCK	
DIAGRAM [WL-C, WE-C]	01-40B-11
IDLE SPEED CONTROL	
OPERATION [WL-C, WE-C]	01-40B-11
IDLE SPEED CONTROL OUTLINE	
[WL-C, WE-C]	01-40B-10
IDLE SWITCH CONSTRUCTION/	
OPERATION [WL-3]	01-40A-19
IDLE SWITCH DESCRIPTION	
[WL-C, WE-C]	01-40B-24
IDLE SWITCH FUNCTION [WL-3]	01-40A-19
IDLE SWITCH FUNCTION [WL-C, WE-C]	01-40B-23
IMMOBILIZER SYSTEM BLOCK	
DIAGRAM [WL-C, WE-C]	01-40B-19
IMMOBILIZER SYSTEM	
OPERATION [WL-C, WE-C]	01-40B-19
IMMOBILIZER SYSTEM OPERATION	09-14-10
IMMOBILIZER SYSTEM	
OUTLINE [WL-C, WE-C]	01-40B-19
IMMOBILIZER SYSTEM OUTLINE	09-14-7
IMMOBILIZER SYSTEM STRUCTURAL VIEW ...	09-14-8
IMMOBILIZER SYSTEM SYSTEM	
COMPONENT	09-14-9
IMMOBILIZER SYSTEM WIRING DIAGRAM	09-14-8
INJECTION NOZZLE	
CONSTRUCTION/OPERATION [WL-3]	01-14A-9
INJECTION NOZZLE FUNCTION [WL-3]	01-14A-9
INJECTION PUMP EPROM	
CONSTRUCTION [WL-3]	01-14A-9
INJECTION PUMP EPROM	
FUNCTION [WL-3]	01-14A-9
INPUT/OUTPUT CHECK MODE OPERATION ...	09-22-5
INPUT/OUTPUT CHECK MODE OUTLINE	09-22-5
INSTRUMENT CLUSTER OUTLINE	09-22-1
INSTRUMENT CLUSTER SPECIFICATIONS ...	09-22-1
INSTRUMENT CLUSTER	
STRUCTURAL VIEW	09-22-2
INSTRUMENT CLUSTER	
SYSTEM WIRING DIAGRAM	09-22-3
INTAKE AIR SYSTEM DIAGRAM [WL-3]	01-13A-3
INTAKE AIR SYSTEM DIAGRAM	
[WL-C, WE-C]	01-13B-3
INTAKE AIR SYSTEM HOSE	
ROUTING DIAGRAM [WL-3]	01-13A-2
INTAKE AIR SYSTEM HOSE	
ROUTING DIAGRAM [WL-C, WE-C]	01-13B-2
INTAKE AIR SYSTEM OUTLINE [WL-3]	01-13A-1
INTAKE AIR SYSTEM OUTLINE	
[WL-C, WE-C]	01-13B-1
INTAKE AIR SYSTEM STRUCTURAL	
VIEW [WL-3]	01-13A-1
INTAKE AIR SYSTEM STRUCTURAL	
VIEW [WL-C, WE-C]	01-13B-2

INTAKE AIR TEMPERATURE (IAT)	
SENSOR NO.1 CONSTRUCTION/	
OPERATION [WL-C, WE-C]	01-40B-22
INTAKE AIR TEMPERATURE (IAT)	
SENSOR NO.1 FUNCTION [WL-3]	01-40A-16
INTAKE AIR TEMPERATURE (IAT)	
SENSOR NO.1 FUNCTION [WL-C, WE-C] ...	01-40B-21
INTAKE AIR TEMPERATURE (IAT)	
SENSOR NO.2 CONSTRUCTION/	
OPERATION [WL-3]	01-40A-16
INTAKE AIR TEMPERATURE (IAT)	
SENSOR NO.2 CONSTRUCTION/	
OPERATION [WL-C, WE-C]	01-40B-21
INTAKE AIR TEMPERATURE (IAT)	
SENSOR NO.2 FUNCTION [WL-3]	01-40A-15
INTAKE AIR TEMPERATURE (IAT)	
SENSOR NO.2 FUNCTION [WL-C, WE-C] ...	01-40B-21
INTAKE SHUTTER SOLENOID VALVE	
DESCRIPTION [WL-C, WE-C]	01-16B-6
INTAKE SHUTTER VALVE	
DESCRIPTION [WL-C, WE-C]	01-16B-6
INTERIOR TRIM OUTLINE	09-17-1
INTERIOR TRIM STRUCTURAL VIEW	09-17-1

K

KEY REMINDER WARNING ALARM OUTLINE ...	09-22-7
KEY REMINDER WARNING	
ALARM CONSTRUCTION/OPERATION	09-22-7
KEYLESS ENTRY SYSTEM OPERATION	09-14-2
KEYLESS ENTRY SYSTEM OUTLINE	09-14-1
KEYLESS ENTRY SYSTEM	
STRUCTURAL VIEW	09-14-1
KEYLESS ENTRY SYSTEM	
WIRING DIAGRAM	09-14-2
KOEO/KOER SELF-TEST [WL-3]	01-02A-8
KOEO/KOER SELF-TEST [WL-C, WE-C]	01-02B-16

L

LIGHTING SYSTEM OUTLINE	09-18-1
LIGHTING SYSTEM STRUCTURAL VIEW	09-18-2
LIGHTING SYSTEMS SPECIFICATION	09-18-1
LIGHTS-ON REMINDER WARNING	
ALARM CONSTRUCTION/OPERATION	09-22-6
LIGHTS-ON REMINDER WARNING	
ALARM OUTLINE	09-22-6
LOAD LIMITER RETRACTOR	
CONSTRUCTION/OPERATION	08-11-1
LOAD SENSING PROPORTIONING	
VALVE (LSPV) CONSTRUCTION	04-11-3
LOAD SENSING PROPORTIONING	
VALVE (LSPV) OPERATION	04-11-4
LUBRICATION SYSTEM	
FLOW DIAGRAM [WL-3]	01-11A-2
LUBRICATION SYSTEM	
FLOW DIAGRAM [WL-C, WE-C]	01-11B-3
LUBRICATION SYSTEM OUTLINE [WL-3]	01-11A-1
LUBRICATION SYSTEM OUTLINE	
[WL-C, WE-C]	01-11B-1
LUBRICATION SYSTEM STRUCTURAL	
VIEW [WL-3]	01-11A-1
LUBRICATION SYSTEM STRUCTURAL	
VIEW [WL-C, WE-C]	01-11B-2

ALPHABETICAL INDEX

M

MAGNETIC CLUTCH CONSTRUCTION	07-40-3
MANUAL AIR CONDITIONER CONTROL SYSTEM	07-40-4
MANUAL TRANSMISSION OUTLINE [R15M-D]	05-11A-1
MANUAL TRANSMISSION OUTLINE [S15M-D, S15MX-D]	05-11B-1
MANUAL TRANSMISSION POWER FLOW [S15M-D, S15MX-D]	05-11B-3
MANUAL TRANSMISSION CROSS-SECTIONAL VIEW [S15M-D, S15MX-D]	05-11B-2
MANUAL TRANSMISSION CROSS-SECTIONAL VIEW [R15M-D]	05-11A-1
MANUAL TRANSMISSION POWER FLOW [R15M-D]	05-11A-2
MASS AIR FLOW (MAF) SENSOR CONSTRUCTION/OPERATION [WL-C, WE-C]	01-40B-20
MASS AIR FLOW (MAF) SENSOR CONSTRUCTION/OPERATION [WL-3]	01-40A-15
MASS AIR FLOW (MAF) SENSOR FUNCTION [WL-3]	01-40A-14
MASS AIR FLOW (MAF) SENSOR FUNCTION [WL-C, WE-C]	01-40B-20
MASTER CYLINDER CONSTRUCTION	04-11-2
MEMORY FUNCTION [WL-3]	01-02A-4
MMINTAKE AIR TEMPERATURE (IAT) SENSOR NO.1 CONSTRUCTION/ OPERATION [WL-3]	01-40A-17
MULTIPLE FUEL INJECTION CONTROL BLOCK DIAGRAM [WL-C, WE-C]	01-40B-15
MULTIPLE FUEL INJECTION CONTROL OPERATION [WL-C, WE-C]	01-40B-15
MULTIPLE FUEL INJECTION CONTROL OUTLINE [WL-C, WE-C]	01-40B-15

N

NEUTRAL SWITCH CONSTRUCTION/ OPERATION [WL-C, WE-C]	01-40B-28
NEUTRAL SWITCH FUNCTION [WL-C, WE-C]	01-40B-28
NEUTRAL SWITCH FUNCTION [WL-3]	01-40A-24
NEUTRAL SWITCH OPERATION [WL-3]	01-40A-24
NEW STANDARDS	00-00-14

O

OIL COOLER, OIL FILTER BODY CONSTRUCTION [WL-3]	01-11A-3
OIL COOLER, OIL FILTER BODY CONSTRUCTION [WL-C, WE-C]	01-11B-4
OIL FILTER CONSTRUCTION [WL-3]	01-11A-2
OIL FILTER CONSTRUCTION [WL-C, WE-C]	01-11B-3
OIL JET VALVE CONSTRUCTION/ OPERATION [WL-C, WE-C]	01-11B-6
OIL JET VALVE CONSTRUCTION/OPERATION [WL-3]	01-11A-5
OIL PAN CONSTRUCTION [WL-3]	01-11A-3

OIL PAN CONSTRUCTION [WL-C, WE-C]	01-11B-4
OIL PUMP CONSTRUCTION [WL-3]	01-11A-4
OIL PUMP CONSTRUCTION [WL-C, WE-C]	01-11B-5
OIL STRAINER CONSTRUCTION [WL-C, WE-C]	01-11B-5
OIL STRAINER CONSTRUCTION [WL-3]	01-11A-4
ON-BOARD DIAGNOSTIC FUNCTION [AIR BAG SYSTEM]	08-02-1
ON-BOARD DIAGNOSTIC OUTLINE [WL-C, WE-C]	01-02B-1
ON-BOARD DIAGNOSTIC OUTLINE [WL-3]	01-02A-1
ON-BOARD DIAGNOSTIC OUTLINE [REMOTE FREEWHEEL (RFW)]	03-02-1
ON-BOARD DIAGNOSTIC FUNCTION OUTLINE	08-02-1
ON-BOARD DIAGNOSTIC SYSTEM ACTIVE COMMAND MODES FUNCTION [4W-ABS] ...	04-02B-3
ON-BOARD DIAGNOSTIC SYSTEM EXTERNAL TESTER COMMUNICATION FUNCTION [4W-ABS]	04-02B-4
ON-BOARD DIAGNOSTIC SYSTEM FUNCTION [4W-ABS]	04-02B-2
ON-BOARD DIAGNOSTIC SYSTEM FUNCTION [REAR ABS]	04-02A-1
ON-BOARD DIAGNOSTIC SYSTEM OUTLINE [4W-ABS]	04-02B-1
ON-BOARD DIAGNOSTIC SYSTEM OUTLINE [REAR ABS]	04-02A-1
ON-BOARD DIAGNOSTIC SYSTEM PID/DATA MONITOR FUNCTION [4W-ABS] ...	04-02B-3
ON-BOARD DIAGNOSTIC SYSTEM [IMMOBILIZER SYSTEM]	09-14-11
ON-BOARD DIAGNOSTIC SYSTEM FUNCTION	09-20-6
ON-BOARD DIAGNOSTIC SYSTEM OUTLINE ...	09-20-6
OVERFLOW VALVE CONSTRUCTION [WL-3] ..	01-14A-6
OVERFLOW VALVE FUNCTION [WL-3]	01-14A-6
OXIDATION CATALYTIC CONVERTER CONSTRUCTION [WL-3]	01-16A-6
OXIDATION CATALYTIC CONVERTER CONSTRUCTION [WL-C, WE-C]	01-16B-7
OXIDATION CATALYTIC CONVERTER FUNCTION [WL-3]	01-16A-6
OXIDATION CATALYTIC CONVERTER FUNCTION [WL-C, WE-C]	01-16B-6
OXIDATION CATALYTIC CONVERTER OPERATION [WL-3]	01-16A-6
OXIDATION CATALYTIC CONVERTER OPERATION [WL-C, WE-C]	01-16B-7

P

PARKING BRAKE SYSTEM OUTLINE	04-12-1
PARKING BRAKE SYSTEM STRUCTURAL VIEW	04-12-1
PASSENGER-SIDE AIR BAG MODULE CONSTRUCTION/OPERATION	08-10-5
PASSENGER-SIDE AIR BAG MODULE FUNCTION	08-10-5
PCM CONSTRUCTION [WL-3]	01-40A-14
PCM CONSTRUCTION [WL-C, WE-C]	01-40B-19
PCM FUNCTION [WL-3]	01-40A-14
PCM FUNCTION [WL-C, WE-C]	01-40B-19

ALPHABETICAL INDEX

PID/DATA MONITOR AND RECORD [WL-C, WE-C]	01-02B-15
PID/DATA MONITOR AND RECORD [WL-3]	01-02A-7
PISTON CONSTRUCTION [WL-C, WE-C]	01-10B-4
PISTON, PISTON RING, PISTON PIN CONSTRUCTION [WL-3]	01-10A-5
POWER BRAKE UNIT CONSTRUCTION	04-11-2
POWER OUTER MIRROR OUTLINE	09-12-3
POWER OUTER MIRROR SYSTEM WIRING DIAGRAM	09-12-4
POWER OUTER MIRROR OPERATION	09-12-5
POWER OUTER MIRROR STRUCTURAL VIEW	09-12-4
POWER STEERING OIL PUMP CONSTRUCTION	06-14-4
POWER STEERING OUTLINE	06-14-1
POWER STEERING STRUCTURAL VIEW	06-14-2
POWER SYSTEMS STRUCTURA VIEW	09-21-1
POWER WINDOW SYSTEM OUTLINE	09-12-2
POWER WINDOW SYSTEM OPERATION	09-12-3
POWER WINDOW SYSTEM STRUCTURAL VIEW	09-12-2
POWER WINDOW SYSTEM WIRING DIAGRAM	09-12-3
PRE-TENSIONER SEAT BELT CONSTRUCTION/OPERATION	08-10-7
PRE-TENSIONER SEAT BELT FUNCTION	08-10-6

R

RADIATOR, COOLING SYSTEM CAP CONSTRUCTION [WL-3]	01-12A-2
RADIATOR, COOLING SYSTEM CAP CONSTRUCTION [WL-C, WE-C]	01-12B-2
REAR AXLE OUTLINE	03-12-1
REAR AXLE CROSS-SECTIONAL VIEW	03-12-1
REAR BRAKE (DRUM) CONSTRUCTION	04-11-7
REAR BRAKE (DRUM) OPERATION	04-11-8
REAR COMBINATION LIGHT STRUCTURAL VIEW	09-18-4
REAR DIFFERENTIAL CROSS-SECTIONAL VIEW	03-14-1
REAR DIFFERENTIAL OUTLINE	03-14-1
REAR SUSPENSION OUTLINE	02-14-1
REAR SUSPENSION STRUCTURAL VIEW	02-14-1
REAR WINDOW DEFROSTER SYSTEM OPERATION	09-12-2
REAR WINDOW DEFROSTER SYSTEM WIRING DIAGRAM	09-12-1
REAR WINDOW DEFROSTER OUTLINE	09-12-1
REAR WINDOW DEFROSTER STRUCTURAL VIEW	09-12-1
REFRIGERANT LINE CONSTRUCTION	07-11-5
REFRIGERANT PRESSURE SWITCH CONSTRUCTION	07-40-4
REMOTE FREEWHEEL (RFW) COMPONENTS AND FUNCTIONS	03-18-2
REMOTE FREEWHEEL (RFW) CONSTRUCTION	03-18-1
REMOTE FREEWHEEL (RFW) OPERATION	03-18-4
REMOTE FREEWHEEL (RFW) SYSTEM DIAGRAM	03-18-3
REMOTE FREEWHEEL (RFW) SYSTEM WIRING DIAGRAM	03-18-4

REMOTE FREEWHEEL (RFW) OUTLINE	03-18-1
RESISTOR CONSTRUCTION	07-40-3
RESONANCE CHAMBER OUTLINE [WL-3]	01-13A-7
RESTRAINTS ABBREVIATIONS	08-00-1
RESTRAINTS FEATURES	08-00-1
REVERSE LOCKOUT MECHANISM CONSTRUCTION/OPERATION [R15M-D]	05-11A-6
REVERSE LOCKOUT MECHANISM CONSTRUCTION/OPERATION [S15M-D, S15MX-D]	05-11B-8
REVERSE LOCKOUT MECHANISM FUNCTION [R15M-D]	05-11A-6
REVERSE LOCKOUT MECHANISM FUNCTION [S15M-D, S15MX-D]	05-11B-8
ROLLOVER VALVE CONSTRUCTION/OPERATION [WL-3]	01-16A-6
ROLLOVER VALVE CONSTRUCTION/OPERATION [WL-C, WE-C]	01-16B-7
ROLLOVER VALVE FUNCTION [WL-3]	01-16A-6
ROLLOVER VALVE FUNCTION [WL-C, WE-C]	01-16B-7

S

SAS CONTROL MODULE CONSTRUCTION/OPERATION	08-10-3
SAS CONTROL MODULE FUNCTION	08-10-3
SEAT BELT OUTLINE	08-11-1
SEAT BELT STRUCTURAL VIEW	08-11-1
SEATS OUTLINE	09-13-1
SEATS SPECIFICATION	09-13-1
SEATS STRUCTURAL VIEW	09-13-2
SECURITY AND LOCKS OUTLINE	09-14-1
SHIFT INTERLOCK MECHANISM FUNCTION [R15M-D]	05-11A-5
SHIFT INTERLOCK MECHANISM FUNCTION [S15M-D, S15MX-D]	05-11B-7
SHIFT INTERLOCK MECHANISM OPERATION [R15M-D]	05-11A-5
SHIFT INTERLOCK MECHANISM OPERATION [S15M-D, S15MX-D]	05-11B-7
SHIFT MECHANISM OUTLINE [S15M-D, S15MX-D]	05-11B-4
SHIFT MECHANISM STRUCTURE [R15M-D]	05-11A-3
SIDE AIR BAG MODULE FUNCTION	08-10-5
SIDE AIR BAG MODULE CONSTRUCTION/OPERATION	08-10-6
SIMULATION TEST [WL-3]	01-02A-8
SIMULATION TEST [WL-C, WE-C]	01-02B-16
SPEEDOMETER CONTROL CONSTRUCTION/OPERATION	09-22-7
SPEEDOMETER CONTROL OUTLINE	09-22-7
STARTER CONSTRUCTION [WL-3, WL-C, WE-C]	01-19-1
STARTING SYSTEM OUTLINE [WL-3, WL-C, WE-C]	01-19-1
STARTING SYSTEM STRUCTURAL VIEW [WL-3, WL-C, WE-C]	01-19-1
STEERING ABBREVIATION	06-00-1
STEERING FEATURES	06-00-1
STEERING GEAR AND LINKAGE CONSTRUCTION	06-14-3
STEERING SHAFT CONSTRUCTION	06-14-5
STEERING SPECIFICATIONS	06-00-1

ALPHABETICAL INDEX

SUPPLY PUMP CONSTRUCTION/
 OPERATION [WL-C, WE-C]01-14B-5
 SUPPLY PUMP FUNCTION [WL-C, WE-C]01-14B-5
 SUSPENSION ABBREVIATIONS02-00-1
 SUSPENSION FEATURES02-00-1
 SUSPENSION SPECIFICATIONS02-00-2

T

TACHOMETER CONTROL OUTLINE09-22-8
 TACHOMETER CONTROL
 CONSTRUCTION/OPERATION09-22-8
 THEFT-DETERRENT SYSTEM CONDITION09-14-4
 THEFT-DETERRENT SYSTEM
 INPUT/OUTPUT DIAGRAM09-14-4
 THEFT-DETERRENT SYSTEM OUTLINE09-14-2
 THEFT-DETERRENT SYSTEM PHASE09-14-5
 THEFT-DETERRENT SYSTEM
 STRUCTURAL VIEW09-14-3
 THEFT-DETERRENT SYSTEM
 SYSTEM WIRING DIAGRAM09-14-3
 THERMOSTAT CONSTRUCTION/
 OPERATION [WL-3]01-12A-3
 THERMOSTAT CONSTRUCTION/
 OPERATION [WL-C, WE-C]01-12B-3
 TIMER CONTROL VALVE (TCV)
 CONSTRUCTION/OPERATION [WL-3]01-14A-8
 TIMER CONTROL VALVE (TCV)
 FUNCTION [WL-3]01-14A-8
 TIMER POSITION SENSOR
 CONSTRUCTION/OPERATION [WL-3]01-40A-22
 TIMER POSITION SENSOR
 FUNCTION [WL-3]01-40A-21
 TIMING GEAR CONSTRUCTION [WL-3]01-10A-8
 TIMING GEAR CONSTRUCTION
 [WL-C, WE-C]01-10B-6
 TRANSFER OUTLINE03-16-1
 TRANSFER POWER FLOW03-16-2
 TRANSFER CROSS-SECTIONAL VIEW03-16-1
 TRANSMISSION/TRANSAXLE
 ABBREVIATIONS05-00-1
 TRANSMISSION/TRANSAXLE FEATURES05-00-1
 TRANSMISSION/TRANSAXLE
 SPECIFICATIONS05-00-1
 TRIPLE CONE SYNCHRONIZER
 MECHANISM OPERATION
 [S15M-D, S15MX-D]05-11B-5
 TRIPLE CONE SYNCHRONIZER
 MECHANISM STRUCTURE
 [S15M-D, S15MX-D]05-11B-5
 TURBOCHARGER CONSTRUCTION [WL-3]01-13A-3
 TURBOCHARGER CONSTRUCTION/
 OPERATION [WL-C, WE-C]01-13B-5
 TURBOCHARGER DESCRIPTION [WL-3]01-13A-4
 TURBOCHARGER FUNCTION [WL-3]01-13A-3

TURBOCHARGER FUNCTION [WL-C, WE-C] .. 01-13B-5

U

UNITS 00-00-13


V

VACUUM CHAMBER FUNCTION
 [WL-C, WE-C] 01-13B-7
 VACUUM CHECK VALVE
 CONSTRUCTION [WL-C, WE-C] 01-13B-8
 VACUUM CHECK VALVE FUNCTION
 [WL-C, WE-C] 01-13B-7
 VACUUM PUMP CONSTRUCTION 04-11-2
 VALVE MECHANISM STRUCTURAL
 VIEW [WL-3] 01-10A-7
 VALVE MECHANISM STRUCTURAL
 VIEW [WL-C, WE-C] 01-10B-6
 VALVE, ROCKER ARM
 CONSTRUCTION [WL-3] 01-10A-9
 VALVE, ROCKER ARM
 CONSTRUCTION [WL-C, WE-C] 01-10B-9
 VARIABLE BOOST CONTROL (VBC)
 SOLENOID VALVE CONSTRUCTION
 [WL-C, WE-C] 01-13B-3
 VARIABLE BOOST CONTROL (VBC)
 SOLENOID VALVE FUNCTION
 [WL-C, WE-C] 01-13B-3
 VEHICLE IDENTIFICATION NUMBER
 (VIN) CODE 00-00-12
 VEHICLE IDENTIFICATION NUMBERS (VIN) ... 00-00-12

W

WASHER TANK SPECIFICATION 09-19-4
 WATER PUMP CONSTRUCTION/
 OPERATION [WL-3] 01-12A-3
 WATER PUMP CONSTRUCTION/
 OPERATION [WL-C, WE-C] 01-12B-3
 WATER TEMPERATURE GAUGE
 CONTROL CONSTRUCTION/
 OPERATION 09-22-9
 WATER TEMPERATURE GAUGE
 CONTROL OUTLINE 09-22-9
 WHEEL AND TIRES OUTLINE 02-12-1
 WHEEL AND TIRES STRUCTURAL VIEW 02-12-1
 WIPER SYSTEM OPERATION 09-19-2
 WIPER SYSTEM OUTLINE 09-19-1
 WIPER SYSTEM WIRING DIAGRAM 09-19-2
 WIPER/WASHER SYSTEM OUTLINE 09-19-1
 WIPER/WASHER SYSTEM
 STRUCTURAL VIEW 09-19-1

SERVICE PROCEDURES



WARNING

Servicing a vehicle can be dangerous. If you have not received service-related training, the risks of injury, property damage, and failure of servicing increase. The recommended servicing procedures for the vehicle in this workshop manual were developed with Ford-trained technicians in mind. This manual may be useful to non-Ford trained technicians, but a technician with our service-related training and experience will be at less risk when performing service operations. However, all users of this manual are expected to at least know general safety procedures.

This manual contains "Warnings" and "Cautions" applicable to risks not normally encountered in a general technician's experience. They should be followed to reduce the risk of injury and the risk that improper service or repair may damage the vehicle or render it unsafe. It is also important to understand that the "Warnings" and "Cautions" are not exhaustive. It is impossible to warn of all the hazardous consequences that might result from failure to follow the procedures.

The procedures recommended and described in this manual are effective methods of performing service and repair. Some require tools specifically designed for a specific purpose. Persons using procedures and tools which are not recommended by Ford Motor Company must satisfy themselves thoroughly that neither personal safety nor safety of the vehicle will be jeopardized.

The contents of this manual, including drawings and specifications, are the latest available at the time of printing, and Ford Motor Company reserves the right to change the vehicle designs and alter the contents of this manual without notice and without incurring obligation.

Parts should be replaced with genuine Ford replacement parts or with parts which match the quality of genuine Ford replacement parts. Persons using replacement parts of lesser quality than that of genuine Ford replacement parts must satisfy themselves thoroughly that neither personal safety nor safety of the vehicle will be jeopardized.

Ford Motor Company is not responsible for any problems which may arise from the use of this manual. The cause of such problems includes but is not limited to insufficient service-related training, use of improper tools, use of replacement parts of lesser quality than that of genuine Ford replacement parts, or not being aware of any revision of this manual.

VEHICLE IDENTIFICATION NUMBERS (VIN)

MNA BS*****
MNA DS*****
MNA LS*****
MNA US*****

RELATED MATERIALS

RANGER Training Manual	F340-10-05L
RANGER Overhaul Manual	F198-20-05L
RANGER Body Measurement Chart Manual	F340-20-05L
RANGER Wiring Diagrams.....	F198-30-05L