Chap.2 Instructions: Language of the Computer

Chap.2 指令系统: 计算机的语言

- 2.1 Introduction
- 2.2 Operations of the Computer Hardware
- 2.3 Operands of the Computer Hardware
- 2.4 Signed and Unsigned Numbers
- 2.5 Representing Instructions in the Computer
- 2.6 Logical Operations
- 2.7 Instructions for Making Decisions
- 2.8 Supporting Procedures in Computer Hardware
- 2.9 Communicating with People

上海交通大学 2014-02 / 39 1

Chap.2: Instructions: Language of the Computer

Chap.2 指令系统: 计算机的语言

- 2.10 MIPS Addressing for 32-Bit Immediates and More Complex Addresses
- 2.11 Parallelism and instructions: Synchronization
- 2.12 Translating and Starting a Program
- 2.13 A C Sort Example to Put it All Together
- 2.14 Arrays versus Pointers
- 2.15 Advanced Material: Compiling C and Interpreting Java
- 2.16 Real Stuff: ARM Instructions
- 2.17 Real Stuff: x86 Instructions

2.1 Introduction

设计目标

computer designers have a common goal:

To find a language that makes it easy to build the hardware and the compiler while maximizing performance and minimizing cost and power.

■ Instruction / Instruction Set: 指令 / 指令集 the words of a computer's language are called instructions, and its vocabulary is called an instruction set.

上海交通大学 2014-02 / 39 3

2.6 Logical Operations


2.6 Logical Operations


Logical operations	C operators	Java operators	MIPS instructions	
Shift left	<<	<<	s11	
Shift right	>>	>>>	srl	
Bit-by-bit AND	&	&	and, andi	
Bit-by-bit OR			or, ori	
Bit-by-bit NOT	~	~	nor	

FIGURE 2.8 C and Java logical operators and their corresponding MIPS instructions. MIPS implements NOT using a NOR with one operand being zero.

上海交通大学 2014-02 / 39 4

sll 指令 (Shift Left Logical)







指令的意義: 把寄存器rt中的數據左移sod位, 結果存放在寄存器rd中

上海交通大学 2014-02 / 39

srl 指令 (Shift Right Logical)






指令的意義: 把寄存器rt中的數據邏輯右移sa位, 結果存放在寄存器rd中


上海交通大学

2014-02

/ 38

and 指令(And)







指令的意義: 寄存器rs中的數據和寄存器rt中的數據相與, 結果存放在寄存器rd中

上海交通大学 2014-02 / 39 7

or 指令 (Or)






指令的意義: 寄存器rs中的數據和寄存器rt中的數據相或, 結果存放 在寄存器rd中


上海交通大学

2014-02

/ 39

xor指令(Exclusive Or)





指令的意義: 寄存器rs中的數據和寄存器rt中的數據相异或, 結果存放在寄存器rd中

上海交通大学 2014-02 / 39

算术右移

算术右移/逻辑右移

■ 算术右移: 在右移的过程中, 左侧填充高位符号位。

■ 算术左移: ? 右侧应该填充什么? (如果)

■ 目的: 算术真值损失最小。


SRA	Shift Right Arithmetic	Rd = (int)Rt >> sa
SRAV	Shift Right Arithmetic Variable	Rd = (int)Rt >> Rs[4:0]
SRL	Shift Right Logical	Rd = (uns)Rt >> sa
SRLV Shift Right Logical Variable		Rd = (uns)Rt >> Rs[4:0]

详细的MIPS指令系统可参考文档:

《MIPS32 4K™ Processor Core Family Software User's Manual》

算术右移

例: SRA \$t1,\$s1,4 #s1中的数值算术右移4位→ t1




目的: 算术真值损失最小。

另: 移位操作还有一种循环移位。

上海交通大学 2014-02 / 39 11

【例】一种能够执行sll/srl/sra指令的CPU电路/datapath



2.6 Logical Operations

指令操作实例:

■ 已知:

```
(\$t1) = 0000\ 0000\ 0000\ 0001\ 1100\ 0000\ 0000\ _2

(\$t2) = 0000\ 0000\ 0000\ 0000\ 0000\ 1101\ 1100\ 0000\ _2
```

分别执行以下指令后,考察\$t0中的值。

```
sll $t0, $t1, 4  # reg $t0 = reg $t1 << 4 bits
and $t0, $t1, $t2  # reg $t0 = reg $t1 & reg $t2
or $t0, $t1, $t2  # reg $t0 = reg $t1 | reg $t2
nor $t0, $t1, $t2  # reg $t0 = - (reg $t1 | reg $t2)

xor $t1, $t1, $t2  # reg $t1 = reg $t1 ^ reg $t2 (有无疑问?)

xor $t1, $t1, $t1  # reg $t1 = reg $t1 ^ reg $t1 (有无疑问?)
```


上海交通大学

2014-02

/ 39

13

可以实现目的操作数与运算操作数相同(例)



上海交通大学

2014-02

/ 39

2.6 Logical Operations

Check Yourself

Which operations can isolate a field in a word?


- 1. AND
- 2. A shift left followed by a shift right

上海交通大学 2014-02 / 39 15

2.7 Instructions for Making Decisions

描述和解决问题中需要判断

- 判断(分支)是智能的最基本标志。
- What distinguishes a computer from a simple calculator is its ability to make decisions.



上海交通大学 2014-02

MIPS32中的部分条件转移(分支)指令

Conditional branch	branch on equal	beq	\$s1,\$s2,25	if (\$s1 == \$s2) go to PC + 4 + 100	Equal test; PC-relative branch
	branch on not equal	bne	\$s1,\$s2,25	if (\$s1!= \$s2) go to PC + 4 + 100	Not equal test; PC-relative
	set on less than	slt	\$\$1.\$\$2.\$\$3	if (\$52 < \$53) \$51 = 1; else \$51 = 0	Compare less than; for beq, bne
	set on less than unsigned	sltu	\$s1,\$s2,\$s3	if (\$s2 < \$s3) \$s1 = 1; else \$s1 = 0	Compare less than unsigned
	set less than immediate	slti	\$\$1,\$\$2,20	if (\$s2 < 20) \$s1 = 1; else \$s1 = 0	Compare less than constant
	set less than immediate unsigned	slti	\$51,\$52,20	if (\$s2 < 20) \$s1 = 1; else \$s1 = 0	Compare less than constant unsigned

MIPS-4000指令说明中关于Branch指令的说明:

10.4.2 Overview of Branch Instructions

All branch instruction target addresses are computed by adding the address of the instruction in the delay slot to the 16-bit offset (shifted left 2 bits and sign-extended to 32 bits). All branches occur with a delay of one instruction. (delay slot: 后续学习解释)

If a conditional branch likely is not taken, the instruction in the delay slot is nullified.

Branches, jumps, ERET, and DERET instructions should not be placed in the delay slot of a branch or jump.

上海交通大学 2014-02 / 39 17


2.7 Instructions for Making Decisions

Conditional branch 条件转移指令


beq: branch on equal

bne: branch on not equal

beq \$s1,\$s2, Label_1





bne \$s1,\$s2, Label_1



beq指令 (Branch on Equal)

beq rs, rt, imm; if(rs==rt)PC<--PC+4+(sign)imm<<2





<mark>指令的意義:</mark> 如果寄存器rs中的數據和寄存器rt中的數據相等, 轉移 到地址 $PC + 4 + (sign)imm \times 4$


上海交通大学 2014-02


/ 39

19

bne 指令 (Branch on Not Equal)

bne rs, rt, imm; if (rs!=rt)PC<--PC+4+(sign)imm<<2





指令的意義: 如果寄存器rs中的數據和寄存器rt中的數據不等, 轉移到地址 $PC + 4 + (sign)imm \times 4$

上海交通大学

2014-02

/ 39

【例】Compiling if-then-else into Conditional Branches

■ C语言描述:




FIGURE 2.9 Illustration of the options in the *if* **statement above.** The left box corresponds to the *then* part of the *if* statement, and the right box corresponds to the *else* part.

上海交通大学 2014-02 / 39 **2**1

2.7 Instructions for Making Decisions

【例】Compiling if-then-else into Conditional Branches

■ C语言描述:


```
if (i == j)
    f = g + h;
else
    f = g - h;
```

■ 经编译后的MIPS指令:

```
bne $s3, $s4, Else # go to Else if i \neq j add $s0, $s1, $s2 # f = g + h (skipped if i \neq j) j Exit # go to Exit (无条件跳转指令) Else: sub $s0, $s1, $s2 # f = g - h (skipped if i == j) Exit:
```

注: "Else"和 "Exit"为用于指示位置的行标号,对应为 "模块内的相对地址"。

【例】Compiling if-then-else into Conditional Branches



上海交通大学 2014-02 / 39 23

2.7 Instructions for Making Decisions

关于编译后汇编语言中的地址标号/行号 Label

Hardware/ Software Interface

Notice that the assembler relieves the compiler and the assembly language programmer from the tedium of calculating addresses for branches, just as it does for calculating data addresses for loads and stores (see Section 2.12).

Compilers frequently create branches and labels where they do not appear in the programming language. Avoiding the burden of writing explicit labels and branches is one benefit of writing in high-level programming languages and is a reason coding is faster at that level.

上海交通大学 2014-02 / 39 24

关于循环操作/Loops

【例】Compiling a while Loop in C

■ C语言描述:


```
while (save[i] == k)
i += 1; // i = i+1;
```

Assume that i and k correspond to registers \$53 and \$55 and the base of the array save is in \$56. What is the MIPS assembly code corresponding to this C segment?

■ 经编译后的MIPS指令:

注: 假定

变量 i 放在\$s3中, 变量 k 放在\$s5中, 数组save[]的基址放在\$s6中。



上海交通大学

2014-02

/ 39


25

关于循环操作/Loops

【例】Compiling a while Loop in C

■ C语言描述:

```
while (save[i] == k)
i += 1; // i = i+1;
```



■ 经编译后的MIPS指令:

注: 假定变量 i 放在\$s3中,变量k放在\$s5中,数组save[]的基址放在\$s6中。

```
Loop: sll $t1, $s3, 2  # Temp reg $t1 = i * 4
add $t1, $t1, $s6  # $t1 = address of save[i]
lw $t0, 0($t1)  # Temp reg $t0 = save[i]
bne $t0, $s5, Exit  # go to Exit if save[i] ≠ k
addi $s3, $s3, 1  # i = i + 1
j Loop  # go to Loop
```

Exit:

(See the exercises for an optimization of this sequence.) 【可否及如何优化?】

上海交通大学

2014-02

/ 39

关于分支中的基本代码/语句块(basic block)

关于basic block (基本语句块)

Hardware/ Software Interface

basic block:

指一段指令代码,它不包含分支(除非在 代码段末尾),也没有其它地方的跳转分 支指向本段代码中的指令(除非指向本代 码段的第一条指令)。 basic block A sequence of instructions without branches (except possibly at the end) and without branch targets or branch labels (except possibly at the beginning).

Such sequences of instructions that end in a branch are so fundamental to compiling that they are given their own buzzword: a **basic block** is a sequence of instructions without branches, except possibly at the end, and without branch targets or branch labels, except possibly at the beginning. One of the first early phases of compilation is breaking the program into basic blocks.

上海交通大学

2014-02

/ 39

27

MIPS32的其它判比指令

- slt \$t0,\$s3,\$s4 # \$t0 = 1 if\$s3 < \$s4 判比操作数为补码有符号数
- slti \$t0, \$s2, 10 # \$t0 = 1 if \$s2 < 10 判比操作数为补码有符号数
- sltu \$t0,\$s3,\$s4 # \$t0=1 if\$s3<\$s4 判比操作数为无符号数
- sltiu \$t0, \$s2, 10 # \$t0 = 1 if \$s2 < 10 判比操作数为无符号数

SLT	Set on Less Than	if (int)Rs < (int)Rt Rd = 1 else Rd = 0
SLTI	Set on Less Than Immediate	
SLTIU	Set on Less Than Immediate Unsigned	
SLTU	Set on Less Than Unsigned	$ \begin{array}{l} if \ (uns)Rs < (uns)Immed \\ Rd = 1 \\ else \\ Rd = 0 \end{array} $

上海交通大学

2014-02

/ 39

MIPS32所设计采用的条件判断和转移方法

- MIPS编译器利用slt、slti、sltu、slti进行条件判断的结果设置,利用 beq、bne指令,以及它们的组合,实现所有条件转移。 包括:相等转、不等转、小于转、小于等于转、大于转、大于等于转。
- 若直接采用"小于比较后跳转",会导致该指令复杂、或执行时间偏长、或需额外时钟周期。(思考:在一条指令中实现为什么会比较复杂?)
- 用2条执行较快的指令,组合实现较复杂的判比跳转,总体效率会更高。

MIPS compilers use the slt, slti, beq, bne, and the fixed value of 0 (always available by reading register \$zero) to create all relative conditions: equal, not equal, less than, less than or equal, greater than, greater than or equal.

Heeding von Neumann's warning about the simplicity of the "equipment," the MIPS architecture doesn't include branch on less than because it is too complicated; either it would stretch the clock cycle time or it would take extra clock cycles per instruction. Two faster instructions are more useful.

上海交通大学

2014-02

/ 39

20

【例】Signed versus Unsigned Comparison

EXAMPLE

Suppose register \$50 has the binary number

and that register \$51 has the binary number

```
0000 0000 0000 0000 0000 0000 0000 0001_{two}
```

What are the values of registers \$t0 and \$t1 after these two instructions?

```
slt $t0, $s0, $s1 \# signed comparison
sltu $t1, $s0, $s1 \# unsigned comparison
```

ANSWER

The value in register \$50 represents -1_{ten} if it is an integer and 4,294,967,295_{ten} if it is an unsigned integer. The value in register \$51 represents 1_{ten} in either case. Then register \$t0 has the value 1, since $-1_{ten} < 1_{ten}$, and register \$t1 has the value 0, since 4,294,967,295_{ten} > 1_{ten} .

【例】关于数组下标是否越界的一种简便判法

EXAMPLE

Bounds Check Shortcut

Use this shortcut to reduce an index-out-of-bounds check: jump to IndexOutOfBounds if $\$s1 \ge \$t2$ or if \$s1 is negative.

ANSWER

The checking code just uses sltu to do both checks:

sltu \$t0.\$s1.\$t2 # \$t0=0 if \$s1>=length or \$s1<0 beg \$t0.\$zero.IndexOutOfBounds #if bad. goto Error

上海交通大学

2014-02

/ 30

21

2.7 Instructions for Making Decisions

Case/Switch 语句的2种实现方法

- 方法1:利用多个if-then-else 语句实现。
- 方法2:编译生成"跳转地址表",直接索引跳至目标代码块。

Case/Switch Statement

Most programming languages have a *case* or *switch* statement that allows the programmer to select one of many alternatives depending on a single value. The simplest way to implement *switch* is via a sequence of conditional tests, turning the *switch* statement into a chain of *if-then-else* statements.

Sometimes the alternatives may be more efficiently encoded as a table of addresses of alternative instruction sequences, called a jump address table or jump table, and the program needs only to index into the table and then jump to the appropriate sequence. The jump table is then just an array of words containing addresses that correspond to labels in the code. The program loads the appropriate entry from the jump table into a register. It then needs to jump using the address in the register. To support such situations, computers like MIPS include a jump register instruction (jr), meaning an unconditional jump to the address specified in a register. Then it jumps to the proper address using this instruction, which is described in the next section.

Check Yourself

- I. C has many statements for decisions and loops, while MIPS has few. Which of the following do or do not explain this imbalance? Why?
 - 1. More decision statements make code easier to read and understand.
 - 2. Fewer decision statements simplify the task of the underlying layer that is responsible for execution.
 - 3. More decision statements mean fewer lines of code, which generally reduces coding time.
 - 4. More decision statements mean fewer lines of code, which generally results in the execution of fewer operations.

上海交通大学 2014-02 / 39 33

2.7 Instructions for Making Decisions

Check Yourself

II. Why does C provide two sets of operators for AND (& and &&) and two sets of operators for OR (| and ||), while MIPS doesn't?

- 1. Logical operations AND and OR implement & and |, while conditional branches implement && and ||.
- 2. The previous statement has it backwards: && and || correspond to logical operations, while & and | map to conditional branches.
- 3. They are redundant and mean the same thing: && and || are simply inherited from the programming language B, the predecessor of C.

上海交通大学 2014-02 / 39 34

Acknowledgements

- These slides contain material developed and copyright by:
 - —Arvind (MIT)
 - —Krste Asanovic (MIT/UCB)
 - —John Kubiatowicz (UCB)
 - —David Patterson (UCB)
 - —Geng Wang (SJTU)
 - —Yanmin Zhu (SJTU)
 - —Li Yamin(Hosei Univ.)