
Tessel Volt: the button names

What to write on the standard panel when the unit is a Volt.



THE FUNCTION BUTTONS

CONTROL	**FILTER**	**CLASSIC**
MOD	**CONTOUR**	**ACID**
OSC 1	**LOUDNESS**	blank
OSC 2	**EXTRA**	blank
OSC 3	blank	blank
MIXER	**SOUNDS**	**SETUP**

Write each name just below its button, on the white area, with a fine permanent marker.

Printed at 100% (not “fit to page”), the drawing is the unit’s real size: lay the unit beside it as you write.

If you like, write the unit’s name to the right of the middle screw, as in the drawing, with a white paint pen.