creep & recovery compliance 
$$J(t) \left[ \frac{1}{Pa} \right] = \frac{strain}{stress}$$