car servo

spus
gnd

VBUS

USB

S0 → steering servo (1)
S1 → speed servo (2)
S2 ← radio steering (ch 1)
S3 ← radio speed (ch 2)