


Quick Guide

■ Button description



1 Earpiece Speaker

2 Top Speaker

3 Front Camera

4 Plus Key

5 Ultrasonic
fingerprint sensor

6 SIM Slot

7 Air Pressure
Equalizing Hole


8 MIC

9 Ambient light/
proximity sensor

10 Volume

11 Power Button

12 Bottom Speaker



13 Wide angle Camera

14 Laser Focus & Infrared Sensor

15 Telephoto Camera

16 Flashlight

17 MIC

18 USB Type-C port

19 Ultra-wide-angle Camera

20 NFC

21 Wireless Charging

22 MIC

■ Learn More

For more information, please download the complete guide on <https://service.oneplus.com/global/user-manual>.

This manual is for reference only, the actual product shall prevail.

The information is subject to change without notice.

This manual is published by OnePlus. OnePlus may correct any misprints, errors, and inaccuracies in the manual or improve its apps and/or devices at any time it deems necessary without any notice. Such changes will be applied in the later versions of this manual. All images in this manual are for reference only and may differ from the actual device and UI.