

TLS_Pie wiring schematic

MicroView / Arduino

Buttons

Stepper Driver

Raspberry Pi

Signals: A0/A1/A2/D2, D3/D5/D6, D7/D8

Notes: Pi triggers GPIO17/GPIO27; shared ground required