



Framework Laptop 16" Bezel Replacement

Use this guide to replace the bezel in your...


Written By: Alex Diaz-Kokaisl



INTRODUCTION

Use this guide to replace the bezel in your Framework 16" laptop.

Step 1 — Create a gap



 The bezel is secured with [magnets](#)!

- Slide your fingernail under the inside edge of either bottom corner of the bezel.
- Pull the bezel away from the screen to release the first few magnets.

Step 2 — Remove the bezel



- Lift the bezel around the perimeter of the screen until all of its magnets are released.
- Remove the bezel.

To reassemble your device, follow these instructions in reverse order.

Repair didn't go as planned? Try some [basic troubleshooting](#), or ask our [Answers Community](#) for help.