


PI PICO

Operation = power Pico through 3V3 pin directly Resistor_SMD-R_0805_2012Metric_Pad1.20x1.40mm_HandSolder disables buck/boost). Under USB debugging open SW1 to allow USB to power the 3.3V peripherals.



Mount Holes

- MTH1 Mounting Hole
- MTH2 Mounting Hole
- MTH3 Mounting Hole
- MTH4 Mounting Hole

