(1)

000000 e205 LDI R16, 0x25 000001 e314 LDI R17, 0x34 LDI R18, 0x31 000002 e321 ADD R16, R17 000003 0f01 000004 0f02 ADD R16, R18 000005 e714 LDI R17, 0x74 000006 0f01 ADD R16, R17 000007 e040 LDI R20, 0 ADD R16, R20 000008 0f04 000009 ef5f LDI R21, 0xFF 00000a b95a OUT DDRD, R21 00000b 9543 L2: INC R20 OUT PORTD, R20 00000c b94b STS SUM, R20 00000d 9340 0300

(2)

(3)

	Instruction	PC	SREG	R16	R17	R18	R20	R21	DDRD	PDRD
1	LDI R16,	0x00000001		0x25	0	0	0	0	0	0
	0x25									
2	LDI R17,	0x00000002		0x25	0x34	0	0	0	0	0
	0x34									
3	LDI R18,	0x00000003		0x25	0x34	0x31	0	0	0	0
	0x31									
4	ADD R16,	0x00000004		0x59	0x34	0x31	0	0	0	0
	R17									
5	ADD R16,	0x00000005	V,N	0x8A	0x34	0x31	0	0	0	0

	R18									
6	LDI R17, 0x74	0x00000006	V,N	0x8A	0x74	0x31	0	0	0	0
7	ADD R16, R17	0x00000007	S,N	0xFE	0x74	0x31	0	0	0	0
8	LDI R20,	0x00000008	S,N	0xFE	0x74	0x31	0	0	0	0
9	ADD R16, R20	0x00000009	S,N	0xFE	0x74	0x31	0	0	0	0
10	LDI R21, 0xFF	0x0000000A	S,N	0xFE	0x74	0x31	0	0xFF	0	0
11	OUT DDRD, R21	0x0000000B	S,N	0xFE	0x74	0x31	0	0xFF	0xFF	0
12	L2: INC R20	0x000000C		0xFE	0x74	0x31	0x01	0xFF	0xFF	0
13	OUT PORTD, R20	0x0000000D		0xFE	0x74	0x31	0x01	0xFF	0xFF	0x01
14	STS SUM, R20	0x0000000F		0xFE	0x74	0x31	0x01	0xFF	0xFF	0x01
15	RJMP L2	0x0000000B		0xFE	0x74	0x31	0x01	0xFF	0xFF	0x01

(4)

1.經由 STS 將 R20 的數值存入 SUM 的 adress,而 SUM 的 adress 為 0x300,當進行到 RJMP L2 時,會將 R20 的數值加一並再存入 0x300

2

.EQU SUM = 0x300

改成

.EQU SUM = 0x150