


BACKSIDE ALIGNMENT TEST

Print BOTH pages double-sided at 100% (Actual Size) - do NOT 'scale to fit'.
Flip on the edge your printer uses for duplex (long or short).

1. Hold the printed sheet up to a bright light, this side toward you;
the back crosshair shows through.
2. Read where the back crosshair's center dot sits on the rulers:
horizontal scale = X, vertical scale = Y (millimetres). 0 = aligned.
3. Enter those readings in Koda Sheets as Back calibration X and Y.
Axes: +X = right, -X = left, +Y = down, -Y = up.
4. Print your real cards. If the back shifts the wrong way,
negate that value and reprint.



50 mm reference - measure this line; if it is not 50 mm, reprint at 100% (Actual Size).

BACKSIDE ALIGNMENT TEST - BACK

Crosshair is at true center (no offset). Print on the back of page 1.

