

Addressing Modes

When ever an intruction executes requires operand to operated con. and opcode means operation to be performed on this opened. There are different method of getting access to the operand. These method are called as the addressing modes Different type of addressing modes are as follows.

1) Direct Add ressing made