
Teensy® 4.0 Back Side

Additional pins and features available on the back side



For solutions to the most common issues and technical support, please visit:

www.pjrc.com/help

Teensy 4.0 System Requirements: PC computer with Windows 7, 8, 10 or later or Ubuntu Linux 14.04 or later or Macintosh OS-X 10.8 or later USB Micro-B Cable

