## **TURNING ON THE LIVE STREAM**

This TV will only get signal about 10 minutes before the service starts. (From when you see the countdown on the outside screens.)


- 1. Turn on the TV.
- 2. Using the remote's **ARROW KEYS** (shown on the right) navigate to **INTERNET**.






3. Press the **ENTER** button inbetween the arrow keys on the remote.

4. Move the cursor to the **HOME** button on the browser, and press the **ENTER** key on the remote.



- 5. Unmute the stream by moving the cursor to the bottom-left corner with the arrow keys.
- 6. Press **ENTER** on the remote, when the cursor is above the speaker icon.



## IF THE PLAYBACK STOPS

Do all the points again from #4 to fix it.