

TURNING ON THE AUDIO SYSTEM

FOLLOW THIS ORDER:

1

TURN ON THE MIXER



2

**WAIT FOR THE CONSOLE
TO START**



3

MAIN SPEAKERS



4

COFFEE SHOP SPEAKERS

The switch is in the kitchen.



5

STAGE

The switch is in the drum room.

