# **Enhance Your Jewish Home**

www.Kosher-Innovations.com




**INSTRUCTION MANUAL** 

#### CONGRATULATIONS!

You are now the owner of the Travel KosherLamp™. We hope you will enjoy the convenience this compact and very bright KosherLamp can offer you on all your travels.


Before operating your KosherLamp, please read the following safety and operation instructions.





# **CAUTION:**

- Do not cover vent holes located on the sides and bottom of the KosherLamp
- Use Travel KosherLamp only on hard, flat surfaces. Do not use it on carpeting or fabric
- Do not immerse in water
- Do not operate near flammable gas or liquids



## **NON-SLIP PADS**

To keep your Travel KosherLamp steady, the bottom of the unit has been fitted with non-slip pads. After some use these pads may get some dust or lint on them and may become less effective. To restore their grip, wipe them off with a slightly damp cloth or paper towel.

## LOCK POSITION FOR STORAGE

Before traveling and after use: lower the Light Cover completely and rotate it clockwise to lock it in place. This will prevent the Light Cover from falling off during travel

#### **TRAVEL**

We have provided a soft travel bag with a drawstring to hold the Travel KosherLamp and its power cord and plug-adapter. Keep all these items together so you will be ready for travel.


## **REPLACEMENT PARTS**

For replacement power cord adapters or plug-adapters: Order Online: www.kosher-innovations.com Call Toll Free: North America: 1-866-661-5483 Call us from Outside North America: 416-638-9111 E-mail: kosherlampsales@gmail.com

### **OPERATING INSTRUCTIONS**

Before first use, remove the plastic sheet attached to the bottom of the Travel KosherLamp. Then place the Lamp in the desired location. There are no bulbs to install.

- 1. Plug in the power cord into an electrical outlet. Use a plug-adapter if necessary, a transformer is not required as it is built into the power cord.
- 2. Plug the cylindrical end of the power cord into the hole at the base of the Travel KosherLamp.
- 3. Press the switch to the ON position. (It is located on the power cord).
- 4. Adjust the light according to your needs.





To prevent movement, it is recommended to hold the base of the Travel KosherLamp with one hand while turning the Light Cover with your other hand.

## TO INCREASE LIGHT:

- 1. Rotate the Light Cover counter-clockwise.
- 2. Lift the Cover slightly and gently turn clockwise while continuing to lift.
- 3. The Light Cover will slide into the next Light Position.
- 4. Repeat steps 1-3 to get more light.

### TO DECREASE LIGHT:

- 1. Rotate Light Cover counter-clockwise.
- 2. Lower the Cover slightly and gently turn clockwise while continuing to lower the Cover.
- 3. The Light Cover will slide into the next Light Position.
- 4. Repeat steps 1-3 to decrease the light.

#### LED LIGHTS IN YOUR TRAVEL KOSHERLAMP

Your Travel KosherLamp is equipped with bright Light Emitting Diodes (LEDs). These light sources are advantageous for travel because:

- They are sturdy and don't have any fragile pieces
- They take up very little physical space thus allowing the KosherLamp to be very compact in size
- They draw a low voltage which makes it easy to use internationally across different electrical systems
- They have a long life-span of 30,000+ hours

Please note that the LED light sources are not replaceable.

### THE POWER CORD

The AC/DC Adapter must be plugged in for the Travel KosherLamp to operate. It has a standard two prong plug for use in North America. Its built-in transformer allows it to be used internationally in electrical outlets from 100 to 240 volts.

For wall sockets in Israel or Europe, use the plug-adapter that we have included for your convenience. For use, simply insert the prongs of the AC/DC adapter into the European plug adapter. Travel tip: if you are traveling to the UK, didn't bring a plug-adapter, and are staying at a hotel, ask the front desk for one. Many hotels will have one available.


#### PRE-SHABBOS SET UP:

Before Shabbos, we recommend the following steps for optimal use:

- 1. Unplug KosherLamp. Ensure that the rubber, non-slip pads on the underside of the KosherLamp are free from lint or dust by wiping them with a slightly dampened cloth. Plug in KosherLamp.
- 2. Unlock the Travel KosherLamp from the Closed Position by twisting the Light Cover counter-clockwise

# RABBINICAL APPROVAL

The following is one psak halacha of many received regarding the Kosherlamp<sup>TM</sup>:



Please see our website www.Kosher-Innovations.com for letters from other Rabbis around the world and English translations



