ARP

LAT. 17°14'26"N
LONG. 078°25'44"E

ELEVATION :2030 FT

TWR 118.450 MHZ
GND 121.850 MHZ

LVP TAXI ROUTING EASTERLY FLOW RWY 09R CAT -III (ARRIVAL AND DEPARTURE)

SCALE 1:3,000

SHAMSHABAD(HYDERABAD),INDIA
RAJIV GANDHI INTL.AIRPORT

North (True)
North (Mag)
Ver 1°07'W (2010)
Annual rate of
change 1'E
0
0.25
0.5
0.75
1
Kilometers
ARP
ATS COMPLEX
PTB PARKING
PROJECT SITE OFFICE
GMR AERO TOWERS
AMAZONE SITE
HANGER SUBSTATION
GATE HOUSE 1
GATE HOUSE 2
GATE HOUSE 3
MAINTENANCE HANGER
AIRCRAFT MAINTENANCE
MRO
FUEL FARM SUBSTATION
NORTH WEST APRON
NORTH EAST APRON
NORTH EAST REMOTE APRON
SOUTH EAST REMOTE APRON
CARGO TERMINAL
CARGO APRON
PASSANGER TERMINAL BUILDING
WEST PIER
EAST PIER
FIRE STATION SATELLITE
FIRE STATION(ARFF) MAIN
ISOLATION BAY
COOLING PIT
VHF
FIRE PIT
BALANCING POND
RWH PUMP ROOM
AIRFIELD WEST SUBSTATION
AIRFIELD EAST SUBSTATION
ILS/LOC
ISAM 110.9 MHz
RESA
283M X 90M
RESA
285M X 150M
RESA
250M X 90M
RESA
285M X 150M
GP/ILS/DME
329.300MHz
GP HUT
GP09L
MET(PWD)
PDP 09L
PDP 09R
PDP 27R
PDP 27L
PDP
PAPI 3°/73.82 ft
END ELEV. 1974 ft.
END ELEV. 1971 ft.
END ELEV. 2030 ft.
END ELEV. 2026 ft.
RWY 09L/27R(3707M X 45M)
RWY 09R/27L(4260M X 60M)
RWY STRIP 3827m x 280m
RWY STRIP 4380m x 280m
ALTIMETER OPERATING AREA
300 M X 60 M
WINDSOCK
CRASH GATE
DVOR/DME
HIA 113.8 MHz
1172/1109 MHz
GP09R
RVR
MET HUT
GP/ILS/DME
329MHz
983/1046MHz
SMR
9375MHz
GP 27L
GP/ILS/DME
HIA 330.8MHz
1007/1070
ILS/LOC
HYN 108.900 MHz
ILS/LOC
IHBD 108.5 MHz
CRASH GATE
FIRE PIT(DRILL)
SEWAGE TREATEMENT PLANT
STP SUBSTATION
U/G SUMP
HS 1
HS 2
HS 3
HS 4
HS 5
HS 6
LANDING T
A
A1
A2
A3
A8
A9
A10
B
B1
B2
B3
B4
B5
B6
C
C1
D
E
E1
E3
E4
H
H1
J
J1
J2
J3
K
K1
K2
K3
L1
L2
L3
L4
R1
R2
R3
R4
M
M1
100
NP7
NP8
NP9
NP10
NP11
03
04
05
06
07
08
09
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26A
26B
27A
27B
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54L
54
54R
55L
55
55R
56L
56
56R
57
57R
57L
58
58L
58R
59
59L
59R
60
60L
60R
61
62
63
63L
63R
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
200
201
202
203
203L
204

AICRRAFT STAND INFORMATIONS

SL No	Stand No.	Stand Compatibility	Remote / Contact	Latitude	Longitude	Elev. In M.
1	**50**	Code C	Contact	17°14'03.5675"N	078°25'53.8492"E	607.4
2	**51**	Code C	Contact	17°14'03.5475"N	078°25'52.3773"E	607.4
3	**52**	Code C	Contact	17°14'03.9627"N	078°25'50.7476"E	607.5
4	**53**	Code C	Contact	17°14'03.3422"N	078°25'49.1319"E	607.3
5	**54L**	Code C (MARS)	Contact	17°14'03.4415"N	078°25'46.3699"E	607.4
6	**54R**	Code C (MARS)	Contact	17°14'04.2449"N	078°25'47.7283"E	607.5
7	**55L**	Code C (MARS)	Contact	17°14'03.3722"N	078°25'43.4087"E	607.3
8	**55R**	Code C (MARS)	Contact	17°14'04.3674"N	078°25'44.7645"E	607.7
9	**56**	Code F (MARS)	Contact	17°14'04.0130"N	078°25'41.1733"E	606.9
10	**57**	Code E (MARS)	Contact	17°14'03.9305"N	078°25'38.3049"E	607.5

ARRIVAL

RWY09R →TWY L4/A3/A2/A1 →TAXI VIA RWY 09L/27R → TWY B4/B5 → TWY E3/E4 →PARKING STAND 50,51,52,53,54L,54R,55L,55R,56,57

DEPARTURE

PARKING STAND 50,51,52,53,54L,54R,55L,55R,56,57 →TWY E/M1/B6 → TAXI VIA RWY 09L/27R→TWY A9/A10 →RWY09R

NOTE:

1:ELEVATIONS IN EGM-08
2:DATUM -WGS84
3:ELEVATIONS ARE IN FEET & DIMENSIONS ARE IN METER
4:BEARINGS ARE MAGNETIC

LEGEND

★	ATC TOWER	🟥	CROSS OVER BRIDGE
●	RVR	🟦	DRAIN
●	PARKING_BAYS	🟥	FIRE DRILL PIT
✳	DVOR	🟧	FIRE MAIN STATION
●	GP ANTENNA	🟥	FIRE PIT
⊙	LOCALIZER ANTENNA	🟧	FIRE SATTELLITTE
✱	SMR RADAR	🟥	LANDING T
◐	ROAD HOLDING POINT	⬜	LANDING T PLATFORM
-·-·-	AIRPORT BOUNDARY		

—	MARKINGS AND EDGE	🟦	ATC COMPLEX
—	RHP	🟨	HOT SPOT
⋀⋀⋀⋀	THP	🟥	PDP
🟦	CARGO TERMINAL	⬛	RESA
🟦	CNS ATM	⬛	RWY
🟩	COOLING PIT	🟦	TERMINAL
⬛	ROAD	⬜	WHITE MARKING
🟩	OPEN AREA	⬜	CONCRETED AREA
—	ARRIVAL RWY09R	—	DEPARTURE RWY09R