

---- CARE & MAINTENANCE ----

Rattan Scratches, Gouges & Dents

Supplies Needed

- 1. Acetone
- 2. Clean soft rag
- 3. Steel wool or fine grit sandpaper
- 4. Blush Spray Paint
- 5. Correct Color Furniture Touch-Up Marker
- 6. Eye protection

Always where eye protection to prevent foreign liquid or material from entering the eye.

Cleaning & Maintaining Rattan

Rattan should be maintained like any other wood furniture. Vacuum your rattan and wicker pieces occasionally with a soft brush attachment to remove dust. Use wood furniture polish such as Murphy's Oil Soap® or Pledge® as directed to keep clean original looking finish.

Scratches to bare wood:

Use these touch up supplies

Pecan Glaze: Maple Brown or cherry universal marker. Fill stick 230-0408 or

similar dark color as the wood.

Whitewash: Whitewash marker (blend with finger or paper towel if to light)

Natural: Clear coat spray

- Apply marker to the affected area and surrounding area to blend. Sand first to make smooth if necessary.
- 2. Rub with finger to blend if the marker blots up You may have to let it dry for 30 seconds and apply another coat to get it darker.
- 3. If the shine on the finish is not consistent apply blush spray. Spray surrounding areas to blend







Gouges, Dents, Cracks:

1. Find a fill stick that is a similar color to the wood

2. Firmly rub fill stick over area



Rub in with finger or paper towel



Remove extra fill stick material off of surrounding area



Spray lightly with gloss to match the shine



3.

4.

5.