The old style ratchet protectors are being replaced with a new Polyurethane Tape with adhesive. This tape will be applied directly to the frame on the headrest support brace at the point where the ratchet meets the support bar.

All frames using a ratchet protector will have 2 pieces of the polyurethane tape applied in the proper contact location with the exception of the South Beach chaise #240532 & double chaise #240575. See below for South Beach application information.

The installation of the tape is quite easy. Simply apply the tape to a clean, dry frame on the headrest support bar where the ratchet contacts the bar. We will publish instructions for this application soon.



