Treasure Garden, Inc.

Replacing TG 8000 – 9200 New Style Umbrella Ribs

(Approximate time 10 – 20 minutes) Two person assembly recommended

- Remove umbrella from its base and remove bottom pole.
- With umbrella in a closed position.
 - Unscrew finial, which is the piece on tip of pole above the cover and set aside.
 - With umbrella on the floor, pick up the bottom part of the umbrella pole near the crank so that umbrella is lifted to a diagonal position.
 - Individually pull end of cover at each tip of a rib to separate the cover pocket from the rib.
 - o Pull cover off and set aside.
- Place umbrella upside down and open frame completely using the crank.
 - Then place umbrella in diagonal position so that crank is near the ground and top of umbrella is facing up. NOTE: Make sure broken rib that is being replaced is facing upward.
 - o Remove 4 screws from top Hub (Notch).
 - Slowly separate top and bottom parts of Notch by pushing up on top part.
 NOTE: Keep all ribs in bottom part of Notch.
 - Gently slide out broken rib from bottom part of Notch and remove the brass metal pin.
 - Reinsert brass metal pin into top section of new rib and slowly slide new rib into bottom part of Notch. NOTE: Rib must be in same direction of all others.
 - Align and gently push together top and bottom parts of Notch. **NOTE:** Top part of Notch has protruding pin that must match up with hole in bottom part of Notch.
 - Reinsert and tighten all four screws.
- Remove 4 screws from bottom Hub (Runner) and place umbrella upright in stand.
 - o Lower umbrella approximately 4 inches with crank.
 - Slowly separate top and bottom parts of Runner by pushing up on top part.
 NOTE: Keep all ribs in bottom part of Runner. NOTE: For UM9000 series, remove umbrella from stand, place it upside down, and keep all ribs in the top part of the Runner.
 - Gently slide out broken rib from bottom part of Runner and remove the brass metal pin.
 - Reinsert brass metal pin into bottom section of new rib and slowly slide new rib into bottom part of Runner.
 - o Align and gently push together top and bottom parts of Runner.
 - Open umbrella completely and remove from base.
 - o Place umbrella in diagonal position to reinsert and tighten screws.
- Close umbrella and stand upright so that you may place cover over frame.
 - o Place opening of cover over finial section and reattach finial loosely.

Treasure Garden, Inc.

- Align each end of cover over the tip of a rib and individually pull each cover pocket to reinsert rib. Tighten finial completely.
- o Reattach bottom pole and place complete umbrella into base.