

---- CARE & MAINTENANCE ----Resin Outdoor Wicker and Cushions

Supplies Needed

- 1. Bucket or Spray bottle
- 2. Soft Bristle Brush or Sponge
- 3. Eye protection

Cleaning & Maintaining the Resin Wicker Frames

Always wear eye protection to prevent foreign liquid or material from entering the eye.

It is best to remove soiling and spills as they happen as they will be much easier to clean. This can be done by rinsing the product thoroughly with fresh water and brushing with a <u>soft</u> bristle brush if necessary.

To remove stubborn dirt or stains from the frame or heavy soiling that has accumulated over time clean the frames with warm, soapy water and mild soap. Brush with a soft bristle brush as necessary.

DO NOT USE SOLVENTS, AEROSOL CARBON TETRACHLORIDE, SCOURING AGENTS, JANITORIAL CLEANSERS, GASOLINE, METAL BRUSHES OR HARD PLASTIC BRUSHES TO CLEAN YOUR WICKER. THEY WILL BREAK THE INTEGRITY OF THE WICKER DOWN AND POSSIBLY CAUSE IT TO BECOME STICKEY.

Cleaning & Maintaining the Cushions and Fabric

Always where eye protection to prevent foreign liquid or material from entering the eye.

Cushions

After a soaking rain or anytime the cores of the cushions get wet it is best to stand the cushion on end to allow them to drain more quickly. This will prevent mold and mildew growth between the frame and the cushion.

Spot wash the fabric to clean spills by using a sponge or a soft bristle brush with a warm soapy solution of mild detergent (Joy or Ivory liquid). Brush or sponge the soiled area and rinse thoroughly with fresh water. Allow to air dry. Repeat if necessary.

DO NOT MACHINE WASH OR MACHINE DRY THE CUSHION CASINGS. YOU COULD DAMAGE THE SEAMS OF THE CASE.