







• USER INTERFACE

WIRING DIAGRAM



PARTS NOT TO SCALE

ITEM NO.	SUBSYSTEM	COMPONENT	QTY
1	Power	Milwaukee M12 Battery	1
2	Power	Battery Adapter	1
3	Power	Switch	1
4	Power	Fuse	1
5	Power	Low Voltage Cutoff Board (30A)	1
6	Power	BusBar	2
7	Motor	2-8S LiPo UBEC-8A For 5 Servos Motors	2
8	Motor	DS5180 High-Torque Servo - 80Kg servo	2
9	Motor	DS3230MG Servo - 30Kg servo	6
10	Motor	5V 3A Low Volt Buck Converter	1
11	Motor	5V 3A Buck Converter USB-C	1
12	Motor	PCA9685 16-Ch Servo Driver	1
13	Control	ESP32-S3-WROOM-U1	1
14	Control	Antenna	1
15	Motor	Micro Linear Servo	5
16	Motor	Goteck 1.5g Micro Digital Linear Servo Actuator	1
17	Audio	3W 8Ω Speaker	1
18	Audio	DFPlayer Mini MP3	1
19	Control	MCP9808 Temp Sensor	1
20	Control	GY-NEO6MV2 NEO-6M GPS Module	1
21	Control	Additional GY-521 IMUs	1