


UNIVERSITY OF BRISTOL
WINDSURFING CLUB

UBWC Kit Member Guide

How to find club kit, rig it up, put it away and log your session, reports faults, and ask for kit on trips.







For club members. Committee tools (adding and editing kit, signing off faults, running trips) are not covered here. Screenshots use example data, so the kit you see in the app will be different.

Contents

1	Getting started	Opening the app, signing up, choosing where you are
2	Finding kit	The Catalogue: search, filters, and what the tiles tell you
3	A piece of kit	The item page: specs, faults, ratings and notes
4	Rigging up	The Rig tab picks a sail and board, then works out the rest
5	De-rig and log your session	Putting kit back, then writing the session up
6	The Logbook and Your sailing	The club feed, your own sessions, and the app's suggestions
7	Faults: spotting and reporting them	Minor and major faults, and reporting a fix
8	Trips	Asking for the kit you want to take away
9	Quick reference	Who can do what, and common questions

The four tabs

The bar along the bottom of the screen is how you get around. Each tab is one job:

Catalogue

Every piece of club kit. Browse, search, filter, and open any piece to see its details.

Rig

Pick a sail and a board. The app finds a mast, extension, boom and fin that fit them.

Log

The club's session feed, plus your own sessions. Gets a dot when you have one to write up.

Trips

Upcoming and past club trips, and the kit going on them. Ask for what you want here.

Committee members see a fifth tab, **Add**, for adding kit to the inventory. You won't see it, and you don't need it.

1 Getting started

The app is a website built for your phone. There is nothing to install, but it works best saved to your home screen.

Open it and save it to your home screen

1. Open the link the committee shared, on your phone.
2. **iPhone (Safari):** tap the Share button, then **Add to Home Screen**.
   Android (Chrome): tap the ⋮ menu, then **Add to Home screen** or **Install app**.
3. It now opens full screen from the **UBWC Kit** icon, like any other app.


Sign up or sign in

You can browse the Catalogue, item pages and Trips without an account. You need to sign in to:

- save a rig and log a session
- rate kit, add notes, report faults and fixes
- ask for kit on a trip
- save favourite kit with the heart

Tap the round **account button** at the top right, then **Sign in**. If you don't have an account, tap **Create an account** and choose a username, a display name (what other members see) and a password.

> **Forgotten your password?**
> Ask a committee member. They can reset it for you.



The sign-in sheet, from the account button

Tell the app where you are

The pill at the top of the Catalogue (All locations) asks **Where are you?** Pick the site you're sailing from, for example **Cheddar**, and two things change:

- the Catalogue only shows kit kept at that site
- the Rig tab only offers kit you can actually pick up there


Choose **All locations** to see everything the club owns.

While the club is away on a trip, that trip also shows up in this list. Pick it and the Catalogue and Rig tab show only the kit that went on the trip.


Your account menu

Tap your initial or photo at the top right to:

- open **Your sailing** (see section 6)
- add a **photo**, shown next to your name on notes and faults
- change your **display name** or **password**. Changing your password signs out your other devices.
- **Sign out**. You can still browse after signing out.



Choosing your location



The account menu

2 Finding kit

The **Catalogue** tab lists every piece of kit at your chosen location, like browsing a shop.


Narrowing it down

- **Search bar:** type a brand, model, size or where it's kept, e.g. *neil pryde*, *5.5* or *blue crate*.
- **Type chips** (All, Boards, Sails, Masts, Extensions, Booms…): one tap shows only that kind of kit. Swipe the row sideways for more.
- **Filter** (funnel icon) and **Sort** (arrows icon) open the same panel. The number badge shows how many filters are on.
- **Grid / list** switch (top right): pictures, or a compact list that fits more on screen.

What a tile tells you

- The **size** (m^2 for sails, litres for boards, cm for masts and so on), the **name**, and its **star rating** from members.
- A ⚠ Fault tag means someone has reported a problem. Open it to see what.
- A **greyed-out** tile is away on a club trip.

Tap any tile to open its item page.



Sails, in list view

The filter and sort panel


The panel slides up over the list. Everything in it applies instantly, and the count at the bottom shows how many pieces match.

- **Type** and **Subtype**: e.g. Sails → Wave, Freeride, Slalom, Kids.
- Kit-specific options appear when they make sense: **Cams** and **Diameter** for sails and masts, **Box** for boards and fins.
- **Faults:** three buckets, No faults Minor faults Major faults.
- **Sort by:** newest, rating, size, name, condition or location, ascending or descending.

Tap **Done** to close the panel, or **Reset** to clear every filter.

> **Why can't I see some kit?**
>
> The Faults filter starts on **No faults** + **Minor faults** each time you open the app. Kit with a **major** fault is out of action and stays hidden until you tick **Major faults**. Even then it sorts to the bottom of the list.

If something's still missing, check the location pill at the top. You may be looking at a single site.



The filter and sort panel

3 A piece of kit


Every physical piece of kit has its own page. Read it from the top down: what it is, whether it's OK to use, what it measures, and what other members think of it.

At the top

- **Size, make and model**, with chips for its type, whether a sail is **Cambered** or **Camless**, its mast **diameter** (RDM/SDM) and its **condition**.
- **Where it lives** (site · spot). Tap it to see a description and photo of the exact spot, so you know where to find it and where it goes back.
- The ♡ **heart** saves it to your kit. Saved kit is flagged when you're choosing in the Rig tab and listed on Your sailing.
- **Rig this kit** (sails, boards and wings) jumps straight into the Rig tab with this piece already chosen.

Open faults

Any open fault shows as a coloured flag under the button: amber for minor (still usable), red for major (out of action). Tap the flag to read what's wrong and how to work around it. See section 7 for reporting faults and fixes.



Top of an item page, with a minor fault opened


Specifications

The full measurements. For a sail, the two numbers that matter when rigging are:

- **Luff**: the length of mast plus extension the sail needs.
- **Boom**: the length to set the boom to.

Sail pages also show a **recommended mast and extension**, worked out from the luff. It's only an example. Any mast and extension that add up to the luff will rig the sail just as well, and the Rig tab finds them for you.


> **Cambered sails**
>
> Cambered sails have cams that clip around the mast and are harder to rig. If you haven't rigged cams before, grab a committee member first.



The recommended mast and extension

Member rating and notes


- **Thumbs up / down** is your vote on this piece. You get one vote per piece and can change it any time. Tap the same thumb again to take it back. The star score is worked out from everyone's votes.
- **Members' notes** are tips and reviews from other members, e.g. "seat the bottom cam before tensioning". Tap **Add a note** to leave your own.
- **Report a fault** flags something wrong with this piece (section 7).
- **Fault & fix history** shows what has gone wrong with it before and how it was fixed.




Rating, notes, and the report button

4 Rigging up

The **Rig** tab asks you two questions: which sail, and which board. From those it works out the mast, extension, boom and fin that fit, using kit that's actually at your location.



Choosing a sail size. The tip shows the first time.



Sail picked (ticked), now choosing a board


1. **Pick your sport** at the top: **Windsurf**, **Windfoil** or **Wingfoil**.
2. **Set a size.** Tap **−** / **+**, or swipe or scroll across the number. The list below sorts so the closest sizes come first, with the club's sizes either side still visible. Use the chips (Freeride, Wave…) to narrow it.
3. **Tap the sail you want.** Its step gets a tick and the app moves on to **Board**.
4. **Pick a board** the same way. You can do the board first if you like: just tap the Board step.

Once both are picked you land on **Your rig**. To change your mind, tap the Sail or Board step to go back. The other pick is kept.


> **Where does the starting size come from?**
>
> At first, the club's usual sizes. Once you've logged a few sessions with wind readings, the app learns what size you rig in what wind and opens on a suggestion for you.

Your rig

Your sail and board sit under **Selected kit**. Under **Recommended**, the app has picked a mast, extension, boom and fin that fit, and shows its working: the extension setting, the boom length, and where each piece is kept.



A recommended mast, opened



After "Use this", parts move up to Selected kit

- **Tap a recommended part** to see why it was chosen (e.g. brand match best match), its rating, its measurements, and where it **lives**.
- **Use this mast / boom / …** confirms it and moves it up into Selected kit.
- **Show other masts** lists every alternative that fits, if you'd rather use a different one. Only kit that actually fits your sail is listed. If you change the mast, the extension setting is re-worked out to match.
- **How to rig** (top of the screen) opens step-by-step rigging instructions and a video.

Your rig is saved to your account, so you can close the app and come back to it on the beach.

5 De-rig and log your session

When you come off the water, tap **De-rig** at the top right of Your rig.


The put-it-back checklist

De-rig lists every piece you took out and the **spot it lives in**. Tick each one as you put it away. If everything is already away, just press the button: the ticks are a reminder, not a requirement.

> **Put kit back where it lives**
>
> If kit goes back in the wrong place, the next person can't find it and it gets lost. If you can't find where something goes, ask a committee member.

If you didn't press **Use this** on some parts, the app warns you first. Only your sail, board and the parts you confirmed go on the checklist and into the log. Choose **De-rig anyway** or **Cancel** to go back.

Press **All away, log this session** to finish. The session form opens straight away.




The de-rig checklist

Log this session

The kit you used is filled in for you. Then:

- **Wind:** the app tries to look up the wind for the time you were out. If it can't, tap **Add** and enter it yourself. You can always **Edit** it.
- **Overall:** tap 1 to 5 stars for the whole session. This is the only thing you have to fill in.
- **Note** (optional): how it went. This appears on the club feed.
- **Rate the kit:** a quick 👍 or 👎 for each piece you used. This counts as your vote on that piece. Tap a row to leave a note, which then appears on the item's page for other members.

Press **Save session** when you're done.



Writing up a session

Not now, or not at all

BUTTON	WHAT HAPPENS
Skip (top right)	Means "later". The session waits for you, and the **Log** tab shows a dot until you write it up.
Don't save (very bottom)	Means "never". The session is thrown away. The app asks first, because this can't be undone.

6 The Logbook and Your sailing


The Logbook (Log tab)

- **Club feed** shows everyone's sessions, newest first: who went out, the wind (mean / gust in knots), the sail and board, their star rating, any note, and how long they were on the water.
- **Mine** shows just your own sessions.

The top of the Log tab also shows your own rig:

- while you're **out**, the rig you haven't de-rigged yet
- after you de-rig, a reminder to **log** the session if you skipped it. The reminder stays until you save or bin the session.

Sessions are visible to every club member, so keep notes friendly and useful.




The club feed

Your sailing

Open it from the account menu (top right → **Your sailing**). It shows what the app has learned about how you sail:

- **Totals:** sessions, average wind, how many pieces you've rated, and how many you've saved.
- **Sail size against wind:** one dot per logged session, with a curve through them. That curve is where the Rig tab's suggested size comes from. Tap a dot to see that session.
- **Kit you keep going back to**, with what you last thought of it.
- **Saved kit:** everything you've hearted.

The chart fills up as you log sessions with a wind reading. The more you log, the better the suggestions get.



Your sailing, for a new member

7 Faults: spotting and reporting them


Faults are tracked for each physical piece of kit. Reporting one quickly stops the next person having a bad session, or getting hurt.

FLAG	MEANS	IN THE APP
Minor fault	Usable, but read the note first. E.g. a cam that falls off, a slipping clamp.	Shown normally, with a ⚠ Fault tag.
Major fault	Out of action. Don't use it.	Hidden from the Catalogue unless you tick **Major faults**, and never offered in the Rig tab.

Report a fault

1. Open the piece's item page and tap **Report a fault** (near the bottom).
2. Give it a **short name**. This becomes the flag label, e.g. "Bottom cam falls off".
3. Say **what's wrong and what it needs**, including any workaround.
4. Choose the **severity**: *Minor fault: usable* or *Major fault: out of action*.
5. Add a **photo** if you can. It helps whoever fixes it. Then tap **Report it**.

> **If in doubt, mark it major**
>
> Anything that could break on the water or hurt someone (cracked mast, torn sail, damaged UJ) should be **Major**. Tell a committee member too.



Reporting a fault


Report a fix

Fixed something? Open the fault flag on the item page and tap **Report a fix**. Describe what you did and, ideally, add a photo of the repair.

Reporting a fix **doesn't close the fault**. The flag changes to *Fix reported, awaiting committee sign-off*, and a committee member clears it once they've checked the repair.

Add a note

Notes aren't faults. Use **Add a note** for tips and reviews ("needs a 460 with the extension right out", "great in gusty conditions"). Use **Report a fault** for anything that's wrong with the kit.



Reporting a fix


8 Trips

Club trips are planned in the **Trips** tab, and members help decide what kit goes. Anyone can read a trip. While a trip is taking requests, any signed-in member can ask for kit.

How a trip works

HEADING	WHAT'S HAPPENING
Upcoming	The trip is **taking requests**. Ask for the kit you'd like to take.
Packing	The kit secretary has settled the list and is loading the trailer. Requests are closed.
Out now	The club is away. That kit is greyed out in the Catalogue.
Past trips	Finished trips are kept as a record of what went.

Open a trip to see when it leaves, where it's going, notes from the committee (tap **More** to read all of them) and a **wind forecast** for each day of the trip: gust over mean, in knots, hour by hour.



A trip taking requests, with its forecast

Asking for kit


1. Open an **Upcoming** trip and tap **Request kit** at the bottom of the list.
2. A picker opens with the whole club's kit. It works like the Catalogue, with search and type chips.
3. Tap the piece you want. It joins the trip's list with your initial on it.

If someone has already asked for a piece, ask for it too: your disc joins theirs. Tap a stack of discs to see who asked for it.


Changed your mind? Long-press your request on the list and confirm **Withdraw**.

> **A request isn't a booking**
>
> Asking reserves nothing. The kit secretary decides the final list, so a request may not go if there isn't room on the trailer. Requests close when the trip moves to Packing.

You don't need to ask for masts, booms, extensions or fins. The kit secretary packs the rig parts that go with the sails and boards on the list.



Requested kit, with who asked (the discs)



The Request kit picker

On the trip

Once the trip is **Out now**, pick it from the location pill (**Where are you?**). The Catalogue and Rig tab then show only the kit that came on the trip, and sessions you log on the trip get the wind for the trip's location.

9 Quick reference

What you can do

WITHOUT SIGNING IN	SIGNED IN AS A MEMBER	ASK THE COMMITTEE TO…
Browse the Catalogue and item pages	Save and de-rig a rig	Add, edit or move kit
Use the Rig tab to plan a rig	Log sessions	Close (sign off) a fault
Read trips and forecasts	Vote 👍 / 👎 on kit, add notes	Create and run trips
Read the club feed	Report faults and fixes	Reset your password
	Ask for kit on a trip	Describe or photograph a storage spot
	Save kit with the ♡	

Common questions

QUESTION	ANSWER
A board I know exists isn't showing.	Check the location pill (you may be looking at one site), the search box, and the Faults filter: kit with a major fault is hidden until you tick **Major faults**. Greyed-out kit is away on a trip.
The Rig tab won't offer a sail.	The Rig tab only offers kit you can finish rigging at your chosen location. If no mast, extension or boom there fits a sail, or it has a major fault, it isn't listed.
Do I have to use the recommended mast?	No. Any mast and extension that add up to the sail's luff will do. Use **Show other masts** to pick one. Same-brand masts are ranked first because they usually suit the sail best.
There's a dot on the Log tab.	You've de-rigged a session but haven't logged it. Open Log to write it up, or bin it.
I reported a fix but the fault is still there.	That's expected. A committee member checks the repair and closes it.
"No connection to the club server."	Your phone lost signal. Try again when you have a connection. Your rig is saved to your account each time it changes.

Three habits that keep the kit shed working

- **Put it back where it lives.** The de-rig checklist shows you where.
- **Report faults straight away**, even small ones, ideally with a photo.
- **Rate what you use.** A quick 👍 or 👎 when you log helps everyone pick good kit.