
case id: 1 to 16
1: Case definition
+nesc/caseDef
vehicle id,
overrides
start: lat, lon,
h, V (F-16)
dt, duration
NASA reference CSVs
(simulators 1 to 6)
bands: floor,
k, spread
2: Vehicle
+nesc/vehicle, f16 config
AC
3: F-16 trim
+nesc/f16Trim
trim controls,
reference states
start state x0
4: NASA control law
+nesc/f16Controller
commands become u
at each stage
5: Rotating-Earth plant
derivativesRotating
xdot, y
x(t), u
6: Time simulation
+sim/run
time histories (SI)
7: NESC signals
+nesc/runCase
NASA names
and units
NESC-named time series
8: Compare with NASA
+nesc/compare
PASS / FAIL and
excess per signal