

ZeroTier VPN Setup for Remote MetaSense-DYNO Access

Step 1: PC Setup (5 minutes)

1. Download & Install ZeroTier from <https://www.zerotier.com/download/>
2. Create a free account at <https://my.zerotier.com>
3. Create a new virtual network and copy the Network ID
4. Join network on PC: Right-click ZeroTier icon → Join Network
5. Authorize your PC in my.zerotier.com by checking the Auth checkbox

Step 2: ESP32 Access

Your ESP32 at 192.168.0.211 is already on your home WiFi.

When you connect to ZeroTier from anywhere, you can access it as normal!

Step 3: Remote Access from Anywhere

Browser: `http://192.168.0.211` (works via VPN tunnel)

OTA Upload: `platformio run -e esp32s3-ota -t upload` (works via VPN)

Monitor: `socket://192.168.0.211:23` (telnet via VPN)

Step 4: Security

- ✓ All traffic encrypted via ZeroTier
- ✓ Port 3232 NOT exposed to internet
- ✓ Works on public WiFi safely
- ✓ No configuration changes needed to platformio.ini