

PN	Desc	CN Desc.	Cond	Qty						PN	qty
521100	GCU-GENERATOR CONTROL UNIT	发电机控制组件	AR	1						id1	1
4383121	FLOODLIGHT	地板灯	AR	1						ID1	1
7530334	SELECTOR,TEMP.	待核实	AR	1							
201122040	UPLOCK-DOOR,MLG	上位门锁	AR	1						ID1	2
0212KTU01	PROBE-FUEL QUANTITY,NO 1	燃油管	AR	2							
0212KTU03	PROBE-FUEL QUANTITY,NO 3	燃油管	AR	2							
0212KTU04	PROBE-FUEL QUANTITY,NO 4	燃油管	AR	2							
0212KTU05	PROBE-FUEL QUANTITY,NO 5	燃油指示传感器	AR	2							
0212KTU06	PROBE-FUEL QUANTITY,NO 6	燃油指示传感器	AR	2							
0212KTU07	PROBE-FUEL QUANTITY,NO 7	燃油指示传感器	AR	2							
0212KTU08	PROBE-FUEL QUANTITY,NO 8	燃油指示传感器	AR	2							
0212KTU09	PROBE-FUEL QUANTITY,NO 9 AND 1	燃油管	AR	4							
0212KTU10	PROBE-FUEL QUANTITY,NO 11	燃油管	AR	2							
0212KTU11	PROBE-FUEL QUANTITY,NO 12	燃油探针	AR	2							
0212KTU13	PROBE-FUEL QUANTITY,NO 14	油管组件	AR	2							
0212KTU14	PROBE-FQI,CENTRE TANK	燃油探针	AR	4							
0212KTU15	PROBE-FQI,CENTRE TANK,NO 5	燃油管	AR	1							
0212KTU16	PROBE-FUEL,QUANTITY,NO 2	燃油管	AR	2							
0212KTU17	PROBE-FUEL,QUANTITY,NO 13	燃油管组件	AR	2							
058-001-00	SWITCH	电门	AR	4							
0851MC	PITOT	皮托管	AR	1							
0861ED	SENSOR-ANGLE OF ATTACK(RVSM关键设备)(RO双证)	迎角传感器	AR	1							
088256-04644	ACCUMULATOR-BRAKE	刹车储压器	AR	1							
1-002-0102-1830	(空白)	逆变器	AR	1							
101809	ALTITUDE SWITCH	电门组件	AR	1							
102EH2EB	SENSOR-TAT(RVSM关键设备)	总温皮托管/钢铁制	AR	2							
1091A0000-01	INJECTOR-WATER	喷水器	AR	2							
11276-3	COMBI UNIT	#N/A	AR	3							
114083003	VALVE-VENT	活门	AR	2							
114086001	VALVE-CUT OUT	活门	AR	1							
114087007	VALVE, BYPASS	阀门	AR	3							
114122014	SENSOR-STEERING FEEDBACK (RO双证)	转弯控制传感组件	AR	2							
114151004	(空白)	隔离活门	AR	1							
114170008	MANIFOLD-VALVE SELECTOR	活门	AR	1							
115370-1318	CONCENTRATOR FCDC	飞行控制数据采集器	AR	1							
1158000-21	VALVE-REFUEL	活门	AR	3							
119003-21	SMOKE HOOD(MRS)	活门	AR	5							
1209-100	SWITCH PRESSURE	氧气面罩	AR	1							
12664	VALVE-CHECK	电门	AR	3							
1298A0000-01	VALVE-CHECK	活门	AR	2							
131280000-02	BYPASS VALVE	检测活门	AR	1							
	VALVE-BYPASS	旁通活门	AR	1							
1320A0000-01	VALVE-TRIM AIR	旁通活门	AR	1							
1320A0000-02	VALVE-TRIM AIR	空气配平活门	AR	1							
1407KID-02-03	INDICATOR-FUEL,QUANTITY	空气配平活门	AR	1							
14330-190	(空白)	指示器	AR	1							
14330-230	VALVE ASSY	冲洗控制单元	AR	3							
14401-085	SEPARATOR-WATER	冲洗阀总成	AR	3							
1553A9900-01	MANIFOLD-HP	水分离器	AR	1							
1555B9900-01	MANIFOLD-PTU(RO双证)	高压液压总管	AR	1							
15800-358	(空白)	液压力转换装置	AR	1							
17A717-03-00	ACCELEROMETER-THREE AXES	冲洗阀	AR	3							
1803B0000-04	CONTROLLER-AIR CONDITIONING SYSTEM (RO双证)	加速度计	AR	1							
1806B0000-01	VALVE-FLOW CONTROL (RO双证)	空温控制器	AR	2							
18301905-1	GAUGE-AIR PRESSURE	流量控制活门	AR	1							
18330904-2	PRESSURE GAUGE NIT.	发动机压力器	AR	3							
196PN01Y02	INDICATOR-RUDDER TRIM	压力表	AR	4							
1982660116	DMC-DISPLAY MANAGE COMPUTE	方向舵配平指示器	AR	1							
181000-1GS	INVERTER-STATIC	显示管理计算机	AR	3							
1M1226	VALVE-CHECK	#N/A	AR	1							
201117021	UPLOCK, MLG, LH	活门	AR	1							
201117022	UPLOCK, MLG, RH	弹箭锁组件	AR	1							
201122040	UPLOCK-DOOR,MLG	弹箭锁组件	AR	1							
20499005	FILTER-OZONE	上位门锁	AR	1							
2050121-201	VALVE DUAL-FLAPPER, CHECK	臭氧转换器	AR	2							
206PN01	VOLTMETER-DC	双重检查活门	AR	1							
20700-300	VALVE-APU FUEL	电压表	AR	2							
2070054-201	IN-TANK HOUSING	APU燃油活门	AR	1							
2070066-104	PALLET-IGGS	进气管道控制活门	AR	1							
20791-12AC	CONTROLLER-PRESSURE (RO双证)	惰性气体发生系统	AR	1							
208724-0	EMERGENCY ESCAPE ROPE	压力控制器	AR	1							
2100-1226-02	CVR-COCKPIT VOICE RECORDER(MRS)	ROPE-EMERGENCY指示器	AR	2							
2100-4045-00	DATA RECORDER SSFDR(A380 FHS)(MRS)	驾驶舱语音记录器	AR	1							
2157S07Y00	LEVER-CONTROL,LANDING GEAR	固态飞行数据记录器	AR	1							
22C221120100009	CONTAINER ASSY-TWO MASK,OXY(MRS)	起落架操纵杆	AR	1							
22C221240100009	CONTAINER ASSY-TWO MASK,OXY(MRS)	#N/A	AR	1							
23948-01AA	CONTROLLER-HEAT	#N/A	AR	2							
2403-89	ANTENNA-VHF	#N/A	AR	1							
241-247-012-005	EYMU-ENGINE VIBRATION MONITORI (RO双证)	天线/飞机用	AR	1							
2438-89-00	ANTENNA-VHF	发动机震动监控组件	AR	1							
2439-89-03	ATC	天线/飞机用	AR	1							
252CA01C1-02Y1	(空白)	天线	AR	4							
2632-82	ANTENNA-ELT	继电器	AR	1							
27-457	SWITCH-CONTROL	天线	AR	1							
2758	BATTERY	开关	AR	1							
	电瓶	#N/A	AR	2							
290-1501-501	TAIL CONE ASSY	尾椎组件	AR	1							
2LA005127-01	LIGHT-EMERGENCY,OVERWING	应急灯	AR	1							
2LA005128-01	LIGHT-EMERGENCY,OVERWING	应急灯	AR	1							
2LA005303-05	LIGHT UNIT-STROBE	频闪灯	AR	1							
2LA005308-05	LIGHT UNIT-STROBE	频闪灯	AR	2							
2LA005413-01	LIGHT-EMERGENCY,OVERWING	应急灯	AR	1							
2LA005414-01	LIGHT-EMERGENCY,OVERWING	应急灯	AR	1							
2LA005469-00	(空白)	应急灯	AR	1							
2LA007307-00	(空白)	面板警示灯	AR	3							
2LA403702-02	LIGHT-NAVIGATION,REAR DUAL	面板警示灯	AR	3							
2LA455010-00	LIGHT-ANTICOLLISION	导航灯	AR	1							
30042-0000-0501	CONTROL UNIT-LEVEL,SENSING	防撞灯	AR	2							
3022016-000	VALVE-BRAKE SYSTEM RELIEF	油量控制组件	AR	2							
3105-89	ANTENNA-GUIDE SLOPE	活门/飞机发动机用	AR	1							
3106-89	ANTENNA-LOCALIZER	甚高频收发天线	AR	1							
31073-110	SERVOCONTROL-AILERON (RO双证)	天线组件	AR	1							
31075-840	SERVOCONTROL-ELEVATOR (RO双证)	副翼伺服控制组件	AR	4							
31077-111	SERVOCONTROL-SPOILER	升降舵伺服控制组件	AR	1							
3107-89	ANTENNA-MARKER	扰流板控制组件	AR	8							
3108-89-04	VOR ANTENNA	天线	AR	1							
3102N01Y01	(空白)	天线组件	AR	1							
321000M03	SSTU-SIDE STICK TRANSDUCER UNIT(RO双证)	传感器	AR	2							
321200M02	TRANSDUCER UNIT-SPEED BRAKE	侧杆传感器组件	AR	4							
3214-62-10	POWER SUPPLY UNIT EPSU	制动控制传感器	AR	1							
322000M02	TRANSDUCER UNIT	应急电源组件	AR	4							
322200-8M00	TRANSMITTER UNIT	升降舵传感器	AR	2							
327000-102M01	FTU-RUDDER PEDAL	前轮转弯手柄组件	AR	1							
330400M01	CONTROL UNIT-THROTTLE (RO双证)	传感器组件	AR	1							
3357S08Y00	FIRE PANEL-ENGINE APU	油门控制器	AR	2							
		火警控制面板	AR	1							

80180500-01	SHAFT ASSY-FLAP DRIVE	轴	AR	2			
80180600-01	SHAFT ASSY-FLAP DRIVE	轴	AR	2			
80180700-01	SHAFT ASSY-FLAP DRIVE	轴	AR	2			
80181200-01	SHAFT ASSY	轴	AR	2			
80181300-01	SHAFT ASSY	轴	AR	2			
80181600-01	SHAFT ASSY-FLAP DRIVE	轴	AR	2			
80184400-01	SHAFT ASSY	轴	AR	2			
80184600-02	SHAFT ASSY-FLAP DRIVE	轴	AR	2			
80184700-01	SHAFT ASSY	轴	AR	2			
80184800-01	SHAFT ASSY	轴	AR	2			
801C1400-01	SHAFT ASSY	轴	AR	2			
801C1700-02	BEARING ASSY-STEADY	滚珠轴承	AR	20			
801C1900-02	BEARING ASSY-STEADY	稳固轴承组件	AR	4			
810A0000-05	SERVOCONTROL-RUDDER	方向舵伺服控制舵	AR	3			
822-0297-020	RECEIVER-VOR,MKR	甚高频接收机	AR	2			
822-0299-020	RECEIVER-ADF	自动定向机接收机	AR	2			
822-0329-020	INTERROGATOR-DME	测距机	AR	2			
822-0987-003	COUPLER-HF ANTENNA	高频天线耦合器	AR	2			
822-0990-003	TRANSCIVER-HF	高频收发机	AR	1			
822-1152-123	MMR-MULTI MODE RECEIV (RO双证)	多模式接收机	AR	2			
822-1250-020	TRANSCIVER-VHF	甚高频收发机	AR	1			
822-1330-001	ACTIVE GPS ANTENNA	天线	AR	2			
828A0000-02	GEARBOX-BEVEL	齿轮箱	AR	4			
829C0000-01	ACTUATOR, A-SLAT	作动筒	AR	4			
830C0000-01	ACTUATOR, B-SLAT (RO双证)	作动筒	AR	16			
831B0000-01	BRAKE-WING TIP	飞机刹车	AR	4			
833A0600-01	SHAFT ASSY	轴组件	AR	2			
833A0700-01	SHAFT ASSY-SLAT DRIVE	轴组件	AR	2			
833A1400-01	SHAFT ASSY	轴组件	AR	2			
833A1500-01	SHAFT ASSY	轴组件	AR	2			
833A1600-01	SHAFT ASSY-SLAT DRIVE	轴组件	AR	2			
833A1700-01	SHAFT ASSY-SLAT DRIVE	轴组件	AR	2			
833A1800-01	SHAFT ASSY-SLAT DRIVE	轴组件	AR	2			
833A1900-01	SHAFT ASSY-SLAT DRIVE	轴组件	AR	2			
833A2000-01	SHAFT ASSY-SLAT DRIVE	轴组件	AR	2			
833A2100-01	SHAFT ASSY-SLAT DRIVE	轴组件	AR	2			
833A2400-02	SHAFT ASSY-APPU	缝翼驱动杆组件	AR	2			
833B0100-01	SHAFT ASSY-SLAT DRIVE	轴组件	AR	2			
833B0200-01	SHAFT ASSY-SLAT DRIVE	轴组件	AR	2			
833B0300-01	SHAFT ASSY-SLAT DRIVE	轴组件	AR	2			
833B0400-01	SHAFT ASSY	轴组件	AR	2			
833B0500-01	SHAFT ASSY	轴组件	AR	1			
833B0800-01	SHAFT ASSY-SLAT DRIVE	轴组件	AR	2			
833B1000-01	SHAFT ASSY	轴组件	AR	2			
833B1100-01	SHAFT ASSY	轴组件	AR	2			
833B2200-01	SHAFT ASSY	轴组件	AR	1			
833C0900-01	SHAFT ASSY-SLAT DRIVE	轴组件	AR	2			
833C1200-01	SHAFT ASSY	轴组件	AR	2			
833C1300-01	SHAFT ASSY	轴组件	AR	2			
833C2300-02	BEARING ASSY-STEADY	轴承组件	AR	2			
833C5200-02	STEADY BEARING ASSY	轴承组件	AR	2			
8410B2-4-90	COCKPIT DOOR CAMERA	摄像头	AR	2			
8410B5-101-105	CAMERA-COCKPIT DOOR	飞机驾驶舱摄像头	AR	1			
8420B1-201	(空白)	摄像头显示器	AR	1			
8450B5	(空白)	铰链	AR	1			
85-16-11494-05	(空白)	手持麦克风	AR	3			
864-001	INDICATOR-LIGHTED,ICING	结冰指示器	AR	1			
87232323V00	SENSOR-DUCT TEMPERATURE	传感器	AR	1			
87232329V03	ADM-AIR DATA MODULE(RVSM关键设备)	大气数据模块	AR	6			
87232329V07	ADM-AIR DATA MODULE(RVSM关键设备)	大气数据模块	AR	2			
8922-01-0000	WARMER-BREAD ROLL	面包加热器	AR	1			
89794077	CREW OXYGEN CYLINDER机组氧气瓶	(空白)	AR	1			
8E5005304-00	PSU-POWER SUPPLY UNIT	供电组件	AR	1			
8E5005309-00	PSU-POWER SUPPLY UNIT	供电组件	AR	1			
8E5403703-02	RWD FACING NAV LIGHT	后导航灯变压器	AR	1			
8E5455012-00	PSU-POWER SUPPLY UNIT	供电组件	AR	1			
8E5455438-07	PSU-POWER SUPPLY UNIT	供电组件	AR	1			
9008000-12100	ATC TRANSPONDER(RVSM关键设备)	空中交通管制应答机	AR	1			
9024-15704-2	SAFETY VALVE	活门	AR	2			
9027-20010	SELECTOR-LDG FIELD	变速杆/飞机用	AR	1			
9028A0004-01	PPU-POSITION PICK OFF UNIT (RO双证)	襟翼控制组件	AR	4			
9106A0005-01	PRESSURE SENSORS IMPR	压力传感器	AR	1			
9106A0005-02	SENSOR PRESSURE	压力传感器	AR	1			
93-A055-66	MICROPHONE ASSY-REMOTE	话筒	AR	1			
93A150-20	MODULE-PREAMPLIFIER	前置放大器模块	AR	1			
94830-04	BRACKET-FWD	支架	AR	1			
94830-05	BRACKET-FWD	支架	AR	1			
94830-06	BRACKET-REAR	支架	AR	1			
94830-09	ISOLATOR-VIBRATION	减震器	AR	1			
94830-10	ISOLATOR-VIBRATION	减震器	AR	1			
94830-11	ISOLATOR-VIBRATION	减震器	AR	1			
9508175	VALVE-FLOAT,VENT	活门	AR	4			
950GC02Y00	MODULE-DC BUS 1 CNTOR	模块-DC总线1控制单元	AR	1			
9599-607-14943	RADIO ALTIMETER TRANSC	无线电高度表收发机	AR	2			
960GC02Y00	MODULE-DC BUS 2 CNTOR	控制模块	AR	1			
965-1676-003	PORTABLE OXY, BPWC (RO双证)	飞机近地警告计算机	AR	1			
9700-C1A-F23AN	COMPUTER OXY, GPWILE 手操氧气瓶	氧气瓶	AR	4			
972C10-1	VALVE-SHUTTLE	活门	AR	2			
9811820	VALVE-NON RETURN	活门	AR	2			
9811839	VALVE-NON RETURN	活门	AR	6			
9815715	VALVE-PRESSURE RELIEF	活门	AR	1			
98G408324-80	CONTROL UNIT-CHART HOLDER	活门	AR	2			
A08000	ACTUATOR-LP FUEL SOV APU	控制组件	AR	1			
A125A	(空白)	作动器	AR	2			
AC40-0217500	(空白)	VOICE GUN	AR	2			
AC68A200	DISK DRIVE UNIT MDDU	货网	AR	1			
ACP2788AB05	ACP-AUDIO CONTROL PANEL (RO双证)	多用途磁盘驱动器	AR	3			
AE86195G	VALVE ASSY	控制面板	AR	1			
APES100-1	CLOCK	加油活门	AR	1			
AR4709-11	(ETOPS禁/慎用). CONTROL-COCKPIT SYSTEM	电子时钟	AR	1			
AR4714-11	ELECTRIC STRIKE, CTR	驾驶舱门锁控制组件	AR	1			
B17CA1042	VALVE-PRESSURE REDUCING	舱门锁	AR	1			
B372BAM0515	SEC-SPOILER ELEVATOR COMPUTER (RO双证)	压力调节活门	AR	1			
B42CA2002	VALVE-NONRETURN	扰流板升降计算机	AR	3			
BA16501-01	(空白)	活门	AR	3			
BA24320A-1	FIRE EXTINGUISHER	APU发电机	AR	1			
BC2065C	PANEL-SELCAL CODE	灭火器	AR	3			
BMA3603AA01	(空白)	控制盒	AR	1			
C12848CA01	RMP-RADIO MANAGEMENT PANEL(ROP)	音频接口	AR	1			
C12850AC02	FCU-FLIGHT CONTROL UNIT(RO双证)(RVSM关键设备)	无线电管理面板	AR	1			
C12860AA06	CFDIU-CENTRALIZED FAULT DISPLAY INTERFACE UNIT	飞控组件	AR	1			
C12C80013	PUMP-FUEL	中央故障显示接口	AR	1			
C13042BA08	FMGC-FLIGHT MANAGEMENT AND GUIDANCE COMPUTER	燃油泵	AR	1			
C20105000-2	TACHOMETER (RO双证)	飞行管理计算机	AR	2			
C24730001-6	UPLOCK ASSY-NLG	转速计	AR	4			
		齿轮控制单元	AR	1			

C24730100-1	UPOLOCK ASSY-NLG DOOR	#N/A	AR	1				
C24837102-2	MANIFOLD-NORM BRK SERVOVALVE	#N/A	AR	1				
C49AA0222	CANISTER-PUMP		AR	1				
C51LM0020	VALVE-4 WAY	活门	AR	1				
C82LL0010	VALVE-DRAIN	活门	AR	1				
CGDU2000-00	DETECTOR-SMOKE,SELF CONTROLLED	烟雾探测器	AR	1				
CMK80-01	PRESSURE SWITCH	电门组件	AR	1				
CT1918	VALVE-CHECK	电门 (航电系统)	AR	1				
C29284E	(空白)	传感器	AR	1				
		压力传感器	AR	4				
CZ9DM6A	SENSOR	压力传感器	AR	1				
D05000	VALVE-FILL AND DRAIN	活门	AR	2				
D24005000	MANIFOLD-SERVOVALVE	备用刹车总管组件	AR	1				
D24006000	MANIFOLD-ALTERNATE BRAKING	刹车总管	AR	1				
D24157000	ELECTRO-HYD. STEERING M	活门	AR	1				
D2727000103400	VERTICAL STABILISER RUDDER CONTROL UNIT	VERTICAL STABILISER	AR	1				
D2727000700600	YAW DAMPER SPRING ROD							
	偏航阻尼器弹簧杆	弹簧	AR	1				
D2727025000600	ROD SPRING	杆组件	AR	1				
D3611013500200	防冰管	左发LH	AR	1				
D5757032200200	STRUCT	支柱组件	AR	2				
D905T2001-000	(空白)	浮子	AR	1				
D905T2002-000	(空白)	浮子	AR	2				
D905T2003-000	(空白)	低油量传感器	AR	1				
D905T2004-000	(空白)	低油量传感器	AR	2				
D9255003200200	PANEL REFUEL	控制面板	AR	1				
DLRBA000	DLRB-DATA LOADING ROUTING BOX	数据装裁器发送盒	AR	1				
DLSA100	(空白)	接口模盒	AR	1				
DR1502C00	KIT-WHEEL ADAPTER	机轮调整器	AR	4				
DVE90-06	VALVE-SOLENOID	活门	AR	1				
E03A00	VALVE ASSY-FIRE SHUTOFF	活门	AR	2				
E21324000-1	TRANSMITTER-BRAKE PEDAL	刹车传感器	AR	2				
E21327007	CONTROL UNIT BSCU (RO双证)	刹车及转弯控制组件	AR	1				
E21330000-1	VALVE	活门	AR	1				
EVT3454HM01	FAN-AVIONICS	活门	AR	2				
F251626WPSN923A	ADAPTOR	电子舱风扇	AR	1				
F251626ZPSY923B	ADAPTOR	适配器	AR	1				
F561626P2953F	PLUG	适配器	AR	1				
		堵头	AR	4				
FE171-000	REGULATOR-CABLE TENTION (RO双证)	管子	AR	1				
FE240-005	CYLINDER-DOOR DAMPER	#N/A	AR	4				
FRH100014A	SWITCH-PRESSURE	压力电门	AR	1				
FRH220034V	VALVE ASSY-NONRETURN	活门	AR	1				
FRH280002	VALVE-AIR RELEASE	活门	AR	2				
	空气释放活门							
FRH340003H	(空白)	排放阀	AR	3				
G6990-40	CONTROL UNIT-ATC,TCAS	控制面板	AR	1				
GL501-002-0000	(空白)	控制面板	AR	3				
HTE200002-1	ACTUATOR-VALVE,SINGLE MOTOR	关断阀	AR	1				
HTE310021-1	VALVE-AIR INLET	作动筒马达	AR	5				
HTE370001	CONNECTOR-HP GROUND	发动机活门	AR	2				
HTE420044	VALVE-PRESSURE HOLDING	高压地面接头	AR	1				
HTE510016	(空白)	阀门	AR	2				
HTE69000-1	SWITCH-PRESSURE	换气阀	AR	2				
HTE690035-1	(空白)	压力电门	AR	3				
HTE690087-001	VALVE-TRANSFER	压力电门	AR	3				
HTE900095	SHAFT-DRIVE,TRANSFER VALVE	阀门	AR	4				
HTE900096	SHAFT-DRIVE,TRANSFER VALVE	活门轴杆	AR	2				
HTE900118-001	VALVE-LOW PRESSURE,FUEL	活门	AR	2				
HTE900133	VALVE-FUEL,DEFUEL	活门	AR	2				
HTE900135	VALVE-CROSSFEED,FUEL	阀门	AR	1				
J172ABM	ACCELEROMETER UNIT-VERTICAL	阀门	AR	1				
L13471-27	BOILER	滤子	AR	4				
L83A13-617	MONITOR-LEAK	#N/A	AR	2				
L95F100-603	PROTECTOR-TANK,OVERPRESSURE	活门	AR	1				
L95F50-603	PROTECTOR-OVERPRESSURE	油嘴超压保护器(飞)	AR	2				
L96H15-501	VALVE-CHECK	发动机气压活门	AR	3				
LH1460205	(空白)	阀门	AR	1				
	MASK REGULATOR ASSEMBLY	DUCT/管路	AR	2				
MF20-534	面罩调节器组件	氧气面罩	AR	1				
MS28889-2	(空白)	换气阀	AR	1				
MXP801-11	STOWAGE BOX ASSY	氧气面罩盒	AR	4				
P2-07-0004-201	FLASHLIGHT ASSEMBLY	手电筒组件	AR	6				
PC01502	TRANSFORMER-CURRENT	变压器组件	AR	2				
PC01801	TRANSFORMER-CURRENT	静止式变流器	AR	7				
PGA0105W	COMPASS-STANDBY	备用罗盘	AR	1				
PPC1200-00	DETECTOR-SMOKE	烟雾探测器	AR	3				
QA05561	FILTER-LP	滤子组件	AR	2				
QA05593	FILTER-HP	气滤	AR	1				
QA05604	FILTER-LP	气滤	AR	1				
QA05797	FILTER ASSY-HYDRAULIC	滤芯	AR	3				
QA05877	VALVE-RESTRICTOR	节流阀	AR	1				
QA06304	(空白)	节油滤	AR	1				
QA07739-02	RESERVOIR-PRESSURE UNIT	液压油滤	AR	1				
RCF6708	PRESSURE REGULATOR TRANSMITTER	压力组件	AR	1				
	压力调节传感器	压力调节器	AR	1				
RDAV1313-01	REPRODUCER UNIT, DVD	#N/A	AR	1				
RDAV9809-01	DU-DISPLAY UNIT	#N/A	AR	3				
		显示组件	AR	5				
RDAV9810-01	LCD Monitor	显示组件	AR	5				
	(空白)	#N/A	AR	3				
RDAX1301-5A	MAIN MULTIPLEXER	#N/A	AR	1				
RDAX4332-01	SEB-SEAT ELECTRONIC BOX	座椅电子盒	AR	51				
RDAX7675-51	(空白)	计算机	AR	1				
RPCU9167-01	CONTROL UNIT	控制组件	AR	1				
RU1502U01	FAN-WHEEL BRAKE	刹车风扇	AR	4				
S1819502-02	ELT 应急定位发射器	#N/A	AR	1				
S1820513-02	(空白)	ELT面板	AR	1				
S1820514-04	CABLE-ADAPTER	导线束	AR	1				
S4-3402180	VALVE-ELECTRO SELECTOR	活门	AR	1				
S4-3500712	MANIFOLD-GROUND SERVICE	活门	AR	1				
S8209L1A1-1484	ACCUMULATOR ASSY	多功能服务器	AR	3				
SC4700-5	SERVO ACTUATOR	蓄压器	AR	2				
SIC5059-13-10	COMPUTER, FOI (RO双证)	伺服控制器	AR	2				
TA0126005	(空白)	燃油量指示器	AR	1				
TM113-1	TRANSDUCER AND SWITCH-TEMPERAT	自耦变压器	AR	3				
VD3810	FAN-MIXED FLOW (CMM库寿)	温度电门	AR	1				
VD3900-03	FAN-RECIRCULATION (CMM库寿)	混流风扇	AR	1				
VD3920	FAN-EXTRACTION	风扇	AR	2				
VT442-2	(空白)	风扇	AR	1				
VT477-2	INDICATOR-QUANTITY	水量指示器	AR	1				
Y005-2	TRANSFORMER RECTIFIER	液流量指示器	AR	1				
Y005-3	TRANSFORMER RECTIFIER	静止式变流器	AR	2				
Z033H0002110	DEU-DECODER ENCODER U	静止式变流器	AR	1				
Z043H0100110	DEU-DECODER ENCODER UNIT B	译码/编码组件	AR	12				
Z120H031230B	AAP-AFT ATTENDANT PANEL	译码/编码组件	AR	1				
		#N/A	AR	1				

Z133H031151A	FAP-FLIGHT ATTENDANT PANEL	飞行控制面板	AR	1						
Z212H0001110	CONTROL UNIT	加热控制组件	AR	1						
Z220H0002110	CONTROL UNIT	控制组件	AR	2						
Z233H0000110	(空白)	接口模盒	AR	6						
Z233H0010110	(空白)	接口模盒	AR	1						
Z350H0401110	PISA-STAND ALONE	供给适配器	AR	2						
ZCV212	VALVE-DOUBLE CHECK	活门	AR	1						
ZCV63-4	VALVE-CHECK	检查活门	AR	8						
ZCV63-6	VALVE-CHECK	检查活门	AR	8						
ZCV63-6-1	VALVE-CHECK	检查活门	AR	10						
ZCV63-6-7	VALVE-CHECK	关断活门	AR	1						
ZCV63-8	VALVE-CHECK	单向活门	AR	4						
ZCV64-10	VALVE-CHECK	减压阀	AR	2						
ZCV64-12	VALVE-CHECK	检查活门	AR	3						
ZCV64-16	(空白)	活门	AR	1						
ZCV64-20	VALVE-CHECK	单向阀	AR	2						
ZRA380-00	TRANSDUCER	阀门	AR	4						
		传感器	AR							