






This 'cam' will raise and lower the pen




















































































1x 13 2 1x **2**x 1x 1x 14 15 1x **2**x 1x 1x














Connect left motor to port B and right motor to port C. This will cause the cables to cross.

